


# Panasonic



## Digital Super Hybrid System Features Guide

---

Model No. **KX-TD500**



Please read this manual before connecting the Digital Super Hybrid System.

# Introduction

## About this Features Guide

This Features Guide is designed to serve as an overall features reference for the Panasonic Digital Super Hybrid System, KX-TD500.

It explains what the KX-TD500 System can do, and how to obtain the most out of its many features and capabilities.

## Terms used in this Features Guide

### Installation Manual References

Lists any additional hardware required to use the feature. Please refer to "Installation" section in the *Installation Manual* for detailed information.

### Programming Guide References

The related and required programming titles are noted for your reference.

**System Programming** should be done with a PC.

Please refer to "System Programming" section in the *Programming Guide* for detailed information.

### Features Guide References

The related feature titles described in this *Features Guide* are noted for your reference.

### User Manual References

The operation required to implement the feature is noted for your reference.

Please refer to Section "Station Features and Operation" section in the *User Manual* for detailed information.

**Station Programming** is individual programming executed by each Proprietary Telephone (PT) user at his or her own PT. They can customise their PTs based on their personal needs.

Please refer to "Station Programming" section in the *User Manual* for detailed information.

## About the other manuals

Along with this Features Guide, the following manuals are available to help you install, programme, and use the KX-TD500 System:

### Installation Manual

Provides instructions for installing the hardware and system maintenance.

**User Manual**

Designed for users of Digital Super Hybrid System, KX-TD500.

The focus is Digital Proprietary Telephones (DPTs), Digital DSS Consoles, Single Line Telephones (SLTs) and their features.

**Programming Guide**

Provides step-by-step instructions for performing system programming using the Maintenance Console software for a PC.

***Warning***

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.



73/23/EEC  
89/336/EEC  
92/31/EEC  
93/68/EEC

# Table of Contents

<b>1</b>	<b>General Features.....</b>	<b>11</b>
<b>1.1</b>	<b>System Expansion.....</b>	<b>12</b>
	EXtra Device Port (XDP) .....	12
<b>1.2</b>	<b>System Administration.....</b>	<b>13</b>
	System Programming and Diagnosis with Personal Computer .....	13
	Traffic Measurement.....	15
	User Programming.....	16
<b>1.3</b>	<b>System Features .....</b>	<b>17</b>
	Account Code Entry.....	17
	Automatic Calling Cancel.....	19
	Automatic Configuration .....	20
	Background Music (BGM) – External.....	21
	Budget Management.....	22
	Calling Party Control (CPC) Signal Detection .....	23
	Charge Fee Reference .....	24
	Class of Service (COS).....	25
	Dial Type Selection.....	27
	DIL 1:N Group.....	28
	Door Opener .....	29
	E1 Carrier.....	30
	EXTENSION GROUP – A SUMMARY .....	31
	Extension Group – Automated Attendant (AA) Group .....	34
	Extension Group – Operator Group.....	35
	Extension Group – Ring Group .....	39
	Extension Group – Station Hunting Group (Circular).....	40
	Extension Group – Station Hunting Group (Terminate).....	42
	Extension Group – Uniform Call Distribution (UCD) Group .....	44
	Extension Group – Voice Mail (VM) Group .....	55
	External Modem Control .....	56
	Flexible Numbering .....	58
	Floating Station.....	63
	Host PBX Access.....	65
	Limited Call Duration.....	66
	Lockout .....	68
	Manager Extension .....	69
	Mixed Station Capabilities.....	70
	Music on Hold .....	72
	Night Service .....	74
	Off Premise Extension (OPX) .....	76
	Outgoing Message (OGM) .....	77
	Outgoing Message (OGM) Group .....	79
	Parallelled Telephone.....	80
	Phantom Extension .....	82
	Released Link Operation .....	84
	Remote Station Feature Control .....	85
	Remote Station Lock Control .....	87

Secret Dialling .....	88
Station Message Detail Recording (SMDR).....	89
System Data Default Set .....	94
T1 Carrier.....	95
Tenant Service .....	97
Time-Out, Variable .....	99
Trunk Busy-out .....	102
Trunk Group .....	107
Trunk Route Control .....	109
VPS INTEGRATION – A SUMMARY .....	110
VPS Integration – Automated Attendant (AA) Service Integration .....	112
VPS Integration – DPT Integration .....	115
VPS Integration – Inband Integration .....	117
VPS Integration – Voice Mail (VM) Service Integration .....	119
Walking Station.....	124
<b>1.4 Fault Recovery / Diagnostics .....</b>	<b>125</b>
Local Alarm .....	125
Power Failure Re-start .....	128
Power Failure Transfer.....	129
<b>1.5 Attended Features.....</b>	<b>130</b>
Caller ID Service .....	130
Direct In Lines (DIL).....	132
Direct Inward Dialling (DID) .....	135
Direct Inward System Access (DISA) .....	138
Trunk Answer From Any Station (TAFAS).....	144
<b>1.6 Originating Features .....</b>	<b>146</b>
Alternate Calling – Ring / Voice.....	146
Automatic Callback Busy (Camp-On).....	147
Automatic Route Selection (ARS).....	148
Busy Station Signalling (BSS) .....	154
Do Not Disturb (DND) Override .....	156
Electronic Station Lockout .....	157
Emergency Call.....	158
Executive Busy Override — Barge-in .....	159
Executive Busy Override — Extension .....	160
Inter Office Calling .....	161
Line Preference — Outgoing (Idle Line / No Line / Prime Line) .....	163
Off-Hook Call Announcement (OHCA).....	165
Off-Hook Call Announcement (OHCA), Whisper .....	167
Operator Call .....	169
PDN Call.....	171
Toll Restriction .....	172
Toll Restriction for Special Carrier Access .....	180
Toll Restriction Override by Account Code Entry .....	181
Toll Restriction Override for System Speed Dialling .....	183
Trunk Access, Direct .....	184
Trunk Access, Idle .....	185
Trunk Access, Individual Trunk .....	187
Trunk Access, Trunk Group .....	188

Trunk Connection Assignment – Outgoing .....	190
Walking COS .....	191
<b>1.7 Dialling Features .....</b>	<b>192</b>
Automatic Station Release .....	192
Full One-Touch Dialling .....	193
One-Touch Dialling .....	194
Pause Insertion, Automatic .....	195
Pickup Dialling (Hot Line) .....	196
Quick Dialling.....	197
Redial, Automatic .....	198
Redial, Last Number .....	199
Redial, Saved Number .....	200
Station Speed Dialling .....	201
System Speed Dialling.....	202
<b>1.8 Ringing Features .....</b>	<b>203</b>
Do Not Disturb (DND) .....	203
Log-In / Log-Out .....	205
STATION HUNTING – A SUMMARY .....	207
Timed Reminder (Wake-Up Call) .....	208
Timed Reminder, Remote (Wake-Up Call).....	210
<b>1.9 Answering Features .....</b>	<b>211</b>
ANSWER and RELEASE buttons Operation.....	211
Answering, Direct Trunk .....	213
CALL PICKUP – A SUMMARY.....	214
Call Pickup – CO Line.....	215
Call Pickup – Directed .....	216
Call Pickup – Group .....	217
Call Pickup Deny .....	218
Call Waiting .....	219
Call Waiting from Central Office.....	221
Executive Busy Override Deny.....	222
Hands-free Answerback.....	223
Line Preference — Incoming (No Line / Prime Line / Ringing Line) .....	224
Live Call Screening (LCS).....	226
<b>1.10 Holding Features.....</b>	<b>228</b>
Automatic Hold – All Calls .....	228
Automatic Hold – Trunk .....	229
Call Hold – Station .....	230
Call Hold – Trunk .....	232
Call Hold Retrieve – Station .....	234
Call Hold Retrieve – Trunk.....	235
Call Hold, Exclusive – Station.....	236
Call Hold, Exclusive – Trunk.....	238
Call Park.....	240
Call Splitting .....	241
Consultation Hold .....	242
<b>1.11 Transferring Features.....</b>	<b>244</b>
CALL FORWARDING – A SUMMARY .....	244
Call Forwarding – All Calls.....	245

Call Forwarding – Busy .....	247
Call Forwarding – Busy / No Answer .....	249
Call Forwarding – Follow Me.....	251
Call Forwarding – No Answer.....	252
Call Forwarding – to CO / TIE .....	254
CALL TRANSFER – A SUMMARY .....	256
Call Transfer – to CO.....	257
Call Transfer, Screened – to Station .....	258
Call Transfer, Screened – to TIE .....	259
Call Transfer, Unscreened – to Station .....	260
Call Transfer, Unscreened – to TIE .....	262
Intercept Routing .....	263
One-Touch Transfer .....	264
Ringing Transfer .....	265
<b>1.12 Conversation Features.....</b>	<b>266</b>
Conference .....	266
Conference, Unattended .....	268
Data Line Security .....	270
Doorphone Call.....	271
End-to-End DTMF Signalling (Tone Through).....	272
External Feature Access .....	273
Flash.....	275
Hands-free Operation.....	276
Off-Hook Monitor.....	277
Privacy Release .....	278
Privacy, Automatic.....	279
Pulse to Tone Conversion .....	280
Two-Way Recording into the Voice Mail.....	281
<b>1.13 Audible Tone Features.....</b>	<b>282</b>
Confirmation Tones .....	282
Dial Tones, Distinctive.....	284
Hold Recall .....	286
Ringing Tone Selection.....	288
Ringing, Delayed.....	289
Ringing, Discriminating .....	290
<b>1.14 Paging Features.....</b>	<b>291</b>
PAGING – A SUMMARY.....	291
Paging – All .....	292
Paging – External.....	294
Paging – Group .....	296
Paging Deny.....	297
<b>1.15 Proprietary Telephone Features.....</b>	<b>298</b>
Background Music (BGM).....	298
DSS Console.....	299
Handset / Headset Selection .....	302
Handset Microphone Mute .....	303
Microphone Mute .....	304
Station Programme Clear.....	305
Station Programming .....	307

Station Programming Data Default Set .....	309
Volume Control – Speaker / Handset Receiver / Headset / Ringer .....	310
<b>1.16 Button Features.....</b>	<b>311</b>
Button, Direct Station Selection (DSS) .....	311
Button, Flexible.....	312
BUTTON, LINE ACCESS – A SUMMARY .....	315
Button, Line Access – Group-CO (G-CO) .....	317
Button, Line Access – INTERCOM (ICM).....	319
Button, Line Access – Loop-CO (L-CO).....	320
Button, Line Access – Primary Directory Number (PDN).....	322
Button, Line Access – Secondary Directory Number (SDN).....	324
Button, Line Access – Single-CO (S-CO).....	327
Buttons on Proprietary Telephones .....	329
LED Indication .....	333
<b>1.17 Display Features.....</b>	<b>334</b>
Absent Message Capability .....	334
Bilingual Display .....	336
Busy Lamp Field.....	337
Call Log, Incoming .....	338
Display Contrast Adjustment.....	341
Display, Call Information.....	342
Display, Date and Time.....	344
Display, Self-Extension Number .....	345
Message Waiting .....	346
SPECIAL DISPLAY Features – A SUMMARY .....	348
Special Display Features – Call Directory – Extension Dialling.....	349
Special Display Features – Call Directory – Station Speed Dialling .....	350
Special Display Features – Call Directory – System Speed Dialling .....	351
Special Display Features – Call Forwarding / Do Not Disturb .....	352
Special Display Features – Call Log, Outgoing .....	353
Special Display Features – System Feature Access Menu .....	354
<b>2 ISDN Features.....</b>	<b>357</b>
<b>2.1 ISDN Features.....</b>	<b>358</b>
Integrated Services Digital Network (ISDN).....	358
<b>2.2 ISDN Originating Features.....</b>	<b>361</b>
Calling Line Identification Presentation (CLIP).....	361
Calling Line Identification Restriction (CLIR).....	362
ISDN Network Service Access .....	363
<b>2.3 ISDN Answering Features.....</b>	<b>364</b>
Connected Line Identification Presentation (COLP) .....	364
Connected Line Identification Restriction (COLR).....	365
<b>2.4 ISDN Attended Features .....</b>	<b>366</b>
Direct Dialling In (DDI) .....	366
Multiple Subscriber Number (MSN) Ringing Service .....	369
<b>2.5 ISDN Transferring Features .....</b>	<b>372</b>
Call Forwarding by ISDN Line.....	372
<b>3 E&amp;M Features.....</b>	<b>373</b>



---

<b>3.1</b>	<b>E&amp;M Features.....</b>	<b>374</b>
	TIE LINES – A SUMMARY .....	374
	TIE LINES – Alternate Routing .....	379
	TIE LINES – Calling from CO-to-TIE.....	382
	TIE LINES – Calling from TIE-to-CO.....	384
	TIE LINES – Calling from TIE-to-TIE .....	386
<b>4</b>	<b>Tones / Ring Tones .....</b>	<b>389</b>



---

# *Section 1*

## *General Features*

# 1.1 System Expansion

## EXtra Device Port (XDP)

### Description

A DPT and an SLT can be connected to the same extension port but have different extension numbers so that they can act as completely different extensions.

### Conditions

- **Hardware Requirements**  
DHLC card (KX-TD50170) is required to utilise this feature.
- XDP requires previous programming of the extension port. Enable XDP mode for the desired port by System Programming.
- If one or more DHLC cards are installed after booting up the System with default values, DN assignment should be done before performing XDP assignment.

### Installation Manual References

- 2.4.13 Extra Device Port (XDP) Connection

### Programming Guide References

- 1.4 Extension Port Assignment
  - Parallel / XDP (DHLC card)

### Features Guide References

- 1.3 System Features
  - Parallelled Telephone

### User Manual References

Not applicable.

## 1.2 System Administration

### System Programming and Diagnosis with Personal Computer

#### Description

The KX-TD500 system can be programmed and administered using a Personal Computer (PC). The Programming Guide is required to perform PC Programming. There are two programming methods:

##### **On-Site Programming**

By connecting a PC to your system, System Programming and maintenance can be performed locally.

There are two ways available to perform the above:

##### **(Method 1.) Using the EIA (RS-232C) port**

Connect the PC to the EIA (RS-232C) port provided. The Basic Shelf is provided with RS-232C Ports. RS-232C Port 1 (PROG) is used for System Programming, diagnostics and external system database storage (Save / Load) functions, and Port 2 (SMDR) for Station Message Detailed Recording (SMDR) only.

##### **(Method 2.) Using an internal modem**

Install the optional Remote Card — RMT card (KX-T96196), ERMT card (KX-TD50197). Connect an extension port to the modem. Assign the FDN of the modem in System Programming. Dial this number from the PC.

##### **Remote Programming**

You can perform System Programming and maintenance from a remote site using a PC. Install the Remote Card and assign the Remote FDN by System Programming.

Starting system administration from a remote location can be done using one of the following ways:

##### **a) [Call Transfer]**

- Call an extension (probably the Operator) from a remote location and request a transfer to the modem.

##### **b) [DISA]**

- Dial the "FDN of the modem" using the DISA feature.

##### **c) [DIL 1:1]**

- Assign the "FDN of the modem" as the destination of the DIL 1:1 feature.

##### **d) [DDI / DID]**

- Programme DDI / DID feature so that the incoming telephone number is converted to the "FDN of the modem."

##### **e) [TIE Lines]**

- Dial the "FDN of the modem."
- Dial the TIE Line access code, the PBX Code and the "FDN of the modem."

##### **(Method 3.) Using an external modem**

Please refer to "External Modem Control" in Section 1.3 System Features of the Features

Guide and "Section 2.11.1 Controlling the External Modem (External Modem Control)" in the User Manual.

For more information and programming instructions, please refer to the Installation Manual and the Programming Guide.

### Conditions

- **One Time One Access**  
Access to System Programming is allowed only one device at a time.
- **System Password**  
To access system administration, a valid password must be entered. The password is factory-programmed and can be changed.
- System administration can be performed on-line except for the procedures of the diagnosis.

### Installation Manual References

- 2.6.3 RMT Card (KX-T96196)
- 2.6.4 ERMT Card (KX-TD50197)

### Programming Guide References

- 10.2 External Modem 1 / 2
- 10.3 External Modem 2 / 2
- 10.6 System Parameters
  - [Password] System Programming
  - [Serial Interface Port] PROG – Parity
  - [Serial Interface Port] PROG – NL Code
  - [Serial Interface Port] PROG – Word Length
  - [Serial Interface Port] PROG – Stop Bit
  - [Serial Interface Port] PROG – Baud Rate

### Features Guide References

- 1.3 System Features
  - External Modem Control

### User Manual References

Not applicable.

# Traffic Measurement

## Description

Provides current traffic information about following items individually.  
You can collect and display the traffic information using the Maintenance Console PC.

1. Station
2. Trunk Group
3. Operator
4. UCD
5. OGM
6. AGC

Please refer to "4.3.1 Traffic Information" in the Installation Manual.

## Conditions

None

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

Not applicable.

# User Programming

## Description

Allows a PT user to assign or change the following System Programming items at his / her own PT.

Access No.	Title
000	System Date / Time
001	System Speed Dial Number
002	System Speed Dial Name
004	Extension Name
005	Flexible CO buttons
006	Caller ID Dial
007	Caller ID Name
008	Absent Messages
009	Quick Dial Number

## Conditions

- User Programming Password is required to perform User Programming.

## Programming Guide References

- 10.6 System Parameters
  - [Password] User Programming

## Features Guide References

None

## User Manual References

- 4.3 Customising Your System (User Programming)



## 1.3 System Features

### Account Code Entry

#### Description

An Account Code (max. 10 digits) is used to identify incoming and outgoing CO calls for accounting and billing purposes.

**[For Outgoing CO Calls]**

One of the following three Account Code Entry modes is selected for each extension on a Class of Service basis:

**Verified-All Calls mode:**

An extension user must always enter a pre-assigned account code when making CO calls.

**Verified-Toll Restriction Override mode:**

An extension user can enter a pre-assigned account code to override toll restriction.

**Option mode:**

An extension user can enter any account code if needed.

**[For Incoming CO Calls]**

Account code entry is optional.

#### Conditions

- Up to 1000 account codes per system can be assigned by System Programming. These account codes are required when extension users in "Verified—All Calls mode" or "Verified—Toll Restriction Override mode" make outside CO calls.
- **Tenant Service**  
If Tenant Service is employed, the affiliation of each account code is determined by System Programming.
- **SMDR**  
The account code is appended to the Station Message Detail Recording (SMDR) call record.  
If two or more different account codes are entered during a single call:  
**Option mode**  
Only the last entered account code is appended to the SMDR.  
**Verified-All Calls mode**  
Only the first entered account code is appended to the SMDR.
- **Memory Dialling**  
An account code can be stored into Memory Dialling (System / Station Speed Dialling; One-Touch Dialling).
- **Account code entry after CPC detection**  
Should be done within 15 seconds. Otherwise, call record is appended to SMDR call record and entry becomes impossible afterwards.

- **TRS Level**  
Each account code is appended with unique TRS Level for "Toll Restriction Override by Account Code Entry" feature.
- **Emergency numbers**  
Regardless of the Account Code Entry mode setting, emergency numbers can be dialled out without entering an account code.
- **Account button**  
The Account button can be used instead of dialling the feature number. It can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.
- The account code used for making a CO call is memorised in the following auto dial memories: Last Number Redial, Saved Number Redial, Call Log - Outgoing

## Programming Guide References

- 2.3 Numbering Plan
  - Account Code
- 2.4 Class of Service (COS)
  - Account Code Mode
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key
- 5.6 Account Code
  - Tenant No.
  - Entry No.
  - Code
  - TRS Level

## Features Guide References

- 1.6 Originating Features
  - Toll Restriction Override by Account Code Entry

## User Manual References

- 2.2.5 Calling without Restrictions
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Automatic Calling Cancel

## Description

If this feature is enabled, the system automatically disconnects the CO line in use when the CO call is not answered in a specified period of time.

## Conditions

- This feature applies to the following trunks:  
E1 (DR2, E&M), E&M, DID, ISDN (PRI30, BRI)

## Programming Guide References

- 4.2 Trunk Line
  - Answer Wait Timer

## Features Guide References

None

## User Manual References

Not applicable.

# Automatic Configuration\*<sup>1</sup>

## Description

This is one of the DPT Integration features.

If DPT Integration is activated, the system transmits the extension number configuration information to the Voice Processing System (VPS). The VPS then automatically creates the mailbox for each extension based on this information.

## Conditions

- Correct Mailbox No. length must be selected in Panasonic Voice Mail System Reset / Clear Menu to create proper Mailbox No. based on three-digit or four-digit numbering plan.
- Automatic Configuration is available with one of the following KX-TVP series VPSs: KX-TVP75, KX-TVP100, KX-TVP200.
- When "Automatic Configuration" is executed, the VPS will automatically create 64 (KX-TVP75 / KX-TVP100) / 1024 (KX-TVP200) mailboxes.
- **"PBX Type" selection of the KX-TVP series VPS**  
When integrating the KX-TD500 System with one of the KX-TVP series VPSs, please select 'TD500' in "PBX Type" menu of the VPS. However, if 'TD500' is not listed in the menu, please select "TD1232" instead.

## Programming Guide References

- 5.11 VPS Integration

## Features Guide References

- 1.3 System Features
  - VPS Integration – DPT Integration

## User Manual References

Not applicable.

---

\*<sup>1</sup> Available when the Digital Super Hybrid System is connected to a Digital Proprietary Telephone capable Panasonic Voice Processing System (one that supports Digital Proprietary Telephone integration; e.g. KX-TVP100).

# Background Music (BGM) – External

## Description

Background Music (BGM) can be broadcast throughout the office via the external pagers. The BGM through External Pagers can be turned on / off by the Manager and the Operators.

## Conditions

- **Hardware Requirements**  
It is required to connect a user-supplied external pager. Up to two pagers and up to two external music sources can be installed in the system.
- To make BGM-External possible, you must enable BGM and select a music source in "External Paging" (System Programming) of the Programming Guide.
- **External Pager Priority**  
Priority of access to external pager is: (1) TAFAS; (2) Paging; (3) BGM. Higher priorities will override the BGM.

## Installation Manual References

- 2.8.2 External Pager (Paging Equipment)
- 2.8.3 Music Source (External / Internal)

## Programming Guide References

- 2.2 Tenant
  - BGM Source
- 2.3 Numbering Plan
  - External BGM On / Off
- 4.6 External Paging
  - BGM
  - BGM Source

## Features Guide References

- 1.15 Proprietary Telephone Features
  - Background Music (BGM)

## User Manual References

- 3.2.1 Turning on the External Background Music (Background Music [BGM] - External)

# Budget Management

## Description

Limits the telephone usage to a pre-assigned amount. For example, the limit may be the amount deposited at check-in of a hotel. If the pre-assigned limit is reached, the extension user cannot make further calls until he / she receives authorisation from the Manager or an Operator. This is useful to keep phone bills down by restricting the excess amount of phone charge.

## Conditions

- ELCOT (KX-TD50180) or BRI (KX-TD50288) or PRI30 (KX-TD50290) or E1 Digital Trunk card (KX-T96188) is required to utilise the feature.
- An emergency call can be made even if the phone charge of the extension reached the pre-assigned amount.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Charge Management
- 5.15 Charge
  - Charge Display on LCD
  - Charge by SMDR
  - [Charge Verification ID Code] Tenant 1-8
  - Rate
  - Currency
  - Currency Display Position
  - Treatment of Charge Limit
  - Meter Count up by Answer Detection

## Features Guide References

- 1.3 System Features
  - Charge Fee Reference

## User Manual References

Not applicable.

# Calling Party Control (CPC) Signal Detection

## Description

The Calling Party Control (CPC) Signal is an on-hook indication (disconnect signal) sent from the Central Office when the telephone is hung up at the other end. To maintain efficient utilisation of CO lines, the system monitors their state and when CPC Signal is detected from a line, the system disconnects the line and alerts the extension with a reorder tone.

## Conditions

- This feature is enabled or disabled on incoming and outgoing CO calls separately by System Programming.
- **CPC Signal Detection on outgoing CO calls**  
Generally CPC Signal Detection works on incoming CO calls, and does not work on outgoing CO calls (except once they are placed on Call Hold, Exclusive Call Hold or Consultation Hold). In this case, if the extension user remains off-hook after the completion of an outgoing CO call, the system does not release all the switches used to establish the connection. The connected CO line will continue to be in use. To prevent this, it is programmable to make CPC Signal Detection work on outgoing CO calls.  
**Note:** Some Central Offices (CO) may send CPC-like signals during the dialling sequence and an attempt to make a call may be terminated. If your CO sends such signals, it is recommended to make CPC Signal Detection work on outgoing CO calls.
- **Digits Restriction in CO Talk Mode**  
If your Central Office does not send CPC-like signals, it is effective to limit the number of dialling digits permitted during a CO call by the programme "Digits Restriction in CO Talk Mode" of Class of Service programming to prevent unauthorised calls.
- If a CPC Signal is detected during a Conference call, the line is disconnected and the remaining two parties resume the call.
- If a CPC Signal is detected during a DISA call, the line is disconnected.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Digits Restriction in CO Talk Mode
- 4.2 Trunk Line
  - [CPC Signal] OUT Detection
  - [CPC Signal] IN Detection

## Features Guide References

None

## User Manual References

Not applicable.

# Charge Fee Reference

## Description

Allows the pre-assigned display telephone user to view, clear charges and print out the data by SMDR. Charges are displayed per extension, CO line, account code, or the total of each can be referred to.

## Conditions

- The allowed extension is determined by System Programming.
- The verification ID is required to perform this feature.
- A maximum of 99999 Meter pulses can be collected. The existing call is not referred.
- It is programmable to select the first display, Meter or Charge by System Programming. This can be switched manually at each extension by Station Programming.
- The conversion of meter pulses to charge amount is set by Station or System Programming.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Charge Management
- 5.15 Charge
  - Charge Display on LCD
  - Charge by SMDR
  - [Charge Verification ID Code] Tenant 1-8
  - Rate
  - Currency
  - Currency Display Position
  - Treatment of Charge Limit
  - Meter Count up by Answer Detection

## Features Guide References

- 1.3 System Features
  - Budget Management

## User Manual References

- 4.2 Charge Fee Management (Station Programming)



# Class of Service (COS)

## Description

Used to define a set of services available to the extension user. Up to 96 different types of Class of Service can be established by System Programming. Each extension is assigned a Class of Service number by System Programming.

The programmable items are shown below:

<b>Account Code Mode</b>	Optional / Verify-Toll / Verify-All
<b>Automatic Hold</b>	Enable / Disable
<b>Call Forwarding Follow Me</b>	Enable / Disable
<b>Call Forwarding to CO</b>	Enable / Disable
<b>Call from TRS (Toll Restriction) Level 7 Extension</b>	Enable / Disable
<b>Charge Management</b>	Enable / Disable
<b>Digits Restriction in CO Talk Mode</b>	Unrestricted / 1-15 digits
<b>DND (Do Not Disturb) Override</b>	Enable / Disable
<b>Executive Busy Override</b>	Enable / Disable
<b>Executive Busy Override Deny</b>	Enable / Disable
<b>ISDN CFU / CFB / CFNR</b>	Enable / Disable
<b>Off-Hook Call Announcement (OHCA)</b>	Enable / Disable
<b>Released Link Operation</b>	Enable / Disable
<b>SDN COS</b>	Owner Extension / PDN
<b>Switching Day / Night Mode</b>	Enable / Disable
<b>Time Limit of Outside Calls</b>	Yes / No
<b>Transfer to CO</b>	Enable / Disable
<b>TRS (Toll Restriction) Level - Day / Night</b>	1-8
<b>Trunk Group Setting, Day / Night</b>	Trunk Group 01-48

## Conditions

- **Walking COS**

The extension user can make a toll call at other lower level COS extensions (toll / outward restricted) by employing his / her own higher level COS temporarily.

## **Programming Guide References**

- 2.4 Class of Service (COS)
- 4.3 Extension Line
  - COS No.

## **Features Guide References**

- 1.6 Originating Features
  - Walking COS

## **User Manual References**

Not applicable.

# Dial Type Selection

## Description

Used to select the desired dialling mode for each CO line regardless of originating call extension (rotary or tone).

There are two dialling modes available:

### **DTMF (Dual Tone Multi-Frequency) Mode**

The dialling signal from an extension, either tone or rotary, is converted to tone dialling. DTMF signals are transmitted to the CO line.

### **Pulse Dial (Rotary) Mode**

The dialling signal from an extension, either tone or rotary, is converted to rotary dialling. Rotary pulses are transmitted to the CO line.

## Conditions

- **Pulse to Tone Conversion**  
The extension user can convert the pre-assigned rotary dialling mode to DTMF mode temporarily. DTMF mode cannot be changed to rotary.
- **DISA**  
Either DTMF or rotary dialling can be assigned for the DISA (Direct Inward System Access) outgoing line. With DISA, Pulse to Tone Conversion is not possible.
- If a line is assigned Pulse Dial mode, select an appropriate pulse speed, pulse break ratio, and inter-digit pause for the line, if necessary. If a line is assigned DTMF, select an appropriate DTMF duration for the line, if necessary. Refer to Programming Guide for further information.

## Programming Guide References

- 1.2 Slot Assignment
- 4.2 Trunk Line
  - Dial Type

## Features Guide References

- 1.12 Conversation Features
  - End-to-End DTMF Signalling (Tone Through)
  - Pulse to Tone Conversion

## User Manual References

- 2.2.5 Calling without Restrictions

## DIL 1:N Group

### Description

Used to group extensions and / or Extension Groups so that an incoming CO call comes in on multiple extensions simultaneously.

Up to 96 DIL 1:N Groups can be set up in the system.

Each group can include up to 72 extensions and / or Extension Groups.

### Conditions

- A single extension can be assigned to up to eight different DIL 1:N Groups at a time.
- **Delayed Ringing**  
When an outside call directed to a DIL 1:N Group comes in, all extensions in the group ring immediately by default.  
This setting can be changed to delayed ringing or no ring on each DIL 1:N Group member (extension or Extension Group) basis.

### Programming Guide References

- 3.5 DIL 1:N Group
  - [Destinations] DN
  - [Destinations] Ringing Type
- 4.2 Trunk Line
  - Incoming Type
  - Destination – Day / Night

### Features Guide References

- 1.13 Audible Tone Features
  - Ringing, Delayed

### User Manual References

Not applicable.

# Door Opener

## Description

Allows the extension users to unlock the door for a visitor from their extensions. The door can be unlocked by extension users assigned as the destination of doorphone calls anytime by dialling the appropriate feature number. However, during a doorphone call, any extension user can open the door from their extensions by dialling "5" to let the visitor in.

## Conditions

- **Hardware Requirements**  
It is necessary to install a DPH Card (KX-T96161) and a user-supplied door opener on each door to be opened. Up to eight door openers can be installed in the system.

## Installation Manual References

- 2.7.2 DPH Card (KX-T96161)

## Programming Guide References

- 2.3 Numbering Plan
  - Door Open
- 2.5 System Timer
  - Door Opener Time
- 4.5 Doorphone
  - Destination – Day / Night

## Features Guide References

- 1.12 Conversation Features
  - Doorphone Call

## User Manual References

- 2.8.1 If a Doorphone / Door Opener is Connected

# E1 Carrier

## Description

The E1 carrier is a hierarchy of digital transmission systems designed to carry roughly 2.048 Mega bps. of speech and other signals in digital form. The E1 carrier has 30 PCM voice channels.

### Trunk Interface

E1 digital trunk card supports the following three different trunk interfaces to provide desired connection at minimum expense.

### Type of interface:

DR2, E&M-C (Continuous E&M), E&M-P (Pulsed E&M),

One of three trunk interfaces can be assigned to one of 30 voice channels of E1 digital trunk card individually according to tariffs and customer need.

## Conditions

- **Hardware Requirements**

E1 digital trunk card (KX-T96188) is required to utilize E1 carrier with the KX-TD500 System. Up to six E1 digital trunk cards (180 ports) can be installed to the system.

## Programming Guide References

- 1.2 Slot Assignment
- 1.7 E1 Port Assignment

## Features Guide References

None

## User Manual References

Not applicable.

# EXTENSION GROUP – A SUMMARY

## Description

To support efficient utilisation of extensions, they can be grouped together as an Extension Group.

Any extension in the Extension Group can pick up a call ringing at another extension within the same Extension Group (Call Pickup - Group).

Extension Group is used to direct incoming calls (both extension and outside) to a group of answering extensions associated with the type of incoming calls.

Up to 128 Extension Groups can be created in the system.

The following seven different types of Extension Group can be created:

- Extension Group – Automated Attendant (AA) Group
- Extension Group – Operator Group
- Extension Group – Ring Group
- Extension Group – Station Hunting Group (Circular)
- Extension Group – Station Hunting Group (Terminate)
- Extension Group – Uniform Call Distribution (UCD) Group
- Extension Group – Voice Mail (VM) Group

## Description of Programming Items

### 1. FDN

Specifies the FDN (Floating Directory Number) for each Extension Group.

### 2. Group Type

Specifies the Group Type for each Extension Group

This determines how the Extension Group handles the incoming calls directed to it.

### 3. Tenant No.

Assigns a Tenant No. (1-8) to which the Extension Group is assigned (Required if "Tenant Service" is employed.)

### 4. Overflow Setting

#### Destination, Day / Night

Specifies the destination extension where the call is transferred to when all extensions in the Extension Group are busy or logged-out.

#### Timer

Specifies the length of time in minutes the system is to wait before transferring the call in the waiting queue to the Overflow Destination. (Assignable only when "Operator" is specified in "Group Type" programming.)

### 5. FWD / DND Mode

Specifies whether to enable or disable the FWD / DND (Call Forwarding or Do Not Disturb) feature assigned on an extension in the Extension Group.

( Assignable only when "Group Type" is set to "Terminate," "Circular" or "UCD.")

**6. Extension Call Hunting**

Specifies whether station hunting feature works or not when the other party calls a busy extension in the group by dialling DN of the extension (extension call).

**7. Operator Setting**

(Assignable only when "Operator" is specified in "Group Type" programming.)

**Ringing Type**

Specifies whether the call coming in on an Operator Group rings one Operator (Single) or all Operators in the group (Multi) simultaneously.

**Call Priority**

Specifies the answering priority of incoming calls to the Extension Group by call type when more than one call is ringing at an Operator extension.

**8. UCD Setting**

(Assignable only when "UCD" is specified in "Group Type" programming.)

**Time Table No.**

Specifies the UCD Time Table number for the Extension Group.

**FWD No Answer**

Specifies the treatment of the call which is not answered by the extension in the UCD group within a specified period of time (Call Forwarding — No Answer Time).

**Auto LOGOUT Mode**

Specifies the treatment of extensions in the UCD group who do not / cannot answer the call. A member extension may be logged-out automatically, if it does not answer the call for pre-determined times (1-10) consecutively. If "Disable" is specified, this setting does not function.

**Supervisor Extension**

Specifies the Supervisor Extension per UCD Group. The extension specified as the Supervisor Extension can monitor the number of calls put in the waiting queue.

**LOGIN Monitor**

Specifies whether or not the extensions in the same UCD Group can monitor (via DSS button) the Login / Logout status of other UCD Group members.

**UCD Call Waiting**

Specifies whether or not Call Waiting to a UCD Group member extension is available.

## Conditions

- **Log-in, Log-out**

Members of an Extension Group (except Group Type:None) can leave the group temporarily when they are away from their desks, to prevent calls being sent to their extension (Log-out). They can return to the group when they are ready to answer a call (Log-in).

- A single extension user cannot belong to two or more different Extension Groups at a time.



## Programming Guide References

- 1.4 Extension Port Assignment
  - Group No.
- 2.3 Numbering Plan
  - Login / Logout
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
  - [Overflow Setting] Timer
  - FWD / DND Mode
  - Extension Call Hunting
  - [Operator Setting] Ringing Type
  - [Operator Setting] Call Priority
  - [UCD Setting] Time Table No.
  - [UCD Setting] FWD No Answer
  - [UCD Setting] Auto LOGOUT Mode
  - [UCD Setting] Supervisor Extension
  - [UCD Setting] LOGIN Monitor
  - [UCD Setting] UCD Call Waiting
- 4.3 Extension Line
  - Group No.

## Features Guide References

- 1.3 System Features
  - Extension Group – Automated Attendant (AA) Group
  - Extension Group – Operator Group
  - Extension Group – Ring Group
  - Extension Group – Station Hunting Group (Circular)
  - Extension Group – Station Hunting Group (Terminate)
  - Extension Group – Uniform Call Distribution (UCD) Group
  - Extension Group – Voice Mail (VM) Group
- 1.8 Ringing Features
  - Log-In / Log-Out
- 1.9 Answering Features
  - Call Pickup – Group

## User Manual References

Not applicable.

# Extension Group – Automated Attendant (AA) Group

## Description

This is one of seven incoming call services assignable on an Extension Group basis. If Voice Processing System is integrated with your KX-TD500 system (VPS Integration), we recommend to group multiple AA extensions together as an AA Group.

This ensures that callers who need AA service can surely access it. Within a group, an incoming call hunts for an idle AA extension in a circular way.

AA Group can be made up by assigning the group type of an Extension Group as "AA." Up to 128 AA Groups, each consisting of more than one extension in the same tenant, can be created in the system.

By default, Extension Group #127 is assigned as AA Group.

## Conditions

- Refer to EXTENSION GROUP – A SUMMARY in this manual.

## Programming Guide References

- 1.5 VPS (DPT) Port Assignment
- 2.3 Numbering Plan
  - Login / Logout
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
- 4.3 Extension Line
  - Group No.
- 5.11 VPS Integration

## Features Guide References

- 1.3 System Features
  - EXTENSION GROUP – A SUMMARY
  - VPS Integration – Voice Mail (VM) Service Integration

## User Manual References

Not applicable.

## Extension Group – Operator Group

### Description

This is one of seven incoming call services assignable on an Extension Group basis. It is efficient to handle a high volume of operator-seeking calls by a group of extensions called "Operator Group," which can consist of one or more extensions.

Within an Operator Group, an operator-seeking call (extension / outside) may come in on a single operator (Single) or all operators in the group simultaneously (Multi) depending on System Programming.


Operator Group can be made up by assigning the group type of an Extension Group to "Operator." Only one Operator Group can be assigned per tenant.

By default, Extension Group #128 is assigned as Operator Group.

### (1) Outline sketch of Operator feature


#### 1. When "Ringling Type" is set to "Multi"


An incoming call (intercom / outside call) arrives at all Operator extensions at the same time.



**2. When "Ringing Type" is set to "Single"**

An incoming call (intercom / outside call) arrives at an Operator extension.



**(2) What if all Operator extensions are busy?****Note**

- An incoming call which is arriving on a CO key of an Operator PT extension is regarded as an arrived call.

**Conditions**

- **Tenant Service**  
If "Tenant Service" is employed, each tenant can have its own unique "Operator Group" independently.

## **Programming Guide References**

- 2.3 Numbering Plan
  - Login / Logout
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
  - [Overflow Setting] Timer
  - [Operator Setting] Ringing Type
  - [Operator Setting] Call Priority
- 4.3 Extension Line
  - Group No.

## **Features Guide References**

- 1.3 System Features
  - EXTENSION GROUP – A SUMMARY
- 1.6 Originating Features
  - Operator Call

## **User Manual References**

- 2.2.1 Basic Calling

# Extension Group – Ring Group

## Description

This is one of seven incoming call services assignable on an Extension Group basis. Allows both extension and outside users to ring all extensions in a Ring Group simultaneously by dialling the Floating Directory Number (FDN) of the Ring Group. This feature is useful for talking to or transferring calls to anyone in the same group. Ring Group can be made up by assigning the group type of an Extension Group as "Ring." Up to 128 Ring Groups, each consisting of more than one extension in the same tenant, can be created in the system.

## Conditions

- Types of calls whose destination can be the Ring Group are:  
Outside calls — DIL 1:1; DISA; IRNA; UCD-Overflow; DDI; DID; MSN; TIE  
Intercom calls — Extension; Transfer

## Programming Guide References

- 2.3 Numbering Plan
  - Login / Logout
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
- 4.3 Extension Line
  - Group No.

## Features Guide References

- 1.3 System Features
  - EXTENSION GROUP – A SUMMARY
  - Floating Station

## User Manual References

Not applicable.

## Extension Group – Station Hunting Group (Circular)

### Description

This is one of seven incoming call services assignable on an Extension Group basis.

If the called extension is busy, Station Hunting redirects the incoming call to an idle extension within the same Extension Group.

In the Circular Hunting Group, the extensions are searched in physical number order (from lower to higher) of the extension port until an idle one is found.

Station Hunting Group (Circular) can be made up by assigning the group type of an Extension Group as "Circular." Up to 128 Station Hunting Groups (Circular), each consisting of more than one extension in the same tenant, can be created in the system.

### Conditions

- **What if all extensions in the group are busy?**  
If all of the searched extensions are busy, the system redirects the call to the overflow destination.
- **FWD / DND Mode**  
If the called extension is in Call Forwarding or Do Not Disturb mode, Station Hunting skips the extension by default. This can be changed by System Programming.

### Programming Guide References

- 2.3 Numbering Plan
  - Login / Logout
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
  - FWD / DND Mode
  - Extension Call Hunting
- 4.3 Extension Line
  - Group No.

### Features Guide References

- 1.3 System Features
  - EXTENSION GROUP – A SUMMARY
- 1.8 Ringing Features
  - STATION HUNTING – A SUMMARY



## User Manual References

Not applicable.

## Extension Group – Station Hunting Group (Terminate)

### Description

This is one of seven incoming call services assignable on an Extension Group basis.

If the called extension is busy, Station Hunting redirects the incoming call to an idle extension within the same Extension Group.

In the Termination Hunting Group, the extensions are searched until reaching the extension which has the highest physical port number in the group.

Station Hunting Group (Terminate) can be made up by assigning the group type of an Extension Group as "Terminate." Up to 128 Station Hunting Groups (Terminate), each consisting of more than one extension in the same tenant, can be created in the system.

### Conditions

- **What if all extensions in the group are busy?**

If all of the searched extensions are busy, the system redirects the call to the overflow destination.

- **FWD / DND Mode**

If the called extension is in Call Forwarding or Do Not Disturb mode, Station Hunting skips the extension by default. This can be changed by System Programming.

### Programming Guide References

- 2.3 Numbering Plan
  - Login / Logout
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
  - FWD / DND Mode
  - Extension Call Hunting
- 4.3 Extension Line
  - Group No.

### Features Guide References

- 1.3 System Features
  - EXTENSION GROUP – A SUMMARY
- 1.8 Ringing Features
  - STATION HUNTING – A SUMMARY

## User Manual References

Not applicable.

# Extension Group – Uniform Call Distribution (UCD) Group


## Description

This is one of seven incoming call services assignable on an Extension Group basis. Calls to a UCD group are distributed uniformly among the group members so that each member can share the same load. Calls to a UCD group hunt for an idle extension in a circular way, starting at the extension following the last one called. This UCD feature is particularly helpful when a certain extension receives a high volume of calls compared with other extensions.


UCD Group can be made up by assigning the group type of an Extension Group as "UCD." Up to 128 UCD Groups, each consisting of more than one extension in the same tenant, can be created in the system.

### (1) Outline sketch of UCD feature

1. When more than one call is in the UCD group, the 1st call will arrive at extension A first.



2. If the 1st call arrives at extension A, the 2nd call will arrive at extension B.



3. When the 2nd call arrives at extension B, the 3rd call will arrive at extension C.

### Notes

#### 1. **Busy status**

If group members are in one of the following conditions, they are considered as busy.

- The extension is in Call Forwarding / Do Not Disturb (FWD / DND) mode.  
— Calls to a UCD Group may ring the extension in FWD / DND mode, or skip it. This is determined by System Programming (Section 3.3 Extension Group, "FWD / DND Mode" in the Programming Guide).
- Another call is already ringing on the extension.
- The extension is off-hook.
- The extension is logged-out.

#### 2. **Login / Logout**

Extension users in the UCD Group can leave the group temporarily when they are away from their desks, to prevent calls being sent to their extensions (Logout). They can return to the group when they are ready to answer calls (Login).

### 3. UCD Supervisory Features

#### **Login Monitor**

Login / Logout status of the UCD Group members can be monitored by the extensions in the same UCD Group through Busy Lamp Field of the corresponding DSS button. Login Monitor is enabled or disabled by System Programming (Section 3.3 Extension Group, "LOGIN Monitor" in the Programming Guide).

#### **UCD Monitor Mode**

The extension specified as the Supervisor Extension can monitor the number of calls put in the waiting queue by dialling the feature number for "UCD Monitor Mode."

To start UCD monitor: dial feature number + UCD Group FDN

To end UCD monitor: dial feature number + "×"

You can also use the Features menu of a large display DPT.

The extension that can perform this feature is determined by System Programming (Section 3.3 Extension Group, "Supervisor Extension" in the Programming Guide).

### 4. What if a call ringing on a member extension is not answered?

If not answered within a specified period of time (Call Forwarding — No Answer Time), the call is transferred to the next idle member extension, or the call continues to ring on the current destination extension.

This is determined by System Programming (Section 3.3 Extension Group, "FWD-No Answer" in the Programming Guide).

### 5. Auto Logout

A member extension may be logged-out automatically, if it does not answer the call for pre-determined times (1-10) consecutively. This is determined by System Programming (Section 3.3 Extension Group, "Auto Logout Mode" in the Programming Guide).

**PT:** To use this feature correctly, programme Login / Logout button. After the system activates Auto Logout, press Login / Logout button in the off-hook status to go back to the Login mode.

**SLT:** After the system activates Auto Logout, enter the feature number for Login in the off-hook status to go back to the Login mode.


### 6. UCD Call Waiting


This feature is different from regular Call Waiting. This feature (if enabled) allows UCD group members to hear a Call Waiting tone when an outside call arrives but all the extensions in the UCD Group are busy.

## (2) Types of calls which come in on a UCD Group

FDN (Floating Directory Number) for UCD Group can be assigned or dialled as a destination of the following calls:

<b>Outside calls</b>	DIL 1:1, DISA, DID, DDI, IRNA, Transfer, TIE
<b>Intercom calls</b>	Intercom, Transfer



**(3) What if all extensions in a UCD Group are busy or logged out?****Notes**

- **Overflow destination**

One of the following four destinations can be assigned as the Overflow destination per UCD Group: an extension, other Extension Group, Phantom Extension or TAFAS (outside calls only).

- If the overflow destination or UCD Time Table is not programmed, the call is put in the waiting queue. Then if not answered within a specified period of time (Intercept time), the call will be transferred to the IRNA destination.



**(4) UCD Time Table**

If all extensions in a UCD group are busy, the incoming CO calls will be handled by the UCD Time Table procedure.

Up to 32 UCD Time Tables, max. 16 steps for each, can be assigned by System Programming. The following commands are provided to make up a UCD Time Table procedure.

**Command list and functions**

<b>Command</b>	<b>Functions</b>
S (1-8)	OGM (1-8) is sent to the caller if available. If not, wait until OGM (1-8) becomes available.
1T-4T	Callers are put in the waiting queue for $N(1-4) \times 8$ seconds while hearing the ringback tone.
RET	Returns to the first step of the sequence.
TR	Transfers a call to the Overflow destination.
OFF	Disconnects the call compulsorily.

**Note**

The first command in each table is set to "1T" by default.

**Example of UCD Time Table Assignment**

<b>UCD</b>	<b>FDN</b>	<b>OFDN</b>	<b>TT</b>
1	191	101	1
2	192	291	2
3	193		
4	194		
5	291		
5	291		
6	292		
7	293		
8	294		

UCD : UCD Group Number (1 - 128)

FDN : Floating Directory Number of the  
UCD Group

OFDN : Overflow Destination FDN

TT : Time Table Number (1 - 32)


### Procedure Assignment Example

UCD Time Table procedure can be assigned as follows:

Table No.	Sequence
1	S1 → 4T → 2T → S2 → TR → →
2	S1 → 2T → S3 → OFF → → →
3	1T → TR → → → → →
4	S1 → 2T → S4 → 2T → TR → →

#### (Example 1)

S1 → 4T → 2T → S2 → TR



1. The caller hears OGM1, if available.

(Sample OGM 1)

Sorry, all lines are busy.  
Please wait a moment.

- What if OGM1 is busy?  
The caller first hears ringback tone and then will hear OGM1 as soon as it becomes available (Go to step 2).
- What if OGM1 is OUS (Out-of-Service)?  
Step 1 will be skipped (Go to step 2).

2. The caller is put in the waiting queue for 48 seconds (4T + 2T).

3. The caller hears OGM2.


(Sample OGM 2)

Sorry, all lines are still busy.  
Calling the Operator.

4. The caller is transferred to the Overflow destination (Operator or covering extension).

#### Note

During Steps 1 - 3, the caller will be connected to a UCD group member as soon as anyone of members becomes available to answer the call.

**(Example 2)**

1. The caller hears OGM1, if available.

(Sample OGM 1)

Sorry, all lines are busy.  
Please wait a moment.

- What if OGM1 is busy?  
The caller first hears ringback tone and then will hear OGM1 as soon as it becomes available (Go to step 2).
- What if OGM1 is OUS (Out-of-Service)?  
Step 1 will be skipped (Go to step 2).

2. The caller is put in the waiting queue for 16 seconds (2T).

3. The caller hears OGM3.


(Sample OGM 3)

Sorry, all lines are still busy.  
Please call us again.  
Thank you for calling.

If OGM3 is busy, the caller first hears ringback tone and then will hear OGM3 as soon as it becomes available.


4. The caller is disconnected from the switch.

### (Example 3)



1. The caller is put in the waiting queue for 8 seconds (1T).
2. The caller is transferred to the Overflow destination.

### (Example 4)



1. The caller hears OGM1, if available.  
 (Sample OGM 1)

Sorry, all lines are busy.  
 Please wait a moment.

- What if OGM1 is busy?  
 The caller first hears ringback tone and then will hear OGM1 as soon as it becomes available (Go to step 2).
- What if OGM1 is OUS (Out-of-Service)?  
 Step 1 will be skipped (Go to step 2).

2. The caller is put in the waiting queue for 16 seconds (2T).
3. The caller hears OGM4.  
 (Sample OGM 4)

Sorry, all lines are still busy.  
 Please wait a moment.

If OGM 4 is busy, the caller hears Music on Hold and then will hear OGM4 as soon as it becomes available.

4. Same as step 2.
5. The caller is transferred to the Overflow destination.

### Notes

- The UCD Time Table procedure applies to outside calls (including transferred calls) only.
- Any command after "TR", "RET" or "Blank" does not function.
- If any unavailable OGM S(1-8) is assigned in the UCD Time Table, it will be ignored.

## Conditions

- This feature must be enabled by System Programming for the desired UCD Group(s).
- In addition, each extension must enable regular Call Waiting feature (Section 2.7.3 Receiving a Call Waiting (Call Waiting / Off-Hook Call Announcement [OHCA] / Whisper OHCA) in the User Manual).
- **UCD-OGM**  
To utilise OGM messages for UCD callers, assign "OGM Type" to "UCD-OGM" by System Programming (Section 3.6 OGM Group, "OGM TYPE" in the Programming Guide).
- **Music on Hold or Ringback Tone**  
It is determined by System Programming (Section 2.8 System Option , "(1) Sound source during transfer" in the Programming Guide) whether to send ringback tone or Music on Hold to the caller.

## Programming Guide References

- 2.3 Numbering Plan
  - Login / Logout
  - UCD Monitor Mode
- 2.5 System Timer
  - Intercept Time
- 2.8 System Option
  - Sound source during transfer
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
  - FWD / DND Mode
  - [UCD Setting] Time Table No.
  - [UCD Setting] FWD No Answer
  - [UCD Setting] Auto LOGOUT Mode
  - [UCD Setting] Supervisor Extension
  - [UCD Setting] LOGIN Monitor
  - [UCD Setting] UCD Call Waiting
- 3.6 OGM Group
  - FDN
  - OGM Type
- 4.3 Extension Line
  - Group No.

## Features Guide References

- 1.3 System Features
  - EXTENSION GROUP – A SUMMARY
- 1.8 Ringing Features
  - Log-In / Log-Out

## User Manual References

- 2.11.3 Monitoring the Number of UCD Calls Waiting to be Answered (UCD Monitor Mode)

# Extension Group – Voice Mail (VM) Group

## Description

This is one of seven incoming call services assignable on an Extension group basis.

If a Voice Processing System is integrated with your KX-TD500 system (VPS Integration), we recommend to group multiple VM extensions together as a VM Group.

This ensures that callers who need VM service can surely access it. Within a group, an incoming call hunts for an idle VM extension in a circular way.

VM Group can be made up by assigning the group type of an Extension Group as "VM." Up to 128 VM Groups, each consisting of more than one extension in the same tenant, can be created in the system.

## Conditions

- Same as Extension Group-Summary

## Programming Guide References

- 1.5 VPS (DPT) Port Assignment
- 2.3 Numbering Plan
  - Login / Logout
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
- 4.3 Extension Line
  - Group No.
- 5.11 VPS Integration

## Features Guide References

- 1.3 System Features
  - EXTENSION GROUP – A SUMMARY
  - VPS Integration – Voice Mail (VM) Service Integration

## User Manual References

Not applicable.

# External Modem Control

## Description


The system supports an external modem (see **Notes**) plugged into the RS-232C Port 1. The system communicates with the remote terminal at data rate of up to 19,200 bps and enables remote system maintenance through an external modem. A pre-assigned AT Command (see **Notes**) can be sent to an external modem automatically when it is plugged into the RS-232C Port 1. The extension user is also allowed to control the external modem by sending the pre-assigned AT Commands.

## Conditions

- To connect an external modem to your system, perform the following procedures:
  1. Connect the modem to the system with the EIA (RS-232C) cable.
  2. Connect the modem to an extension port which is assigned as the DIL 1:1 destination. Or connect the CO line directly to the modem.
  3. Set the power switch of the modem to "ON," then the modem will be initialised with the default values.
  4. The following AT Command programming may be required for the modem.
    - The Data Terminal Ready (DTR) signal should be ignored.
    - The Data Terminal Equipment (DTE) / Modem flow control should be turned off.
    - The data compression should be disabled.
    - Error Correction is not necessary.


### Notes

- **Not all modems will be compatible. Please contact the Panasonic Bulletin Board System (BBS).**
- **Please refer to the modem instructions as the AT Commands depend on the manufacturer of your model.**



- The connection chart for the external modem (25-pin) is as follows:





- EIA (RS-232C) parameters of the EIA / remote programming software should be the same as the PBX. When you use 9600 bps, we recommend the combination of "8" Word Length, "None" Parity and "1" Stop Bit.
- An AT Command (for initialisation, enabling Automatic Answer, etc.) can only be programmed by EIA / remote programming software. The default is *"AT&F0Q0E0V1S0=1X0&D0."*
- For more information about the AT Command, please refer to the modem instructions.

## Programming Guide References

- 2.3 Numbering Plan
  - MODEM Control
- 10.2 External Modem 1 / 2
  - Manual Initialization Command (1- 5)
  - Automatic Initialization Command
- 10.3 External Modem 2 / 2
  - Connection Message (1-5)
  - Disconnection Message (1-5)

## Features Guide References

- 1.2 System Administration
  - System Programming and Diagnosis with Personal Computer

## User Manual References

- 2.11.1 Controlling the External Modem (External Modem Control)

# Flexible Numbering

## Description

The numbers used for the access codes of system features and the numbers used for extension numbers are not fixed. They can be set as required, provided there are no conflicts.

**Feature numbers** can be from **1 to 4 digits**, utilising numbers "0 through 9" as well as "×" and "#."

**Extension numbers** can be **3 to 4 digits** in length. Numbers "0 through 9" can be set as the leading 1 or 2 digits of the extension number. If 1 digit is assigned as the leading digit, extension numbers are 3-digit in length. If 2 digits are assigned as the leading digits, extension numbers are 4-digit in length.

**Flexible Feature Numbers**

Number	Feature	Default
01	1st Hundred Block Extension	10
02	2nd Hundred Block Extension	11
03	3rd Hundred Block Extension	12
04	4th Hundred Block Extension	13
05	5th Hundred Block Extension	14
06	6th Hundred Block Extension	20
07	7th Hundred Block Extension	21
08	8th Hundred Block Extension	22
09	9th Hundred Block Extension	23
10	10th Hundred Block Extension	24
11-16	11th through 16th Hundred Block Extension	Blank
17	Operator Call	0*1
18	Local CO Line Access / ARS	9*2
19	Trunk Group Access	8
20	Speed Dialling - System	×
21	Speed Dialling - Station	3×
22	Speed Dialling - Station Programming	30
23	Doorphone Call	31
24	External Paging	32
25	External Paging Answer / TAFAS Answer	42
26	Station Paging	33

## Flexible Feature Numbers

Number	Feature	Default
27	Station Paging Answer	43
28	CO Call Pickup	4*
29	Group Call Pickup	40
30	Directed Call Pickup	41
31	Hold	50
32	Hold Retrieve - Station	51
33	Hold Retrieve - Trunk	53
34	Redial	#
35	Call Park / Call Park Retrieve	52
36	Account Code	49
37	Door Open	55
38	External Feature Access	6
39	Station Program Clear	790
40	Message Waiting Set / Cancel / Call Back	70
41	OGM Playback / Record	36
42	Call FWD - Do Not Disturb Set / Cancel	710
43	Dial Call Pickup Deny Set / Cancel	720
44	Data Line Security Set / Cancel	730
45	Call Waiting Set / Cancel	731
46	Executive Override Deny Set / Cancel	733
47	Pickup Dialling Programme / Set / Cancel	74
48	Absent Message Set / Cancel	750
49	Timed Reminder Confirm / Set / Cancel	761
50	Station Lock Set / Cancel	762
51	Night Mode Set / Cancel	78
52	Parallel telephone mode	39
53	External BGM On / Off	35
54*3	Live Call Screening	799
55	Call Log Incoming, Overwrite Mode	56
56	Call Log Incoming, Log Lock	57
57	Timed Reminder, Remote	7*

---

**Flexible Feature Numbers**

<b>Number</b>	<b>Feature</b>	<b>Default</b>
58	Login / Logout	45
59	Automatic Callback Busy Cancel	46
60	Walking COS	47
61	MODEM Control	791
62	Reserved	—
63-70	Quick dial 1-8	Blank
71	Reserved	—
72	Remote DND	722
73	Remote FWD Cancel - Once	723
74	Trunk Route Control	724
75	UCD Monitor Mode	725
76	TIE Line Access	77
77-92	Other PBX 01-16	Blank
93	Paging Deny Set / Cancel	721
94	Trunk Busy-out	726
95	Walking Station	727
96	CLIP / COLP	711
97	CLIR	59
98	COLR	58
99	Dial Information (CTI)	Blank

\*1 0(BX), 9(SA)

\*2 9(BX), 0(SA)

\*3 Available when the Digital Super Hybrid System is connected to a Digital Proprietary Telephone capable Panasonic Voice Processing System (one that supports Digital Proprietary Telephone integration; e.g. KX-TVP100).

Default feature numbers are shown above.

In addition to the flexible feature numbers above, fixed feature numbers are provided on the next page.

## Fixed Feature Numbers

Feature	Type-1	Type-2
<b>While busy tone is heard:</b>		
Automatic Callback Busy	6	6
Busy Station Signalling (BSS) / Off-Hook Call Announcement (OHCA) / Whisper OHCA	1	2
Executive Busy Override	2	3
<b>While Do Not Disturb tone is heard:</b>		
Do Not Disturb Override	1	2
<b>While calling or talking:</b>		
Account Code Delimiter	# / 99	# / 99
Alternate Calling - Ring / Voice	✖	✖
Conference	3	3
Door Open	5	5
Pulse to Tone Conversion	✖ #	✖ #
<b>When the extension is on-hook:</b>		
Background Music (BGM) on / off	1	HOLD / TRANSFER
Day / Night mode display	#	#
Time display / Self-Extension Number display switching	✖	✖
<b>When a CO call is arriving (Receiving the Caller ID information):</b>		
Switching CO Line Name / Caller ID Number / Caller ID Name	✖	✖

## Conditions

- Flexible feature numbers can only be dialled during dial tone.
- **Feature Number Conflicts**  
Examples: 1 and 11, 0 and 00, 2 and 21, 10 and 101, 32 and 321, etc.
- **Additional Digits**  
Some flexible feature numbers require additional digits to make the feature active. For example, to set Call Waiting, the feature number for "Call Waiting" must be followed by "1" and to cancel it, the same feature number should be followed by "0."
- Fixed Feature Numbers Type-1 or Type-2 can be selected by System Programming.  
(Default: Type-1 (BX) Type-2 (SA))

## **Programming Guide References**

- 1.4 Extension Port Assignment
  - Attribute
  - DN
- 2.3 Numbering Plan
- 2.8 System Option
  - Fixed Feature Number

## **Features Guide References**

None

## **User Manual References**

Not applicable.

# Floating Station

## Description

Virtual extension numbers can be assigned to resources to make them appear as real extensions. These numbers are defined as Floating Directory Numbers (FDN). The following resources can have FDNs:

Resource Name	Max. number of FDN	Incoming Call Type					
		DIL1:1	DISA	DID / DDI	TIE	Intercept Routing	Intercom Call
External Pager (TAFAS)	2	✓	✓	✓	–	✓	–
OGM Group (DISA)	8	✓	–	–	–	✓	–
Modem (Remote System Administration)	1	✓	✓	✓	✓	–	✓
Extension Group	128	✓	✓	✓	✓	✓	✓
Phantom Extension	448	✓	✓	✓	✓	✓	✓

"✓" indicates that the FDN can be assigned as the destination.

## Conditions

- FDNs cannot be used for setting a feature such as Call Forwarding, etc.

## Installation Manual References

- 2.6.1 DISA Card (KX-T96191)
- 2.6.3 RMT Card (KX-T96196)
- 2.6.4 ERMT Card (KX-TD50197)

## Programming Guide References

- 2.3 Numbering Plan
  - 1st Hundred Block Extension
  - 2nd Hundred Block Extension
  - 3rd Hundred Block Extension
  - 4th Hundred Block Extension
  - 5th Hundred Block Extension
  - 6th Hundred Block Extension
  - 7th Hundred Block Extension
  - 8th Hundred Block Extension
  - 9th Hundred Block Extension
  - 10th Hundred Block Extension
  - 11th Hundred Block Extension - 16th Hundred Block Extension
- 3.3 Extension Group
  - FDN
- 3.6 OGM Group
  - FDN
- 4.6 External Paging
  - FDN
- 5.3 Phantom Extension
  - FDN
- 10.6 System Parameters
  - Remote FDN

## Features Guide References

None

## User Manual References

Not applicable.



# Host PBX Access

## Description

The system may be installed behind an existing host PBX. This is performed by connecting (extension) lines from the host PBX to CO line ports of the KX-TD500 System.

## Conditions

- To enable Host PBX Access, put the host PBX line in a Trunk Group. The extension user can access the host PBX by selecting that CO line.
- **Host PBX Access Code**  
A Host PBX Access Code is required to access CO lines of the host PBX for making an outside call.
- **Automatic Pause Insertion**  
A pause, if programmed, can be inserted between the user-dialled Host PBX Access Code and the following digits. Programme the pause time required by the Host PBX for that Trunk Group.
- **External Feature Access**  
Access to the host PBX during a conversation is also possible.

## Programming Guide References

- 3.2 Trunk Group
  - Pause Time
  - PBX Access Code

## Features Guide References

- 1.7 Dialling Features
  - Pause Insertion, Automatic
- 1.12 Conversation Features
  - External Feature Access

## User Manual References

- 2.8.2 If a Host PBX is Connected

# Limited Call Duration

## Description

Limited Call Duration is a system programmable feature that disconnects a CO call when a specified timer expires. A warning tone is sent to the extension user 15 seconds, 10 seconds, and 5 seconds before the time-limit.

## Conditions

- **Class of Service**  
Limiting the call duration can be activated or deactivated on a Class of Service (COS) basis for each extension.
- **Extension-to-CO Line Call**  
Any outside call except CO-to-CO line call is limited by this feature. For CO-to-CO line calls, CO-to-CO Duration Time is activated.
- This feature applies to the following calls:
  - a) Ordinary CO calls
  - b) Calls forwarded by "Call Forwarding to Trunk" feature<sup>\*1</sup>
  - c) Calls transferred by "Call Transfer to Trunk" feature<sup>\*1</sup>
- **Outgoing CO calls only or both**  
This feature may apply to outgoing CO calls only or both outgoing and incoming CO calls. This is determined by System Programming (Section 2.8 System Option , "(5) Limited Call Duration" in the Programming Guide).

## Programming Guide References

- 2.4 Class of Service (COS)
  - Time Limit of Outside Calls
- 2.5 System Timer
  - Extension-to-CO Line Call Duration Time
- 2.8 System Option
  - Limited call duration

## Features Guide References

- 1.11 Transferring Features
  - Call Forwarding – to CO / TIE
  - Call Transfer – to CO
- 1.12 Conversation Features
  - Conference, Unattended

---

<sup>\*1</sup> Determined by COS of the extension who initiated the feature.

## User Manual References

Not applicable.

# Lockout

## Description

If one party in a conversation goes on-hook, they both are disconnected from the speech path automatically. A reorder tone is sent to the off-hook party before it is disconnected. No operation is necessary.

## Conditions

- If nothing is dialled within a certain period of time after the other party goes on-hook, a reorder tone is sent to the extension user and then is disconnected from the speech path.

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

Not applicable.

# Manager Extension

## Description

One extension in each tenant can be assigned as the Manager Extension. This extension can perform the following Manager services:

**<System / Tenant>**

- BGM External Turn on / off
- Local Alarm Indication
- OGM (outgoing messages) record / play
- Trunk Busy-out set
- Trunk Route Control

**<To other extensions>**

- Caller ID Log Lock clear
- DND remote set / cancel
- Live Call Screening Password clear
- Remote FWD (Call Forwarding) Cancel - Once
- Remote Station Lock set / cancel
- Timed Reminder (Wake-up Call), Remote set / cancel / confirm

## Conditions

- **Operator Extensions**  
Operator extensions can also perform the above mentioned Manager Service functions except "Local Alarm Indication."
- **Tenant Service**  
If Tenant Service is employed, the Manager extension can be assigned to each tenant individually.

## Programming Guide References

- 2.2 Tenant
  - Manager Extension DN

## Features Guide References

None

## User Manual References

- 3 Operator / Manager Operation

# Mixed Station Capabilities

## Description

The KX-TD500 system supports a wide range of telephone sets as follows:

- **Digital Proprietary Telephones (DPTs)**
- **Analogue Proprietary Telephones (APTs)**
- **Single Line Rotary Telephones — Dial Pulse Signalling**
- **Single Line Touch Tone Telephones — Tone Dialling**

The super hybrid method used in this system allows any telephone to be connected to an extension port without a special adaptor.

### Extension cards and compatible terminals

↓ Card / Terminal →	DSS Console	Proprietary Telephone		SLT
		DPT	APT	
HLC (KX-T96170)	✓		✓	✓
PLC (KX-T96172)	✓		✓	
SLC (KX-T96174)				✓
SLC-M (KX-T96175)				✓
DHLC (KX-TD50170)	✓	✓	✓	✓
DLC (KX-TD50172)	✓	✓		
ESLC (KX-TD50175)				✓

" ✓ " indicates that the extension card is available for the terminal.

## Conditions

- If a telephone is replaced by another one, the stored data (such as feature button storage) is held for the new one.

## Installation Manual References

- 2.4 Extension Cards

## Programming Guide References

System programming is not required.

## **Features Guide References**

None

## **User Manual References**

Not applicable.

# Music on Hold

## Description

The system provides "Music on Hold" to callers on hold, if available.

## Conditions

- To utilise "Music on Hold", either "Internal Music Source" (Provided on the TSW card) or "External Music Source" (user-supplied) is required.
- Operations such as Call Hold, Exclusive Call Hold or Consultation Hold generates Music on Hold.
- **Music on Hold or Ringback tone**  
It is system programmable whether to send ringback tone or "Music on Hold" to the caller while his / her call is being transferred.  
To send "Music on Hold" to the caller, the following optional equipment and System Programming are required:
  - Connect External Music Source, such as a radio, to the system (Section 2.8.3 Music Source (External / Internal) in the Installation Manual).
  - Select 'MUS1' or 'MUS2' in "Music on Hold" menu ("System - Tenant").
  - Select 'Music on Hold' in "(1) Sound source during transfer" menu (Section 2.8 System Option in the Programming Guide).
- **Hardware Requirements**  
It is necessary to connect a user-supplied external music source such as a radio to the system. Up to two external music sources can be connected to the system.
- The music source is used for Music on Hold and / or BGM. If external music sources are in use, you can select a music source for each usage.

## Installation Manual References

- 2.8.3 Music Source (External / Internal)

## Programming Guide References

- 2.2 Tenant
  - Music on Hold Source
  - BGM Source
- 2.8 System Option
  - Sound source during transfer

## Features Guide References

- 1.15 Proprietary Telephone Features
  - Background Music (BGM)



## User Manual References

Not applicable.

# Night Service

## Description

The system supports both Night and Day modes of operation in a different arrangement. The system operation for originating and receiving calls can be different for day and night modes. The system operation for restricting toll calls can be arranged separately to prevent unauthorised toll calls at night.

### **Switching of the Day / Night Mode**

Day / Night mode can be switched either automatically at a pre-assigned time or manually, by the extension allowed by COS (Class of Service) programming, at any time desired within each tenant individually.

#### **Automatic Night Service:**

If automatic switching mode is selected, the system will automatically switch the Day / Night mode at the programmed time each day. The starting time of the Day / Night mode can be set twice for each day.

#### **Manual Night Service:**

If manual switching mode is selected, **the extension allowed by COS (Class of Service) programming** can switch the Day / Night mode by dialling the feature number or pressing the Day / Night button.

## Conditions

- **Class of Service**  
Class of Service programming determines the extensions that can perform this feature.
- **Day / Night button**  
Day / Night button can be assigned to a flexible CO button by Station, User or System Programming.
- The following programming items may be assigned in a different way between day mode and night mode:
  - Trunk Connection Assignment - Outgoing Destination
  - Intercept Destination
  - Toll Restriction Level
  - Doorphone Destination
  - Overflow Destination

## Programming Guide References

- 2.2 Tenant
  - DAY / NIGHT Switching Mode
- 2.3 Numbering Plan
  - Night Mode Set / Cancel
- 2.4 Class of Service (COS)
  - Switching Day / Night Mode
  - TRS Level – Day / Night
  - Trunk Group Setting
- 3.2 Trunk Group
  - Intercept Destination – Day / Night
- 3.3 Extension Group
  - [Overflow Setting] Destination – Day / Night
- 4.2 Trunk Line
  - Destination – Day / Night
- 4.3 Extension Line
  - CO Key
- 4.5 Doorphone
  - Destination – Day / Night
- 9.2 Number Transformation

## Features Guide References

None

## User Manual References

- 2.11.4 Switching the Day / Night Service
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Off Premise Extension (OPX)

## Description

SLTs installed off the premise can be operated via a public or private network in the same way as extensions on the premise. These telephones are called Off Premise Extensions (OPX).

## Conditions

- **Hardware Requirements**  
OPX card (KX-T96185) or T1 Digital Trunk card (KX-T96187), and OPX Power Unit (KX-T96186) are required.
- **Ring Tone Pattern**  
When an incoming calls is placed to an OPX, the ringing tone is same as the CO line incoming patterns.
- **Call Restriction**  
Calls between OPX and Doorphone are restricted. That is, both "Calling from OPX to Doorphone" and "Calling from Doorphone to OPX" are not possible.

## Programming Guide References

- 1.6 T1 Port Assignment
  - Channel Type
  - DN
- 4.3 Extension Line

## Features Guide References

None

## User Manual References

Not applicable.

# Outgoing Message (OGM)

## Description

Allows the Manager or an Operator to record and playback Outgoing Messages. The following three types of Outgoing Messages can be recorded.

**DISA message:**

This message is played when an outside caller accesses the system via DISA line.

**Timed Reminder (wake-up) message:**

This message is used in Timed Reminder. When answering the Timed Reminder alarm (often used as a wake-up call), the extension user will hear this message.

**UCD (Uniform Call Distribution) message:**

This message is played to the outside callers in conjunction with the UCD feature.

## Conditions

- **Hardware Requirements**  
A DISA card (KX-T96191) is required to record an OGM.  
Up to eight DISA cards can be installed in the system.
- One OGM message can be recorded on a DISA card.
- **OGM Group**  
Recording of OGM is performed per OGM Group (1-8) which consists of one or more DISA cards. Up to eight OGM Groups are available in the system.
- **OGM Type**  
OGM Type is decided on an OGM Group basis.
- **Tenant Service**  
If Tenant Service is employed, the affiliation of OGM Group should be decided by System Programming.

## Installation Manual References

- 2.6.1 DISA Card (KX-T96191)

## Programming Guide References

- 2.2 Tenant
  - Manager Extension DN
- 2.3 Numbering Plan
  - OGM Playback / Record
- 3.6 OGM Group
  - FDN
  - Tenant No.
  - OGM Type

## Features Guide References

### 1.3 System Features

- Extension Group – Uniform Call Distribution (UCD) Group
- Outgoing Message (OGM) Group

### 1.5 Attended Features

- Direct Inward System Access (DISA)

### 1.8 Ringing Features

- Timed Reminder (Wake-Up Call)

## User Manual References

- 3.2.2 Recording Outgoing Messages

# Outgoing Message (OGM) Group

## Description

OGM resources on the DISA card can be grouped together as an OGM Group. Up to eight OGM Groups can be created in the system.

## Conditions

- **Tenant Service**  
If Tenant Service is employed, the affiliation of OGM Group should be decided by System Programming.

## Installation Manual References

- 2.6.1 DISA Card (KX-T96191)

## Programming Guide References

- 1.8 DISA Port Assignment
- 3.6 OGM Group
  - FDN
  - Tenant No.
  - OGM Type
  - Security Mode
  - DISA built-in Automated Attendant Tables

## Features Guide References

- 1.3 System Features
  - Outgoing Message (OGM)

## User Manual References

Not applicable.

# Paralleled Telephone

## Description

Any PT can be connected in parallel with an SLT.

The following two combinations of telephones are available:

- a) **APT + SLT** (an Analogue Proprietary Telephone and a Single Line Telephone / a single extension port)
- b) **DPT + SLT** (a Digital Proprietary Telephone and a Single Line Telephone / a single extension port)

When a parallel connection is made, an extension user can make and answer a call using either one of two telephones.

## Conditions

- To enable Paralleled Telephone mode, set "Parallel / XDP" to "Parallel" in the Extension Port Assignment screen (See "Section 1.4 Extension Port Assignment" of the Programming Guide).
- The corresponding PT user can activate or deactivate the paralleled SLT ringing by dialling the feature number for "Parallel telephone mode."
- Paralleled Telephones (APT+SLT / DPT+SLT) share the same extension number.
- **Extra Device Port (XDP)**  
If EXtra Device Port feature (DPT+SLT) is activated, each telephone has its own unique extension number and acts as completely different extensions.
- The PT can be used to perform normal operations whether or not the SLT is enabled.
- In the DPT + SLT combination, if one telephone goes off-hook while the other telephone is on a call, the call is switched to the former.
- In the APT + SLT combination, if one telephone goes off-hook while the other telephone is on a call, a 3-party call is established. If one user goes on-hook, the other user continues the call.
- **When receiving a call;**  
The SLT is activated; Both the PT and the SLT will ring except when the PT is in Hands-free Answerback mode or Voice Alerting mode.  
The SLT is deactivated; PT rings but the SLT does not ring.
- When the SLT is in operation, the display and LED indicator on the paired PT will work in the same way as if the PT is in operation.
- If APT + SLT are used, the extension user cannot originate a call from the SLT if the APT is:
  - playing BGM
  - in programming mode
  - receiving a paging announcement over the built-in speaker
- If DPT + SLT are used, the extension user cannot originate a call from the SLT if the DPT is:
  - in programming mode
- **Call Waiting Tone**  
Call Waiting tone rings at PT only.



## **Installation Manual References**

- 2.4.12 Parallel Connection of the Extensions

## **Programming Guide References**

- 1.4 Extension Port Assignment
  - Parallel / XDP (DHLC card)
  - Parallel / XDP (HLC card)

## **Features Guide References**

- 1.1 System Expansion
  - EXtra Device Port (XDP)

## **User Manual References**

- 2.7.13 Setting the Parallel Connected Telephone Ringer (Parallelled Telephone Connection)

# Phantom Extension

## Description

This allows the system to route the calls to a phantom extension. The call to a phantom extension arrives at the extension who has the corresponding Phantom button. One phantom extension number can be assigned to multiple extensions so that the caller can ring a group of extensions simultaneously.

- The lighting patterns and status of the Phantom button are shown below.

Lighting pattern	Phantom Extension Status
Off	Idle
Red on	Calling a phantom extension
Green rapid flash	Incoming call

## Conditions

- A phantom button can be assigned to a flexible CO button by Station, User or System Programming.
- A phantom extension number must be assigned by System Programming before assigning the Phantom button.
- A maximum of 448 phantom extension numbers can be assigned. Each number has 3 to 4 digits, consisting of numbers **0 through 9**.
- Phantom extension number can be assigned to both PTs and SLTs.
- Types of calls whose destination can be the phantom extension are:  
Outside calls — DIL 1:1; DISA; IRNA; UCD-Overflow; TIE; DID; DDI  
Intercom calls — Extension; Transfer
- The extension user can call the phantom extension by pressing the Phantom button or by dialling the phantom extension number. If several extensions have the same phantom extension number, they will ring simultaneously.
- The phantom extension number cannot be used for feature settings such as Call Forwarding.
- Phantom Extension ringing is programmable.

## Programming Guide References

- 4.3 Extension Line
  - CO Key
- 5.3 Phantom Extension

## Features Guide References

None

## User Manual References

- 2.2.2 Easy Dialling
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Released Link Operation

## Description

When Released Link Operation is enabled, an extension user will be automatically released from a call (extension, outside) after transferring it to the destination, if the destination extension is idle. This feature simplifies the transfer operation by eliminating the need for going on-hook or pressing the RELEASE button after transferring the call.

This feature is convenient for extension users, such as Operators, who handle a large volume of calls.

## Conditions

- **Class of Service**  
Class of Service programming determines the extension that can perform this feature.
- Released Link Operation functions when transferring a call to the ordinary extensions or floating extensions (extension group, phantom extensions).
- If the destination party is busy, Camp-on Transfer is set by going on-hook.
- The SLT extension user cannot establish a conference call, if "Released Link Operation" is enabled by System Programming.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Released Link Operation

## Features Guide References

None

## User Manual References

- 2.4.3 Transferring a Call

# Remote Station Feature Control

## Description

Allows both the Manager and the Operators to set and cancel the following features for other extensions.

### **Remote Station Lock**

Used to lock other extensions so that no one can make an outside call or an intercom call (except an operator call) from those extensions.

### **Caller ID Log Lock Clear**

Used to clear the Caller ID Log Lock Code set by an extension user.

This is convenient when an extension user cannot remember his or her own lock code.

### **LCS (Live Call Screening) Password Clear**

Used to clear the password for LCS feature set by an extension user.

This is convenient when an extension user cannot remember his or her own password.

### **Remote DND (Do Not Disturb)**

Used to set or cancel Do Not Disturb feature for other extensions.

### **Timed Reminder, Remote**

Used to set, cancel and confirm the Timed Reminder feature for other extensions.

### **Remote FWD (Call Forwarding) Cancel-Once**

Used to cancel the Call Forwarding feature set on an extension temporarily.

## Conditions

None

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.3 System Features
  - Manager Extension
- 1.5 Attended Features
  - Caller ID Service
- 1.6 Originating Features
  - Electronic Station Lockout
- 1.8 Ringing Features
  - Do Not Disturb (DND)
  - Timed Reminder, Remote (Wake-Up Call)
- 1.9 Answering Features
  - Live Call Screening (LCS)

### 1.11 Transferring Features

- CALL FORWARDING – A SUMMARY

## User Manual References

- 3.1.1 Setting the Alarm for Other Extensions (Remote Timed Reminder)
- 3.1.2 Setting or Cancelling the DND Feature to Other Extensions (Remote DND Control)
- 3.1.3 Calling the Extension that has set Call Forwarding (Remote FWD Cancel-Once)
- 3.1.4 Changing the Settings (Station Programming)

# Remote Station Lock Control

## Description

Allows the Manager and the Operators to lock other extensions remotely, that is, from their own extensions.

Locked extensions cannot be used for making calls, either outside calls or intercom calls (except calls to the Operators and the emergency calls) depending on the setting.

## Conditions

- **Electronic Station Lockout Override**  
"Remote Station Lock Control" overrides "Electronic Station Lockout." If Station Lockout has already been set by the extension user and Remote Station Lock is set by the Manager or an Operator, cancelling the lock is only possible by the Manager or an Operator.

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.3 System Features
  - Manager Extension
- 1.6 Originating Features
  - Electronic Station Lockout

## User Manual References

- 3.1.4 Changing the Settings (Station Programming)

# Secret Dialling

## Description

Used to conceal all or part of a registered telephone number that normally appears on the display.

Secret Dialling applies to the following features:

- One-Touch Dialling
- System Speed Dialling
- Station Speed Dialling (Special display features)

When a display PT user makes a call using a telephone number with Secret Dialling, all or part of the number does not appear on the display.

## Conditions

- CO line access code must be placed before placing 's' or '['.
- One or more parts of a telephone number can be concealed.
- The concealed part will be printed out by SMDR.

## Programming Guide References

- 5.2 System Speed Dialling

## Features Guide References

### 1.7 Dialling Features

- One-Touch Dialling
- System Speed Dialling

### 1.17 Display Features

- Special Display Features – Call Directory – Station Speed Dialling

## User Manual References

- 4.1.2 Customising the Buttons



# Station Message Detail Recording (SMDR)

## Description

Station Message Detail Recording (SMDR) automatically records detailed call information for CO calls. A printer connected to SIO #2 port of RS-232C on the basic shelf can be used to print incoming and outgoing CO calls. To print the call records, use the programme "SMDR," which allows you to print out the following records:

- Record all outgoing CO calls or outgoing toll calls.
- Record all incoming CO calls.

### Examples of a printed call record:

#### <Pattern A> (default)

Date	Time	T	Ext	CO	Dial Number	Ring	Duration	Acct code	CC
02/02/99	03:01PM	1	E1001	T10101	1234567890123456789		00:00'14	1234567890	
02/02/99	03:13PM	1	E1001	T10101	<INCOMING>				RC
02/02/99	03:13PM	1	E1001	T10101	<INCOMING>	0'12			AN
02/02/99	03:13PM	1	E1001	T10101	<INCOMING>	0'12	00:00'11		
•	•	•	•	•	•	•	•	•	•
•	•	•	•	•	•	•	•	•	•
•	•	•	•	•	•	•	•	•	•
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(10)	(11)

The SMDR is printed with the above format when "Type-A" is selected as Output Type by System Programming.

[Upper limit of digits / characters to be printed]

- Dial Number (6)— Outgoing Call: 19 digits
- Dial Number (6)— Caller ID Name: 16 characters
- Dial Number (6)— Caller ID Dial: 16 digits
- Ring (7): 9'59
- Acct code (10): 10 digits

**<Pattern B>**

Date	Time	T	Ext	CO	Dial Number		Duration	Acct code	CC
02/15/99	06:42PM	1	E1009	T10801	123456789012345678901234		00:01'24	1234567890	
02/16/99	01:29PM	1	E1001	T10101	<INCOMING>				RC
02/16/99	01:29PM	1	E1001	T10101	<INCOMING>				AN
02/16/99	01:29PM	1	E1001	T10101	<INCOMING>		00:00'10		
.	.	.	.	.	.	.	.	.	.
.	.	.	.	.	.	.	.	.	.
.	.	.	.	.	.	.	.	.	.
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(10)	(11)

The SMDR is printed with the above format when "Type-B" is selected as Output Type by System Programming.

[Upper limit of digits / characters to be printed]

- Dial Number (6)— Outgoing Call: 24 digits
- Dial Number (6)— Caller ID Name: 16 characters
- Dial Number (6)— Caller ID Dial: 21 digits
- Acct code (10): 10 digits

**<Pattern C>**

Date	Time	T	Ext	CO	Dial Number		Duration	Cost:DM	Acct code	CC
02/02/99	03:01PM	1	E1001	T10801	1234567890123456789		00:01'14	12345678	1234567890	
02/02/99	03:13PM	1	E1001	T10101	<INCOMING>					RC
02/02/99	03:13PM	1	E1001	T10101	<INCOMING>					AN
02/02/99	03:13PM	1	E1001	T10101	<INCOMING>		00:00'11			
.	.	.	.	.	.	.	.	.	.	.
.	.	.	.	.	.	.	.	.	.	.
.	.	.	.	.	.	.	.	.	.	.
(1)	(2)	(3)	(4)	(5)	(6)	(8)	(9)	(10)	(11)	

The SMDR is printed with the above format when "Type-C" is selected as Output Type by System Programming.

[Upper limit of digits / characters to be printed]

- Dial Number (6)— Outgoing Call: 14 digits
- Dial Number (6)— Caller ID Name: 14 characters
- Dial Number (6)— Caller ID Dial: 14 digits
- Acct code (10): 10 digits

## &lt;Pattern D&gt;

Date	Time	T	Ext	CO	Dial Number	Ring	Duration	Cost:DM	Acct code	CC
02/02/99	03:01PM	1	E1001	T10101	1234567890123456789		00:00'14	12345678	1234567890	
02/02/99	03:13PM	1	E1001	T10101	<INCOMING>					RC
02/02/99	03:13PM	1	E1001	T10101	<INCOMING>	0'12				AN
02/02/99	03:13PM	1	E1001	T10101	<INCOMING>	0'12	00:00'11			
•	•	•	•	•	•	•	•	•	•	•
•	•	•	•	•	•	•	•	•	•	•
•	•	•	•	•	•	•	•	•	•	•
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)	(10)	(11)

The SMDR is printed with the above format when "Type-D" is selected as Output Type by System Programming.

[Upper limit of digits / characters to be printed]

- Dial Number (6)— Outgoing Call: 29 digits
- Dial Number (6)— Caller ID Name: 16 characters
- Dial Number (6)— Caller ID Dial: 29 digits
- Ring (7): 9'59
- Acct code (10): 10 digits

**Example of SMDR print out format:****Explanation**

1. Date : shows the date of the call in Month / Day / Year.
2. Time : shows the end time of a call as Hour / Minute / AM or PM.
3. T : Tenant No. (1-8)
4. Ext : shows the extension number, floating number, etc., which was engaged in the call.
5. CO : shows the CO line number used for making or receiving the call.
6. Dial Number
 

**Outgoing call:** shows the other party's telephone number. Valid digits are 0 through 9, \*, #, P (if PAUSE button is pressed), "=" (if a host PBX access code is entered) or "-" (if registered in a memory dialling number.)

**Received call:** shows <INCOMING>. If a Caller ID is assigned to the other party, it shows <I>, number or name.
7. Ring : shows the ring duration of the incoming call in Minutes / Seconds.
8. Duration : shows the duration of the call in Hours / Minutes / Seconds.
9. Cost: shows the telephone charge information with "in Meter" or "in Charge" depending on the System Programming. If "in Meter" is specified by System Programming, charge currency is not printed.
10. Acct code (Account Code) : shows the account code appended to the call.

**11.CC** (Condition Code): shows call handling type with the following codes:

**TR:** Transfer  
**FW:** Call Forwarding to Trunk  
**D0:** Non Security Trunk Access by a DISA caller  
**NN:** DISA User Code No. (NN=01-32)  
**RM:** Remote access to a modem  
**RC:** Received an incoming call  
**AN:** Answered an incoming call  
**NA:** Not answered an incoming call  
**OR:** COS Override  
**T0:** TIE line access

### Conditions

- When programmed for outgoing toll calls only, printing occurs only for calls which start with the numbers stored in any Denied Code Table from levels 2 to 6. In the ARS mode, the phone number modified by the ARS procedure will be printed out by SMDR whether it is registered in the Denied Code Table or not.
- The KX-TD500 System can store up to 200 call information data. If more than 200 calls are originated or received, the oldest data is overwritten by the newest one.
- It is possible to select whether SMDR prints out the caller's number or caller's name by System Programming.
- It is possible to select whether or not the SMDR prints out received incoming calls (RC) and answered incoming calls (AN) information by System Programming.
- SMDR data is not deleted when you reset the system.
- If FLASH is manually sent out during a call, the call record is printed and a new record is started.

### Installation Manual References

- 2.8.4 Personal Computer/Printer

## Programming Guide References

- 2.5 System Timer
  - Call Duration Count Start Time
- 5.15 Charge
  - Charge by SMDR
- 10.4 SMDR
  - SMDR Connection
  - Output Type
  - Print out Error Information
  - [Format] Page Length
  - [Format] Skip Perforation
  - [Duration Log] Outgoing Calls
  - [Duration Log] Incoming Calls
  - Priority of Caller ID information
  - Print out DDI / DID subscriber number
  - Print out Incoming Call Start "RC" and Incoming Call Answer "AN" information
  - Print out No Answer of Timed Reminder information
  - Print out Account Code
  - Print out LOGIN / LOGOUT
- 10.6 System Parameters
  - [Serial Interface Port] SMDR – Parity
  - [Serial Interface Port] SMDR – NL Code
  - [Serial Interface Port] SMDR – Word Length
  - [Serial Interface Port] SMDR – Stop Bit
  - [Serial Interface Port] SMDR – Baud Rate
- 10.7 System Time

## Features Guide References

None

## User Manual References

Not applicable.

# System Data Default Set

## Description

This system permits re-initialisation of system-programmed data. Starting up the KX-TD500 system with default values can be done using the Operation Switch (MODE) on the CPU card (see "CPU Rotary-Switch Features" in the Installation Manual).

## Conditions

- The default setting for each programming item is listed in "Section 13 Default Values" in the Programming Guide.

## Installation Manual References

- 2.10.2 CPU Rotary-Switch Features

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

Not applicable.

# T1 Carrier

## Description

The T1 line is at the bottom of the digital transmission hierarchy. A T1 line carries 1.544 Mbps of data (which can be voice or anything else). The T1 line contains 24 voice channels. Voice is digitized by Pulse Code Modulation.

## Conditions

- **Hardware Requirements**

T1 Digital Trunk card (KX-T96187) and user-supplied CSU (Channel Service Unit) are required to utilise T1 carrier with the KX-TD500 System.

- **Trunk Interface**

This card supports five different trunk interfaces to provide desired connection at minimum expense. One of the following five trunk types can be assigned to one of 24 channels of T1 card individually according to tariffs and customer needs.

LCOT, GCOT, DID, OPX, TIE

- Up to eight T1 cards (192 ports) can be installed in the system under the following conditions. One T1 card occupies 24 trunk ports.

HLC+PLC+SLC+MSLC+ESLC+DLC+ DHLC+OPX+DID+LCOT+GCOT+T1	512 ports / system
HLC+PLC+SLC+MSLC+ESLC+DLC+ DHLC+OPX+DID+LCOT+GCOT+T1	192 ports / basic shelf
HLC+PLC+SLC+MSLC+ESLC+DLC+ DHLC+OPX+DID+LCOT+GCOT+T1	224 ports / expansion shelf
DID+LCOT+GCOT+T1	192 ports / system
T1	72 ports (3 cards) / shelf

- The T1 card needs to be installed to free slot no.1, 5 or 9.
- Physical port number for each T1 trunk channel is as follows:

Slot No.	Channel	Port No.
1	1-24ch	X0101-X0124
5	1-24ch	X0501-X0524
9	1-24ch	X0901-X0924

X: Shelf No.(1=Basic, 2=Expansion 1, 3=Expansion 2)

- Extension Number Assignment is required when a channel of T1 card is assigned as "OPX."

- Select the external clock mode, if your system is interfaced by T1 interface with another exchange.

### **Programming Guide References**

- 1.2 Slot Assignment
- 1.6 T1 Port Assignment

### **Features Guide References**

None

### **User Manual References**

Not applicable.



# Tenant Service

## Description

The KX–TD500 System can be shared with up to **eight tenants**. When tenant service is utilised, each tenant can use the system resource differently and independently from other tenants. This enables the configuration of more than two systems which, in each case, are suited to different tenants.

Some system resources can be used in common and some can be divided among tenants.

### Common Resources:

1. Absent Messages
2. AGC (Automatic Gain Control)
3. ARS Table
4. COS (Class of Service)
5. DDI / DID Number Transformation
6. Emergency Number
7. Music Sources (MUS1, 2 on TSW card)
8. Numbering Plan
9. Phantom Extension
10. Quick Dialling
11. Remote Administration
12. SMDR (Station Message Detail Recording)
13. System Administration Terminal
14. Toll Restriction Tables

### Resources which can be divided:

1. Account Code
2. Call Park Area
3. Caller ID Registration Table
4. Day / Night Mode Switching Time
5. Doorphone
6. Extension Group
7. External Pager
8. OGM (Outgoing Message) Group
9. Station Paging Group
10. System Speed Dialling
11. Trunk Group

### Conditions

- The following features do not work between extensions if they do not belong to the same tenant.
  - CALL FORWARDING – A SUMMARY
  - Executive Busy Override — Barge-in
  - Executive Busy Override — Extension
  - Message Waiting
  - Privacy Release

#### **Note**

These restrictions apply even if "Inter-tenant Calling" is enabled between two tenants.

### Programming Guide References

- 2.2 Tenant
- 3.2 Trunk Group
  - Tenant No.
- 3.3 Extension Group
  - Tenant No.
- 3.4 Paging Group
- 3.6 OGM Group
  - Tenant No.
- 4.5 Doorphone
  - Tenant No.
- 4.6 External Paging
  - Tenant No.
- 5.2 System Speed Dialling
  - Tenant No.
- 5.6 Account Code
  - Tenant No.
- 5.13 Caller ID Registration
  - Tenant No.

### Features Guide References

None

### User Manual References

Not applicable.

# Time-Out, Variable

## Description

Provides timers to control various features or functions.  
The following timers are programmable:

System Data	Range
Hold Recall Time	0-240 s
Transfer Recall Time	0-48 rings
Pickup Dial Waiting Time	1-5 s
Call Duration Count Start Time	0-60 s
First Digit Time	5-120 s
Inter-digit Time	1-30 s
Intercept Time	3-48 rings
Call Forwarding - No Answer Time	1-12 rings
Extension-to-CO Line Call Duration Time	1-64 min
CO-to-CO Line Call Duration Time	1-64 min
Automatic Redial Interval Time	30-1200 s
Automatic Redial Repeat Times	0-30 times
Door Opener Timer	0-10 s
Timed Reminder Ringing Time	30-240 s
Call Parking Recall Time	0-1800 s
TIE Inter-digit Time	3-30 s
DISA Prolong Time	0-7 min
DISA Delayed Answer Time	0-6 rings
DISA Automated Attendant Time	1-5 s
DISA IRNA Time	5-240 s
Intercept Time after OGM	0 / 5 s

Trunk Group Data	Range
Disconnecting Time	0.5 / 1.5 / 2.0 / 4.0 / 12.0 s
Pause Time	1.5 / 2.5 / 3.5 / 4.5 s
Flash Time	None / 80 / 300 / 600 / 900 / 1200 ms

Trunk Group Data	Range
Pause Time before Flash Signal	None / 512 / 1024 / 1536 / 2048 ms

Extension Group Data	Range
Overflow Setting - Timer (for Operator)	None / 5-180 s

DIL 1:N Group Data	Range
Ringling Type	Immediate / 1-ring Delay / 3-ring Delay / 6-ring Delay / No Ring

Trunk Data	Range
CPC Signal Detection Time (Outgoing / Incoming) - Type A (for ELCOT / GCOT / LCOT / PCOT / RCOT / T1[LCO] / T1[GCO])	None / 6.5 / (2-75) × 8 ms
CPC Signal Detection Time (Outgoing / Incoming) - Type B (for DID-2W, DID-MFC, E1[DR2])	None / (1-15) × 80 ms
Wink Signal Time-out	None / 1 - 127 × 64 ms
Answer Wait Timer	None / 1 / 2 / 3 / 4 min

Extension Data (Flexible CO Key - PDN / SDN)	Range
Ringling Type	Immediate / 1-ring Delay / 3-ring Delay / 6-ring Delay / No Ring

## Conditions

None

## Programming Guide References

- 2.5 System Timer
- 3.2 Trunk Group
- 4.2 Trunk Line
- 4.3 Extension Line

## **Features Guide References**

None

## **User Manual References**

Not applicable.

# Trunk Busy-out

## Description

Allows the Manager and an Operator to busy out a CO line to prevent extension users from accessing it.

### [The details of Trunk Busy-out feature]

There are the following two types of trunk port relay status which is set to Trunk Busy-out.

- a) Busy (Loop Relay On) : making the line busy by hardware
- b) Idle (Loop Relay Off) : making the line busy by software

The Central Office recognizes a trunk line as shown in Table 1.

The actual behavior of the PBX is as follows:

#### 1. Idle status

- a) When the PBX user makes a call:  
The trunk line is recognised as busy and making a CO call is disabled.
- b) When the outside caller makes a call and then the Central Office gives the incoming call to PBX:  
The Central Office recognizes the PBX as idle and the call is processed. (The outside caller hears ringback tone.) However, even though the PBX receives the bell signal from the Central Office, the PBX ignores it.

#### 2. Busy status (the status of grabbing a CO line) / during a conversation

- a) When the PBX user makes a call:  
The trunk line is recognised as busy and making a CO call is disabled.
- b) When the outside caller makes a call and then the Central Office gives the incoming call to PBX:  
The Central Office recognizes the PBX as busy and the caller hears busy tone.

#### Notes

- The default of each card is "Idle." If it were "busy," there is a possibility that the Central Office will mistakenly believe that there is something wrong with the trunk line.
- T1 standard does not have Busy-out Status (Block).  
Therefore, the default of all interfaces (Loop Start CO / Ground Start CO / DID / TIE) are regarded as idle status.

---

**The specification of Trunk Busy-out On**

Card Type	The state of Trunk Busy-out set to "On"			Note
LCOT / RCOT / PCOT	Idle status (Default) Loop OFF	Busy status (the status of grabbing a CO line) Loop ON		
ELCOT	Idle status (Default) Loop OFF	Busy status (the status of grabbing a CO line) Loop ON		
GCOT	Idle status (Default) Loop OFF + Not connected to Ring FG	Busy status (the status of grabbing a CO line) Loop OFF + Connected to Ring FG	During a conversation Loop ON + Not connected to Ring FG	The busy status depends on the Central Office connected to the PBX.
DID	Idle status (Fixed)			The DID card is a card for only incoming call. It is assignable for Trunk Busy-out, but DID call comes in on even after the setup because the DC power (On / Off) to the Central Office from a DID card cannot be controlled.
DID-2W / DID-MFC	Busy status (the status of grabbing a CO line) (Fixed)			
E&M	Busy status (the status of grabbing a CO line) (Fixed)			The way of making the line busy by software is not available for this version.

---

**The specification of Trunk Busy-out On**

Card Type		The state of Trunk Busy-out set to "On"			Note
T1	LCO	Idle status (Fixed)			
	GCO	Idle status (Fixed)			
	TIE				<p>The behavior depends on the Start Signal Type. (System Programming)</p> <ol style="list-style-type: none"> <li>1. Immediate: the same as the usual idle status.</li> <li>2. Wink: When Wink Mode is selected by the PBX. When the Central Office processes an incoming call, it grabs a CO line to the PBX. But when the PBX has "busy-out" that trunk port, the PBX does not issue a wink signal. So the Central Office cannot complete the call. A reorder tone is returned to the caller. If the Central Office is a KX-TD500, the caller will see on his phone display, "CO Not Assigned."</li> </ol>
	DID	Idle status (Fixed)			



### The specification of Trunk Busy-out On

Card Type		The state of Trunk Busy-out set to "On"			Note
E1	E&M-C E&M-P				<p>The behavior depends on the Start Signal Type. (System Programming)</p> <ol style="list-style-type: none"> <li>1. Immediate: the same as the usual idle status.</li> <li>2. Wink: When Wink Mode is selected by the PBX. When the Central Office processes an incoming call, it grabs a CO line to the PBX. But when the PBX has "busy-out" that trunk port, the PBX does not issue a wink signal. So the Central Office cannot complete the call. A reorder tone is returned to the caller. If the Central Office is a KX-TD500, the caller will see on his phone display, "CO Not Assigned."</li> </ol>
	DR2				<p>When the Central Office processes an incoming call, it grabs a CO line to the PBX. But when the PBX has "busy-out" that trunk port, the PBX does not issue a wink signal. So the Central Office cannot complete the call. A reorder tone is returned to the caller. If the Central Office is a KX-TD500, the caller will see on his phone display, "CO Not Assigned."</p>

### Conditions

None

### Programming Guide References

- 2.3 Numbering Plan
  - Trunk Busy-out
- 2.8 System Option
  - ELCOT / LCOT Busy-out Loop Relay
  - GCOT Busy-out Loop Relay

### Features Guide References

None

## User Manual References

- 3.2.3 Trunk Busy-out Setting

# Trunk Group

## Description

All CO lines and TIE lines in the system can be grouped into up to 48 Trunk Groups. This allows extension users to call outside parties without designating a specific CO line, since a CO line is automatically selected from the designated Trunk Group. All CO lines belonging to a Trunk Group follow the assignment determined for that Trunk Group.

## Conditions

- Each CO line can only belong to one Trunk Group.
- **Line Hunting Order**  
An idle CO line in a trunk group is selected in one of the following three line hunting orders.
  - a) Normal (default)  
The system connects the user to an idle trunk line with the lowest trunk port physical number.
  - b) Reverse  
The system connects the user to an idle trunk line with the highest trunk port physical number.
  - c) Sequential  
To avoid repeated use of the same trunk line, rotation is performed in numerical order (from the lowest to the highest trunk port physical number). Busy lines are skipped, of course.
- **Tenant Service**  
If Tenant Service is employed, the affiliation of each trunk group is determined by System Programming.

## **Programming Guide References**

- 2.3 Numbering Plan
  - Trunk Group Access
- 2.4 Class of Service (COS)
  - Trunk Group Setting
- 2.7 Trunk to Trunk Restriction
- 3.2 Trunk Group
  - Tenant No.
  - Intercept Destination – Day / Night
  - Line Hunting Order
  - Disconnecting Time
  - Pause Time
  - Pause Time before Flash Signal
  - Flash Time
  - PBX Access Code
  - Cyclic Signal Detection
  - Continuous Signal Detection
  - Silence Detection

## **Features Guide References**

None

## **User Manual References**

Not applicable.

# Trunk Route Control

## Description

Allows the Manager and the Operators to make a call using a specific trunk.  
They can verify the status of the specified trunk.

## Conditions

- This feature does not override the Toll Restriction by COS or the Tenant Service.
- Redial does not work if a call has been made using this feature.

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

- 3.2.4 Trunk Route Control

## VPS INTEGRATION – A SUMMARY

### Description

The Voice Processing System (VPS) provides Automated Attendant and Voice Mail Services. The KX-TD500 System works well with all Panasonic KX-TVP series Voice Processing System (VPS) and it can be programmed to work with most other manufactures' VPSs that fully support Inband Integration.

However, since both the PBX and VPS are independent systems, "Integration" with the VPS is necessary to make the two systems work more closely.

Without integration, both systems will work separately without knowing the status of other system.

### How the KX-TD500 System communicate with VPS:

#### 1. Inband Integration

The KX-TD500 System sends the VPS several codes with DTMF tone via speech path. Available with not only Panasonic KX-TVP series VPSs but with most other manufactures' VPSs that fully support Inband Integration.

#### 2. DPT Integration

The KX-TD500 System sends the VPS the information and commands over the DPT data link. Available with Panasonic KX-TVP series VPS only.

### Available features:

#### 1. VM (Voice Mail) Service Integration

Allows the caller to leave a message in the mailbox of their destination party without knowing the mailbox number.


#### 2. AA (Automated Attendant) Service Integration

Used to improve the call handling performance of the VPS.

#### 3. Special features for DPT Integration (DPT Integration only)

- Auto Configuration
- Live Call Screening (LCS)
- Two-way Recording
- Two-way Transfer

**Outline sketch of VPS Integration**




**Conditions**

## VPS Integration – Automated Attendant (AA) Service Integration

### Description

This is one of the VPS Integration features.

With AA Service Integration, the KX-TD500 System transmits the call status code (busy, answered, ringing, disconnected, etc.) before sending the normal call progress tones to an AA extension. These codes enable the VPS to immediately recognize the current status of the call and improve its call handling performance.



Integration Code Table

Code (default)	Call State	Sent to the Voice Mail Port When
1	Ring-back Tone	The extension dialled is ringing.
2	Busy Tone	The extension dialled is busy.
3	Reorder Tone	An invalid extension number is dialled or the call is inadvertently connected to another Voice Mail port (also heard when no DTMF receiver is available to the Voice Mail extension).
4	DND	The extension dialled has set DND (Do Not Disturb) feature.
5	Answer	The extension dialled is answered.



Integration Code Table

Code (default)	Call State	Sent to the Voice Mail Port When
6	Forwarded to Voice Mail (Ringing)	The extension dialled is forwarded to Voice Mail and another Voice Mail port is able to answer. (This lets the first Voice Mail port, usually an Automated Attendant, send the call to the other Voice Mail port.)
7	Forwarded to Voice Mail (Busy)	The extension dialled is forwarded to Voice Mail and no other Voice Mail ports are available to accept the call. (This signals the Voice Mail port [usually Automated Attendant] to let the caller to leave a message.)
8	Forwarded to Ext.	The extension dialled is forwarded to another, non-Voice Mail extension.
9	Confirmation Tone	The Message Waiting Lamp On or Message Waiting Lamp Off code is dialled successfully.
#9	Disconnect	The caller disconnects. The central office must set a CPC signal to the PBX line for this signal to work for CO calls.

## Conditions

- **Start AA Service after FWD, IRNA of CO call**  
When an outside call is routed to a VM port by Call Forwarding or IRNA feature, AA Service can be activated instead of VM Service by System Programming.
- **Call from AA port to AA port**  
Prevents or allows a call originated by an AA port of VPS to another AA port.

## **Programming Guide References**

- 1.5 VPS (DPT) Port Assignment
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
- 4.3 Extension Line
  - Group No.
  - COS No. – Primary
  - Mailbox No.
- 5.11 VPS Integration
  - Start AA service after FWD, IRNA of CO call
  - Call from AA port to AA port

## **Features Guide References**

- 1.3 System Features
  - VPS INTEGRATION – A SUMMARY

## **User Manual References**

Not applicable.

## VPS Integration – DPT Integration<sup>\*1</sup>

### Description

This is one of the VPS Integration features. With DPT Integration, the KX-TD500 System sends the VPS the information and commands on the calling extension via DPT interfaced data link to help it work more effectively. This is available only with Panasonic KX-TVP series VPS.

Using the information and commands, the VPS can:

- a) identify the extension number of the caller
- b) know where the call is forwarded from and its line status
- c) recognize what the caller wants to do.

In addition to VM Service Integration and AA Service Integration, following special features are available only with DPT Integration.

- Auto Configuration
- Live Call Screening
- Two-Way Recording
- Two-Way Transfer

### Conditions

- A maximum of eight Panasonic Voice Processing Systems can be connected to the KX-TD500 system.
- To utilise this feature, DOHCA Card and DLC card (KX-TD50172) / DHLC card (KX-TD50170) are required.
- Only one Panasonic Voice Processing System can be connected to a DHLC / DLC card.
- The jack with the lowest physical number of the DHLC / DLC card must be connected to the VPS port with the lowest physical number.

---

<sup>\*1</sup> Available when the Digital Super Hybrid System is connected to a Digital Proprietary capable Panasonic Voice Processing System (one that supports Digital Proprietary Telephone integration; e.g. KX-TVP100).

## Programming Guide References

- 1.2 Slot Assignment
- 1.4 Extension Port Assignment
  - Card No.
  - Attribute
- 1.5 VPS (DPT) Port Assignment
  - TVP No.
  - VPS card
  - Type
  - Jack No.
  - Port No.
  - [Ext No.1] DN
  - [Ext No.1] Group No.
  - [Ext No.2] DN
  - [Ext No.2] Group No.
  - Status
- 3.2 Trunk Group
  - Intercept Destination – Day / Night
- 3.3 Extension Group
  - Group No.
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
- 4.2 Trunk Line
  - Incoming Type
  - Destination – Day / Night
- 4.3 Extension Line
  - Group No.
  - COS No. – Primary
  - Mailbox No.
- 5.11 VPS Integration
  - Turn off control of Message Waiting lamp
  - Extension's mailbox number

## Features Guide References

- 1.3 System Features
  - VPS INTEGRATION – A SUMMARY

## User Manual References

Not applicable.

# VPS Integration – Inband Integration

## Description

This is one of the VPS Integration features.

With Inband Integration, the KX-TD500 System sends the certain information to the VPS with DTMF tones. Inband Integration can be categorised into the following two types:

### 1. VM Service Integration

This integration works together with Call Forwarding and IRNA features. When activated, the KX-TD500 System sends the digits of the mailbox number of the called extension with DTMF tone to the VPS before connecting the caller.

These digits are commonly known as the Follow-on ID.

As a result, the caller who does not know the mailbox number of the corresponding extension can leave a message.

### 2. AA Service Integration

This integration works together with AA (Automated Attendant) service of the VPS. When activated, the KX-TD500 System informs the VPS of the state of the call (busy, answered, ringing, etc.) by sending a code with DTMF tone before sending the normal call progress tone (busy tone, ringback tone, etc.).

These codes enable the VPS to immediately recognize the current state of the call and improve its call handling performance.

## Conditions

- To utilise this feature, one of the following extension cards which support the SLT interface is required: SLC, SLC-M, ESLC, HLC, DHLIC.

## Programming Guide References

- 3.2 Trunk Group
  - Intercept Destination – Day / Night
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
- 4.2 Trunk Line
  - Incoming Type
  - Destination – Day / Night
- 4.3 Extension Line
  - Group No.
  - COS No. – Primary
  - Mailbox No.
- 5.11 VPS Integration

## Features Guide References

1.3 System Features

- VPS Integration – DPT Integration

## User Manual References

Not applicable.

# VPS Integration – Voice Mail (VM) Service Integration

## Description

This is one of the VPS Integration features.

With VM Service Integration, the KX-TD500 System connects the caller to a VM extension and sends the mailbox number (**Follow-on ID**) of the corresponding extension so that the caller can leave the message in the mailbox of the corresponding extension without knowing their mailbox number.


This feature applies to the following calls:


- **Call Forwarding – All Calls to VM extensions**
- **Call Forwarding – Busy to VM extensions**
- **Call Forwarding – No Answer to VM extensions**
- **Call Forwarding – Busy / No Answer to VM extensions**
- **Intercept Routing No Answer (IRNA) to a VM extension**
- **Transfer by VM Transfer button**
- **Notification by Message Waiting Lamp**

## System Explanation

### 1. Call Forwarding (All Calls, Busy, No Answer, Busy / No Answer) to a VM extension


If the extension user sets Call Forwarding to a VM extension, the call directed to that extension is forwarded to a VM extension with Follow-on ID of the extension user.





## 2. Intercept Routing No Answer (IRNA) to a VM extension


If an incoming CO call directed to a certain extension is not answered within a specified period of time (IRNA timer), the call is redirected to a VM extension with Follow-on ID of the corresponding extension.



## 3. Transfer by VM Transfer button

VM Transfer button is used to transfer a call to a VM extension with Follow-on ID of the corresponding extension so that the caller can leave the message in the mailbox of the destination extension user without knowing the mailbox number.





#### 4. Notification by Message Waiting Lamp

If the caller leaves a message in a mailbox, the VPS notifies the corresponding extension user that there is a message in their mailbox by turning on the Message Waiting Lamp on their extension.

The extension user can listen to the message simply by pressing the red lit Message Waiting Lamp

### Conditions

- **IRNA of DIL 1:N calls**

If a DIL 1:N call (an outside call which comes in on multiple extensions simultaneously) is not answered within a specified period of time, the system redirects the call to the pre-determined covering extension. If a VM extension is assigned as the covering extension, the VM port automatically starts the AA (Automated Attendant) service of the VPS.

- **Mailbox Number**

The extension user's extension number is assigned as the mailbox number by default (Section 4.3 Extension Line "Mailbox No."). Mailbox number can be changed by System Programming (Section 5.11 VPS Integration "Extension's mailbox number" in the Programming Guide).

- **Voice Mail Transfer**

Pressing the Voice Mail Transfer button and dialling the extension number allows the extension user to transfer the call to the corresponding mailbox. In this case, Follow On ID function is available.

- **Voice Mail Transfer button**

This button can be assigned to a flexible (CO, DSS) button by Station, User or System Programming.

- **Data Line Security**

The Voice Mail extension should be set to "Data Line Security" to achieve proper recording.

- **Busy Station Signalling**

The Voice Mail extension can execute the "Busy Station Signalling (BSS)" function to the busy extension.

- **Turn off Control of Message Waiting Lamp**  
Used to determine whether the System turns off the Message Waiting lamp or the VPS does when the VPS answers the callback from the message receiver.
- **Sending out Follow-on ID after FWD**  
Used to determine whether to send or not the Follow-on ID after an outside call is forwarded to a VM extension.
- **Sending out Follow-on ID after IRNA**  
Used to determine whether to send or not the Follow-on ID after an outside call is redirected to a VM extension by IRNA feature.

## Installation Manual References

- 2.4 Extension Cards

## Programming Guide References

- 2.3 Numbering Plan
  - Message Waiting Set / Cancel / Call Back
  - Call FWD - Do Not Disturb Set / Cancel
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
- 4.3 Extension Line
  - Group No.
  - COS No. – Primary
  - Mailbox No.
  - CO Key
  - [LCS Setting] Status
  - [LCS Setting] Operation Mode
  - [LCS Setting] Recording Mode
  - [LCS Setting] LCS Password
- 4.4 DSS Console
  - DSS Key
- 5.11 VPS Integration

## Features Guide References

- 1.3 System Features
  - Extension Group – Automated Attendant (AA) Group
  - Extension Group – Voice Mail (VM) Group

1.11 Transferring Features

- Call Forwarding – All Calls
- Call Forwarding – Busy
- Call Forwarding – Busy / No Answer
- Call Forwarding – No Answer
- Intercept Routing

## **User Manual References**

- 2.8.3 If a Voice Processing System is Connected
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Walking Station

## Description

Used to move an extension to a new location without re-programming. Extension data such as extension number, One-Touch dialling memory remain the same after the re-location of the extension.

## Conditions

- The telephone type (PT, SLT, OPX) must be the same at the source and destination.
- Walking Station is not available for the extensions connected to a DHLC card (KX-TD50170) or HLC card (KX-T96170).

## Programming Guide References

- 2.3 Numbering Plan
  - Walking Station

## Features Guide References

None

## User Manual References

- 2.9.1 Using the Same Extension Number and the Setting of Your Previous Extension (Walking Station)

# 1.4 Fault Recovery / Diagnostics

## Local Alarm

### Description

If a system error is detected during on-line communication mode, the system alerts the extension of the Manager by turning on the Alarm button on it. The Alarm button lights in red. An error message will be shown on the display PT of the Manager by pressing the red lit Alarm button.

If a major error occurs, minor errors will be neglected and only the first major error message will be displayed. The second error will be neglected, if the error priority is the same as the first one. Please refer to "Section 5 Troubleshooting" in the Installation Manual for further information on error messages.

**Error Indications List (Priority order)**

Indications	Description	Priority	Alarm LED
ERR CLCK IC	Calendar IC failure	1	A
ERR DC DOWN	DC power down	1	A
B/S FAN FLT!	Basic shelf fan alarm	1	B
E/S1 FAN FLT!	Expansion shelf 1 fan alarm	1	B
E/S2 FAN FLT!	Expansion shelf 2 fan alarm	1	B
B/S OVER HEAT!	Basic shelf heat alarm	1	B
E/S1 OVER HEAT!	Expansion shelf 1 heat alarm	1	B
E/S2 OVER HEAT!	Expansion shelf 2 heat alarm	1	B
ERR TSW DWN	TSW clock down	1	A
ERR BAT ALM	CPU RAM battery alarm	1	A
ERR AC DOWN	AC power down	2	A
ERR xyy CRD ERR	Option Card failure	2	A
ERR xyy DISCNCT	Card disconnect	2	A
ERR xyy DTR AIS	Digital trunk AIS reception	2	C
ERR xyy DTR FRM	Digital trunk frame failure	2	C
ERR xyy DTR RAI	Digital trunk RAI reception	2	C
ERR xyy DTR SYC	Digital trunk out of synchronisation	2	C
ERR xyy LPR RAM	Option Card RAM failure	2	A
ERR xyy LPR ROM	Option Card ROM failure	2	A

**Error Indications List (Priority order)**

<b>Indications</b>	<b>Description</b>	<b>Priority</b>	<b>Alarm LED</b>
ERR xyz MODEM	Modem failure	2	A
ERR xy OGM LOS	DISA OGM is lost	2	C
ERR xy OPX POW	OPX power failure	2	C
ERR SMDR	Printer is not connected	2	A

**[Legend]*****Indications***

- x : Shelf Number (1-3)  
 yy : Slot Number (01-14)  
 z : Error Number

***Priority***

- 1 : Major Error  
 2 : Minor Error

***Alarm LED***

(When a problem occurs)

- A : LED on PT / Top Shelf.....OFF → ON  
 The corresponding error indication will be displayed on the LCD by pressing the red lit Alarm button.
- B : LED on PT / Top Shelf.....OFF → ON  
 The corresponding error indication will be displayed on the LCD automatically.
- C : LED on PT / Top Shelf.....OFF (no change)  
 The contents of the error will be printed out by SMDR.

(When the problem is solved)

- A : LED on PT.....ON (no change)  
 LED on Top Shelf.....ON → OFF
- B : LED on PT / Top Shelf.....ON → OFF

**Conditions**

- **Alarm button assignment**

Alarm button can be assigned to a flexible CO button on PT by Station, User or System Programming.

- **Alarm LED indication**  
Major alarm (Priority 1) - Red moderate flash  
Minor alarm (Priority 2) - Red On
- If multiple errors occur at a time, only the error with highest priority will be displayed by pressing the red lit Alarm button.

## **Programming Guide References**

- 4.3 Extension Line
  - CO Key

## **Features Guide References**

- 1.4 Fault Recovery / Diagnostics
  - Local Alarm

## **User Manual References**

- 3.2.5 Displaying a System Error Indication (Local Alarm Indication) [Manager only]
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Power Failure Re-start

## Description

When turning back on the electricity, the system re-starts the stored data automatically. Before re-starting, the system records the error log if necessary.

## Conditions

- **Memory Protection**  
In the event of a power failure, system memory is protected by a factory-provided lithium battery.

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

Not applicable.



# Power Failure Transfer

## Description

Power Failure Transfer connects specific telephones (any SLT and a certain type of PT) to the pre-determined CO lines in the event of system power failure.

## Conditions

- Up to 192 pairs of extension / CO connection are available to maintain a conversation when power is restored or TSW recovery.
- Auxiliary Connection between the Trunk card and the Extension card should be done as per the System Programming so that conversation is maintained when the power is restored or TSW recovery.
- KX-TD500 System changes the current connection to the Auxiliary connection automatically when the power supply stops.
- **DC Power Source**  
If DC power is available by the backup batteries even if the AC power fails, the KX-TD500 System will not change the current connection to the Auxiliary connection.

## Installation Manual References

- 2.4 Extension Cards
- 2.5 Trunk Cards
- 2.9.1 Auxiliary Connection for Power Failure Transfer

## Programming Guide References

- 10.5 Power Failure Transfer

## Features Guide References

- 1.4 Fault Recovery / Diagnostics
  - Power Failure Re-start

## User Manual References

Not applicable.

# 1.5 Attended Features

## Caller ID Service

### Description

Provides the display PT user with a caller's information, such as name and telephone number, sent from the Central Office over the CO line assigned to receive Caller ID service calls.

### Conditions

- A special arrangement is required with the telephone company to utilise the Caller ID Service.
- **Hardware Requirements**  
To utilise this feature, the ELCOT card (KX-TD50180) and Caller ID card (KX-TD193) are required.
- **Caller ID Number and Name Registration**  
Up to 1000 entries of number and name for Caller ID Service can be programmed either by User or System Programming.
- **Tenant Service**  
If "Tenant Service" is employed, up to 2000 entries of number and name for Caller ID Service can be shared among each tenant under the condition of up to 1000 entries per tenant.
- If neither the telephone number nor the name is stored in the Caller ID Table, the number sent from Caller ID service is displayed.
- If the network provides a telephone number only, the system searches for the matching name for the number from the Caller ID Table and displays both of them.
- **Call Log, Incoming**  
A Caller ID information is recorded in the Call Log of a display DPT (KX-T7230, KX-T7235, KX-T7433, KX-T7436) either automatically or manually.
- A display PT with one-line readout (display APTs) will show either the name or the number at a time. To alternate the display, press the \* key.
- **Initial Display Selection**  
If Caller ID is available, the initial display (Caller ID or CO Line Name) is determined either by Station or System Programming. Caller ID Detection is set by System Programming (1 Configuration - 1.2 Slot Assignment - Card Properties (ELCOT) "Caller ID Detection" in the Programming Guide). CO Line Name can be changed by System Programming (Section 4.2 Trunk Line, "Name" in the Programming Guide).
- **Display Selection During a Call**  
During a call, the extension user can alternate the display (Caller ID or CO Line Name) by pressing the SHIFT or "\*" button.

## Installation Manual References

- 2.5.11 ELCOT Card (KX-TD50180)
- 2.7.3 Caller ID Card (KX-TD193)

## Programming Guide References

- 2.8 System Option
  - Automatic adjustment of the clock using Caller ID information
  - LCD Display Mode while CO talking
- 4.2 Trunk Line
  - Name
- 4.3 Extension Line
  - Initial Display Selection
  - [Call Log Incoming] Overwrite Mode
  - [Call Log Incoming] Lock Password
- 5.12 Caller ID Modification
  - [Local Call] Area Code
  - [Local Call] Digits to delete
  - [Local Call] Number to be added
  - [Long Distance Call] Digits to delete
  - [Long Distance Call] Number to be added
- 5.13 Caller ID Registration
- 10.4 SMDR
  - Priority of Caller ID information

## Features Guide References

- 1.17 Display Features
  - Call Log, Incoming

## User Manual References

- 2.10.1 Calling Using the Call Log (Incoming Call Log) [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]
- 2.10.2 Recording a Call Log [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]
- 4.1.1 Initial Settings
- 4.3.6 Caller ID Dial Set (006)
- 4.3.7 Caller ID Name Set (007)

## Direct In Lines (DIL)

### Description

Enables an incoming CO call to go directly to one or more answering points without assistance of the operator.

**DIL 1:1** puts an incoming CO call to a single destination. Assignable destinations are:


**(1) Extension**

**(2) Floating Extension**

- Modem (Remote Administration)
- External Pager (TAFAS)
- OGM Group (DISA message)
- Extension Group
- DIL 1:N Group
- Phantom Extension

This CO line can be used by multiple extension users to make calls but can be used by only one extension to receive calls.

DIL 1:1 can have different destinations for day and night modes (Night Service).

**Outline sketch of Direct In Lines (DIL)****Conditions**

- DIL 1:1 to the modem allows the caller to perform remote administration. When receiving incoming calls (TAFAS feature), DIL 1:1 pages an external pager. DIL 1:1 to DISA message allows an external caller to access the system directly (DISA feature).

**Programming Guide References**

- 4.2 Trunk Line
  - Incoming Type
  - Destination – Day / Night

## **Features Guide References**

None

## **User Manual References**

Not applicable.

# Direct Inward Dialling (DID)


## Description

Allows incoming CO calls to reach a specific extension, a virtual extension or a group of extensions in the system directly in accordance with the subscriber number sent from the Central Office.

### Possible destination of DID calls

- Extension user
- Extension Group
- TAFAS
- Remote
- Phantom extension

### Call Flow



### DID Digits Modification Procedures

The System modifies the subscriber number according to the following three parameters.

**a) Digits to receive DDI / DID**

The number of digits effective in the received subscriber number.

**b) Digits to delete**

The number of digits to be deleted from the beginning of the digits processed in Step 1.

**c) Number to be added**

The digits to be inserted at the beginning of the digits processed in Step 2.

**[Example]**

Digits to receive DDI / DID: 4 (digits)

Digits to delete: 1 (digit)

Number to be added: 2

The System modifies the received subscriber number "4311" into "2311" as follows:

**Processed in Step 1:** 4311 → 311

The first digit "4" was deleted. This results in "311."

**Processed in Step 2:** 311 → 2311

The digit "2" was added to the beginning of "311." This results in "2311."

### DDI / DID Number Transformation

The System converts the modified number into the destination DN according to this table.

**[Example]**

The System searches for the number "2311" in the table. When matching is found, the call rings the corresponding extension or floating station.

<b>DID / DDI / MSN (Max. 16 digits)</b>	<b>Destination (Day)</b>	<b>Destination (Night)</b>	<b>Name (Max. 10 characters)</b>
2311	200	300	PANASONIC

### Conditions

- **What if the dialling digits received is not enough to decide the call destination?**  
If the number of digits received is less than the number which is programmed in Digits to receive DDI / DID, reorder tone is sent to the caller, or the call is redirected to the IRNA destination (IRNA feature). This is determined by System Programming (Section 2.8 System Option , "(22) Illegal Number - DDI / DID" in the Programming Guide).
- **What if the call destination is not registered?**  
If the recieved number has no corresponding destinations, reorder tone is sent to the caller, or the call is redirected to the IRNA destination (IRNA feature). This is determined by System Programming (Section 2.8 System Option , "(22) Illegal Number - DDI / DID" in the Programming Guide).
- **What if the call destination is busy?**  
If the destination of a DID call is in busy status, the caller may hear a busy tone or the call is redirected to the IRNA destination. This is determined by System Programming (Section 2.8 System Option , "(18) Destination Busy - DDI / DID" in the Programming Guide).
- **Hardware Requirements**  
DID card (KX-T96182), E1 Digital Trunk card (KX-T96188) or T1 Digital Trunk card (KX-T96187) is required to utilise this feature.  
These cards are used for receiving incoming calls only.



## Programming Guide References

- 1.3 Trunk Port Assignment
  - Group No.
- 1.6 T1 Port Assignment
  - Channel Type
  - Group No.
- 1.7 E1 Port Assignment
  - Channel Type
  - Group No.
- 2.8 System Option
  - Destination Busy - DDI / DID
  - Illegal Number - DDI / DID
- 3.2 Trunk Group
  - Intercept Destination – Day / Night
- 4.2 Trunk Line
  - Group No.
  - Incoming Type
  - Start Signal Type
  - Digits to receive DDI / DID
  - [DDI / DID / TIE] Digits to delete
  - [DDI / DID / TIE] Number to be added
- 9.2 Number Transformation
  - DID / DDI / MSN No.
  - Destination – Day / Night

## Features Guide References

- 1.3 System Features
  - Floating Station

## User Manual References

Not applicable.

## Direct Inward System Access (DISA)

### Description

Allows an outside caller to access specific system features without operator assistance as if the caller is an extension user in the system.

The outside caller can have direct access to features such as:

- **Placing an intercom call** to an extension, modem (for remote system administration), external pager (for TAFAS), Phantom extension or Extension Group.

**DISA built-in Automated Attendant**

A DISA caller can access the desired extension simply by dialling a one-digit code.


- **Calling an outside party.**

To control the DISA caller's calling ability, one of the following three Security modes can be assigned on an OGM Group basis.

<b>Non Security mode</b>	DISA callers can make both outside and intercom calls without restriction.
<b>Trunk Security mode</b>	DISA callers are required to enter a pre-assigned DISA user code to make outside calls.
<b>All Security mode</b>	DISA callers are required to enter a pre-assigned DISA user code to make both outside and intercom calls.

**Outgoing Message (OGM)** can be recorded for the DISA feature. When a caller reaches the system via DISA line, a pre-recorded message will greet the caller. DISA OGMs may be recorded by the Manager extension or an Operator.

### Flow chart of possible cases and results for DISA calls



### Conditions

- The following items are required to utilise the DISA feature:
  - a) An optional DISA Card (KX-T96191) must be installed.  
Up to eight DISA cards can be installed in the system.
  - b) The FDN of the OGM Group number should be assigned as the DIL 1:1 destination.  
This assigns the DISA line and the message accessed by external callers.

c) The DISA OGM(s) should be recorded by the Manager or an Operator.

d) The OGM Type should be set to "DISA" under OGM Group setting.

- **DISA Delayed Answer Time**

A DISA call is answered after a ringback tone is returned to the caller after the "DISA Delayed Answer Time" expires. The caller can dial while hearing the OGM message.

- **DISA User Code**

This system can store up to 32 programmable DISA user codes with a COS (Class of Service) level for each. Each code should be unique.

- **DISA User Code Entry Failure**

If the DISA caller fails to enter the valid DISA user code three times consecutively, the call will be disconnected.

- **DISA built-in Automated Attendant Table**

This system can store up to 8 DISA built-in auto attendant number tables, each having 10 one-digit numbers.

- **DISA built-in Automated Attendant Number**

The DISA built-in auto attendant number may be the same as the first digit of other numbers (extension number, Floating Number, etc.). To avoid confusion, the system waits for the second digit for a pre-programmed amount of time (default: 1 second). If the second digit is not dialled before the timer expires, the system assumes that the first digit is a DISA built-in auto attendant number.

- **Call Forwarding-to CO or TIE Line**

If a DISA call is forwarded to an outside party, the caller is not required to enter a DISA user code if the DISA security mode is "Non Security" or "Trunk Security."

- **CO-to-CO line call duration**

The duration of CO-to-CO line calls can be limited by System Programming. When a specified period of time (default:10 min) expires, both lines are disconnected unless the caller prolongs the duration time, if available. A warning tone is sent to both parties 15 seconds before the time-limit at 5-second intervals.

- Prolonging the CO-to-CO line call is possible. To prolong his / her call, the caller should press any dialpad key except \*. The amount of prolonging is set by "DISA Prolong Time" (0 to 7 minutes). (If this is set to zero, then prolonging is disabled.) Depending on System Programming (Section 2.8 System Option , "(13) DISA prolong operation" the call can be prolonged 10 timers or without limit.

- To detect the end of a CO-to-CO line call, CPC Signal Detection and Tone Detection can be assigned.

- **Tone Detection**

The following three ways of "Tone Detection" are enabled to disconnect a CO-to-CO line call by default.

1. **Cyclic Signal Detection:**

Used to disconnect the trunk line if the system detects a cyclic signal during a CO-to-CO line call by DISA or AGC.

2. **Continuous Signal Detection:**

Used to disconnect the trunk line if the system detects a continuous signal during a CO-to-CO line call by DISA or AGC.

3. **Silence Detection:**

Used to disconnect the trunk line if the system detects no signal during a CO-to-CO line call by DISA or AGC.

- **DISA Call Re-try by Pressing \***

The "\*" key can be entered during a DISA call. The action taken by the system depends upon System Programming (Section 2.8 System Option , "(14) Dialling "\*" in DISA CO-to-CO talking" in the Programming Guide). If "Disconnect and make a new call" is selected, then the system will disconnect the current call and prepare for a new call. Otherwise, the \* will be transmitted down the line to the other party.

- **Intercept Routing**

The Floating Number of a DISA OGM Group may be selected as the destination of Intercept Routing.

- **What if the destination is busy?**

If the destination has enabled Call Waiting, then he or she will hear the Call Waiting tone. Otherwise, the caller may hear a busy tone, or the call is redirected to the IRNA destination. This is determined by System Programming (Section 2.8 System Option , "(17) Destination Busy - DISA" in the Programming Guide).

- **What if an illegal number is dialled?**

The caller may hear a reorder tone, or the call is redirected to the IRNA destination. This is determined by System Programming (Section 2.8 System Option , "(21) Illegal Number - DISA" in the Programming Guide).

- **How many times does the IRNA destination ring?**

This is determined by System Programming (Section 2.5 System Timer, "Call Forwarding - No Answer Time" in the Programming Guide).

## Installation Manual References

- 2.6.1 DISA Card (KX-T96191)
- 2.6.3 RMT Card (KX-T96196)
- 2.6.4 ERMT Card (KX-TD50197)

## Programming Guide References

- 1.8 DISA Port Assignment
- 2.3 Numbering Plan
  - OGM Playback / Record
- 2.5 System Timer
  - CO-to-CO Line Call Duration Time
  - DISA Prolong Time
  - DISA Delayed Answer Time
  - DISA Automated Attendant Time
  - DISA IRNA Time
  - Intercept Timer after OGM
- 2.7 Trunk to Trunk Restriction
- 2.8 System Option
  - DISA prolong operation
  - Dialing "\*" in DISA CO-to-CO talking
  - Destination Busy - DISA
  - Illegal Number - DISA
- 3.2 Trunk Group
  - Intercept Destination – Day / Night
- 3.6 OGM Group
  - FDN
  - Tenant No.
  - OGM Type
  - Security Mode
  - DISA built-in Automated Attendant Tables
- 4.2 Trunk Line
  - Incoming Type
  - Destination – Day / Night
  - [CPC Signal] OUT Detection
  - [CPC Signal] OUT Detection - Detection Time (Type A)
  - [CPC Signal] OUT Detection - Detection Time (Type B)
  - [CPC Signal] IN Detection
  - [CPC Signal] IN Detection - Detection Time (Type A)
  - [CPC Signal] IN Detection - Detection Time (Type B)
- 5.10 DISA / TIE User Code
  - Code
  - COS

## Features Guide References

- 1.3 System Features
  - Outgoing Message (OGM)
- 1.11 Transferring Features
  - Intercept Routing

## User Manual References

- 2.2.7 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])

# Trunk Answer From Any Station (TAFAS)

## Description

A tone signal is emitted from the external pager when an incoming CO call is received. Any extension user can answer the call.

## Conditions

- **Hardware Requirements**  
A user-supplied external paging device is required to utilise this feature. Up to two external pagers can be installed in the system.
- To answer an incoming CO call ringing at an external pager, dial the feature number and TAFAS number 1 or 2. The feature number is the same as that used to answer Paging — External.
- TAFAS can be used in the following cases:
  - a) The FDN of an external pager is assigned as the Destination of a trunk line (DIL 1:1). In this case, all incoming calls on the specified line will be signalled.
  - b) A DISA caller dials the FDN of an external pager.
  - c) The FDN of an external pager is assigned as the Intercept Routing destination. In this case incoming calls redirected to the destination will be signalled.
  - d) When a TIE call comes in.
- **Confirmation Tone**  
A confirmation tone is sent to the extension user before being connected to the caller. Eliminating the tone is programmable.

## Installation Manual References

- 2.8.2 External Pager (Paging Equipment)

## Programming Guide References

- 2.3 Numbering Plan
  - External Paging Answer / TAFAS Answer
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve
- 4.2 Trunk Line
  - Incoming Type
  - Destination – Day / Night
- 4.6 External Paging
  - Tenant No.
  - FDN



## Features Guide References

- 1.3 System Features
  - Floating Station

## User Manual References

- 2.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])

## 1.6 Originating Features

### Alternate Calling – Ring / Voice

#### Description

Allows an extension user either to ring-signal (Ring call) or voice-signal (voice call) the other PT extensions.

**Ring call:** The called PT rings.

**Voice call:** The caller's voice is heard through the built-in speaker of the called PT instead of ringing.

The calling extension user can switch ring-signalling to voice-signalling and vice versa by pressing "\*" during an intercom call.

#### Conditions

- **Mode Selection**  
The PT user can select either to be ring-signalled or voice-signalled by Station Programming.
- Any extension user (PT, SLT) can use this feature during an intercom call if destination extension is a PT.
- **One time switching**  
Switching of signalling mode is available only once during a call.
- **Voice-signalling is not available in the following cases:**
  - if the other extension is an SLT.
  - if the other extension is busy on another call.
  - if another call is ringing on the other extension.

#### Programming Guide References

System programming is not required.

#### Features Guide References

- 1.9 Answering Features
  - Hands-free Answerback

#### User Manual References

- 2.2.6 Alternating the Calling Method (Alternate Calling — Ring / Voice)
- 4.1.1 Initial Settings

# Automatic Callback Busy (Camp-On)

## Description

The system calls back the extension user when the called party or the selected CO line becomes idle, if this feature was activated beforehand.

### Automatic Callback - Extension

If the extension user answers the callback ringing, the called extension (previously busy) automatically starts ringing.

### Automatic Callback - Trunk

If the extension user answers the callback ringing, the designated CO line (previously busy) is automatically selected for making a CO call.

## Conditions

- If the callback ringing is not answered in four rings (within 10 seconds), this feature is cancelled.
- The extension user can cancel this feature by dialling the feature number for "Automatic Callback Busy Cancel."
- More than one extension user can set this function to one extension or CO line at the same time.
- **FWD / DND Override**  
Call Forwarding or Do Not Disturb feature does not work for the callback ringing. It always rings the extension on which this feature was activated.

## Programming Guide References

- 2.3 Numbering Plan
  - Automatic Callback Busy Cancel

## Features Guide References

- 1.6 Originating Features
  - Automatic Route Selection (ARS)
  - Trunk Access, Idle
  - Trunk Access, Individual Trunk

## User Manual References

- 2.2.4 When the Dialled Line is Busy or There is No Answer

## Automatic Route Selection (ARS)

### Description

Automatic Route Selection (ARS) is a system programmable feature that automatically selects the least expensive route available at the time an outgoing CO call is made. ARS applies to an outgoing CO call made by dialling the feature number for Local Access / ARS (9 = default). Pre-programming eliminates the need of dialling the access code of the least expensive carrier. The appropriate Trunk Group is selected and the carrier access code is added before the number is outputted.

### System Programming Example (See "System Programming" section in the Programming Guide)

The following shows how to programme ARS so that the extension user can call the XYZ Company via the least expensive line.

**Step 1.** To utilise ARS feature, set "Automatic Route Selection" in "System-Tenant" to "Yes."

**Step 2.** Store the telephone number of the outside party that will use the ARS feature. For example, if XYZ Company's telephone number is "1-234-567-8910" (not including the line access code), store the leading 7 digits of the number "1234567" and associated Routing Plan No. (01 for example) in "ARS - Leading Digits table."

**Table A (Example: ARS Leading Digits Table)**

Entry	Dialling No.	RPT No.
001	1234567	01
002		
•		
•		
•		
800		


**Step 3.** Check all carriers available to call the stored telephone number and their Trunk Groups. Supposing that there are three carriers available to call the XYZ Company and each carrier's line is assigned to a Trunk Group as follows:

Carrier E — Trunk Group 1

Carrier F — Trunk Group 2

Carrier G — Trunk Group 3

Then check the fee charged by each carrier:



As shown in Table B, the least costly route varies with the day of the week and the time of day. To select the least expensive line at a certain time, split the day into three zones as follows:

**Table B**

Sat. / Sun.	Mon. - Fri.
(1) 7:00 a.m. - 2:00 p.m.	(1) 7:00 a.m. - 1:00 p.m.
(2) 2:00 p.m. - 5:00 p.m.	(2) 1:00 p.m. - 6:00 p.m.
(3) 5:00 p.m. - 7:00 a.m.	(3) 6:00 p.m. - 7:00 a.m.

To programme the time zones listed on the previous page, use the programme "ARS - ARS Time Table." In this table, up to four time zones (Time-A, Time-B, Time-C, Time-D) can be programmed. Enter the starting hour for each zone.

**Table C (Example: ARS Time Table)**

Sat. / Sun.		Mon. - Fri.	
Time Zones	Entry	Time Zones	Entry
Time-A	7:00 a.m.	Time-A	7:00 a.m.
Time-B	2:00 p.m.	Time-B	1:00 p.m.
Time-C	5:00 p.m.	Time-C	6:00 p.m.
Time-D	Disable	Time-D	Disable

← Enter the starting time of each zone. If a zone is not necessary, select "Disable."

**Step 4.** Determine the priority of the Trunk Groups in each time zone.

The table below shows the carriers and Trunk Groups selected for each priority and time zone:

**Table D**

	<b>Time-A</b>	<b>Time-B</b>	<b>Time-C</b>
Least Costly Carrier / Trunk Group (Priority 1)	Carrier F / Group 2	Carrier F / Group 2	Carrier E / Group 1
Next Less Costly Carrier / Trunk Group (Priority 2)	Carrier E / Group 1	Carrier G / Group 3	Carrier F / Group 2
Most Costly Carrier / Trunk Group (Priority 3)	Carrier G / Group 3	Carrier E / Group 1	Carrier G / Group 3

Assign the above Routing Plan (Table D) to "ARS - Routing Plan" in the Programming Guide. Enter the Trunk Group numbers in order of priority. If the specified Trunk Group requires digits modification, assign the appropriate Digits Modification Table number (01 to 48).

This table is required to have the system automatically add a specific carrier access code to the extension user-dialled number.

**Table E (Example: ARS Routing Plan Table)**

	<b>Time -A</b>		<b>Time -B</b>		<b>Time -C</b>		<b>Time -D</b>	
	<b>TRG</b>	<b>Modify</b>	<b>TRG</b>	<b>Modify</b>	<b>TRG</b>	<b>Modify</b>	<b>TRG</b>	<b>Modify</b>
Priority 1	2	2	2	2	1	1		
Priority 2	1	1	3	3	2	2		
Priority 3	3	3	1	1	3	3		

TRG: Trunk Group

Modify: Modification Table Number

### **Note**

Up to 16 Priorities (01-16) can be utilised in the system.

**Step 5.** Create Digits Modification Table. Carriers E, F and G match the Trunk Groups and Modification Tables as follows and have the following Access Code:

**Table F**

<b>Carrier</b>	<b>TRG</b>	<b>Mod. Table</b>	<b>Access Code</b>
E	1	1	1-0-333
F	2	2	1-0-555
G	3	3	1-0-666

According to Table F, enter the Access Codes in the respective Modification Tables as follows:

**Table G (Example : ARS Digits Modification Table)**

Modification Table 1		Modification Table 2		Modification Table 3		
Remove	0	Remove	0	Remove	0	← Enter the number of digits to be deleted.
Add	10333	Add	10555	Add	10666	← Enter the digits to be added.

If Modification Table 1 is applied, the user-dialled number "9-1-234-567-8910" is modified to "9-10333-1-234-567-8910" to access the least expensive Carrier E.

Similarly, if Modification Table 2 is applied, it is modified to "9-10555-1-234-567-8910" to access Carrier F.

Use the "Digits to delete" programme when it is necessary to delete some leading digits from the extension user-dialled number. For example, if the extension user manually dials a Carrier Access Code but the carrier is not the least expensive, modification is required. For example, to delete "10333" from the beginning of the extension user-dialled number and add "10555," enter "5" in the "Digits to delete" programme. Enter "10555" in the "Number to be added" programme. When "9-10333-1-234-567-8910" is dialled,

9-10333-1-234-567-8910.



The leading 5 digits (except a line access code) are deleted and "10555" is added. "10555-1-234-567-8910" is sent to the CO line.


### **Note**

"X" can be used as a wild card character which substitutes any digit in its position.

(Example 1.) Leading Digits: 1800->ARS Plan 1. Leading Digits:

1XXX->ARS Plan 2. If the user-dialled number is "1800," the system selects ARS Plan 1.

(Example 2.) Leading Digits: 1800->ARS Plan 1. Leading Digits: 1X->ARS Plan 2. If the user-dialled number is "1800," the system selects ARS Plan 2.

**Flow Chart of ARS procedures**



## Conditions

- **Tenant Service**  
ARS mode can be turned on / off on a tenant basis.
- **Toll Restriction**  
Toll Restriction check is performed before ARS is applied.
- **Dialling Plan**  
ARS works according to the selected dialling plan. Thus, if the dialled number is not found in the dialling plan (Leading Digits Table), the CO call is made by Trunk Access, Idle (Automatic Line Access) feature.
- **ARS Override**  
ARS is not applied to a call made by specifying a Trunk Group.
- This feature also applies to a call forwarded by "Call Forwarding - to Trunk" feature.
- If a call is made by using a memory dialling (Redial, One-Touch, Station / System Speed Dialling, Call Log-Outgoing) a dial tone is not sent to the extension user.

## Programming Guide References

- 2.2 Tenant
  - Automatic Route Selection
- 2.3 Numbering Plan
  - Local CO Line Access / ARS
- 7.2 Time Table
- 7.3 Leading Digits Table
- 7.4 Routing Plan
- 7.5 Digits Modification Table

## Features Guide References

- 1.6 Originating Features
  - Trunk Access, Idle

## User Manual References

- 2.2.1 Basic Calling

## Busy Station Signalling (BSS)

### Description

Used to prompt a busy extension (engaged in a call) to answer a new incoming call. When BSS is activated by the calling extension, a call waiting tone is generated at the busy extension to inform that another call is waiting.

### Conditions

- BSS feature functions, if the other busy extension is an ICM type PT in the following state:
  - (1) The extension is off-hooked.
  - (2) ICM button is idle.
  - (3) "Call Waiting" is enabled.
- BSS feature does not function, if the other busy extension is a DN type PT.
- **BSS / OHCA / Whisper OHCA**  
 If an extension user dials "1" while hearing a busy tone, BSS or OHCA or Whisper OHCA may be activated at the called extension.  
 This is determined by the following conditions.

Calling extension	Called extension			
COS-OHCA assignment	Call Waiting setting			
	OFF	ON		
	0	1	2	3
Disable	-	BSS	BSS	BSS
Enable	-	BSS	OHCA <sup>*1</sup> →BSS	W-OHCA <sup>*2</sup> →OHCA→BSS

<sup>\*1</sup> OHCA (Off-Hook Call Announcement) is activated when the called extension is KX-T7130, KX-T7235 or KX-T7436.

<sup>\*2</sup> Whisper OHCA is activated when the called extension is using one of the KX-T7400 series PT.

### Programming Guide References

- 2.3 Numbering Plan
  - Call Waiting Set / Cancel

## Features Guide References

- 1.6 Originating Features
  - Off-Hook Call Announcement (OHCA)
  - Off-Hook Call Announcement (OHCA), Whisper
- 1.9 Answering Features
  - Call Waiting

## User Manual References

- 2.2.4 When the Dialed Line is Busy or There is No Answer

# Do Not Disturb (DND) Override

## Description

Allows the extension user to ring the other extension in DND mode by dialling "1" while hearing the DND tone.

## Conditions

- **Class of Service**  
Class of Service (COS) programming determines the extension users who can perform DND Override.
- **What if a busy tone is heard after executing DND override?**  
If the extension user hears a busy tone after performing this feature, the other extension in DND mode is busy.  
In this case, the extension can perform the following features.
  - Automatic Callback (Camp-on)
  - Busy Station Signalling (BSS)
  - Executive Busy Override-Extension
  - Off-Hook Call Announcement (OHCA)
  - Off-Hook Call Announcement (OHCA), Whisper

## Programming Guide References

- 2.4 Class of Service (COS)
  - DND Override

## Features Guide References

- 1.8 Ringing Features
  - Do Not Disturb (DND)

## User Manual References

- 2.2.5 Calling without Restrictions

# Electronic Station Lockout

## Description

Allows the extension user to lock his / her extension so that other users cannot make outside calls. Any 3-digit numeric code (000-999) can be used to lock and unlock the extension.

## Conditions

- **How does this feature restrict the extension?**  
This feature restricts the extension from making an outside call only. Other operations are not affected.
- **Remote Station Lock**  
Remote Station Lock Control overrides Electronic Station Lockout. If the Manager extension or an Operator extension sets Remote Station Lock on an extension that has already been locked by the extension user, the extension user cannot unlock it.

## Programming Guide References

- 2.3 Numbering Plan
  - Station Lock Set / Cancel

## Features Guide References

- 1.3 System Features
  - Remote Station Lock Control

## User Manual References

- 2.5.4 Preventing Other People from Using Your Telephone (Electronic Station Lockout)

# Emergency Call

## Description

Allows any extension user to dial out a pre-assigned emergency number after seising a CO line regardless of the restrictions imposed on the extension.

## Conditions

- Up to 10 emergency numbers can be stored.
- Emergency number is allowed to call even in the following cases;
  - in Account Code — Verified (All Calls, Toll Restriction Override) mode
  - in any toll restriction level
  - in Electronic Station Lockout / Remote Station Lock
  - after the pre-programmed charge limit is reached.

## Programming Guide References

- 5.4 Emergency Dial Code

## Features Guide References

None

## User Manual References

- 2.2.1 Basic Calling

# Executive Busy Override — Barge-in

## Description

Allows the PT user to interrupt an existing outside call (either between two outside parties or between an outside party and an inside party) by pressing the red lit S-CO or DN button. This establishes a 3-party conference call.

## Conditions

- **<DN type PT>**  
This feature is available when one extension has an SDN button associated with the PDN button of the other.
- **Executive Busy Override Deny**  
Extension users can prevent this function from being executed by another extension user.
- **Class of Service**  
Class of Service programming determines the extension users who can perform this feature.
- The pre-assigned extension users can interrupt an existing outside call even if access to that line is not allowed by System Programming.
- This feature does not work if "Executive Busy Override Deny" or "Data Line Security" is set at either one of two extensions or both of them.
- **Confirmation tone**  
When a 2-party call is changed to a 3-party call and vice versa, a confirmation tone is sent to all three parties. This tone can be eliminated by System Programming.

## Programming Guide References

- 2.3 Numbering Plan
  - Data Line Security Set / Cancel
  - Executive Override Deny Set / Cancel
- 2.4 Class of Service (COS)
  - Busy Override
  - Busy Override Deny
- 2.8 System Option
  - Confirmation tone for Override, Barge-in, Conference and Privacy Release

## Features Guide References

- 1.9 Answering Features
  - Executive Busy Override Deny
- 1.12 Conversation Features
  - Conference

## User Manual References

- 2.2.4 When the Dialed Line is Busy or There is No Answer

# Executive Busy Override — Extension

## Description

Allows the extension user to interrupt an existing extension call (either between two inside parties or between an outside party and an inside party) by dialling "2". This establishes a 3-party conference call.

## Conditions

- **Class of Service**  
Class of Service programming determines the extension users who can perform this feature.
- **Executive Busy Override Deny**  
It is possible for extension users to prevent this feature from being executed by another extension user.
- This feature does not work if "Executive Busy Override Deny" or "Data Line Security" is set at either one of two extensions or both of them.
- **Confirmation tone**  
When a 2-party call is changed to a 3-party call and vice versa, a confirmation tone is sent to all three parties. This tone can be eliminated by System Programming.

## Programming Guide References

- 2.3 Numbering Plan
  - Data Line Security Set / Cancel
  - Executive Override Deny Set / Cancel
- 2.4 Class of Service (COS)
  - Busy Override
  - Busy Override Deny
- 2.8 System Option
  - Confirmation tone for Override, Barge-in, Conference and Privacy Release

## Features Guide References

- 1.9 Answering Features
  - Executive Busy Override Deny
- 1.12 Conversation Features
  - Conference

## User Manual References

- 2.2.4 When the Dialed Line is Busy or There is No Answer



# Inter Office Calling

## Description

Allows the extension user to call another extension user within the system or a tenant. An inter office call is a call between two extensions in the KX-TD500 system.

## Conditions

- **Definition of extension busy status**
  - <ICM type PT>
    - Off-hook
    - ICM button is not idle.
  - <DN type PT>
    - There is no idle DN buttons on a PT.
  - <SLT>
    - Off-hook
    - an SLT is ringing.
    - an SLT has a call placed on hold.
- **Extension Number Assignment**

Extension numbers (3 or 4 digits) are assigned to all extensions according to "Numbering Plan" by System Programming.
- **DSS Button**

DSS buttons permit One-Touch access to an extension and provide Busy Lamp Field. A DSS button can be assigned on a Proprietary Telephone (PT) or DSS Console by Station, User or System Programming.
- **Call Directory - Extension Dialling**

The extension user with one of the following PTs can make an extension call with "Call Directory - Extension Dialling" on the display of the following PTs: KX-T7235, KX-T7433, KX-T7436.
- **Call Progress Tone**

After dialling an extension number, the extension user may hear one of the following call progress tones:

  - **Ringback tone:** indicates that the other extension is being called.
  - **Confirmation tone:** indicates that the user can perform Voice Calling.
  - **Busy tone:** indicates that the other extension is busy.
  - **Do Not Disturb tone:** indicates that the other extension has DND enabled.
- **Tenant Service**

If "Tenant Service" is employed, calling to other extensions in other tenants is enabled / disabled by System Programming.
- Names can be given to all extensions by User or System Programming. An extension number and a name, if programmed, are shown on the display PT during an intercom call.

## Programming Guide References

- 1.4 Extension Port Assignment
  - Attribute
  - Tel. Type
  - DN
- 2.2 Tenant
  - Inter-tenant Calling (1 - 8)
- 2.3 Numbering Plan
  - 1st Hundred Block Extension
  - 2nd Hundred Block Extension
  - 3rd Hundred Block Extension
  - 4th Hundred Block Extension
  - 5th Hundred Block Extension
  - 6th Hundred Block Extension
  - 7th Hundred Block Extension
  - 8th Hundred Block Extension
  - 9th Hundred Block Extension
  - 10th Hundred Block Extension
  - 11th Hundred Block Extension - 16th Hundred Block Extension
- 4.3 Extension Line
  - Name
  - CO Key
- 4.4 DSS Console
  - DSS Key

## Features Guide References

- 1.16 Button Features
  - Button, Direct Station Selection (DSS)
- 1.17 Display Features
  - Busy Lamp Field

## User Manual References

- 2.2.1 Basic Calling
- 4.1.2 Customising the Buttons
- 4.3.4 Extension Name Set (004)
- 4.3.5 Flexible CO Button Assignment (005)

# Line Preference — Outgoing (Idle Line / No Line / Prime Line)

## Description

A PT user can select a desired outgoing line preference to originate calls from the following three line preferences:

**a) Idle Line Preference**

When an extension user goes off-hook to make a call, an idle line is automatically selected from the pre-assigned lines.

**b) No Line Preference**

No line is selected when an extension user goes off-hook to make a call. He or she must select an appropriate Line Access button to make a call.

**c) Prime Line Preference (default)**

When an extension user goes off-hook to make a call, a pre-programmed prime line is selected automatically. A Prime Line can be selected from the following line access buttons.

<ICM type PT>

ICM, S-CO, G-CO, L-CO

<DN type PT>

PDN, SDN, S-CO, G-CO, L-CO

## Conditions

- This feature is available when there is no incoming call on the extension or when the extension has set "No Line Preference for incoming calls," that is, "Line Preference-Incoming" overrides "Line Preference-Outgoing."
- Setting a new line preference feature cancels the previous setting.
- The CO lines available for extension users must be assigned by System Programming.
- **Line Preference Override**  
The extension user can override the Idle / Prime Line Preference temporarily by pressing the desired line access button (INTERCOM, CO or DN (PDN / SDN)) before going off-hook; or if Full One-Touch Dialling is enabled, press One-Touch Dialling, DSS, REDIAL, or SAVE button.

## Programming Guide References

- 4.3 Extension Line
  - CO Key
  - [Preferred Line] Outgoing

## Features Guide References

- 1.6 Originating Features
  - Trunk Connection Assignment – Outgoing

## User Manual References

- 2.2.1 Basic Calling
- 4.1.1 Initial Settings
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Off-Hook Call Announcement (OHCA)

## Description

OHCA allows the extension user to inform a busy extension (engaged in a call using the handset) that another call is waiting by talking through the built-in speaker of the busy extension's PT. If the existing call is performed over the handset, the second conversation is made with the speakerphone so that the called extension can talk to two parties independently. OHCA is performed the same way as Busy Station Signalling (BSS). It depends on the telephone type of the called party whether BSS or OHCA is activated by the operation. If the called extension is KX-T7130, KX-T7235 or KX-T7436, OHCA becomes active.

## Conditions

- **Call Waiting**  
This feature is only effective if the called extension has set Call Waiting. If not, the caller will hear a reorder tone after dialling the extension number.
- **BSS / OHCA / Whisper OHCA**  
If an extension user dials "1" while hearing a busy tone, BSS or OHCA or Whisper OHCA will be activated at the called extension.  
This is determined by the following conditions.

Calling extension	Called extension			
COS-OHCA assignment	Call Waiting setting			
	OFF	ON		
	0	1	2	3
Disable	—	BSS	BSS	BSS
Enable	—	BSS	OHCA* <sup>1</sup> →BSS	W-OHCA* <sup>2</sup> →OHCA →BSS

\*<sup>1</sup> OHCA (Off-Hook Call Announcement) is activated when the called extension is KX-T7130, KX-T7235 or KX-T7436.

\*<sup>2</sup> Whisper OHCA is activated when the called extension is using one of the KX-T7400 series PT.

- BSS, OHCA and Whisper OHCA do not function at a DN type PT.

## Hardware Requirements

- DPT  
Basic shelf, expansion shelf 1, 2 have 16 OHCA paths which are connected each other.
- APT  
To utilise this feature, the OHCA card should be installed on a PLC card or HLC card beforehand.

- DPT  
To utilise this feature, the DOHCA card should be installed on the TSW card beforehand.
- DLC card with DPT  
A DLC card allows 8 DPTs that can be called with the OHCA feature at the same time.
- DHLC card with DPT  
A DHLC card allows 8 DPTs that can be called with the OHCA feature at the same time.
- DHLC card with APT  
A DHLC card allows one APT telephone that can be called with the OHCA feature at the same time.

### Installation Manual References

- 2.7.1 OHCA Card (KX-T96136)
- 2.7.5 DOHCA Card (KX-TD50105)

### Programming Guide References

- 2.3 Numbering Plan
  - Call Waiting Set / Cancel
- 2.4 Class of Service (COS)
  - Off-Hook Call Announcement (OHCA)

### Features Guide References

- 1.6 Originating Features
  - Busy Station Signalling (BSS)
  - Off-Hook Call Announcement (OHCA), Whisper
- 1.9 Answering Features
  - Call Waiting

### User Manual References

- 2.7.3 Receiving a Call Waiting (Call Waiting / Off-Hook Call Announcement [OHCA] / Whisper OHCA)

# Off-Hook Call Announcement (OHCA), Whisper

## Description

This is a variation of the OHCA feature.

The difference is, OHCA provides two-way communication, but Whisper OHCA provides one-way (from the calling extension to the called extension) communication.

## Conditions

- **Call Waiting**  
This feature is only effective if the called extension has set Call Waiting feature.  
By default, this feature works only when the called extension user is using KX-T7400 series PT. If the other extension is not a KX-T7400 series PT, Call Waiting works instead of this feature.
- **Non-KX-T7400 cases**  
If the Whisper OHCA sender does not use a KX-T7400 series PT, it will work as OHCA.  
If the receiver does not use a KX-T7400 series PT, it may not work properly (e.g., the OHCA may be heard by unintended parties.)
- **Enabling Feature for Any PT**  
It is possible to enable the Whisper OHCA by any PT by System Programming. But it may not work properly (e.g., the OHCA may be heard unintended parties.)
- **Conference Trunk**  
An idle conference trunk is required to perform this feature.
- **BSS / OHCA / Whisper OHCA**  
If an extension user dials "1" while hearing a busy tone, BSS or OHCA or Whisper OHCA will be activated at the called extension. This is determined by the following conditions.

Calling extension	Called extension			
COS-OHCA assignment	Call Waiting setting			
	OFF	ON		
	0	1	2	3
Disable	———	BSS	BSS	BSS
Enable	———	BSS	OHCA <sup>*1</sup> →BSS	W-OHCA <sup>*2</sup> →OHCA→BSS

<sup>\*1</sup> OHCA (Off-Hook Call Announcement) is activated when the called extension is KX-T7130, KX-T7235 or KX-T7436.

<sup>\*2</sup> Whisper OHCA is activated when the called extension is using one of the KX-T7400 series PT.

- BSS, OHCA and Whisper OHCA do not function at a DN type PT.

## **Programming Guide References**

- 2.3 Numbering Plan
  - Call Waiting Set / Cancel
- 2.4 Class of Service (COS)
  - Off-Hook Call Announcement (OHCA)
- 2.8 System Option
  - Whisper OHCA to extensions other than T74 / 75XX

## **Features Guide References**

- 1.6 Originating Features
  - Busy Station Signalling (BSS)
  - Off-Hook Call Announcement (OHCA)
- 1.9 Answering Features
  - Call Waiting

## **User Manual References**

- 2.7.3 Receiving a Call Waiting (Call Waiting / Off-Hook Call Announcement [OHCA] / Whisper OHCA)



# Operator Call

## Description

To direct operator-seeking incoming calls to the Operators, one of the following ways can be used.

### **Intercom calls**

Extension users can call the Operator:

- by dialling the feature number for Operator Call
- by dialling the FDN for Operator Group

### **Outside calls**

To direct outside callers to the Operators, set the FDN of an Operator Group as the destination of the following calls:

- DISA
- DID
- DDI
- DIL 1:1
- IRNA
- TIE

## Conditions

- An operator-seeking call (extension / outside) may come in on a single operator or all operators in the group at once depending on System Programming.
- The Operators can perform the special features which are available for the Manager.

## Programming Guide References

- 2.3 Numbering Plan
  - Operator Call
- 3.3 Extension Group
  - FDN
  - Group Type
  - Tenant No.
  - [Overflow Setting] Destination – Day / Night
  - [Overflow Setting] Timer
  - [Operator Setting] Ringing Type
  - [Operator Setting] Call Priority

## Features Guide References

- 1.3 System Features
  - Extension Group – Operator Group
  - Manager Extension

## User Manual References

- 2.2.1 Basic Calling

# PDN Call

## Description

If the Extension 2001 has an SDN button which corresponds with the PDN button of the Extension 3001 (PDN owner), the Extension 2001 can call the Extension 3001 simply by pressing the associated SDN button twice.

The Extension 2001 can also transfer a call (on the CO / PDN) to the Extension 3001 with a simple operation.

## Conditions

- **SDN button**  
An SDN button can be assigned to a flexible CO button on a DN type PT by Station, User or System Programming.
- **FWD / DND Override**  
The call originated by this feature overrides FWD / DND (Call Forwarding / Do Not Disturb) feature assigned on the PDN owner extension.
- A call made by this feature rings the destination PDN button immediately even if delayed ringing or no ring is set on that PDN button.

## Programming Guide References

- 4.3 Extension Line
  - CO Key

## Features Guide References

- 1.11 Transferring Features
  - Ringing Transfer
- 1.16 Button Features
  - Button, Line Access – Primary Directory Number (PDN)
  - Button, Line Access – Secondary Directory Number (SDN)

## User Manual References

- 2.2.1 Basic Calling
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Toll Restriction

## Description

Toll Restriction is a system programmable feature that, in conjunction with the assigned Class of Service, can prohibit certain extension users from placing unauthorised toll calls.

Every extension is programmed to belong to one of **96 Classes of Service**. Each Class of Service is programmed to have a toll restriction level for day mode and night mode respectively.

There are **eight toll restriction levels available**. Toll restriction level 1 is the highest level and the level 8 is the lowest. That is, level 1 allows all toll calls and levels 7 and 8 disallow all toll calls. Levels 2 through 6 are used to restrict calls by combining pre-programmed deny and excepted code tables.

### TRS Deny Code Tables

An outgoing CO call made by an extension user with a toll restriction level between 2 and 6 is first checked against the selected TRS Deny Code Tables. If the leading digits of the dialled number (not including the CO line access code) are not found in the table, the call is made.

**System Programming, Toll Restriction - TRS Deny** is used to make up a TRS Deny Code Table for Levels 2 through 6 respectively.

Complete every table by storing numbers that are to be prohibited. These numbers are defined as deny codes. Up to 400 deny codes (max.10 digits for each) can be stored for TRS Levels 2 through 6.

### TRS Exception Code Tables

These tables are used to override a programmed deny code. A call denied by the selected TRS Deny Code Tables is checked against the selected TRS Exception Code Tables, and if a match is found, the call is made.

**System Programming, Toll Restriction - TRS Exception** is used to make up a TRS Exception Code Table for Levels 2 through 6. Complete every table by storing numbers that are exceptions to the TRS deny codes. These numbers are defined as exception codes. Up to 200 exception codes (max.10 digits for each) can be stored for TRS Levels 2 through 6.

Applicable TRS Deny and TRS Exception Code Tables depend on the assigned toll restriction level of an extension as follows:

	TRS Deny Code Tables	TRS Exception Code Tables
Level 1	None	None
Level 2	Table for Level 2	Tables for Levels 2 - 6
Level 3	Tables for Levels 2 and 3	Tables for Levels 3 - 6
Level 4	Tables for Levels 2 to 4	Tables for Levels 4 - 6
Level 5	Tables for Levels 2 to 5	Tables for Levels 5 - 6
Level 6	Tables for Levels 2 to 6	Tables for Level 6

	TRS Deny Code Tables	TRS Exception Code Tables
Level 7	None	None
Level 8	None	None

**[Explanation]**

- Level 1: allows all calls.
- Level 2: denies codes stored in the TRS Deny Code Table for Level 2 except the codes stored in TRS Exception Code Tables for Levels 2 through 6.
- Level 3: denies codes stored in the TRS Deny Code Tables for Levels 2 and 3 except the codes stored in TRS Exception Code Tables for Levels 3 through 6.
- Level 4: denies codes stored in the TRS Deny Code Tables for Levels 2 through 4 except the codes stored in TRS Exception Code Tables for Levels 4 through 6.
- Level 5: denies codes stored in the TRS Deny Code Tables for Levels 2 through 5 except the codes stored in TRS Exception Code Tables for Levels 5 and 6.
- Level 6: denies codes stored in the TRS Deny Code Tables for Levels 2 through 6 except the codes stored in TRS Exception Code Table for Level 6.
- Level 7: Allows intercom calls only. Available only if COS "Call From TRS Level 7 Extension" is enabled.
- Level 8: Allows operator calls only.

**Example of Toll Restriction programming**

Here is an example to explain the procedures for Toll Restriction programming.

**1. Determining the application**

Determine the dialling numbers that should be denied for levels 2 through 6. (Levels 1, 7 and 8 are fixed and do not require programming.)

[Entry Example]

Level	TRS Deny Code	TRS Exception Code
2	011	None
3	011 976 1XXX976	None
4	011 976 1XXX976 0	None
5	011 976 1XXX976 0 411 1XXX555	None
6	011 976 1XXX976 0 411 1XXX555 1 X0 X1	911 1911 800 1800

Note: "X" substitutes a digit.

**2. System Programming (See Programming Guide)****a) System - Class of Service, "TRS Level, Day / Night"**

Assign a toll restriction level to each Class of Service (COS).

COS	Level (Day)	Level (Night)
1	1	6
2	2	6
:	:	:
8	8	8

**[Example]****b) Toll Restriction - "TRS Deny Code"**

Depending on the application, enter the TRS Deny codes in the associated tables.  
 Numeric characters and the wild card character "X" can be used.

<b>Level-2 TRS Deny Code Table</b>	
<b>Location</b>	<b>Code</b>
001	011
:	
:	
400	

<b>Level-3 TRS Deny Code Table</b>	
<b>Location</b>	<b>Code</b>
001	976
002	1XXX976
:	
400	

<b>Level-4 TRS Deny Code Table</b>	
<b>Location</b>	<b>Code</b>
001	0
:	
:	
400	

<b>Level-5 TRS Deny Code Table</b>	
<b>Location</b>	<b>Code</b>
001	411
002	1XXX555
:	
400	

Level-6 TRS Deny Code	
Location	Code
001	1
002	X0
003	X1
:	
400	

**c) Toll Restriction - "TRS Exception Code"**

Depending on the application, enter the exception codes in the associated tables.  
Numeric characters and the wild card character "X" can be used.


Level-6 TRS Exception Code Table	
Location	Code
001	911
002	1911
003	800
004	1800
:	
200	

**[Explanation]**

If the extension user's Toll Restriction Level is 6;

- a) The extension user cannot make a call whose toll call number is "201," because the number whose second digit "0" is one of the TRS Deny Codes for Level 6.
- b) The extension user can make a call whose toll call number is "800." Though the number whose second digit "0" is one of the TRS Deny Codes for Level 6, the number "800" is one of the TRS Exception Codes for Level 6. The Exception Codes override the Deny Codes.



**Flow Chart of Toll Restriction****Conditions**

- Toll restriction checks are applied to the following:
  - a) Automatic Route Selection (ARS)
  - b) Account Code Entry

- c) Trunk Access, Idle
- d) Trunk Access, Trunk Group
- e) Trunk Access, Individual Trunk
- f) Special Carrier Access
- g) System Speed Dialling
- **Emergency Numbers**  
The Emergency numbers such as Police or Fire Department should be stored in System Programme (Section 5.4 Emergency Dial Code in the Programming Guide) so that they are excepted from toll restriction.
- If a stored Host PBX access code or a stored carrier code is found in the dialled number, a toll restriction check starts for the succeeding telephone number.
- **Toll Restriction Override for System Speed Dialling**  
This feature can be activated or deactivated per tenant.
- **Checking Dial \*, # by Toll Restriction**  
It is programmable whether the "\*" or "#" dialled by an extension user is to be checked or not in Toll Restriction procedure. This is useful to prevent unauthorised calls which could be possible through certain Central Offices' exchange system.

## Programming Guide References

- 2.2 Tenant
  - System Speed Dial TRS Level Override
- 2.4 Class of Service (COS)
  - TRS Level – Day / Night
  - Call from TRS Level 7 Extension
- 2.5 System Timer
  - First Digit Time
  - Inter-digit Time
- 2.8 System Option
  - Checking dial \*, # by toll restriction
- 4.3 Extension Line
  - COS No. – Primary
- 5.4 Emergency Dial Code
- 5.7 Special Carrier Code
- 6.2 TRS Deny Code
- 6.3 TRS Exception Code

## Features Guide References

- 1.6 Originating Features
  - Toll Restriction for Special Carrier Access
  - Toll Restriction Override by Account Code Entry
  - Toll Restriction Override for System Speed Dialling

## User Manual References

Not applicable.

# Toll Restriction for Special Carrier Access

## Description

If your system has access to multiple telephone companies, access to a specific company requires a carrier access code preceding the telephone number. Toll Restriction on these calls is activated by storing the carrier codes (maximum 100). If a stored carrier code is found in the dialled number, a toll restriction check starts for the succeeding telephone number.

## Conditions

- **Automatic Pause Insertion**  
A carrier access code is followed by Automatic Pause Insertion. It is possible to select the pause time by System Programming.

## Programming Guide References

- 3.2 Trunk Group
  - Pause Time
- 5.7 Special Carrier Code

## Features Guide References

- 1.6 Originating Features
  - Toll Restriction

## User Manual References


Not applicable.

# Toll Restriction Override by Account Code Entry

## Description

Allows the extension user to override toll restriction temporarily to make a toll call from a toll-restricted telephone. The extension user can carry out this feature by entering the appropriate account code before dialling the telephone number.

### Flow Chart of TRS Override by Account Code Entry



## Conditions

- Class of Service Programming**  
 This feature applies to the extension user whose Account Code Mode is set to "Verified–Toll Restriction Override" by Class of Service Programming.
- Toll Restriction Level for Account Code**  
 Each account code has its own toll restriction level. The toll restriction level of the extension user is changed according to the account code selected. This can be used by extension users assigned a toll restriction level from 2 through 8. Level 1 is not changed.
- Up to 1000 account codes per system / tenant can be programmed for Verified Account code operation. These are used for Toll Restriction Override.
- If the extension user does not enter any account code or enters an invalid account code, an ordinary toll restriction check is done.

## **Programming Guide References**

- 2.3 Numbering Plan
  - Account Code
- 2.4 Class of Service (COS)
  - Account Code Mode
- 5.6 Account Code
  - Tenant No.
  - Entry No.
  - Code
  - TRS Level

## **Features Guide References**

- 1.3 System Features
  - Account Code Entry
- 1.6 Originating Features
  - Toll Restriction

## **User Manual References**

- 2.2.5 Calling without Restrictions

# Toll Restriction Override for System Speed Dialling

## Description

Allows the extension user to override Toll Restriction in System Speed Dialling. Normally, calls originated by System Speed Dialling are restricted depending on the extension's toll restriction level. Once this feature is activated, it permits all extension users to make System Speed Dialling calls without restriction.

## Conditions

- **Tenant Service**  
This feature can be activated or deactivated on a tenant basis by System Programming.

## Programming Guide References

- 2.2 Tenant
  - System Speed Dial TRS Level Override

## Features Guide References

- 1.6 Originating Features
  - Toll Restriction
- 1.7 Dialling Features
  - System Speed Dialling

## User Manual References

Not applicable.

# Trunk Access, Direct

## Description

Allows the PT user to get an idle CO line for making a call by pressing an idle CO button directly. This automatically establishes the hands-free operation mode and allows the extension user to perform On-Hook Dialling. There is no need to press the SP-PHONE button, MONITOR button nor lift the handset.

## Conditions

- **CO Button Assignment**  
The following three types of CO buttons can be programmed on an extension by Station, User or System Programming: Single-CO button, Group-CO button, and Loop-CO button.
- **Class of Service programming**  
COS (Class of Service) programming determines the trunk groups available for each extension user.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Trunk Group Setting
- 4.3 Extension Line
  - CO Key

## Features Guide References

- 1.6 Originating Features
  - Trunk Connection Assignment – Outgoing
- 1.16 Button Features
  - Button, Line Access – Group-CO (G-CO)
  - Button, Line Access – Loop-CO (L-CO)
  - Button, Line Access – Single-CO (S-CO)

## User Manual References

- 2.2.1 Basic Calling
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)



# Trunk Access, Idle

## Description

Allows the extension user to get an idle CO line for making an outside call by dialling the feature number for "Local access / ARS" (default=9). An idle CO line is automatically selected from the Trunk Groups assigned for the extension. The PT user can use the Loop-CO button instead of dialling the feature number.

## Conditions

- This feature functions when Automatic Route Selection (ARS) is not activated.
- **Class of Service programming**  
COS (Class of Service) programming determines the trunk groups available for each extension user.
- **Hunting Order**  
An idle CO line is selected from the Trunk Groups assigned to the extension. If multiple Trunk Groups are available, the Trunk Group hunting sequence is determined by System Programming.
- **Idle Line Preference — Outgoing**  
If Idle Line Preference — Outgoing is set by System Programming, the extension user can access an idle CO line simply by going off-hook.
- **<ICM type PT>**  
This feature requires a CO button (G-CO, L-CO or S-CO) assignment on a PT. Dialling the line access code selects a CO button on a PT according to the priority as follows:  
S-CO > G-CO > L-CO on a hunted Trunk Group

## Programming Guide References

- 2.2 Tenant
  - Automatic Route Selection
- 2.3 Numbering Plan
  - Local CO Line Access / ARS
- 2.4 Class of Service (COS)
  - Trunk Group Setting
- 2.6 Local Hunt Sequence
- 3.2 Trunk Group
  - Line Hunting Order
- 4.3 Extension Line
  - CO Key
  - [Preferred Line] Outgoing

## Features Guide References

- 1.6 Originating Features
  - Trunk Connection Assignment – Outgoing

## User Manual References

- 2.2.1 Basic Calling

# Trunk Access, Individual Trunk

## Description

Allows the PT user to get an idle CO line for making a CO call simply by pressing an idle Single-CO button.

## Conditions

- **Class of Service programming**  
COS (Class of Service) programming determines the trunk groups available for each extension user.
- **Single-CO Button**  
This button can be assigned to a flexible CO button by Station, User or System Programming.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Trunk Group Setting
- 4.3 Extension Line
  - CO Key

## Features Guide References

- 1.6 Originating Features
  - Trunk Connection Assignment – Outgoing
- 1.16 Button Features
  - Button, Line Access – Single-CO (S-CO)

## User Manual References

- 2.2.1 Basic Calling
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Trunk Access, Trunk Group

## Description

Allows the extension user to get an idle CO line for making a CO call by specifying a Trunk Group. An idle line is selected from the Trunk Group. To specify a Trunk Group, dial the feature number for "Trunk Group Access" (default = 8) and a desired Trunk Group number (01 through 48). A PT user can also specify a Trunk Group by pressing a Group–CO button.

## Conditions

- **Class of Service programming**  
COS (Class of Service) programming determines the trunk groups available for each extension user.
- **Line Hunting Order**  
An idle CO line in a trunk group is selected in one of the following three line hunting orders.
  - a) Normal (default)
  - b) Reversal
  - c) SequentialRefer to "Trunk Group" in this manual for further information.
- If a "Group–CO button is selected by Idle Line Preference — Outgoing" assignment, the user can access a Trunk Group simply by going off–hook.
- **Group–CO button**  
This button can be assigned to a flexible CO button by Station, User or System Programming.

## Programming Guide References

- 2.3 Numbering Plan
  - Trunk Group Access
- 2.4 Class of Service (COS)
  - Trunk Group Setting
- 3.2 Trunk Group
  - Line Hunting Order
- 4.3 Extension Line
  - CO Key
  - [Preferred Line] Outgoing

## Features Guide References

- 1.3 System Features
  - Trunk Group
- 1.6 Originating Features
  - Trunk Connection Assignment – Outgoing

1.16 Button Features

- Button, Line Access – Group-CO (G-CO)

## **User Manual References**

- 2.2.1 Basic Calling
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Trunk Connection Assignment – Outgoing

## Description

Used to determine the Trunk Group which can be accessed by an extension user for making outside calls on a Class of Service basis. This feature is useful to prevent unauthorised toll calls.

## Conditions

- When the extension user tries to make an outside call on a disallowed Trunk Group, a reorder tone is sent to indicate that the user cannot use it.
- **Night Service**  
Trunk Groups available for each Class of Service can be determined for Day and Night respectively.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Trunk Group Setting

## Features Guide References

None

## User Manual References

Not applicable.

# Walking COS

## Description

Allows an extension user to make a toll call at other lower level COS extensions (toll / outward restricted) by employing his / her own higher level COS temporarily.

## Conditions

None

## Programming Guide References

- 2.3 Numbering Plan
  - Walking COS
- 2.4 Class of Service (COS)
  - Trunk Group Setting
  - TRS Level – Day / Night
  - Time Limit of Outside Calls
  - Transfer to CO
  - Digits Restriction in CO Talk Mode
  - Account Code Mode
- 4.3 Extension Line
  - COS No. – Primary
- 10.6 System Parameters
  - [Password] Walking COS

## Features Guide References

- 1.3 System Features
  - Class of Service (COS)
- 1.6 Originating Features
  - Toll Restriction

## User Manual References

- 2.2.5 Calling without Restrictions

## 1.7 Dialling Features

### Automatic Station Release

#### Description

If the extension user fails to dial any digits within a specified time period after going off-hook, the user will be disconnected from the line after reorder tone is sent. To get a line again, the user must go on-hook first and then go off-hook.

#### Conditions

- This function works in the following cases:  
When making a call
  - (1)The first digit has not been dialled within 10 seconds.
  - (2)After a digit is dialled, the next one is not dialled within 10 seconds (Intercom call only).

#### Programming Guide References

System programming is not required.

#### Features Guide References

- 1.7 Dialling Features
  - Pickup Dialling (Hot Line)

#### User Manual References

Not applicable.



# Full One-Touch Dialling

## Description

Allows the PT user to have simple access to a desired party or system feature by pressing just one button without first going off-hook.

Hands-free operation is automatically provided simply by pressing one of the following buttons.

- **One-Touch Dialling**
- **DSS** (both on PTs and DSS consoles)
- **REDIAL**
- **SAVE**
- **Function (F1-F10)** (Special Display Features for KX-T7235 and KX-T7436 only).

## Conditions

- This feature can be enabled or disabled by Station Programming.

## Programming Guide References

System programming is not required.

## Features Guide References

### 1.7 Dialling Features

- One-Touch Dialling
- Redial, Last Number
- Redial, Saved Number

### 1.16 Button Features

- Button, Direct Station Selection (DSS)

### 1.17 Display Features

- SPECIAL DISPLAY Features – A SUMMARY

## User Manual References

- 2.2.2 Easy Dialling
- 4.1.1 Initial Settings

# One-Touch Dialling

## Description

One-Touch Dialling offers the PT user One-Touch access to a desired party or system feature by storing an extension number, telephone number, account code or a feature number (up to 24 digits) in a One-Touch Dialling button. The number of buttons available depends on the type of PT. One-Touch Dialling buttons can be programmed to flexible buttons: CO, DSS or PF (Programmable Feature).

## Conditions

- **Combination dialling**  
Speed Dialling, One-Touch Dialling, manual dialling, Last Number Redial and Saved Number Redial can be used together in a combination.
- **Storing more than 25 digits**  
It is possible to store a number consisting of 25 digits or more by dividing it and storing it in two One-Touch Dialling buttons. In this case, a CO line access code should be stored in the first button.
- **Full One-Touch Dialling**  
If "Full One-Touch Dialling" is enabled, press the One-Touch Dialling button directly without going off-hook.
- To store the telephone number of an outside party, a line access code (9 or 801 through 848) must be stored as the leading digit.

## Programming Guide References

- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## Features Guide References

- 1.17 Display Features
  - Full One-Touch Dialling

## User Manual References

- 2.2.2 Easy Dialling
- 4.1.1 Initial Settings
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Pause Insertion, Automatic

## Description

Used to insert a pre-assigned pausing time between the access code (CO line / host PBX / Centrex / Special Carrier) and dialled digits.

## Conditions

- This feature requires previous programming of the access code (CO line / host PBX / Centrex / Special Carrier) as well as assignment of the pause duration.
- **This feature applies to:**  
This feature works for Speed Dialling, One-Touch Dialling, Last Number Redial, Saved Number Redial, Pickup Dialling and Call Forwarding — to Trunk.
- **Pause time (Manual)**  
Pressing the PAUSE button in dialling number inserts a pause for a pre-assigned time.

## Programming Guide References

- 3.2 Trunk Group
  - Pause Time
  - PBX Access Code
- 5.7 Special Carrier Code
  - Code

## Features Guide References

- 1.3 System Features
  - Host PBX Access
- 1.6 Originating Features
  - Toll Restriction

## User Manual References

Not applicable.

## Pickup Dialling (Hot Line)

### Description

Allows the extension user to call a pre-determined extension or outside party automatically just by lifting the handset.

This feature is also known as Hot Line.

If the feature is activated and the extension user goes off-hook, a dial tone is generated for the waiting time and then dialling starts. During the waiting time the user can dial another party, overriding the Pickup Dialling function.

### Conditions

- To utilise this feature, an extension number or an outside telephone number (up to 24 digits) should be programmed beforehand.
- This feature works only when an extension user goes off-hook from on-hook status directly.
- A rotary dial telephone without the "#" button cannot programme this feature. For programming the phone number, temporarily replace a rotary dial telephone with a pulse telephone with the "#" button.
- This feature does not work if the extension user goes off-hook to answer an incoming call or retrieve a call on hold.
- This feature does not work if a message notification is left on the extension.
- For a PT with a PF 12 button, the number stored in the PF12 button is used for Pickup Dialling.

### Programming Guide References

- 2.3 Numbering Plan
  - Pickup Dialling Program / Set / Cancel
- 2.5 System Timer
  - Pickup Dial Waiting Time
- 4.3 Extension Line
  - [Pickup Dialling] Mode
  - [Pickup Dialling] Dial

### Features Guide References

None

### User Manual References

- 2.2.2 Easy Dialling

# Quick Dialling

## Description

Allows the extension user to call a desired party by dialling a short code (1-digit code). Quick Dialling is convenient for room service calls in a hotel, for example.

## Conditions

- To utilise this feature, an extension number or a telephone number should be stored beforehand either by User or System Programming.
  - Up to eight quick dial numbers can be stored in the system.
  - Assign a feature number in programme "Numbering Plan" first and then a quick dial number in programme "Quick Dialling" in order for Quick Dialling to be effective.  
**Example:** To assign the extension number 101 in quick dial number 3;
1. Change or clear the feature numbers which have "3" in the first digit in programme "Numbering Plan."
  2. Assign "3" in the selection number 63 (Quick dial location number 1) in programme "Numbering Plan."
  3. Assign "101" in location number 1 in programme "Quick Dialling" (same location number as the quick dial location number 1 in programme "Numbering Plan") in programme "Quick Dial."

Now quick dial number 3 is available to call extension 101.

## Programming Guide References

- 2.3 Numbering Plan
  - Quick dial 1 - Quick dial 8
- 5.5 Quick Dialling

## Features Guide References

None

## User Manual References

- 2.2.2 Easy Dialling
- 4.3.9 Quick Dial Number Set (009)

# Redial, Automatic

## Description

This is a special feature for PTs, that provides automatic redialling of the last dialled number, saved number or call log number, if the called party is busy. If the Last Number Redial, Saved Number Redial or Call Log operation is performed in hands-free mode and the call is not answered, redialling will be automatically repeated pre-determined times at pre-determined interval until the called party answers the call.

## Conditions

- Redial Repeat Times and Interval Time can be changed by System Programming.
- Automatic Redialling can be terminated by pressing the FLASH button.
- If any dialling operation is done during Automatic Redial, this function is finished.
- This feature is not available for KX-T7250.

## Programming Guide References

- 2.5 System Timer
  - Automatic Redial Interval Time
  - Automatic Redial Repeat Times

## Features Guide References

- 1.7 Dialling Features
  - Redial, Last Number
  - Redial, Saved Number
- 1.17 Display Features
  - Call Log, Incoming
  - Special Display Features – Call Log, Outgoing

## User Manual References

- 2.2.3 Redial

# Redial, Last Number

## Description

Every extension telephone in the system automatically saves the last telephone number dialled to a CO line and allows the extension user to dial the same number again with a simple operation.

## Conditions

- Up to 24 digits (excluding the CO line access code) can be stored and redialled.
- The memorised telephone number is replaced by a new one if at least one digit sent to a CO line is dialled. Dialling a CO line access code alone does not change the memorised number.

## Programming Guide References

- 2.3 Numbering Plan
  - Redial

## Features Guide References

- 1.7 Dialling Features
  - Redial, Automatic

## User Manual References

- 2.2.3 Redial

# Redial, Saved Number

## Description

Allows the PT user to save a telephone number of the current call and redial the number afterwards. The PT user can store it during a call on a CO line. The saved number can be redialled repeatedly until another number is stored.

## Conditions

- Up to 24 digits (not including the CO line access code) can be stored and redialled.
- **SAVE button**  
If the SAVE button is not provided on a PT, it can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.

## Programming Guide References

- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## Features Guide References

- 1.16 Button Features
  - Button, Flexible

## User Manual References

- 2.2.3 Redial
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)



# Station Speed Dialling

## Description

Allows the extension user to store frequently dialled numbers (up to 24 digits) in order to place a call with abbreviated dialling for personal use. Up to 10 station speed dialling numbers appended with 1–digit station speed dialling code (0-9), can be stored in each telephone.

## Conditions

- Station Speed Dialling numbers and names can be assigned by Station or System Programming. Station Speed Dialling name assignment is available for KX-T7235, KX-T7433 and KX-T7436 only.
- Station Speed Dialling can be followed by manual dialling to supplement the dialled digits.

## Programming Guide References

- 2.3 Numbering Plan
  - Speed Dialling - Station
  - Speed Dialling - Station Programming

## Features Guide References

None

## User Manual References

- 2.2.2 Easy Dialling
- 2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235

# System Speed Dialling

## Description

The KX-TD500 system provides up to 1000 / tenant, 2000 / System abbreviated speed dial numbers (24-digit long for each) available to all extension users.

## Conditions

- System Speed Dialling numbers and names can be programmed either by User or System Programming.
- **Toll Restriction Override for System Speed Dialling**  
Overriding Toll Restriction for System Speed Dialling can be activated or deactivated per tenant by System Programming.
- **Tenant Service**  
If "Tenant Service" is employed, up to 2000 Speed Dialling codes can be shared among each tenant under the condition of up to 1000 codes per tenant.
- **<For PT users>**  
Speed Dialling, One-Touch Dialling, manual dialling, Last Number Redial and Saved Number Redial can be used in combinations.
- **<For SLT users>**  
If a stored feature number includes "\*" or "#," rotary or pulse SLTs cannot use it.

## Programming Guide References

- 2.2 Tenant
  - System Speed Dialling Entries Max.
  - System Speed Dial TRS Level Override
- 2.3 Numbering Plan
  - Speed Dialling - System
- 5.2 System Speed Dialling
  - Name
  - Number

## Features Guide References

- 1.6 Originating Features
  - Toll Restriction Override for System Speed Dialling

## User Manual References

- 2.2.2 Easy Dialling
- 4.3.2 System Speed Dialling Number Set (001)
- 4.3.3 System Speed Dialling Name Set (002)

## 1.8 Ringing Features

### Do Not Disturb (DND)

#### Description

Allows the extension user to appear busy to an incoming CO or extension calls.

#### Conditions

- **DND does not work for the following calls:**
  - Hold Recall
  - Timed Reminder Alarm Tone
  - Calls directed by Intercept Routing
- **Do Not Disturb Override**  
An extension in DND mode can be called by other extension users who are allowed to override DND in their Class of Service.
- An extension user may have only one type of Call Forwarding / Do Not Disturb feature in effect at any time. If one of Call Forwarding / Do Not Disturb feature is assigned, another does not function but the assignment itself is preserved for future use. The extension user can choose either one by pressing the FWD / DND button while on-hook.  
In this case, pressing the button changes the settings as follows:



The lighting patterns of the FWD / DND button are as follows:

Off : Both functions are cancelled.

Red flash : FWD mode  This setting can be changed  
Red on : DND mode  by System Programming.

- **FWD / DND button**  
Regarding the PT (KX-T7250) without the FWD / DND button, it can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.
- A PT user in DND mode can answer a call by pressing a flashing button which shows the arrival of the call.
- **Distinctive Dial Tone**  
Distinctive Dial Tone is sent to the user on the extension with this feature when the extension user goes off-hook.

## **Programming Guide References**

- 2.3 Numbering Plan
  - Call FWD - Do Not Disturb Set / Cancel
- 2.4 Class of Service (COS)
  - DND Override
- 2.8 System Option
  - Special dial tone after setting feature
  - FWD / DND lamp pattern
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## **Features Guide References**

- 1.6 Originating Features
  - Do Not Disturb (DND) Override

## **User Manual References**

- 2.7.2 Refusing Incoming Calls (Do Not Disturb [DND])
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Log-In / Log-Out

## Description

Allows members (extension users) of an **Extension Group** (extension users) of an Extension Group (except Group Type:None) and **Phantom Extensions** to join (log-in) or leave (log-out) the group.

They can leave the group temporarily when they are away from their desks, to prevent calls being sent to their extensions.

They can return to the group when they are ready to answer calls.

- The lighting patterns and status of the Log-In / Log-Out button are shown below:

### The lighting patterns and status of the Log-In / Log-Out button

Lighting pattern	Status
Off	Log-In (no calls)
Red On	Log-Out
Red slow flash (UCD Group only)	Log-In (waiting calls)

## Conditions

- **Log-In / Log-Out button**

Log-In / Log-Out button can be assigned to a flexible CO button by Station, User or System Programming.

- When extensions are logged out, calls directed to the above mentioned group do not come in on their extension.

However, calls directed to their individual extension (extension call, DIL 1:1, DIL 1:N, etc.) still ring at their extension.

- The extension user cannot leave the group (Log-Out), if at least one call is coming in on the group.

- **UCD Login Monitor**

Login / Logout status of the UCD Group members can be monitored by the extensions in the same UCD Group through Busy Lamp Field of the corresponding DSS button. UCD Login Monitor is enabled or disabled by System Programming.

## Programming Guide References

- 2.3 Numbering Plan
  - Login / Logout
- 3.3 Extension Group
  - [UCD Setting] LOGIN Monitor
- 4.3 Extension Line
  - CO Key

## **Features Guide References**

### 1.3 System Features

- EXTENSION GROUP – A SUMMARY
- Phantom Extension

## **User Manual References**

- 2.5.5 Leaving an Extension Group (Log-In / Log-Out)
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# STATION HUNTING – A SUMMARY

## Description

If a called extension is busy, Station Hunting redirects the incoming call to an idle extension within the same Extension Group.

Idle extensions are automatically searched for according to the pre-determined hunting type.

There are two hunting types available as follows:

### **Circular hunting:**

The extensions are searched in numerical order of the extension port physical numbers in a circular way until an idle one is found. (See "Extension Group – Station Hunting Group (Circular)" in Section 1.3 System Features of this Features Guide).

### **Termination hunting:**

The extensions are searched in numerical order of the extension port physical numbers in a linear way until reaching the extension with the highest physical numbered port in the group. (See "Extension Group – Station Hunting Group (Terminate)" in Section 1.3 System Features of this Features Guide).

One of the two hunting types is selected for each extension group.

## Timed Reminder (Wake-Up Call)

### Description

Each telephone can be set to generate an alarm tone at a preset time as a reminder. When this feature is set, an alarm tone will ring for 30 seconds (default) at the programmed time.

#### **Wake-up call**

If a voice message is recorded beforehand, a wake-up message is heard instead of an alarm tone when an extension user goes off-hook.

This feature can be activated only once or everyday at a specified time.

### Conditions

- **System Time**  
Be sure that the system clock is working correctly.  
System Time can be programmed either by User or System Programming.
- Setting a new time clears the preset time.
- **Timed Reminder Ringing Time**  
The alarm continues for a specific period of time (default: 30 seconds).  
This period of time can be changed by System Programming.
- **Hardware Requirements for a wake-up call**  
To utilise a wake-up call, DISA card (KX-T96191) is required.
- **OGM Recording**  
To utilise a wake-up call, set OGM Type of an OGM Group to "Wake-up."  
OGM Recording can be done only by the Manager or an Operator.
- **What if a wake-up message is not recorded?**  
An alarm tone is heard instead of a wake-up message.
- The number of extension users who can set this feature is not limited. However, the number of extension users who can hear the wake-up message at a time is limited to a maximum of 56 per DISA card.  
If the 57th or later extension user goes off-hook to hear the wake-up message, he or she will hear the alarm tone instead of the wake-up message.
- **Station Message Detail Recording (SMDR)**  
SMDR automatically records the detailed Timed Reminder information (date, time, extension number, start / no answer). It is programmable to be printed out when the Timed Reminder starts and the alarm is not answered.
- To stop the alarm, lift the handset or, with a PT, press any button.

### Installation Manual References

- 2.6.1 DISA Card (KX-T96191)



## Programming Guide References

- 2.3 Numbering Plan
  - Timed Reminder Confirm / Set / Cancel
- 2.5 System Timer
  - Timed Reminder Ringing Time
- 3.6 OGM Group
  - OGM Type
- 10.4 SMDR
  - Print out No Answer of Timed Reminder information
- 10.7 System Time

## Features Guide References

- 1.3 System Features
  - Outgoing Message (OGM)
- 1.8 Ringing Features
  - Timed Reminder, Remote (Wake-Up Call)

## User Manual References

- 2.7.1 Setting the Alarm (Timed Reminder)
- 4.3.1 Date and Time Set (000)

# Timed Reminder, Remote (Wake-Up Call)

## Description

Allows the Manager extension and the Operators to remotely set, cancel and confirm the wake-up call for an extension.

## Conditions

- Only the latest time setting is valid at the extension whether it was set by the extension user (Timed Reminder) or by the Manager or an Operator (Timed Reminder, Remote).
- **Station Message Detail Recording (SMDR)**  
SMDR automatically records the detailed Timed Reminder information (date, time, extension number, start / no answer). It is programmable by System Programming to be printed out when the Timed Reminder starts and the alarm is not answered. Please refer to "Station Message Detail Recording (SMDR)" in 1.3 System Features of the Features Guide for further information.

## Installation Manual References

- 2.6.1 DISA Card (KX-T96191)

## Programming Guide References

- 2.3 Numbering Plan
  - Timed Reminder, Remote
- 2.5 System Timer
  - Timed Reminder Ringing Time
- 3.6 OGM Group
  - OGM Type
- 10.4 SMDR
  - Print out No Answer of Timed Reminder information
- 10.7 System Time

## Features Guide References

- 1.3 System Features
  - Outgoing Message (OGM)
- 1.8 Ringing Features
  - Timed Reminder (Wake-Up Call)

## User Manual References

- 3.1.1 Setting the Alarm for Other Extensions (Remote Timed Reminder)
- 3.2.2 Recording Outgoing Messages
- 4.3.1 Date and Time Set (000)

# 1.9 Answering Features

## ANSWER and RELEASE buttons Operation

### Description

ANSWER and RELEASE buttons are useful when using the headset or in hands-free mode. With the ANSWER button, an extension user can answer all incoming calls. With the RELEASE button, an extension user can disconnect the line during or after a conversation or complete a Call Transfer.

### Conditions

- **ANSWER and RELEASE Buttons Assignment**  
ANSWER and RELEASE buttons are provided as a fixed button on the KX-T7441 (DSS Console). For other PTs and DSS Consoles, these buttons can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.
- **What if the ANSWER button is pressed during a call?**  
If a new call comes in while engaged in the current call, the extension user can answer it simply by pressing the ANSWER button.  
In this case, the current call will be disconnected.
- **Call Answering Priorities**  
If the ANSWER button is pressed when two or more calls are ringing on an extension at a time, the extension will be connected to one of them according to the following priorities:
  - (1)BSS (Busy Station Signalling ) calls
  - (2)Line Preference
  - (3)In the order of arrival
- **Delayed Ringing or No Ringing Calls**  
If a call which comes in on the extension is not ringing (Delayed Ringing or No Ring), it cannot be answered by pressing the ANSWER button.

### Programming Guide References

- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

### Features Guide References

None

## **User Manual References**

- 2.3.5 Using the ANSWER / RELEASE Button
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Answering, Direct Trunk

## Description

Allows the PT user to answer an incoming CO call simply by directly pressing a flashing CO button without lifting the handset or pressing the SP-PHONE / MONITOR button.

This feature permits the extension user to answer the desired line when multiple incoming CO calls are coming in on their extension.

## Conditions

None

## Programming Guide References

- 4.3 Extension Line
  - CO Key

## Features Guide References

None

## User Manual References

- 2.3.1 Answering Calls
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## CALL PICKUP – A SUMMARY

### Description

Allows an extension user to answer a call ringing at another extension.

This feature can be categorised as the following three types:

- Call Pickup – CO Line
- Call Pickup – Directed
- Call Pickup – Group

### Conditions

The following conditions apply to all Call Pickup features.

- A confirmation tone is sent to the extension user who picked up the call. Eliminating the tone is programmable.
- This feature is not available to answer the following calls:
  - a call ringing at an extension in "Call Pickup Deny" mode
  - a call which shows the call arrival indication but is not ringing yet (Delayed Ringing).

# Call Pickup – CO Line

## Description

Allows the extension user to answer an outside call ringing at another extension in the system simply by dialling the appropriate feature number. There is no need to specify the extension number and the CO line number.

## Conditions

- **Tenant Service**  
If "Tenant Service" is utilised, this feature is only available for an outside call ringing on an extension within the same tenant.
- Call Pickup starts with the lowest physical number CO.
- **Call Waiting**  
This feature does not apply to a call waiting call.
- **Confirmation tone**  
Confirmation tone is sent to the extension user who picked up the call. Eliminating the tone is programmable.

## Programming Guide References

- 2.3 Numbering Plan
  - CO Call Pickup
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve

## Features Guide References

- 1.9 Answering Features
  - Call Pickup Deny

## User Manual References

- 2.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)

# Call Pickup – Directed

## Description

Allows the extension user to answer a call (intercom, outside, doorphone) ringing at any other extension in the system by specifying the extension number.

## Conditions

- **Tenant Service**  
If "Tenant Service" is utilised, this feature is only available for the calls ringing on an extension within the same tenant.
- **Doorphone call**  
Doorphone calls can be picked up from extensions that are not programmed to answer doorphone calls.
- **Call Waiting**  
This feature applies to a call waiting call.
- **Confirmation tone**  
Confirmation tone is sent to the extension user who picked up the call. Eliminating the tone is programmable.

## Programming Guide References

- 2.3 Numbering Plan
  - Directed Call Pickup
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve

## Features Guide References

- 1.9 Answering Features
  - Call Pickup Deny

## User Manual References

- 2.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)



# Call Pickup – Group

## Description

Allows the extension user to answer a call (intercom, outside, doorphone) ringing at another extension within the same Extension Group.

## Conditions

- **Group Call Pickup Priority:**  
Outside call > Transferred call > Extension call > Doorphone call

If more than one call is ringing on an extension, Call Pickup to that extension works for the first arrived call.

- **Call Waiting Call**  
This feature does not apply to a call waiting call.
- **Confirmation tone**  
Confirmation tone is sent to the extension user who picked up the call. Eliminating the tone is programmable.

## Programming Guide References

- 2.3 Numbering Plan
  - Group Call Pickup
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve
- 3.3 Extension Group

## Features Guide References

- 1.3 System Features
  - EXTENSION GROUP – A SUMMARY
- 1.9 Answering Features
  - Call Pickup Deny

## User Manual References

- 2.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)

# Call Pickup Deny

## Description

Allows the extension user to prevent other extensions from picking up calls ringing at his / her extension using the Call Pickup features.

## Conditions

- This feature does not apply to calls coming in on multiple extensions simultaneously.
- **Distinctive Dial Tone**  
Distinctive Dial Tone is sent to the user on the extension with this feature when the user goes off-hook.
- An extension user in "Call Pickup Deny" mode can pick up calls ringing at another extension.

## Programming Guide References

- 2.3 Numbering Plan
  - Dial Call Pickup Deny Set / Cancel
- 2.8 System Option
  - Special dial tone after setting feature

## Features Guide References

- 1.9 Answering Features
  - Call Pickup – CO Line
  - Call Pickup – Directed
  - Call Pickup – Group

## User Manual References

- 2.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)
- 2.7.8 Denying Other People the Possibility of Picking up Your Calls (Call Pickup Deny)

# Call Waiting

## Description

Used to inform a busy extension that another call is waiting. The busy extension can answer the second call by disconnecting the current call or placing it on hold. This feature can be activated or deactivated by dialling the appropriate feature number.


## Conditions

- The Call Waiting tone is generated at the busy extension which is engaged in a call (extension, outside, conference), when an outside call or a doorphone call comes in on the busy extension or when another extension caller executes Busy Station Signalling (BSS) to the busy extension.

- Call Waiting Tone Selection**

For PT users, two types of call waiting tones (shown below) are provided to prevent them from missing the tone.

A Call Waiting Tone type can be selected either by Station or System Programming.



- BSS / OHCA / Whisper OHCA**

If an extension user dials "1" while hearing a busy tone, BSS or OHCA or Whisper OHCA may be activated at the called extension.

This is determined by the following conditions.

Calling extension	Called extension			
COS-OHCA assignment	Call Waiting setting			
	OFF	ON		
	0	1	2	3
Disable	_____	BSS	BSS	BSS
Enable	_____	BSS	OHCA <sup>*1</sup> →BSS	W-OHCA <sup>*2</sup> →OHCA→BSS

\*1 OHCA (Off-Hook Call Announcement) is activated when the called extension is KX-T7130, KX-T7235 or KX-T7436.

\*2 Whisper OHCA is activated when both calling and called extensions are using one of the KX-T7400 series PT.

- **Data Line Security**  
Setting Data Line Security temporarily cancels Call Waiting which has been turned on by an extension user.
- BSS, OHCA and Whisper OHCA do not function at a DN type PT.
- "Call Waiting" does not function, when only one PDN button is assigned on a DN type PT.

## Programming Guide References

- 2.3 Numbering Plan
  - Call Waiting Set / Cancel
- 2.4 Class of Service (COS)
  - Off-Hook Call Announcement (OHCA)
- 4.3 Extension Line
  - Call Waiting Tone Type

## Features Guide References

- 1.6 Originating Features
  - Busy Station Signalling (BSS)
  - Off-Hook Call Announcement (OHCA)
  - Off-Hook Call Announcement (OHCA), Whisper
- 1.12 Conversation Features
  - Data Line Security
- 1.13 Audible Tone Features
  - Ringing, Delayed

## User Manual References

- 2.4.4 Answering a Call Waiting
- 4.1.1 Initial Settings

# Call Waiting from Central Office

## Description

During a conversation, a call waiting tone offered by the local Central Office informs the extension user of another incoming call that is waiting. He or she can answer the new call by placing the current call on hold.

## Conditions

- This is an optional telephone company service. For more information, consult the local telephone company.

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

- 2.4.4 Answering a Call Waiting

# Executive Busy Override Deny

## Description

Allows the extension user to prevent his / her extension from being interrupted by "Executive Busy Override" from another extension user.

## Conditions

- **Class of Service**  
Class of Service programming determines the extension that can perform this feature.

## Programming Guide References

- 2.3 Numbering Plan
  - Executive Override Deny Set / Cancel
- 2.4 Class of Service (COS)
  - Busy Override Deny

## Features Guide References

- 1.6 Originating Features
  - Executive Busy Override — Barge-in
  - Executive Busy Override — Extension

## User Manual References

- 2.2.4 When the Dialed Line is Busy or There is No Answer
- 2.7.9 Denying Other People the Possibility of Joining Your Conversation (Executive Busy Override Deny)

# Hands-free Answerback

## Description

Allows the PT (with SP-PHONE) user to answer an intercom call and talk to the caller without lifting the handset.

When an intercom call comes in on an extension in Hands-free Answerback mode, the speakerphone is turned on automatically and hands-free conversation is established immediately after the called extension hears a beep tone and the caller hears a confirmation tone.

## Conditions

- **AUTO ANSWER / MUTE Button**  
Hands-free answerback mode can be turned on / off by pressing the AUTO ANSWER / MUTE button.
- This feature does not work for the following calls:
  - CO calls
  - Doorphone calls
  - Calls to a Ring Group
  - Calls to a Phantom button
  - Calls from a VM (Voice Mail) extension
  - Calls ringing on an SDN button
- **Ring / Voice Intercom Alerting Mode Override**  
Hands-free Answerback set on a telephone overrides "Ring / Voice Intercom Alerting mode" preset on the extension; Hands-free conversation mode is established immediately after a confirmation tone is sent.

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.6 Originating Features
  - Alternate Calling – Ring / Voice

## User Manual References

- 2.3.2 Answering Hands-free (Hands-free Answerback)

## Line Preference — Incoming (No Line / Prime Line / Ringing Line)

### Description

A PT user can select the method used to answer incoming calls from the following three line preferences:

**a) No Line Preference**

No line is selected when an extension user goes off-hook to answer a call. He or she must press a desired Line Access button to answer an incoming call.

**b) Prime Line Preference**

An extension user can assign a prime line beforehand and answer a call ringing on that line simply by lifting the handset, even when multiple calls are ringing on his or her extension simultaneously.

A Prime Line can be selected from the following line access buttons.

<ICM type PT>

ICM, S-CO, G-CO, L-CO

<DN type PT>

PDN, SDN, S-CO, G-CO, L-CO

**c) Ringing Line Preference (default)**

An extension user can answer the call ringing at his or her extension simply by going off-hook.

### Conditions

- Setting a new line preference feature cancels the previous setting.
- If "Prime Line Preference" is selected, an incoming call coming from a line other than the prime line cannot be answered just by going off-hook. To answer the call, the extension user must press the flashing button associated with the ringing line.
- **Delayed Ringing**  
If "Ringing Line Preference" is selected, going off-hook does not answer a line programmed for "no ring" even though there is an incoming call. Going off-hook during the delay time does not answer a line programmed for "delayed ringing."
- **<SLT>**  
An SLT is fixed to Ringing Line Preference mode.

### Programming Guide References

- 4.3 Extension Line
  - CO Key
  - [Preferred Line] Incoming

### Features Guide References

None



## User Manual References

- 2.3.1 Answering Calls
- 4.1.1 Initial Settings
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## Live Call Screening (LCS)\*<sup>1</sup>

### Description

This is one of the DPT Integration features.

Allows the PT user to monitor his / her voice mailbox while a caller is leaving a message in it. The extension user can intercept the recording in order to talk with the caller. The voice mailbox can be monitored in one of the following two ways:


#### **Hands-Free Mode**

When a caller starts to record a message, the caller's voice is heard through the built-in speaker of a PT automatically; the extension user can talk to the caller by going off-hook.

#### **Private Mode**

When a caller starts to record a message, a notification tone is emitted by the DPT. The extension user can monitor the caller's voice by going off-hook.

#### **Notification Tone**



To intercept the call in either Hands-Free or Private mode, press the LCS button.

### Conditions

- **Call Waiting**  
If the extension user is busy on a call when a caller begins to leave a message, a call waiting tone is sent (if programmed beforehand). The extension user can put the current call on hold before accessing LCS.
- **LCS button / LCS Cancel button**  
LCS / LCS Cancel button can be assigned to a flexible (CO, DSS) button by Station, User or System Programming.
- **LCS Password Clear**  
To prevent unauthorised monitoring, a 3-digit password must be set by the extension user. If the extension user forgets his / her password, it can be cleared by the Manager or an Operator.
- **Recording mode**  
Each extension can be programmed to either stop or continue recording the conversation after intercepting the recording in order to talk with the caller.
- **LCS by an SLT (only in Private Mode)**  
A single line telephone, which is connected with a proprietary telephone in parallel, can also be used to monitor a recording message. Be sure that Live Call Screening has been activated on the connected proprietary telephone.  
This feature is useful when you are out with a portable handset of a cordless telephone

---

\*<sup>1</sup> Available when the Digital Super Hybrid System is connected to a Digital Proprietary Telephone capable Panasonic Voice Processing System (one that supports Digital Proprietary Telephone integration; e.g. KX-TVP100).

(SLT). The handset sounds an alert tone to let you know that a message is being recorded. To intercept the call, flash the switchhook.

## **Programming Guide References**

- 2.3 Numbering Plan
  - Live Call Screening
- 4.3 Extension Line
  - [LCS Setting] Status
  - [LCS Setting] Operation Mode
  - [LCS Setting] Recording Mode
  - [LCS Setting] LCS Password
  - CO Key
- 4.4 DSS Console
  - DSS Key

## **Features Guide References**

- 1.3 System Features
  - VPS Integration – DPT Integration

## **User Manual References**

- 2.8.3 If a Voice Processing System is Connected
- 4.1.1 Initial Settings
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## 1.10 Holding Features

### Automatic Hold – All Calls

#### Description

Allows the PT user engaged in a call (both extension and outside) to hold the current call and get a new line for transfer with a single operation.

This simplifies the transfer operation by eliminating the need for pressing the TRANSFER button.

The PT user engaged in a call can also answer a new incoming call without losing the current call by pressing the CO / DN (on which the call is coming) button. Then the current call is placed on consultation hold automatically.

Buttons / operation available for this feature are:

DSS<sup>\*1</sup>, SCO, GCO, LCO, PDN, SDN, Phantom<sup>\*1</sup>, direct dial

This feature is convenient for extension users, such as Operators, who handle a large volume of calls.

#### Conditions

- COS (Class of Service) programming determines the extension that can perform this feature.
- If this feature is not allowed by COS programming, the current call will be disconnected by pressing an idle button, or dialling the extension number. "Automatic Hold – Trunk" is not available for all extension users by default.
- It is possible to return to the held party by pressing the corresponding button.

#### Programming Guide References

- 2.4 Class of Service (COS)
  - Automatic Hold

#### Features Guide References

- 1.10 Holding Features
  - Automatic Hold – Trunk
- 1.11 Transferring Features
  - One-Touch Transfer

#### User Manual References

Not applicable.

---

<sup>\*1</sup> One-Touch Transfer will be activated.

# Automatic Hold – Trunk

## Description

Allows the PT user engaged in a CO call to hold the current call and get a new line with a single operation.

This feature can be categorised as the following two types:

### **Automatic Hold - Trunk (CO)**

Allows the PT user engaged in a CO call to hold the current call and get another CO line for making or answering purpose with a single operation.

### **Automatic Hold - Trunk (DSS)**

Allows the PT user engaged in a CO call to transfer the current call to another extension simply by pressing the DSS button associated with that extension.

Refer to "One-Touch Transfer" in this manual.

## Conditions

- This feature is enabled / disabled on a system-wide basis.
- If Automatic Hold for DSS is disabled, pressing DSS button disconnects the current call. (Default=Hold)
- If Automatic Hold for CO is disabled, pressing CO button disconnects the current call. (Default=Hold)
- It is possible to return to the held party by pressing the corresponding CO button.

## Programming Guide References

- 2.8 System Option
  - Pressing DSS key operation in CO talking
  - Pressing CO key operation in CO talking

## Features Guide References

- 1.10 Holding Features
  - Automatic Hold – All Calls
- 1.11 Transferring Features
  - One-Touch Transfer

## User Manual References

Not applicable.

# Call Hold – Station

## Description

Allows the extension user to put an intercom call on hold. The held call can be retrieved from any extension in the same tenant.

## Conditions

- **Music on Hold**  
"Music on Hold" is sent to the party on hold, if available.
- **What if a call on hold is not retrieved?**  
If a call on hold is not retrieved in a specified period of time (Hold Recall Time), Hold Recall tone (if the extension is on-hook) or Hold Warning tone (if engaged in another call) rings the extension where the call is held.
- **Automatic Disconnection**  
If a call placed on hold is not retrieved within 30 minutes, it is automatically disconnected.
- **How many intercom calls can be held?**  
The number of intercom calls that can be held on an extension at a time differs depending on the telephone type as follows:
  - < ICM type PT>, < SLT>  
one
  - < DN type PT>  
as many intercom calls as the number of DN (PDN, SDN) buttons on it

## Programming Guide References

- 2.2 Tenant
  - Music on Hold Source
- 2.3 Numbering Plan
  - Hold
- 2.5 System Timer
  - Hold Recall Time

## Features Guide References

- 1.3 System Features
  - Music on Hold
- 1.10 Holding Features
  - Call Hold Retrieve – Station
  - Call Park
- 1.13 Audible Tone Features
  - Hold Recall

## User Manual References

- 2.4.1 Holding a Call

# Call Hold – Trunk

## Description

Allows the extension user to put an outside call (CO, TIE) on hold. The held call can be retrieved from any extension.

## Conditions

- **Music on Hold**  
"Music on Hold" is sent to the party on hold, if available.
- **What if a call on hold is not retrieved?**  
If a call on hold is not retrieved in a specified period of time (Hold Recall Time), Hold Recall tone (if the extension is on-hook) or Hold Warning tone (if engaged in another call) rings the extension where the call is held.
- **Automatic Disconnection**  
If an outside call placed on hold is not retrieved within 30 minutes, it is automatically disconnected.
- **How many outside calls can be held?**  
The number of outside calls that can be held on an extension at a time differs depending on the telephone type as follows:
  - < ICM type PT>  
as many outside calls as the number of CO buttons on it
  - < DN type PT>  
as many outside calls as the number of CO buttons and DN buttons on it
  - <SLT>  
one

## Programming Guide References

- 2.2 Tenant
  - Music on Hold Source
- 2.3 Numbering Plan
  - Hold
- 2.5 System Timer
  - Hold Recall Time

## Features Guide References

- 1.3 System Features
  - Music on Hold
- 1.10 Holding Features
  - Call Hold Retrieve – Trunk
  - Call Park
- 1.13 Audible Tone Features
  - Hold Recall



## User Manual References

- 2.4.1 Holding a Call

## Call Hold Retrieve – Station

### Description

Allows the extension user to retrieve a call held at other extensions by specifying the extension number.

### Conditions

- **Confirmation Tone**  
A Confirmation tone is sent to the extension user who retrieved the held call. Eliminating the tone is programmable.
- The extension user cannot retrieve the following calls.
  - Unattended Conference Calls
  - Calls held at the System Call Parking Area
  - Calls placed on Exclusive Hold
- **Tenant Service**  
If "Tenant Service" is utilised, this feature is only available within the same tenant.

### Programming Guide References

- 2.3 Numbering Plan
  - Hold Retrieve - Station
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve

### Features Guide References

- 1.10 Holding Features
  - Call Hold – Station

### User Manual References

- 2.4.1 Holding a Call

# Call Hold Retrieve – Trunk

## Description

Allows the extension user to retrieve a specific outside call (CO, TIE) held at other extensions including a call on Consultation Hold by specifying the trunk number.

## Conditions

- **Confirmation Tone**  
A confirmation tone is sent to the extension user who retrieved the held call. Eliminating the tone is programmable.
- The extension user cannot retrieve the following calls.
  - Unattended Conference Calls
  - Calls held at the System Call Parking Area
  - Calls placed on Exclusive Hold
- **Tenant Service**  
If "Tenant Service" is utilised, this feature is only available for outside calls placed on hold at an extension within the same tenant.

## Programming Guide References

- 2.3 Numbering Plan
  - Hold Retrieve - Trunk
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve

## Features Guide References

- 1.10 Holding Features
  - Call Hold – Trunk

## User Manual References

- 2.4.1 Holding a Call

## Call Hold, Exclusive – Station

### Description

Allows the PT user to prevent any other extension users from retrieving a held intercom call. A call on Exclusive Hold can only be retrieved from the extension on which it is held.

### Conditions

- **Music on Hold**  
"Music on Hold" is sent to the party on hold, if available.
- **What if a call on Exclusive Hold is not retrieved?**  
If a call on Exclusive Hold is not retrieved in a specified period of time (Hold Recall Time), Hold Recall tone (if the extension is on-hook) or Hold Warning tone (if engaged in another call) rings the extension where the call is held. After this, the held call can be retrieved from any extension.
- **Automatic Disconnection**  
If a call placed on hold is not retrieved within 30 minutes, it is automatically disconnected.
- **How many intercom calls can be put on Exclusive Hold?**  
The number of intercom calls that can be placed on Exclusive Hold on an extension at a time differs depending on the telephone type as follows :
  - <ICM type PT >  
One
  - <DN type PT>  
as many intercom calls as the number of DN (PDN, SDN) buttons on it
  - < SLT>  
Not available

### Programming Guide References

- 2.2 Tenant
  - Music on Hold Source
- 2.3 Numbering Plan
  - Hold
- 2.5 System Timer
  - Hold Recall Time

### Features Guide References

- 1.3 System Features
  - Music on Hold
- 1.13 Audible Tone Features
  - Hold Recall

## User Manual References

- 2.4.1 Holding a Call

## Call Hold, Exclusive – Trunk

### Description

Allows the PT user to prevent any other extension users from retrieving a held outside call (CO, TIE). A call on Exclusive Hold can only be retrieved from the extension on which it is held.

### Conditions

- **Music on Hold**  
"Music on Hold" is sent to the party on hold, if available.
- **What if a call on Exclusive Hold is not retrieved?**  
If a call on Exclusive Hold is not retrieved in a specific period of time (Hold Recall Time), Hold Recall (if the extension is on-hook) or Hold Warning tone (if engaged in another call) rings the extension where the call is held. After this, the held call can be retrieved from any other extension.
- **Automatic Disconnection**  
If an outside call placed on hold is not retrieved in 30 minutes, it is automatically disconnected.
- **How many outside calls can be put on Exclusive Hold?**  
The number of outside calls that can be placed on Exclusive Hold on an extension at a time differs depending on the telephone type as follows :
  - <ICM type PT >  
as many outside calls as the number of CO buttons on it
  - <DN type PT>  
as many outside calls as the number of CO buttons and DN buttons on it
  - < SLT>  
Not available

### Programming Guide References

- 2.2 Tenant
  - Music on Hold Source
- 2.3 Numbering Plan
  - Hold
- 2.5 System Timer
  - Hold Recall Time

### Features Guide References

- 1.3 System Features
  - Music on Hold
- 1.13 Audible Tone Features
  - Hold Recall

## User Manual References

- 2.4.1 Holding a Call

# Call Park

## Description

Allows the extension user to place a call on hold into a system parking area so that any extension user can retrieve the call. This releases the user from the parked call to perform other operations.

## Conditions

- Up to 100 parking areas, numbered from 00 to 99, are available in the system by default. Up to 800 calls can be parked at the same time in the system.
- **Tenant Service**  
If "Tenant Service" is employed, each tenant can use up to 100 parking areas independently.
- **Call Park Recall**  
If a parked call is not retrieved in a specific period of time, Call Park Recall rings back the extension who parked the call.
- **Automatic Disconnection**  
If a parked call is not retrieved in 30 minutes, it is automatically disconnected.
- **Confirmation Tone**  
A confirmation tone is sent to the extension user who retrieved the parked call. Eliminating the tone is programmable.

## Programming Guide References

- 2.3 Numbering Plan
  - Call Park / Call Park Retrieve
- 2.5 System Timer
  - Call Parking Recall Time
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve

## Features Guide References

None

## User Manual References

- 2.4.1 Holding a Call



# Call Splitting

## Description

When there are two active calls on an extension, an extension user can talk either one of them alternately.

## Conditions

- This feature does not work for the following calls:
  - Doorphone call
  - Paging

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

- 2.4.2 Talking to Two Parties Alternately (Call Splitting)

# Consultation Hold

## Description

Allows an extension user to place a call on hold temporarily on purpose to transfer it, to make a Conference call, or to perform Call Splitting.

**A PT user** can place a call on Consultation Hold by pressing TRANSFER or CONF button.

**An SLT user** can place a call on Consultation Hold by pressing the switchhook lightly only to transfer it.

## Conditions

- The following calls cannot be placed on Consultation Hold.
  - Doorphone calls
  - Paging
- <ICM type PT>  
A new incoming call will not come in on the extension which has a call on Consultation Hold. The extension is regarded as busy.
- **Music on Hold**  
When a call (extension / outside) is placed on Consultation Hold, Music on Hold is sent to the caller, if available.
- **Hold Recall**  
If a call on hold is not retrieved in a specific period of time, Hold Recall starts.
- **Automatic Disconnection**  
If a call (extension / outside) placed on consultation hold is not retrieved in 30 minutes, it is disconnected automatically.

## Programming Guide References

- 2.5 System Timer
  - Hold Recall Time
- 2.8 System Option
  - SLT On-hook with consulting held call

## Features Guide References

- 1.3 System Features
  - Music on Hold
- 1.10 Holding Features
  - Call Splitting
- 1.11 Transferring Features
  - Call Transfer – to CO
  - Call Transfer, Screened – to Station
  - Call Transfer, Unscreened – to Station

1.12 Conversation Features

- Conference
- Conference, Unattended

## **User Manual References**

Not applicable.

## 1.11 Transferring Features

### CALL FORWARDING – A SUMMARY

#### Description

Provides automatic redirection of incoming calls to the pre-assigned destination (extension or outside party).

Call Forwarding features can be categorised as follows:

- Call Forwarding – All Calls
- Call Forwarding – Busy
- Call Forwarding – Busy / No Answer
- Call Forwarding – Follow Me
- Call Forwarding – No Answer
- Call Forwarding – to CO / TIE

#### Conditions

# Call Forwarding – All Calls

## Description

All incoming calls to an extension are automatically redirected to the pre-assigned extension regardless of the status of the called extension.

## Conditions

- **Applicable Call Types**

This feature applies to the following calls:

Outside calls — DIL 1:1; DISA; Intercept Routing; TIE; DID; DDI; MSN

Intercom calls — Extension; Transfer

- **Floating Station**

A Floating Station cannot be programmed as the destination of this feature.

- **Forwarded call is not forwarded furthermore**

There can be only one stage of Call Forwarding. If a call is forwarded to an extension in Call Forwarding mode, the call is not forwarded furthermore.

- **Message Waiting**

Although calls are forwarded, Message Waiting is not. The MESSAGE button indicator is lit on the originally called extension.

- **Station Hunting**

Station Hunting applies to calls forwarded to a busy extension in a Station Hunting group.

- An extension user may have only one type of Call Forwarding / Do Not Disturb feature in effect at any time. If one of Call Forwarding / Do Not Disturb feature is assigned, another does not function but the assignment itself is preserved for future use. The extension user can choose either one by pressing the FWD / DND button while on-hook.

In this case, pressing the button changes the settings as follows:



The lighting patterns of the FWD / DND button are as follows:

Off : Both functions are cancelled.

Red flash : FWD mode  This setting can be changed

Red on : DND mode  by System Programming.

- **Station Programming mode**

This feature functions even if the extension is in Station Programming mode.

- **Remote FWD (Call Forwarding) Cancel - Once**

The Manager and the Operators can reach an extension that has set Call Forwarding.

- **FWD / DND button**

Regarding the PT (KX-T7250) without the FWD / DND button, it can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.

- **Distinctive Dial Tone**

Distinctive Dial Tone is sent to the user on the extension with this feature when the extension user goes off-hook.

## **Programming Guide References**

- 2.3 Numbering Plan
  - Call FWD - Do Not Disturb Set / Cancel
- 2.8 System Option
  - Special dial tone after setting feature
  - FWD / DND lamp pattern
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## **Features Guide References**

None

## **User Manual References**

- 2.5.1 Forwarding Your Calls (Call Forwarding)
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Call Forwarding – Busy

## Description

Incoming calls to an extension are re-directed to the pre-assigned extension if the called extension is busy.

## Conditions

- **Applicable Call Types**

This feature applies to the following calls:

Outside calls — DIL 1:1; DISA; Intercept Routing; TIE; DID; DDI; MSN

Intercom calls — Extension; Transfer

- **Floating Station**

A Floating Station cannot be programmed as the destination of this feature.

- **Forwarded call is not forwarded furthermore**

There can be only one stage of Call Forwarding. If a call is forwarded to an extension in Call Forwarding mode, the call is not forwarded furthermore.

- **Message Waiting**

Although calls are forwarded, Message Waiting is not. The MESSAGE button indicator is lit on the originally called extension.

- **Station Hunting**

Station Hunting applies to calls forwarded to a busy extension in a Station Hunting group.

- An extension user may have only one type of Call Forwarding / Do Not Disturb feature in effect at any time. If one of Call Forwarding / Do Not Disturb feature is assigned, another does not function but the assignment itself is preserved for future use. The extension user can choose either one by pressing the FWD / DND button while on-hook.

In this case, pressing the button changes the settings as follows:



The lighting patterns of the FWD / DND button are as follows:

Off : Both functions are cancelled.

Red flash : FWD mode  This setting can be changed

Red on : DND mode  by System Programming.

- **Station Programming mode**

This feature functions even if the extension is in Station Programming mode.

- **Remote FWD (Call Forwarding) Cancel - Once**

The Manager and the Operators can reach an extension that has set Call Forwarding.

- **FWD / DND button**

Regarding the PT (KX-T7250) without the FWD / DND button, it can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.

- **Distinctive Dial Tone**

Distinctive Dial Tone is sent to the user on the extension with this feature when the extension user goes off-hook.

## **Programming Guide References**

- 2.3 Numbering Plan
  - Call FWD - Do Not Disturb Set / Cancel
- 2.8 System Option
  - Special dial tone after setting feature
  - FWD / DND lamp pattern
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## **Features Guide References**

None

## **User Manual References**

- 2.5.1 Forwarding Your Calls (Call Forwarding)
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)



# Call Forwarding – Busy / No Answer

## Description

Incoming calls to an extension are re-directed to the pre-assigned extension if the called extension is busy or the call was not answered within a pre-determined time.

## Conditions

- **Applicable Call Types**

This feature applies to the following calls:

Outside calls — DIL 1:1; DISA; Intercept Routing; TIE; DID; DDI; MSN

Intercom calls — Extension; Transfer

- **Floating Station**

A Floating Station cannot be programmed as the destination of this feature.

- This feature operates the same way as Call Forwarding — Busy and Call Forwarding — No Answer.

- **Forwarded call is not forwarded furthermore**

There can be only one stage of Call Forwarding. If a call is forwarded to an extension in Call Forwarding mode, the call is not forwarded furthermore.

- **Message Waiting**

Although calls are forwarded, Message Waiting is not. The MESSAGE button indicator is lit on the originally called extension.

- **Station Hunting**

Station Hunting applies to calls forwarded to a busy extension in a Station Hunting group.

- An extension user may have only one type of Call Forwarding / Do Not Disturb feature in effect at any time. If one of Call Forwarding / Do Not Disturb feature is assigned, another does not function but the assignment itself is preserved for future use. The extension user can choose either one by pressing the FWD / DND button while on-hook.

In this case, pressing the button changes the settings as follows:



The lighting patterns of the FWD / DND button are as follows:

Off : Both functions are cancelled.

Red flash : FWD mode  This setting can be changed by System Programming.

Red on : DND mode 

- **Station Programming mode**

This feature functions even if the extension is in Station Programming mode.

- **Remote FWD (Call Forwarding) Cancel - Once**

The Manager and the Operators can reach an extension that has set Call Forwarding.

- **FWD / DND button**

Regarding the PT (KX-T7250) without the FWD / DND button, it can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.

- **Distinctive Dial Tone**

Distinctive Dial Tone is sent to the user on the extension with this feature when the extension user goes off-hook.

### Programming Guide References

- 2.3 Numbering Plan
  - Call FWD - Do Not Disturb Set / Cancel
- 2.5 System Timer
  - Call Forwarding- No Answer Time
- 2.8 System Option
  - Special dial tone after setting feature
  - FWD / DND lamp pattern
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

### Features Guide References

- 1.11 Transferring Features
  - Call Forwarding – Busy
  - Call Forwarding – No Answer

### User Manual References

- 2.5.1 Forwarding Your Calls (Call Forwarding)
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Call Forwarding – Follow Me

## Description

If you forget to set Call Forwarding — All Calls before you leave your desk, you can set the same function from the destination extension.

## Conditions

- **Class of Service**  
Class of Service programming determines the extension that can perform this feature.
- Other conditions are the same as that of Call Forwarding — All Calls.

## Programming Guide References

- 2.3 Numbering Plan
  - Call FWD - Do Not Disturb Set / Cancel
- 2.4 Class of Service (COS)
  - Call FWD Follow me
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## Features Guide References

- 1.11 Transferring Features
  - Call Forwarding – All Calls

## User Manual References

- 2.5.1 Forwarding Your Calls (Call Forwarding)
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## Call Forwarding – No Answer

### Description

Incoming calls to an extension are re-directed to the pre-assigned extension if they are not answered within a specified period of time.

### Conditions

- **Applicable Call Types**

This feature applies to the following calls:

Outside calls — DIL 1:1; DISA; Intercept Routing; TIE; DID; DDI; MSN

Intercom calls — Extension; Transfer

- **Floating Station**

A Floating Station cannot be programmed as the destination of this feature.

- **Call Forwarding-No Answer Time**

This feature operates if an incoming call is not answered (including a busy status) in a specified period of time (Call Forwarding-No Answer Time).

- **Forwarded call is not forwarded furthermore**

There can be only one stage of Call Forwarding. If a call is forwarded to an extension in Call Forwarding mode, the call is not forwarded furthermore.

- **Message Waiting**

Although calls are forwarded, Message Waiting is not. The MESSAGE button indicator is lit on the originally called extension.

- **Station Hunting**

Station Hunting applies to calls forwarded to a busy extension in a Station Hunting group.

- An extension user may have only one type of Call Forwarding / Do Not Disturb feature in effect at any time. If one of Call Forwarding / Do Not Disturb feature is assigned, another does not function but the assignment itself is preserved for future use. The extension user can choose either one by pressing the FWD / DND button while on-hook.

In this case, pressing the button changes the settings as follows:



The lighting patterns of the FWD / DND button are as follows:

Off : Both functions are cancelled.

Red flash : FWD mode

Red on : DND mode



This setting can be changed  
by System Programming.

- **Remote FWD (Call Forwarding) Cancel - Once**

The Manager and the Operators can reach an extension that has set Call Forwarding.

- **FWD / DND button**

Regarding the PT (KX-T7250) without the FWD / DND button, it can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.

- **Distinctive Dial Tone**

Distinctive Dial Tone is sent to the user on the extension with this feature when the extension user goes off-hook.

## Programming Guide References

- 2.3 Numbering Plan
  - Call FWD - Do Not Disturb Set / Cancel
- 2.5 System Timer
  - Call Forwarding- No Answer Time
- 2.8 System Option
  - Special dial tone after setting feature
  - FWD / DND lamp pattern
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## Features Guide References

None

## User Manual References

- 2.5.1 Forwarding Your Calls (Call Forwarding)
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Call Forwarding – to CO / TIE

## Description

All incoming calls to an extension are automatically re-directed to the pre-assigned outside party via a CO line or a TIE line regardless of the status of the called extension.

## Conditions

- **Applicable Call Types**

This feature applies to the following calls:

Outside calls — DIL 1:1; DISA; TIE; DID; DDI; MSN

Intercom calls — Extension; Transfer

- **Class of Service**

Class of Service programming determines the extensions that can perform this feature.

- **Treatment of the forwarded call**

Toll Restriction, Automatic Route Selection (ARS) and Account Code Entry requirements of the extension in Call Forwarding mode still apply to the call forwarded by this feature.

- An extension user may have only one type of Call Forwarding / Do Not Disturb feature in effect at any time. If one of Call Forwarding / Do Not Disturb feature is assigned, another does not function but the assignment itself is preserved for future use. The extension user can choose either one by pressing the FWD / DND button while on-hook.

In this case, pressing the button changes the settings as follows:



The lighting patterns of the FWD / DND button are as follows:

Off : Both functions are cancelled.

Red flash : FWD mode  This setting can be changed

Red on : DND mode  by System Programming.

- **Extension-to-CO Line Call**

If a call between an extension and an outside party is established by this feature, the call duration can be restricted by the system timer "Extension-to-CO Line Call Duration Time (1-64 min)."

- **CO-to-CO Line Call**

If a call between two outside parties is established by this feature, the call duration is determined by "CO-to-CO Line Call Duration Time (1-64 min)." An alarm tone is sent to both outside parties 15 seconds before the time-out. The call is disconnected at the time-out.

- **Remote FWD (Call Forwarding) Cancel - Once**

The Manager and the Operators can reach an extension that has set Call Forwarding.

- **FWD / DND button**

Regarding the PT (KX-T7250) without the FWD / DND button, it can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.

- **Distinctive Dial Tone**

Distinctive Dial Tone is sent to the user on the extension with this feature when the extension user goes off-hook.

## Programming Guide References

- 2.3 Numbering Plan
  - Call FWD - Do Not Disturb Set / Cancel
- 2.4 Class of Service (COS)
  - Time Limit of Outside Calls
  - Call FWD to CO
  - Trunk Group Setting
- 2.5 System Timer
  - Extension-to-CO Line Call Duration Time
  - CO-to-CO Line Call Duration Time
- 2.7 Trunk to Trunk Restriction
- 2.8 System Option
  - Special dial tone after setting feature
  - FWD / DND lamp pattern
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## Features Guide References

- Limited Call Duration

## User Manual References

- 2.5.1 Forwarding Your Calls (Call Forwarding)
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## CALL TRANSFER – A SUMMARY

### Description

Call Transfer allows the extension user to transfer a call (Intercom, CO, TIE) to another party (extension or outside party).

Call Transfer can be performed in one of the following two ways:

#### **Screened Call Transfer**

An extension user can transfer a call after announcing it to the destination party.

#### **Unscreened Call Transfer**

An extension user can transfer a call without announcing it.

Call Transfer feature can be categorised as follows:

- Call Transfer – to CO
- Call Transfer, Screened – to Station
- Call Transfer, Screened – to TIE
- Call Transfer, Unscreened – to Station
- Call Transfer, Unscreened – to TIE



# Call Transfer – to CO

## Description

Allows an extension user to transfer a call (intercom, CO, TIE) to an outside party via CO line.

## Conditions

- **Class of Service**  
Class of Service programming determines the extensions that can perform this feature.
- **CO-to-CO call**  
If a CO call is transferred to an outside party, "CO-to-CO call" is established and the call duration is restricted by a system timer "CO-to-CO Line Call Duration Time (1-64 min)."  
Hold Recall tone  
Hold Recall tone is generated to the extension who transferred the call 50 seconds before the time-out.  
Hold Alarm tone  
Hold Alarm tone is generated to both outside parties 15 seconds before the time-out. The call is disconnected at the time-out unless the extension user (who transferred the call) joins the CO-to-CO call to establish a conference call.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Trunk Group Setting
  - Transfer to CO
- 2.5 System Timer
  - CO-to-CO Line Call Duration Time

## Features Guide References

- 1.3 System Features
  - Released Link Operation
- 1.10 Holding Features
  - Hold Recall

## User Manual References

- 2.4.3 Transferring a Call

## Call Transfer, Screened – to Station

### Description

Allows any extension user to transfer a call (intercom, CO, TIE) to another extension after announcing it.

### Conditions

None

### Programming Guide References

System programming is not required.

### Features Guide References

- 1.3 System Features
  - Released Link Operation

### User Manual References

- 2.4.3 Transferring a Call

# Call Transfer, Screened – to TIE

## Description

Allows the PT user to transfer a call (intercom, CO, TIE) to an outside party via TIE line after announcing it to the destination party.

## Conditions

- **Class of Service**  
Class of Service programming determines the extensions that can perform this feature.
- **CO-to-TIE call**  
If a CO call is transferred to the destination party via TIE line, a CO-to-TIE call is established and the call duration is restricted by the System Timer "CO-to-CO Line Call Duration Time (1-64 min)."

## Programming Guide References

- 2.4 Class of Service (COS)
  - Trunk Group Setting
  - Transfer to CO
- 2.5 System Timer
  - CO-to-CO Line Call Duration Time

## Features Guide References

- 1.3 System Features
  - Released Link Operation
- 3.1 E&M Features
  - TIE LINES – A SUMMARY

## User Manual References

- 2.4.3 Transferring a Call

## Call Transfer, Unscreened – to Station

### Description

Allows the extension user to transfer a call (intercom, CO, TIE) to an extension user without announcing it. After dialling the destination extension number, the extension user can replace the handset.

### Conditions

- **Music on Hold or Ringback Tone**  
If "Music on Hold" is enabled, music is sent to the caller while being transferred. It is system programmable whether to send ringback tone or "Music on Hold" to the caller.
- **Transfer Recall Destination**  
If the call (either extension or outside) transferred to the destination party is not answered within a specified period of time (Transfer Recall Time), it may ring an Operator Group extension instead of the extension who originally transferred it. This is determined by System Programming.
- **Automatic Disconnection**  
If there is no answer for 30 minutes after "Transfer Recall" starts, the line will be disconnected.
- **Remote Administration**  
Any extension user can transfer a call to the Remote resource (Modem) for Remote Administration.
- **Camp-on Transfer**  
When the transfer destination party is busy, the call is put in waiting status. If the destination party remains busy or does not answer the call within a specified period of time (Transfer Recall Time), the call will ring back the extension who transferred the call.
- **Ringling Pattern**  
A transferred call will ring following the regular ringing pattern depending on the type of call being transferred.
- During a call transfer to the Remote Resource (Modem) or a UCD group, a confirmation is not emitted after dialling the FDN for the Remote Resource or a UCD Group.

### Programming Guide References

- 2.5 System Timer
  - Transfer Recall Time
- 2.8 System Option
  - Sound source during transfer
  - Transfer recall destination

### Features Guide References

- 1.3 System Features
  - Released Link Operation

## User Manual References

- 2.4.3 Transferring a Call

## Call Transfer, Unscreened – to TIE

### Description

Allows any extension user to transfer a call (intercom, CO, TIE) to an outside party via TIE line without announcing it.

### Conditions

- **Class of Service**  
Class of Service programming determines the extensions that can perform this feature.
- **CO-to-TIE call**  
If a CO call is transferred to the destination via TIE line, a CO-to-TIE call is established and the call duration is restricted by the System Timer "CO-to-CO Line Call Duration Time (1-64 min)."

### Programming Guide References

- 2.4 Class of Service (COS)
  - Trunk Group Setting
  - Transfer to CO
- 2.5 System Timer
  - CO-to-CO Line Call Duration Time

### Features Guide References

- 1.3 System Features
  - Released Link Operation
- 3.1 E&M Features
  - TIE LINES – A SUMMARY

### User Manual References

- 2.4.3 Transferring a Call

# Intercept Routing

## Description

Provides automatic redirection of incoming CO calls. There are the following two types of Intercept Routing:

### **Rerouting**

Activated when an incoming CO call cannot be placed on the destination extension.

### **Intercept Routing-No Answer (IRNA)**

Activated when an incoming CO call is not answered within a specified period of time (Intercept time).

## Conditions

- **Intercept Routing applies to:**  
DIL 1:1, DIL 1:N, DISA, TAFAS, TIE, DID, DDI, Call Forwarding, and Station Hunting.
- **IRNA destinations**  
The final destination of intercepted calls can be programmed for day and night modes individually.  
There are five possible destinations:
  - 1) an extension
  - 2) an external pager
  - 3) a DISA outgoing message
  - 4) an Extension Group
  - 5) a phantom extension
- **Do Not Disturb**  
Even if the destination is in Do Not Disturb mode, it does not function and the call re-directed by Intercept Routing is placed there.

## Programming Guide References

- 2.5 System Timer
  - Intercept Time
- 3.2 Trunk Group
  - Intercept Destination – Day / Night

## Features Guide References

None

## User Manual References

Not applicable.

# One-Touch Transfer

## Description

This feature can be categorised as follows:

**One-Touch Transfer (DSS or Phantom) for Automatic Hold — All Calls**

Allows the PT and DSS console users to transfer a call (extension, outside) to another extension simply by pressing the DSS or Phantom button (PT only) associated to that extension.

**One-Touch Transfer (DSS) for Automatic Hold — Trunk (DSS)**

Allows the PT user to transfer an outside call to another extension simply by pressing the DSS button associated to that extension.

## Conditions

- This feature does not function if there is another call on Consultation Hold.
- If this feature is disabled by System Programming, performing One-Touch Transfer operation disconnects the current call.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Automatic Hold
- 2.8 System Option
  - Pressing CO key operation in CO talking

## Features Guide References

- 1.10 Holding Features
  - Automatic Hold – All Calls
  - Automatic Hold – Trunk

## User Manual References

- 2.4.3 Transferring a Call



# Ringing Transfer

## Description

If the Extension 2001 has an SDN button which corresponds with the PDN button of the Extension 3001 (PDN owner), the Extension 2001 can transfer the call on the SDN button to the Extension 3001 with a simple operation. This is called "Ringing Transfer."

## Conditions

- **SDN button**  
SDN button can be assigned to a flexible CO button on a DN type PT by Station, User or System Programming.
- **FWD / DND Override**  
The call transferred by this feature overrides FWD (Call Forwarding) / DND (Do Not Disturb) feature assigned on the PDN owner extension.
- A call made by this feature rings the destination PDN button immediately even if delayed ringing or no ring has been set on that PDN button.

## Programming Guide References

- 4.3 Extension Line
  - CO Key

## Features Guide References

None

## User Manual References

- 2.4.3 Transferring a Call
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## 1.12 Conversation Features

### Conference

#### Description

The system supports 3-party conference calls which include outside and / or inside parties. During a 2-party conversation, the extension user can add a third party to their conversation, thereby establishing a conference.

#### Conditions

- **Conference call arrangements**  
A conference call can be one of the following three arrangements:  
1-inside and 2-outside; 2-inside and 1-outside; and 3-inside.
- **Conference trunk**  
Up to eight conference calls are available simultaneously at a time by default. If the optional TSW Conference Expansion card is installed, up to 64 conference calls are available simultaneously.
- **Executive Busy Override, Privacy Release**  
A 3-party call is also established by Executive Busy Override or Privacy Release.
- **Confirmation tone**  
When a 2-party call is changed to a 3-party conference call or vice versa, a confirmation tone is sent to all three parties. Eliminating the tone is programmable.
- **CONFERENCE button**  
If CONFERENCE button is not provided on a PT, it can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.
- **Call Splitting**  
During a 3-party conference call, the conference originator can talk to either one of other two parties alternately by pressing the TRANSFER button (for PT user) or flashing the switchhook (for SLT user). In this case, the PT user is connected with the latter party first and the SLT user is connected with the previous party first.

#### Programming Guide References

- 2.8 System Option
  - Confirmation tone for Override, Barge-in, Conference and Privacy Release
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## Features Guide References

- 1.6 Originating Features
  - Executive Busy Override — Extension
- 1.10 Holding Features
  - Call Splitting
- 1.12 Conversation Features
  - Conference, Unattended
  - Privacy Release

## User Manual References

- 2.4.5 Three-party Conversation
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Conference, Unattended

## Description

A PT user who originated a conference call with two outside parties can leave the conference for a while to allow the other two parties to continue conversation. This is called an Unattended Conference. The conference originator may return to the conference, if desired.

## Conditions

- **Class of Service**  
An Unattended Conference cannot be established unless the extension is allowed to transfer a call to an outside party by COS programming.
- **Call duration limit**  
The duration of an unattended conference is restricted by a system timer.  
Hold Recall tone  
Hold Recall tone is sent to the extension user who left the conference 50 seconds before the time-out.  
Alarm tone  
An alarm tone is sent to both outside parties three times at 5-second interval 15 seconds before the time-out. The call is disconnected at the time-out unless the extension who originated the Unattended Conference returns to the call.
- **CONFERENCE button**  
If CONFERENCE button is not provided on a PT, it can be assigned to a flexible (CO, DSS, PF) button by Station, User or System Programming.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Trunk Group Setting
  - Transfer to CO
- 2.5 System Timer
  - CO-to-CO Line Call Duration Time
- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## Features Guide References

- 1.3 System Features
  - Limited Call Duration
- 1.12 Conversation Features
  - Conference

1.13 Audible Tone Features

- Hold Recall

## **User Manual References**

- 2.4.5 Three-party Conversation
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Data Line Security

## Description

Once Data Line Security is set on the extension, communication between the extension and the other end is protected from any signal such as Call Waiting, Hold Recall and Executive Busy Override. Data equipment or a facsimile may be connected to an extension port so that the extension user can perform data communications. During communication, Data Line Security maintains secure data transmission against tones or interruptions from other extensions.

## Conditions

- **Automatic Privacy**  
Assigning Data Line Security always offers conversation privacy unless Privacy Release is executed.
- If one extension in a conversation has set Data Line Security, it applies to the both extensions.

## Programming Guide References

- 2.3 Numbering Plan
  - Data Line Security Set / Cancel
- 4.3 Extension Line
  - Data Line Mode

## Features Guide References

None

## User Manual References

- 2.7.11 Protecting Your Line against Indication Tones (Data Line Security)

# Doorphone Call

## Description

Doorphone provides a conversation between an extension user and a visitor at a door. When a visitor presses the doorphone button, pre-assigned destination extensions ring. The extension who answered the call can talk to the visitor. It is possible for any extension user to call a doorphone.

## Conditions

- **Hardware Requirements**  
To utilise this feature, a DPH Card (KX-T96161) and a Doorphone are required. The System supports up to eight doorphones.
- **Doorphone Call Destination**  
It is necessary to programme the extensions that can receive doorphone calls during day and night mode.
- **What if a doorphone call is not answered?**  
If not answered within 30 seconds, the call stops ringing and is cancelled.
- **Unlocking the door opener**  
During a doorphone call, any extension user can unlock the door opener (user-supplied) from his / her extension by dialling "5" to let the visitor in.
- The extension user cannot hold and transfer the doorphone call.

## Installation Manual References

- 2.7.2 DPH Card (KX-T96161)

## Programming Guide References

- 2.3 Numbering Plan
  - Doorphone Call
- 2.5 System Timer
  - Door Opener Time
- 4.5 Doorphone
  - Destination – Day / Night

## Features Guide References

- 1.3 System Features
  - Door Opener

## User Manual References

- 2.8.1 If a Doorphone / Door Opener is Connected

# End-to-End DTMF Signalling (Tone Through)

## Description

DTMF signalling is required for access to special network services offered by some telephone companies. This system allows the extension user to signal the other end using DTMF tones during an established call.

## Conditions

- If the dial type of the line is assigned to DTMF, Tone Through mode is established automatically after the dialling sequence is finished and the call is established.
- **Pulse to Tone Conversion**  
If the dial type of the line is assigned to dial pulse, Tone Through mode is established after the dialling sequence is finished and the "\*#" buttons are pressed.
- This function also works during extension and conference calls.
- **Tone Through button**  
This button can be assigned to a flexible button (CO, DSS) by Station, User or System Programming.
- **Automatic Hold**  
If Automatic Hold mode is enabled by System Programming, Tone Through button is required to perform End-to-End DTMF Signalling.
- Tone Through button is effective during a call between two extensions, extension to outside, or a conference call.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Automatic Hold
- 4.3 Extension Line
  - CO Key
- 4.4 DSS Console
  - DSS Key

## Features Guide References

- 1.3 System Features
  - Dial Type Selection
- 1.12 Conversation Features
  - Pulse to Tone Conversion

## User Manual References

- 2.4.8 End-to-End DTMF Signalling (Tone Through)
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)



# External Feature Access

## Description

Allows the extension user to have access to the features of a host PBX, Centrex or Central Office, such as Call Waiting, etc. This is performed by putting the current party on hold and sending a flash signal to the other end during an outside call.

## Conditions

- **FLASH Button Operation**  
Pressing the FLASH button on a PT results in either sending Flash signal or disconnecting the current call.  
This is determined by System Programming (Section 2.8 System Option , "(3) and (4)" in the Programming Guide).
- **Flash Time**  
The flash time must be assigned as required by the Centrex, host PBX or CO line.
- **Memory Dialling**  
During outside calls, a FLASH stored in System Speed Dialling, Station Speed Dialling or One-Touch Dialling works as External Feature Access, not as Flash (Disconnect Signal) used to disconnect the calls.
- **<PT>**  
FLASH button or the feature number is used to perform this feature.
- **<SLT>**  
Feature number is used to perform this feature. This feature does not function, if an SLT has a call on Consultation Hold.

## Programming Guide References

- 2.3 Numbering Plan
  - External Feature Access
- 2.8 System Option
  - FLASH button operation while CO talking
  - FLASH button operation when "Don't release the trunk" is selected at #3
- 3.2 Trunk Group
  - Flash Time
  - Max. Dial No. after EFA Signal

## Features Guide References

- 1.3 System Features
  - Host PBX Access
- 1.12 Conversation Features
  - Flash

## User Manual References

- 2.8.2 If a Host PBX is Connected

# Flash

## Description

The FLASH button is used to allow a PT user to disconnect the current call and originate another call without hanging up.

## Conditions

- **Flash or External Feature Access**  
Pressing the FLASH button on a PT results in either sending Flash signal (External Feature Access) or disconnecting the current call (Flash). This is determined by System Programming (See Programming Guide References below).
- Pressing the FLASH button re-starts the conversation duration, outputs an SMDR record and checks toll restriction level again.

## Programming Guide References

- 2.8 System Option
  - FLASH button operation while CO talking
  - FLASH button operation when "Don't release the trunk" is selected at #3
- 3.2 Trunk Group
  - Disconnecting Time

## Features Guide References

- 1.6 Originating Features
  - Electronic Station Lockout
- 1.12 Conversation Features
  - External Feature Access

## User Manual References

- 2.2.1 Basic Calling

# Hands-free Operation

## Description

Allows the PT user to dial and to talk to the other party without lifting the handset. Pressing an appropriate button provides hands-free mode.

## Conditions

- This function can be utilised by pressing a button listed below when the SP-PHONE / MONITOR button indicator is off:
  - SP-PHONE button
  - MONITOR button
  - INTERCOM button
  - CO button
  - DN button
- The hands-free mode is cancelled if nothing is dialled within 10 seconds.
- **PT with MONITOR button**  
The KX-T7250 can be used for hands-free dialling operations, etc., but cannot be used for a hands-free conversation.
- **Full One-Touch Dialling**  
A single press of a One-Touch Button, DSS button, REDIAL button or a SAVE button also provides the hands-free mode if Full One-Touch Dialling is activated.

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.6 Originating Features
  - Full One-Touch Dialling

## User Manual References

- 2.3.1 Answering Calls

# Off-Hook Monitor

## Description

Allows a PT user on a handset call to let other people around him / her monitor the call by pressing the SP-PHONE button.

## Conditions

- This feature is available for the following KX-T7400 series PT only:  
KX-T7431, KX-T7433, KX-T7436
- If the SP-PHONE button is pressed during a handset call, either Off-Hook Monitor or SP-PHONE mode (hands-free mode) will be established. This is determined by System Programming (Section 2.8 System Option , (20) Off-hook Monitor" in the Programming Guide).
- Making an OHCA call is not available if the other extension is in Off-Hook Monitor mode.

## Programming Guide References

- 2.8 System Option
  - Off-hook Monitor

## Features Guide References

- 1.12 Conversation Features
  - Hands-free Operation

## User Manual References

- 2.4.7 Letting Other People Listen to the Conversation (Off-Hook Monitor) [KX-T7431, KX-T7433 and KX-T7436 only]

# Privacy Release

## Description

Allows the PT user to release Automatic Privacy for an existing call in order to establish a 3-party call. During a conversation with an outside party on a CO button, the extension user can allow another extension user to join in the existing call by pressing the CO button.

## Conditions

- **Confirmation Tone**  
When a 2-party call is changed to a 3-party call and vice versa, a confirmation tone is sent to all three parties. Eliminating the tone is programmable.
- This feature overrides "Data Line Security" and "Executive Busy Override Deny."

## Programming Guide References

- 2.8 System Option
  - Confirmation tone for Override, Barge-in, Conference and Privacy Release

## Features Guide References

- 1.12 Conversation Features
  - Privacy, Automatic

## User Manual References

- 2.4.5 Three-party Conversation

# Privacy, Automatic

## Description

By default all conversations established on CO lines, extension lines and doorphone lines have privacy activated, that is, an existing call is not interrupted by anyone.

## Conditions

- **Privacy Release**  
Automatic privacy may be temporarily released to establish a 3-party conference, either by Executive Busy Override or Privacy Release.

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.6 Originating Features
  - Executive Busy Override — Barge-in
  - Executive Busy Override — Extension
- 1.12 Conversation Features
  - Privacy Release

## User Manual References

Not applicable.

# Pulse to Tone Conversion

## Description

Allows the extension user to change the dialling mode from pulse dial to tone dial (DTMF) temporarily during a call so that they can access special services which require tone dialling such as a computer-accessed long distance call.

## Conditions

- This feature works only for CO lines set to Pulse Dialling mode.
- Dial Type Selection provides selection of a dial mode for each CO line.
- **DISA**  
This feature is not available during a DISA call.
- Changing from tone to pulse is not possible.

## Programming Guide References

- 4.2 Trunk Line
  - Dial Type

## Features Guide References

- 1.3 System Features
  - Dial Type Selection

## User Manual References

- 2.2.5 Calling without Restrictions



# Two-Way Recording into the Voice Mail<sup>\*1</sup>

## Description

This is one of the DPT Integration features.

Allows the PT user to record the current telephone conversation into his / her own mailbox or another extension user's mailbox.

### Note

During the recording of Two-Way telephone conversations, inform the other party that the conversation is being recorded.

## Conditions

- **Two-Way Record / Two-Way Transfer button**  
These buttons can be assigned to a flexible (CO, DSS) button by Station, User or System Programming.
- If all voice mail ports are busy, pressing the Two-Way Record button does not function and an alarm tone sounds.
- If all voice mail ports are busy, pressing the Two-Way Transfer button followed by an extension number sends an alarm tone.
- When you record Two-Way telephone conversations, you should inform the other party that the conversation is being recorded.

## Programming Guide References

- 4.3 Extension Line
  - CO Key
- 4.4 DSS Console
  - DSS Key

## Features Guide References

- 1.3 System Features
  - VPS Integration – DPT Integration

## User Manual References

- 2.8.3 If a Voice Processing System is Connected
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

---

<sup>\*1</sup> Available when the Digital Super Hybrid System is connected to a Digital Proprietary Telephone capable Panasonic Voice Processing System (one that supports Digital Proprietary Telephone integration; e.g. KX-TVP100)

## 1.13 Audible Tone Features

### Confirmation Tones

#### Description

Confirmation tone indicates an action was accepted by the system, and the extension user can proceed to the next operation.

At the end of various operations, the extension user can confirm the success of the operation by hearing a confirmation tone.


#### Confirmation tone 1:

- (a) Indicates that the new setting differs from the previous setting.
- (b) Set or cancel the Electronic Station Lockout.



#### Confirmation tone 2:

- (a) Indicates that the new setting is identical to the previous one.
- (b) In addition, sent when various features are successfully performed or accessed. (e.g. Call Hold; Automatic Callback Busy)
- (c) Sent when accessing external paging equipment. (e.g. Paging - All; Paging - External)  
Confirmation tone from external pagers can be enabled or disabled by System Programming.



#### Confirmation tone 3:

Sent when a conversation is established just after dialling.

For example, when accessing the following features by the feature numbers:

- Call Park Retrieve
- Call Pickup
- Hold Retrieve
- Paging Answer
- TAFAS Answer

This tone can be eliminated by System Programming so that the user can start talking instantly.



**Confirmation tone 4:**

Sent when a 2-party call is changing to a 3-party call and vice versa. (These are caused by Executive Busy Override, Barge-in, Conference, or Privacy Release.) It is possible to eliminate this tone by System Programming.

**Conditions**

- Confirmation Tone 1 and 2 are provided to reconfirm the assigned feature.

**Programming Guide References**

- 2.2 Tenant
  - External Paging Tone
- 2.8 System Option
  - Confirmation tone for Override, Barge-in, Conference and Privacy Release
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve

**Features Guide References**

None

**User Manual References**


Not applicable.

## Dial Tones, Distinctive

### Description


The following four types of dial tone patterns are provided to give information about features activated on the extension.

**Dial tone 1:** Normal dial tone. None of the features listed below are activated.




**Dial tone 2:** Emitted when any one or more of the features below are set.


1. Absent Message Capability
2. Background Music (BGM)
3. Call Forwarding
4. Call Pickup Deny
5. Call Waiting
6. Data Line Security
7. Do Not Disturb (DND)
8. Electronic Station Lockout
9. Executive Busy Override Deny
10. Paging Deny
11. Pickup Dialling
12. Timed Reminder



**Dial tone 3:** Emitted when performing Account Code Entry. Also sounds when answering Timed Reminder call.



**Dial tone 4:** Emitted when messages are waiting for extension.



**Conditions**

None

**Programming Guide References**

- 2.8 System Option
  - Special dial tone after setting feature

**Features Guide References**

None

**User Manual References**

Not applicable.


# Hold Recall

## Description

Prevents a call on hold from being kept waiting longer than a pre-determined time. If the timer expires, ringing or an alarm tone is sent to the extension user who held the call as a reminder. If the extension user is on-hook and its speaker-phone is off, the phone will ring. If the extension user is engaged in a call when the Hold Recall Time expires, an alarm tone is sent from the built-in speaker of a PT or from the handset of an SLT at 15-second intervals. In this case, Call Waiting feature should be enabled at the extension beforehand.

## Conditions

- Hold Recall applies to the following calls:
  - Calls on Consultation Hold
  - Calls on Hold
  - Calls on Exclusive Hold
- **Automatic Disconnection**  
If an outside call placed on hold is not retrieved within 30 minutes, it is automatically disconnected.
- Hold Recall can be disabled by System Programming.
- If "Call Waiting" is enabled at the extension where the call is held, an alarm tone is emitted as follows:



- The display PT flashes the indication of the held party for five seconds at 15-second intervals synchronising with the tone.

## Programming Guide References

- 2.3 Numbering Plan
  - Call Waiting Set / Cancel
- 2.5 System Timer
  - Hold Recall Time

## Features Guide References

- 1.10 Holding Features
  - Call Hold – Station
  - Call Hold, Exclusive – Station
  - Call Hold – Trunk
  - Call Hold, Exclusive – Trunk

## **User Manual References**

Not applicable.

# Ringling Tone Selection

## Description

Allows the DPT user to select one of eight ringer frequencies for each line access button (ICM, CO, DN). This is useful to distinguish the type of incoming calls by ringing.

## Conditions

None

## Programming Guide References

- 4.3 Extension Line
  - CO Key

## Features Guide References

None

## User Manual References

- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)



# Ring, Delayed

## Description

The extension can be set to ring immediately, delayed ringing, or no ringing.

## Conditions

- **DIL 1:N Call**  
When a DIL 1:N call (an outside call directed to multiple extensions) comes in, all destination extensions ring immediately by default. This setting can be changed to delayed ringing or no ringing on each member of the DIL 1:N Group basis.
- **<ICM type PT>**  
At an ICM type PT, this feature does not apply to DISA or DIL 1:1 calls.
- **<DN type PT>**  
Line Ringing Selection is assignable on a DN button (PDN, SDN) basis. However, if Direct In Lines (DIL) 1:N is established, Line Ringing Selection is determined by incoming DIL 1:N call group setting.  
"PDN / SDN Button Delayed Ringing Assignment" does not function for a call which comes in on a Ring Group extension or a Phantom extension.
- **Answering a no-ringing call**  
If delayed ringing or no ringing is assigned to an extension, the extension can answer an incoming call during no ring or the delay time by pressing the flashing button.

## Programming Guide References

- 3.5 DIL 1:N Group
  - [Destinations] Ringing Type
- 4.3 Extension Line
  - CO Key

## Features Guide References

- 1.5 Attended Features
  - Direct In Lines (DIL)

## User Manual References

- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Ringing, Discriminating

## Description

Allows the extension user to identify the incoming call by the ringing pattern (See Section 4 Tone / Ring Tone in this Guide.)

## Conditions

- **Call Ringing Priority**  
When there are multiple incoming calls and the extension goes from off-hook to on-hook, the calls ring according to the following priority:
  1. Consultation Hold Recall
  2. An incoming call from a line in which the Prime Line Preference – Incoming function has been set (PT only)
  3. Call Waiting
  4. Incoming calls; Hold Recall; Transfer Recall; Unattended Conference Recall
  5. Timed Reminder
  6. Automatic Callback Busy
- **Prime Line Preference-Incoming**  
When multiple calls are ringing simultaneously at a PT on which "Prime Line Preference - Incoming" feature is assigned, the extension user can answer the call on the prime line simply by going off-hook.
- **Ring Tone Type Selection**  
The DPT user can select a desired ringing tone type for CO buttons.

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.13 Audible Tone Features
  - Ringing Tone Selection

## User Manual References

- 4.1.2 Customising the Buttons

## 1.14 Paging Features

### PAGING – A SUMMARY

#### Description

Allows the extension user to broadcast a paging announcement to other users in the system. The KX-TD500 System provides the following two types of Paging.

- **Paging - Station**

Pages through the built-in speakers of PTs.

The extension user can make a paging announcement by specifying one of Station Paging Groups or to all of them simultaneously.

A maximum of 16 Station Paging Groups, each consisting of one or more Extension Groups, can be created in the system.

- **Paging - External**

Pages through the External Paging Equipment (user-supplied).

A maximum of two External Paging Equipment can be installed in the system.

Paging features are classified as follows:

Paging – All

Paging – External

Paging – Group

**(Paging Answer)**

The paged party can reply to the paging announcement by dialling the feature number for paging answer from any extension.

**(Paging and Transfer)**

The extension user can transfer the call after paging the destination party.

**(Paging Deny)**

The PT users can deny receiving a paging announcement through the built-in speakers of their PTs.

# Paging – All

## Description

Allows the extension user to make a voice announcement through the built-in speakers of the PTs and the External Paging Equipment (external pagers) simultaneously. The paged party can reply to the paging announcement by dialling the feature number for paging answer from any extension.

## Conditions

- **Confirmation tone for station paging**  
A confirmation tone is sent to extensions, when the page is made or answered. Eliminating the tone is programmable.
- **External Paging Tone**  
External paging tone is emitted from external pagers, before the voice announcement. Eliminating the tone is programmable.
- A ringing or busy extension cannot receive a paging announcement.
- To page extensions, paged extensions must belong to some extension group(s), and this / these extension group(s) must belong to some paging group(s).

## Installation Manual References

- 2.8.2 External Pager (Paging Equipment)

## Programming Guide References

- 2.2 Tenant
  - External Paging Tone
  - Confirmation Tone for Station or External Paging
- 2.3 Numbering Plan
  - External Paging
  - External Paging Answer / TAFAS Answer
  - Station Paging
  - Station Paging Answer
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve
- 3.4 Paging Group
  - Paging Group No.
  - Extension Group No.

## Features Guide References

None

## **User Manual References**

- 2.6.1 Paging
- 2.6.2 Paging a Person and Transferring a Call
- 2.6.3 Answering a Paged Announcement

# Paging – External

## Description

Allows the extension user to make a voice announcement through the External Paging Equipment (external pagers). Up to two External Pagers can be installed in the system. It is possible to select one or two pagers to perform the paging. Any extension user can answer the Paging – External by dialling the appropriate feature number.

## Conditions

- A user-supplied external pager is required to utilise this feature.
- **External paging Priority**  
External pagers can be used for TAFAS, Paging – External , or Background Music (BGM) – External in this order.  
For example, if Paging – External is overridden by TAFAS, reorder tone is returned to the performer of the Paging – External. If BGM is overridden by another higher priority, it is interrupted and starts again when the higher priority is finished.
- A confirmation tone is sent to the extensions, when the paging is made or answered. Eliminating the tone is programmable.
- External paging tone is emitted from external pagers before the voice announcement. Eliminating the tone is programmable.

## Installation Manual References

- 2.8.2 External Pager (Paging Equipment)

## Programming Guide References

- 2.2 Tenant
  - External Paging Tone
  - Confirmation Tone for Station or External Paging
- 2.3 Numbering Plan
  - External Paging
  - External Paging Answer / TAFAS Answer
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve

## Features Guide References

None

## **User Manual References**

- 2.6.1 Paging
- 2.6.2 Paging a Person and Transferring a Call
- 2.6.3 Answering a Paged Announcement

# Paging – Group

## Description

Allows the extension user to make a voice announcement by specifying one of 16 Paging Groups. All PTs in the group will receive the page. The paged party can reply to the paging announcement by dialling the feature number for paging answer.

## Conditions

- A maximum of 16 Paging Groups, each consisting of up to 24 Extension Groups, can be set up.
- A single Extension Group cannot belong to two or more different Paging Groups at a time.
- A confirmation tone is sent to extensions when the paging is made or answered. Eliminating the tone is programmable.

## Programming Guide References

- 2.2 Tenant
  - Confirmation Tone for Station or External Paging
- 2.3 Numbering Plan
  - Station Paging
  - Station Paging Answer
- 2.8 System Option
  - Confirmation tone for Call Pickup, Paging- Answer, TAFAS-Answer, Hold Retrieve and Call Park Retrieve
- 3.4 Paging Group
  - Paging Group No.
  - Extension Group No.

## Features Guide References

- 1.14 Paging Features
  - Paging Deny

## User Manual References

- 2.6.1 Paging
- 2.6.2 Paging a Person and Transferring a Call
- 2.6.3 Answering a Paged Announcement



# Paging Deny

## Description

Allows the PT users to deny receiving a paging announcement through the built-in speakers of their PTs.

## Conditions

None

## Programming Guide References

- 2.3 Numbering Plan
  - Paging Deny Set / Cancel

## Features Guide References

- 1.14 Paging Features
  - PAGING – A SUMMARY

## User Manual References

- 2.7.4 Denying the Paged Announcement (Paging — Deny)

## 1.15 Proprietary Telephone Features

### Background Music (BGM)

#### Description

Allows the PT user in on-hook status to listen to Background Music (BGM) from the built-in speaker of his / her PT.

#### Conditions

- **Hardware Requirements**  
A user-supplied external music source, such as a radio, is required to utilise this feature. Up to two music sources can be connected to the system.
- **Tenant Service**  
If "Tenant Service" is utilised, a music source for BGM is determined by System Programming on a tenant basis.
- **Turning on / off**  
This feature can be turned on / off by pressing "1" while the extension is on-hook. If it goes off-hook, BGM is suspended temporarily.
- **Changing Music Source**  
Before changing the music source (MUS1 or MUS2) by software control, you must first turn off the BGM at your extension; change the source; and then turn on the BGM again.

#### Installation Manual References

- 2.8.3 Music Source (External / Internal)

#### Programming Guide References

- 2.2 Tenant
  - BGM Source

#### Features Guide References

- 1.3 System Features
  - Music on Hold

#### User Manual References

- 2.7.10 Turning on the Background Music (BGM)

# DSS Console

## Description

The DSS (Direct Station Selection) Console (KX-T7240, KX-T7440, KX-T7441) provides DSS buttons for direct access to stations and busy lamp display, and PF (Programmable Feature) buttons.

The DSS Console must be programmed to work with a PT in pairs. System Programming assigns the extension port numbers of the DSS Console and its associated PT.

Up to 8 DSS Consoles can be connected to a PT.


In total, up to 64 DSS Consoles can be installed in the system.

The paired PT user can carry out the following operations simply by pressing buttons on the DSS console which were pre-programmed as function buttons:

- Direct access to an extension (Direct Station Selection)
- Quick access to an outside party (One-Touch Dialling)
- Easy transfer of an outside call to an extension (The programmable One-Touch Transfer feature provides simplified operation.)
- Quick access to a system feature

A DSS Console has two types of buttons as shown below:

### Example: DSS Console KX-T7240



**DSS (Direct Station Selection) buttons:** Used to call a corresponding extensions with One-Touch. Every button is provided with an indicator (Busy Lamp Field), which shows the current state of the corresponding extension as shown in the following Table:

**Busy Lamp Field Table**

Light	State of extension
Off	Idle
On	Busy <sup>*1</sup>
Flash	Logout <sup>*2</sup>

<sup>\*1</sup> If the DSS button is corresponded with a DN type PT, the DSS indicator turns on when at least one PDN button on the corresponding DN type PT becomes busy.

<sup>\*2</sup> If the extension corresponding with the DSS button is in "Logout" status and idle, the DSS indicator flashes in red.

To meet the user's various needs, DSS buttons can be changed to the other function buttons.

**PF (Programmable Feature) buttons printed as F1 through F16:** These buttons are provided without default setting. The paired PT user can programme the buttons for the other function buttons.

## Conditions

- Programming the DSS and PF buttons can be done only from the paired PT by Station Programming, or System Programming with Personal Computer.
- If the extension number assigned to a DSS button is changed to another number, the DSS button automatically follows the new number. (Re-programming is not necessary.)

## Installation Manual References

- 2.4 Extension Cards

## Programming Guide References

- 1.4 Extension Port Assignment
  - Attribute
  - DN
- 4.4 DSS Console
  - Paired Extension
  - DSS Key
  - PF Key

## Features Guide References

- 1.1 System Expansion
  - EXtra Device Port (XDP)
- 1.11 Transferring Features
  - One-Touch Transfer

1.16 Button Features

- Button, Direct Station Selection (DSS)
- Button, Flexible

## **User Manual References**

- 4.1.2 Customising the Buttons

## Handset / Headset Selection

### Description

The system supports the use of optional headset on PTs.

### Conditions

- Headset mode can be set by:  
[DPT]  
Station Programming  
[APT]  
HANDSET / HEADSET selector on the APT and / or on the handset
- "OHCA" is available on an extension in Headset mode.
- Refer to the Operating Instructions of the Headset KX-T7090 or KX-T30890 for operation.

### Programming Guide References

System programming is not required.

### Features Guide References

None

### User Manual References

- 4.1.1 Initial Settings

# Handset Microphone Mute

## Description

While on a handset call, the PT user (KX-T7400 series PT only) can turn off the handset microphone by pressing the AUTO ANSWER / MUTE button for privacy reasons.

If the caller turns on the Handset Microphone Mute mode, the other party cannot hear the caller's voice, but the caller can hear the other party's voice.

## Conditions

- This feature is available for KX-7400 series PT only.
- If AUTO ANSWER / MUTE button is pressed during an OHCA call, Handset Microphone Mute mode will be turned on.
- If AUTO ANSWER / MUTE button is pressed in Hands-free mode, Microphone Mute mode will be turned on.

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.15 Proprietary Telephone Features
  - Microphone Mute

## User Manual References

- 2.4.6 Mute

# Microphone Mute

## Description

Allows the PT user to turn off the microphone for privacy reasons.

## Conditions

- This is effective for the microphone only; only your voice will be muted during a hands-free conversation.
- The extension user in Microphone Mute mode can hear the other party's voice.
- This feature is not available for KX-T7250.

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

- 2.4.6 Mute



# Station Programme Clear

## Description

Allows the extension user to cancel the following functions assigned to his / her extension with a single operation.

(a) <b>Absent Message Capability</b> (The message set on the extension)
(b) <b>Automatic Callback Busy</b>
(c) <b>Background Music that has been turned on</b>
(d) <b>Call Forwarding, Do Not Disturb (DND)</b>
(e) <b>Call Log, Incoming</b>
(f) <b>Call Pickup Deny</b>
(g) <b>Call Waiting (BSS, OHCA, Whisper OHCA)</b>
(h) <b>Data Line Security mode</b>
(i) <b>Executive Busy Override Deny</b>
(j) <b>Log-out</b>
(k) <b>Message Waiting</b> (All the messages that have been left by other extension users)
(l) <b>Paging Deny</b>
(m) <b>Paralleled Telephone enabled</b>
(n) <b>Pickup Dialling</b> (The stored telephone number will be removed.)
(o) <b>Timed Reminder</b>
(p) <b>Walking Station</b>

## Conditions

None

## Programming Guide References

- 2.3 Numbering Plan
  - Station Program Clear

## Features Guide References

None

## **User Manual References**

- 2.7.14 Clearing the Feature Settings at Your Extension (Station Programme Clear)

# Station Programming

## Description

Allows the PT user to customise the extension to his / her needs. The following are the programming items available:

**For both APT and DPT:**

- Call Waiting Tone Type Assignment
- Flexible Button Assignment
- Full One-Touch Dialling Assignment
- Intercom Alert Assignment
- Preferred Line Assignment – Incoming / Outgoing
- Station Programming Data Default Set
- Live Call Screening Mode Set

**For DPT only:**

- Handset / Headset Selection
- Ringing Tone Selection for Line Access Buttons

**For display PT only:**

- Bilingual Display Selection
- Initial Display Selection
- Self-Extension Number Confirmation

**For display DPT only:**

- Station Speed Dialling Number / Name Assignment

**For the Manager's or Operator's extension PT only:**

- Control of Call Log Incoming, Log Lock
- Live Call Screening Password Control
- Remote Station Lock Control

Detailed information and programming instructions are described in "Station Programming" Section (User Manual).

## Conditions

- During Station Programming, the PT is treated as a busy extension.

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.15 Proprietary Telephone Features
  - Station Programming

## **User Manual References**

- 3.1.4 Changing the Settings (Station Programming)
- 4.1 Customising Your Phone (Station Programming)
- 4.2 Charge Fee Management (Station Programming)

# Station Programming Data Default Set

## Description

Allows the PT user to return all the following items programmed on the telephone to default setting.

Programming Items	Default
Bilingual Display Selection	English
Call Waiting Tone Type Assignment	Tone 1
Full One-Touch Dialling Assignment	On
Handset / Headset Selection	Handset
Initial Display Selection	Caller ID
Intercom Alert Assignment	Tone Call
Live Call Screening Mode Set	Hands-free
Preferred Line Assignment - Incoming	Ringing Line
Preferred Line Assignment - Outgoing	Intercom Line

Station Programming is used to set or cancel these items at individual telephones.

## Conditions

None

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.15 Proprietary Telephone Features
  - Station Programming

## User Manual References

- 4.1.1 Initial Settings

## Volume Control – Speaker / Handset Receiver / Headset / Ringer

### Description

Allows the PT user to change the following as desired:

- Handset receiver volume
- Headset volume
- Ringer volume
- Speaker volume

### Conditions

- The control method depends on the telephone type:
  - [KX-T7400 series DPTs]**
    - Rotate the Jog Dial in the desired direction.
  - [KX-T7200 series DPTs]**
    - Press the volume control button (UP ^ / DOWN v) to select a desired volume level. However the ringer volume of KX-T7220 and KX-T7250 is selected with Ringer Volume Selector (OFF / LOW / HIGH).
  - [APTs]**
    - Slide the following levers located on the left side of the telephone.
      - Volume Control (MIN - MAX)
      - Handset Headset
      - Volume Selector (NORMAL / MID / HIGH)
      - Ringer Volume Selector (OFF / LOW / HIGH)

### Programming Guide References

System programming is not required.

### Features Guide References

None

### User Manual References

- 2.1 Before Operating the Telephones

# 1.16 Button Features

## Button, Direct Station Selection (DSS)

### Description

DSS button permits the PT user one-touch access to other extension users.

### Conditions

- A DSS button can be assigned to a flexible CO button on a PT by Station, User or System Programming.
- **Busy Lamp Field**  
Once a button is assigned as a DSS button, it provides Busy Lamp Field (BLF) status.

### Programming Guide References

- 4.3 Extension Line
  - CO Key
- 4.4 DSS Console
  - DSS Key

### Features Guide References

- 1.11 Transferring Features
  - One-Touch Transfer
- 1.15 Proprietary Telephone Features
  - DSS Console
- 1.17 Display Features
  - Busy Lamp Field

### User Manual References

- 2.2.1 Basic Calling
- 2.4.3 Transferring a Call
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Button, Flexible

## Description

The use of Flexible Buttons on PT is determined by Station, User or System Programming. The following three types of Flexible Buttons are provided on PT and / or DSS Consoles:

- **Flexible CO buttons** (provided on all PTs)
- **Flexible DSS buttons**(provided on DSS Consoles)
- **Flexible PF (Programmable Feature) buttons**

Assignable features by Flexible Button type

↓ Features to be assigned / Button →	CO (PT)	DSS (DSS)	PF (PT / DSS)
Single-CO	✓	✓*1	
Group-CO	✓	✓*1	
Loop-CO	✓		
DSS(Direct Station Selection)	✓	✓	
Phantom	✓		
PDN (Primary Directory Number)	✓		
SDN (Secondary Directory Number)	✓		
ONE-TOUCH (One-Touch Dialling)	✓	✓	✓
MESSAGE (Message Waiting)	✓	✓	
FWD / DND (Call Forwarding / Do Not Disturb)	✓	✓	✓
SAVE (Saved Number Redial)	✓	✓	✓
ACCOUNT (Account Code Entry)	✓	✓	✓
CONF (Conference)	✓	✓	✓
VTR (Voice Mail Transfer)	✓	✓	
Log-In / Log-Out	✓		
2WAY-REC (Two-Way Record)*2	✓	✓	
2WAY-TRAN (Two-Way Transfer)*2	✓	✓	
LCS (Live Call Screening)*2	✓	✓	



↓ Features to be assigned / Button →	CO (PT)	DSS (DSS)	PF (PT / DSS)
LCS (Live Call Screening) Cancel* <sup>2</sup>	✓	✓	
DAY / NIGHT (Day / Night Switch)	✓		
Alarm	✓		
Answer	✓	✓	✓
Release	✓	✓	✓
Tone Through	✓	✓	
SS (ISDN Service)	✓	✓	✓

"✓" indicates that the feature is available.

\*<sup>1</sup> Available for monitoring the call activity only.

\*<sup>2</sup> Available when the Digital Super Hybrid System is connected to a Digital Proprietary Telephone capable Panasonic Voice Processing System (one that supports Digital Proprietary Telephone integration; e.g. KX-TVP100).

## Conditions

- **Station Programming mode**  
A PT in Station Programming mode is treated as a busy extension. CO buttons and DSS buttons on a PT in Station Programming mode do not show the indication of call activity.
- **Flexible CO buttons**  
Flexible CO buttons are provided on all types of PTs.

## Programming Guide References

- 4.3 Extension Line
  - CO Key
  - PF Key
- 4.4 DSS Console
  - DSS Key
  - PF Key

## Features Guide References

- 1.15 Proprietary Telephone Features
  - DSS Console
- 1.16 Button Features
  - Buttons on Proprietary Telephones

## User Manual References

- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# BUTTON, LINE ACCESS – A SUMMARY

## Description

Used to get a line for making / answering a call. Line Access Buttons are provided on PTs only. They are categorised as follows:

<b>ICM (INTERCOM)</b>		Used to make or receive intercom calls and to access various system features.
<b>DN</b>	<b>PDN</b>	Used to make or receive both intercom and outside calls (CO, TIE) and to access various system features.
	<b>SDN</b>	
<b>CO</b>	<b>S-CO</b>	Used to make or receive outside calls (CO, TIE).
	<b>G-CO</b>	
	<b>L-CO</b>	

All PTs in the system can be categorised as <ICM type PT> or <DN type PT>.

**<ICM type PT>** (default)

ICM button + CO buttons

All PTs in the system have one ICM button and one L-CO button by default.

**<DN type PT>**

DN button(s) + CO buttons

If at least one PDN is assigned, all intercom calls come on a PDN button instead of ICM button.

## Conditions

- DN buttons and CO buttons can be assigned to a PT by Station, User or System Programming.

## Programming Guide References

- 4.3 Extension Line
  - CO Key

## Features Guide References

### 1.16 Button Features

- Button, Line Access – Group-CO (G-CO)
- Button, Line Access – INTERCOM (ICM)
- Button, Line Access – Loop-CO (L-CO)
- Button, Line Access – Primary Directory Number (PDN)
- Button, Line Access – Secondary Directory Number (SDN)
- Button, Line Access – Single-CO (S-CO)

## User Manual References

- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## Button, Line Access – Group-CO (G-CO)

### Description

To support efficient utilisation of CO lines, a group of CO lines (Trunk Group) can be assigned to a flexible CO button as Group-CO (G-CO). Any incoming call from CO lines in the Trunk Group arrives at the G-CO button. To make an outside call, the extension user can get an idle CO line in the trunk group simply by pressing the assigned G-CO button. Assignable for both ICM type and DN type PTs.

#### LED Indicator Patterns — G-CO

Indicator	Line status
Off	Idle
Green On	You are using the line.
Green slow flash	You have a held call.
Green moderate flash	You have one of the following: <ol style="list-style-type: none"> <li>1. Exclusive hold</li> <li>2. CO-to-CO line call</li> <li>3. Conference, unattended</li> </ol>
Green rapid flash	Hold Recall / an outside call is coming in on a single extension.
Red On	Other in use
Red slow flash	_____
Red moderate flash	_____
Red rapid flash	An outside call is coming in on multiple extensions simultaneously.

### Conditions

- **G-CO Button Assignment**  
A G-CO button can be assigned to a flexible CO button on a PT or a flexible DSS button on a DSS Console by Station, User or System Programming.  
However, a G-CO button assigned to a DSS button of a DSS console is available for monitoring the call activity only, not available for making or receiving a call.
- It is possible to assign the same Trunk Group to more than one different G-CO button on the same PT.
- It is possible to assign the same CO line to an S-CO button and to a G-CO button.
- It is possible to assign the Single-CO, Group-CO and Loop-CO buttons on one PT.  
Incoming and outgoing calls on the line are shown on the button in the following priority.  
Single-CO > Group-CO > Loop-CO

- **Ringing Tone Selection (DPT only)**

A ringing tone type for G-CO buttons can be selected either by Station or System Programming.

## **Programming Guide References**

- 2.4 Class of Service (COS)
  - Trunk Group Setting
- 3.2 Trunk Group
- 4.3 Extension Line
  - CO Key
- 4.4 DSS Console
  - DSS Key

## **Features Guide References**

- 1.6 Originating Features
  - Trunk Access, Direct
  - Trunk Access, Trunk Group
- 1.13 Audible Tone Features
  - Ringing Tone Selection
- 1.16 Button Features
  - Button, Direct Station Selection (DSS)
  - LED Indication

## **User Manual References**

- 2.2.1 Basic Calling
- 2.3.1 Answering Calls
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Button, Line Access – INTERCOM (ICM)

## Description

Used to make or receive intercom calls, and to set or cancel various features. Available for an ICM type PT only.

### LED Indicator Patterns - INTERCOM

Indicator	Line status
Off	Idle
Green On	Intercom call / Conference established
Green slow flash	Inerecom call hold
Green moderate flash	On exclusive hold / consultation hold
Green rapid flash	An intercom call or a doorphone call is coming in.

## Conditions

None

## Programming Guide References

System programming is not required.

## Features Guide References

- 1.6 Originating Features
  - Inter Office Calling
- 1.16 Button Features
  - LED Indication

## User Manual References

- 2.2.1 Basic Calling
- 2.3.1 Answering Calls
- 4.1.2 Customising the Buttons

## Button, Line Access – Loop-CO (L-CO)

### Description

All CO lines in the system or in a tenant (if "Tenant Service" is utilised) can be assigned to a flexible CO button on a PT as a Loop-CO (L-CO) button. An incoming CO call on any CO line arrives at the L-CO, unless there are S-CO or G-CO buttons associated with the line or unless the L-CO button is already in use. The PT user can get an idle CO line simply by pressing the dedicated L-CO button. Available for both ICM type and DN type PTs.

#### LED Indicator Patterns — L-CO

Indicator	Line status
Off	Idle
Green On	You are using the line.
Green slow flash	You have a held call.
Green moderate flash	You have one of the following: <ol style="list-style-type: none"> <li>1. Exclusive hold</li> <li>2. CO-to-CO line call</li> <li>3. Conference, unattended</li> </ol>
Green rapid flash	Hold Recall / an outside call is coming in on a single extension.
Red On	_____
Red slow flash	_____
Red moderate flash	_____
Red rapid flash	An outside call is coming in on multiple extensions simultaneously.

### Conditions

- **L-CO Button Assignment**  
An L-CO button can be assigned to a flexible CO button by Station, User or System Programming. By default, there is one L-CO button on each PT.
- It is possible to assign the Single-CO, Group-CO and Loop-CO buttons on one PT. Incoming and outgoing calls on the line are shown on the button in the following priority.  
Single-CO > Group-CO > Loop-CO
- **Local Access / ARS**  
Pressing the L-CO button provides the same operation as dialling the feature number for "Local Access / ARS" (default = 9). This results in "Trunk Access, Idle" or "Automatic Route Selection (ARS)," depending on the System Programming.



- **Ringing Tone Selection (DPT only)**  
A ringing tone type for L-CO buttons can be selected either by Station or System Programming.

## **Programming Guide References**

- 2.4 Class of Service (COS)
  - Trunk Group Setting
- 2.6 Local Hunt Sequence
- 4.3 Extension Line
  - CO Key

## **Features Guide References**

- 1.6 Originating Features
  - Automatic Route Selection (ARS)
  - Trunk Access, Direct
  - Trunk Access, Idle
- 1.9 Answering Features
  - Answering, Direct Trunk
- 1.13 Audible Tone Features
  - Ringing Tone Selection
- 1.16 Button Features
  - LED Indication

## **User Manual References**

- 2.2.1 Basic Calling
- 2.3.1 Answering Calls
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## Button, Line Access – Primary Directory Number (PDN)

### Description

Used to make or receive both intercom and outside (CO, TIE) calls, and access various system features.

**LED Indicator Patterns — PDN**

Indicator	Line status
Off	Idle
Green On	You are using the line.
Green slow flash	You have a held call.
Green moderate flash	You have one of the following: <ol style="list-style-type: none"> <li>1. Exclusive hold</li> <li>2. Consultation hold</li> <li>3. Conference, unattended</li> </ol>
Green rapid flash	A CO call is coming in on a single extension. Hold Recall / Automatic Callback Busy
Red On	Other in use / SDN on exclusive hold
Red slow flash	SDN on hold
Red moderate flash	_____
Red rapid flash	A CO call is coming in on multiple extensions simultaneously.

### Conditions

- **PDN Button Assignment**

A PDN button can be assigned to any one of the flexible CO buttons on a PT by Station, User or System Programming.

Up to three PDN buttons can be assigned to any flexible CO button on a PT. However, the first PDN button should always be assigned to the CO 01 button regardless of the number of the PDN buttons assigned.

- **<DN type PT>**

If at least one PDN button is assigned on a PT, it functions as a DN type PT. ICM button on a DN type PT does not function.

- Both incoming extension and CO calls appear on a PDN button either when the extension is on-hook or off-hook (including when engaged in another call) if at least one PDN button is idle.

- **Priority of CO Call Indication**

Both DN buttons and CO buttons can be assigned on one PT at a time. In this case, an

incoming CO call appears on a CO button if it has the associated CO line. If not, the incoming CO call appears on a PDN button.

- **Delayed Ringing**

Immediate, delayed or no ringing can be assigned to the first PDN button. This assignment applies to all PDN buttons on the same PT.

- **Ring Tone Selection (DPT only)**

A ringing tone type for PDN buttons can be selected either by Station or System Programming.

## Programming Guide References

- 4.3 Extension Line

## Features Guide References

1.11 Transferring Features

- Ringing Transfer

1.13 Audible Tone Features

- Ringing, Delayed

1.16 Button Features

- Button, Line Access – Secondary Directory Number (SDN)
- LED Indication

## User Manual References

- 2.2.1 Basic Calling
- 2.3.1 Answering Calls
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## Button, Line Access – Secondary Directory Number (SDN)

### Description

The extension user can assign the PDN of other extension (owner extension) on his / her own extension as the SDN button. SDN button reflects the status of the PDN button of owner extension. Incoming calls to the owner extension appear on both PDN button and SDN button. Assignable for a DN type PT only.

#### LED Indicator Patterns — SDN

Indicator	Line status
Off	Idle
Green On	You are using the line.
Green slow flash	You have a held call.
Green moderate flash	You have one of the following: <ol style="list-style-type: none"> <li>1. Exclusive hold</li> <li>2. Consultation hold</li> <li>3. Conference, unattended</li> </ol>
Green rapid flash	Hold Recall / Automatic Callback Busy
Red On	Other in use / PDN on exclusive hold
Red slow flash	PDN on hold
Red moderate flash	_____
Red rapid flash	A call is coming in.

### Conditions

- **SDN Button Assignment**  
An SDN button can be assigned to a flexible CO button on a PT by Station, User or System Programming.
- **<DN type PT only>**  
An SDN button should be assigned to a DN type PT. If an SDN button is assigned on an ICM type PT, it does not function.
- **Associated PDN button**  
An SDN button should have its associated PDN button. Otherwise, it does not function.
- **SDN COS (Class of Service)**  
This setting is applied when the extension user makes an outside call using an SDN button on his / her own extension.
  1. Own Extension (default)  
His / her own toll restriction level (determined by COS programming) is applied to the call.

## 2. PDN

Toll restriction level of the PDN owner is applied to the call.

- SDN buttons can be used to answer the following types of call which come in on its associated PDN.
  - DIL 1:1
  - DISA
  - DID / DDI / MSN
  - UCD
  - Call hunting
  - IRNA
  - Extension
- Up to eight SDN buttons per PDN button (DN type PT only) can be assigned on eight different PTs respectively.
- On a single PT, up to three different SDN buttons can be assigned.
- **Delayed Ringing**  
Immediate, delayed or no ringing can be assigned to SDN buttons. Each SDN button can have unique delayed ringing assignment respectively.
- **Ring Tone Selection (DPT only)**  
A ringing tone type for an SDN button can be selected either by Station or System Programming.
- **Ring Transfer**  
An extension user can transfer a call on an SDN button to its associated PDN button simply by pressing the SDN button.  
Please refer to "Ring Transfer" in this manual.
- **PDN Call**  
An SDN button can be used to call the extension which has the PDN button associated with the SDN with a simple operation.  
Please refer to "PDN Call" in this manual.

## Programming Guide References

- 2.4 Class of Service (COS)
  - SDN COS
- 4.3 Extension Line
  - CO Key

## Features Guide References

- 1.6 Originating Features
  - PDN Call
- 1.11 Transferring Features
  - Ring Transfer
- 1.13 Audible Tone Features
  - Ringing, Delayed

1.16 Button Features

- Button, Line Access – Primary Directory Number (PDN)
- LED Indication

**User Manual References**

- 2.2.1 Basic Calling
- 2.3.1 Answering Calls
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## Button, Line Access – Single-CO (S-CO)

### Description

A Single-CO (S-CO) button is a CO line access button. This allows the PT user to get a specific line for making or receiving outside calls simply by pressing an S-CO button. An incoming call can be directed to an S-CO button.

Assignable for both ICM type and DN type PTs.

#### LED Indicator Patterns — S-CO

Indicator	Line status
Off	Idle
Green On	You are using the line.
Green slow flash	You have a held call.
Green moderate flash	You have one of the following: <ol style="list-style-type: none"> <li>1. Exclusive hold</li> <li>2. Consultation hold</li> <li>3. Conference, unattended</li> </ol>
Green rapid flash	Hold Recall / Privacy release possible / an outside call is coming in on a single extension.
Red On	Other in use / Other on exclusive hold
Red slow flash	Other on hold
Red moderate flash	—————
Red rapid flash	An outside call is coming in on multiple extensions simultaneously.

### Conditions

- **S-CO Button Assignment**  
 An S-CO button can be assigned to a flexible CO button on a PT or a flexible DSS button on a DSS Console by Station, User or System Programming.  
 However, an S-CO button assigned to a DSS button of a DSS console is available for monitoring the call activity only, not available for making or receiving a call.
- **Busy / Idle Status**  
 An S-CO button indicator provides busy / idle status of the CO line.
- It is possible to assign one CO line to both an S-CO and a G-CO button at a time.
- It is possible to assign the Single-CO, Group-CO and Loop-CO buttons on one PT.  
 Incoming and outgoing calls on the line are shown on the button in the following priority.  
 Single-CO > Group-CO > Loop-CO
- You cannot assign the same CO line to more than one S-CO button on a PT.

- **ARS Override**  
If Automatic Route Selection (ARS) is set, it is overridden by an outgoing call made by pressing the S-CO button.
- **Ringing Tone Selection (DPT only)**  
A ringing tone type for S-CO buttons can be selected either by Station or System Programming.

## Programming Guide References

- 2.4 Class of Service (COS)
  - Trunk Group Setting
- 4.3 Extension Line
  - CO Key
- 4.4 DSS Console
  - DSS Key

## Features Guide References

- 1.6 Originating Features
  - Trunk Access, Direct
  - Trunk Access, Individual Trunk
- 1.9 Answering Features
  - Answering, Direct Trunk
- 1.13 Audible Tone Features
  - Ringing Tone Selection
- 1.16 Button Features
  - LED Indication

## User Manual References

- 2.2.1 Basic Calling
- 2.3.1 Answering Calls
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)



# Buttons on Proprietary Telephones

## Description

Proprietary Telephones are provided with the feature / line access buttons listed below:

Buttons	7020	7030	7050	7055	7130	7220	7230	7235	7250	7420	7425	7431	7433	7436	7450	7451
AUTO ANSWER / MUTE* <sup>1</sup>	✓	✓			✓	✓	✓	✓		✓	✓	✓	✓	✓	✓	
AUTO DIAL / STORE* <sup>1</sup>	✓	✓	✓	✓* <sup>2</sup>	✓	✓	✓	✓	✓* <sup>2</sup>	✓	✓	✓	✓	✓	✓	✓
CO* <sup>1</sup> * <sup>3</sup>	✓ (12)	✓ (12)	✓ (12)	✓ (3)	✓ (12)	✓ (24)	✓ (24)	✓ (12)	✓ (6)	✓ (12)	✓ (24)	✓ (12)	✓ (24)	✓ (24)	✓ (12)	✓ (4)
CONF* <sup>1</sup>	✓	✓	✓* <sup>2</sup>	✓* <sup>2</sup>	✓	✓	✓	✓		✓	✓	✓	✓	✓	✓	
FLASH* <sup>1</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Function								✓ (10)						✓ (10)		
FWD / DND* <sup>1</sup>	✓	✓			✓	✓	✓	✓		✓	✓	✓	✓	✓	✓	
HOLD	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
INTERCOM* <sup>1</sup>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Jog Dial										✓	✓	✓	✓	✓	✓	
MESSAGE* <sup>1</sup>	✓	✓	✓		✓	✓	✓	✓		✓	✓	✓	✓	✓	✓	
MODE												✓				
MONITOR			✓* <sup>1</sup>	✓					✓						✓	✓
PAUSE	✓	✓	✓	✓	✓		✓	✓		✓	✓	✓	✓	✓	✓	
PF (Programmable Feature)	✓ (4)	✓ (4)	✓ (4)	✓ (3)	✓ (12)											
PROGRAM						✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
REDIAL	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
SAVE					✓											
SELECT												✓				

Buttons	7020	7030	7050	7055	7130	7220	7230	7235	7250	7420	7425	7431	7433	7436	7450	7451
SHIFT* <sup>1</sup>							✓	✓					✓	✓		
Soft							✓ (3)	✓ (3)					✓ (3)	✓ (3)		
SP-PHONE* <sup>1</sup>	✓	✓			✓	✓	✓	✓		✓	✓	✓	✓	✓		
TRANSFER	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
VOLUME						✓	✓	✓	✓							✓

✓ : The button is provided on the designated telephones.

(x) : Shows the number of buttons only if multiple buttons are provided.

\*<sup>1</sup> : The button is provided with an LED (Light Emitting Diode).

\*<sup>2</sup> : The button is provided without an LED.

\*<sup>3</sup> : The buttons which can be changed to function as a feature button are called flexible buttons.

The functions of the listed buttons are described below:

**AUTO ANSWER / MUTE:**

This dual function button is used for hands-free answer back and microphone mute during a conversation.

**AUTO DIAL / STORE:**

Used for System Speed Dialling and storing programme changes.

**CO (Central Office line):**

Used to make or receive an outside call. This can be re-assigned to a different CO or to various feature buttons.

**CONF (Conference):**

Used to establish a 3-party conference call.

**FLASH:**

Used to disconnect the current call and get another line for making a call without hanging up (Flash). Sends a flash signal to the Central Office or host PBX to access their features (External Feature Access).

**Function:**

Used to perform the displayed function / operation.

**FWD / DND (Call Forwarding / Do Not Disturb):**

Used to programme Call Forwarding, set Do Not Disturb.

**HOLD:**

Used to place a call on hold.

**INTERCOM:**

Used to make or receive intercom calls.

**Jog Dial:**

Used to adjust the volume of the handset receiver, headset, ringer and speaker. It also adjusts the display contrast. Please refer to "2.1 Before Operating the Telephones" of the User Manual. For KX-T7431, KX-T7433 and KX-T7436 users, it is also used to select data from the Call Directory and the System Feature Access Menu.

**MESSAGE:**

Used to send a message indication to another extension, and confirm and call back the message sender.

**MODE:**

Used to shift the display in order to access various features.

During the Station Speed Dialling Number / Name assignment, this button is used to enter the name assignment mode.

**MONITOR:**

Used for hands-free operation.

**PAUSE:**

Used to insert a pause in a System Speed / Station Speed / One-Touch Dialling number. With an APT, this button is used as the PROGRAM button.

**PF (Programmable Feature):**

This flexible button can be programmed to be a One-Touch Dialling, FWD / DND, SAVE, Account, CONF (Conference), Answer or Release button as desired.

**PROGRAM:**

Used to enter / exit the Programming mode. With the KX-T7220 and KX-T7250, this button can be used as the PAUSE button.

**REDIAL:**

Used for Last Number Redial.

**SAVE:**

Used to store a dialled telephone number for Saved Number Redial.

**SELECT:**

Used to select the displayed function or to call the displayed phone number.

**SHIFT:**

Used to access the next level of Soft button function.

**Soft:**

Pressing a Soft button performs the function / operation appearing on the bottom line of the display.

**SP-PHONE (Speakerphone):**

Used for hands-free operation. Pressing the button causes the telephone to switch between handset and hands-free operation.

**TRANSFER:**

Used to transfer a call to another extension or external destination.

**VOLUME:**

Used to adjust the speaker / handset receiver / headset / ringer, speaker, handset and headset volume and the display contrast.

During Special Display Features operation, this button is used to change the display.

## Conditions

- **LED Indication**  
Certain buttons are equipped with LED (light-emitting diode) indicators to show line or feature status.
- **CO Button Type**  
CO buttons can be classified as the following three types:  
Single-CO (S-CO) button / Group-CO (G-CO) button / Loop-CO (L-CO) button
- For the operation of each button, please refer to the User Manual.

## Programming Guide References

- 4.3 Extension Line
  - CO Key

## Features Guide References

None

## User Manual References


- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# LED Indication

## Description

The LED (Light Emitting Diode) indicators of the Line Access Buttons display the line conditions with the following lighting patterns: Off, Steady On, Slow flash, Moderate flash, Rapid flash

### Flashing light (winks) patterns



## Conditions

None

## Programming Guide References

System programming is not required.

## Features Guide References

### 1.16 Button Features

- Button, Line Access – Group-CO (G-CO)
- Button, Line Access – INTERCOM (ICM)
- Button, Line Access – Loop-CO (L-CO)
- Button, Line Access – Primary Directory Number (PDN)
- Button, Line Access – Secondary Directory Number (SDN)
- Button, Line Access – Single-CO (S-CO)

## User Manual References

Not applicable.

## 1.17 Display Features

### Absent Message Capability

#### Description

Once set, this option provides a message, on the display of the calling extension, to show the reason for the called extension's absence. Up to nine absent messages, common to all extension users, can be programmed as desired.

There are six pre-programmed default absent messages.

Message No.	Message
1	Will Return Soon
2	Gone Home
3	At Ext % % % % └── Extension number
4	Back at % % : % % └── Minute └── Hour
5	Out Until % % / % % └── Day └── Month
6	In a Meeting
7-9	—

#### Note

The "%" means a parameter to be entered when assigning a message at individual extension.

#### Conditions

- Absent Messages can be programmed either by User or System Programming.
- Setting or cancelling an absent message can be done by any extension user but only callers with a display PT can receive the absent message.
- An extension user can select only one absent message at a time.  
A newly assigned absent message overwrites the previous one.
- The selected message is displayed every time the extension user (who set the message) goes off-hook.

## **Programming Guide References**

- 2.3 Numbering Plan
  - Absent Message Set / Cancel
- 5.9 Absent Message

## **Features Guide References**

None

## **User Manual References**

- 2.5.3 Showing an Absent Message on the Caller's Telephone Display (Absent Message Capability)
- 4.3.8 Absent Messages Set (008)

# Bilingual Display

## Description

Provides the display PT user with either an English or the second language (option) display. Either display can be selected by Station or System Programming.

## Conditions

None

## Programming Guide References

- 2.9 Language Data
- 4.3 Extension Line
  - Language

## Features Guide References

None

## User Manual References

- 4.1.1 Initial Settings



# Busy Lamp Field

## Description

The LED (Light Emitting Diode) indicators of the DSS (Direct Station Selection) buttons, each of which corresponds to a selected extension, display whether the corresponding extensions are idle or busy.

## Conditions

- **DSS Button Assignment**  
This function is available for DSS buttons on DSS Consoles and for flexible CO buttons assigned as DSS buttons on PTs.
- **Log-in / Log-out**  
DSS buttons reflect the Log-in / Log-out status of the extensions in the Extension Group (UCD) as follows: Off - Log-in, Red slow flashing - Log-out.
- A DSS button indicator lights red if the corresponding extension is busy.

## Programming Guide References

- 3.3 Extension Group
  - [UCD Setting] LOGIN Monitor
- 4.3 Extension Line
  - CO Key
- 4.4 DSS Console
  - DSS Key

## Features Guide References

- 1.15 Proprietary Telephone Features
  - DSS Console
- 1.16 Button Features
  - Button, Direct Station Selection (DSS)

## User Manual References

- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

# Call Log, Incoming

## Description

This is one of the Caller ID service features available for the display DPT (KX-T7230, KX-T7235, KX-T7433, KX-T7436) users only. When an incoming CO call with Caller ID information directed to an extension is not answered, Caller ID information is automatically recorded in the Call Log of the called extension. This information can be used for confirming the caller and callback purposes.

### Automatic Recording

If an incoming CO call directed to a single extension was not answered, the caller's information is automatically recorded in the Call Log of the called extension just after the call ringing has stopped.

### Manual Recording

The extension user can record the caller's information manually during or after the call until the next caller information is displayed.

Up to 30 Call Records can be logged in the Call Log either automatically or manually per display DPT extension.

### [Display example]

Caller's information is displayed as follows:

10101:AB COMPANY	— Trunk Port Physical Number, Name
0102030405	— Caller ID Number
BOB HANKS	— Caller ID Name
Oct30 09:00PM	— Date, Time
SEQ01 02 CALL	— Sequence Number (01-30)/
MENU CLR NEXT	Number of Times Called (30 times max.)

### Callback

The extension user can call back the outside caller by choosing the appropriate Call Records in the Call Log.

## Conditions

- **Calls to multiple DPTs (DIL 1:N, Ring Group, Phantom extensions)**  
If a call rang at more than one extension simultaneously but was not answered, the caller's information is recorded in the Call Log of the DPT with the lowest physical number.
- **Transferred Call**  
If a Caller ID call is transferred to an extension but not answered by the destination extension, the Call Record is logged in the Call Log of both the transfer originator and the transfer destination.
- **Call Log Incoming, Overwrite Mode**  
If the Call Log is full (30 call records are already logged) when a new Caller ID call comes in, the extension user can choose one of the following two options.
  - a) a new call record overwrites the oldest one in the Call Log
  - b) a new call record is not logged

- **Call Log Incoming, Log Lock**  
The extension user can lock the call log display so that incoming call information is not shown on the display. The Manager or an Operator can cancel the "Call Log Incoming, Log Lock" in case the extension user forgets the lock code.
- **Callback Process**  
The system automatically modifies the incoming caller's number in a pre-programmed way for local or long distance calls.
- **<System Programming example>**  
"Section 5.12 Caller ID Modification" (See Programming Guide)
  - (1) Local Area Code : 201
  - (2) Digits to delete for local calls : 3
  - (3) Number to be added for local calls : blank
  - (4) Digits to delete for long distance calls : 0
  - (5) Number to be added for long distance calls : 1

	<b>Caller's number provided by CO</b>	<b>Recorded caller's number</b>
Local call	2011234567	1234567 (modified by steps (2) and (3))
Long distance call	7149876543	17149876543 (modified by steps (4) and (5))

## Installation Manual References

- 2.5.11 ELCOT Card (KX-TD50180)
- 2.7.3 Caller ID Card (KX-TD193)

## Programming Guide References

- 2.3 Numbering Plan
  - Call Log Incoming, Overwrite Mode
  - Call Log Incoming, Log Lock
- 2.8 System Option
  - Automatic adjustment of the clock using Caller ID information
- 4.2 Trunk Line
  - Name
- 4.3 Extension Line
  - Initial Display Selection
  - [Call Log Incoming] Overwrite Mode
  - [Call Log Incoming] Lock Password
- 5.12 Caller ID Modification
  - [Local Call] Area Code
  - [Local Call] Digits to delete
  - [Local Call] Number to be added
  - [Long Distance Call] Digits to delete
  - [Long Distance Call] Number to be added
- 5.13 Caller ID Registration
- 10.4 SMDR
  - Priority of Caller ID information

## Features Guide References

- 1.5 Attended Features
  - Caller ID Service

## User Manual References

- 2.10.1 Calling Using the Call Log (Incoming Call Log) [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]
- 2.10.2 Recording a Call Log [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]
- 2.10.3 Denying Other People the Possibility of Seeing Your Call Log (Incoming Call Log Lock) [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]
- 3.1.4 Changing the Settings (Station Programming)

# Display Contrast Adjustment

## Description

Allows the display PT user to adjust the display contrast.

The adjusting method differs depending on the type of PT.

### **DPT**

Soft buttons and Volume button are used to adjust the contrast to one of three levels.

### **APT**

A sliding lever on the telephone (CONTRAST selector) is used to select one of three levels.

## Conditions

None

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

- 2.1 Before Operating the Telephones

# Display, Call Information

## Description

The display PT shows the extension user the following call information:

### Extension number and name

These are shown when calling or called by an extension user and during an established intercom call.

A display example: **123: Tony Viola**

### Dialled telephone number

This is shown when dialling the telephone number.

A display example: **1234567890**

### Number or name of the caller

These are shown if the Caller ID feature is available.

Display examples:

**10101: 1234567890**

**10101: Panasonic**

### CO Line number and name

This is shown when receiving a CO call.

A display example: **10101: AB COMPANY**

### Charge Meter

This is shown during an established call.

A display example: **10101: 5**

### Charge Fee

This is shown during an established call.

A display example: **10101: \$ 1.15**

### DDI / DID number and name

These are shown when receiving a DDI / DID call.

Display examples:

**DID: Tony Viola** (When "Name" is registered.)

**10101: CO001**(When "Name" is not registered.)

### Call duration of outside call

This is shown during an established CO call. The display remains for 5 seconds after the call is finished.

A display example: **10101 0 : 02'28**

## Conditions

- Extension numbers and names are programmable. If no extension name is stored, only the extension number is displayed.
- Intercom Call Duration is not shown on the display.
- The outgoing CO call duration count starts when a specified time expires.

- **Caller ID Service**

Depending on a type of the CO line, Caller ID Service can be classified as follows:

- 1) Analogue CO line - Caller ID Service
- 2) ISDN CO line - CLIP (Calling Line Identification Presentation) Service
- 3) E-1 CO line - ANI (Automatic Number Indication) Service

- **Charge Fee Reference**

It is programmable to select the first display, meter or charge, by System Programming. To alternate the display, press the FWD / DND button.

## **Programming Guide References**

- 2.5 System Timer
  - Call Duration Count Start Time
- 4.2 Trunk Line
  - Name
- 4.3 Extension Line
  - DN
  - Name
  - Initial Display Selection
- 5.13 Caller ID Registration
- 5.15 Charge

## **Features Guide References**

- 1.5 Attended Features
  - Caller ID Service

## **User Manual References**

- 2.10.1 Calling Using the Call Log (Incoming Call Log) [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]

# Display, Date and Time

## Description

Allows the display PT users to display the following "Date and Time Notation" while on-hook.

**Display example :** Day, Month, Time (AM / PM)

01 JAN 12:00AM
----------------

## Conditions

- The display PT users can alternate between "Date and Time" display and " Self-extension number" display by pressing "\*" while on-hook.
- The "Date and Time" display can be set to either "D / M / Y" or "M / D / Y" (default) format by System Programming.
- The "Date and Time" display can be set to either "12-hour" (default) or "24-hour" format by System Programming.
- The current date and time are set by User or System Programming.

## Programming Guide References

- 2.8 System Option
  - LCD Time Display Mode
  - Date Display
- 10.7 System Time

## Features Guide References

None

## User Manual References

- 4.3.1 Date and Time Set (000)




# Display, Self-Extension Number

## Description

Allows the display PT user to display their own extension port physical number and extension number in Station Programming mode.

### Display example :



## Conditions

None

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

- 4.1.1 Initial Settings

# Message Waiting

## Description

Allows an extension user to indicate to another extension that a message is waiting for him or her, by turning on the MESSAGE indicator (button) of the called extension.

The extension that received the message waiting indication can call back the message sender simply by going off-hook and pressing the red lit MESSAGE indicator (button). Up to 448 message indications can be set in the system. This feature is useful when the called extension is busy or does not answer the call.

## Conditions

- **Turning off the light**  
Either the message sender or the receiver can turn off the light.
- Messages are always left on the first called extension. It is not sent to a Call Forwarding or Station Hunting destination.
- **MESSAGE button**  
If a MESSAGE button is not provided on a PT, it can be assigned to a flexible (CO, DSS) button by Station, User or System Programming.
- **VPS Integration**  
If VPS Integration is employed, a VM extension informs an extension that a message is left in his / her mailbox by turning on the MESSAGE lamp. The extension user can listen to the message in the mailbox simply by pressing the red lit MESSAGE lamp.
- **SLTs with message waiting lamp**  
Any extension user can turn on the message waiting lamp on an SLT in the same way as the PTs. SLTs with message waiting lamp should be connected to an ESLC (KX-TD50175) or SLC-M (KX-T96175) card.  
One of 12 message waiting lamp lighting patterns (for SLTs) can be selected by System Programming.

## Programming Guide References

- 2.3 Numbering Plan
  - Message Waiting Set / Cancel / Call Back
- 2.8 System Option
  - Message Waiting lamp pattern
- 4.3 Extension Line
  - Message Lamp
  - CO Key
- 4.4 DSS Console
  - DSS Key
- 5.11 VPS Integration
  - Turn off control of Message Waiting lamp

## Features Guide References

### 1.3 System Features

- VPS Integration – Voice Mail (VM) Service Integration

## User Manual References

- 2.2.4 When the Dialed Line is Busy or There is No Answer
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

## SPECIAL DISPLAY Features – A SUMMARY

### Description

With the display telephone, KX-T7235, KX-T7433 or KX-T7436, the extension user can easily access several features. The display telephones have the ability to perform the following features.

Feature	KX-T7235	KX-T7433	KX-T7436
Call Directory	✓	✓	✓
Extension Dialling	✓	✓	✓
Station Speed Dialling	✓	✓	✓
System Speed Dialling	✓	✓	✓
Call Forwarding / Do Not Disturb	✓		✓
Call Log, Outgoing	✓		✓
System Feature Access Menu	✓	✓	✓

" ✓ " indicates the feature is available.

### Conditions

# Special Display Features – Call Directory – Extension Dialling

## Description

Provides a display of extension names. This is convenient to make an extension call just by name. The extension user can call another extension simply by pressing the Function button associated with the name.

## Conditions

- Extension name can be programmed either by User or System Programming.
- **Tenant Service**  
If Tenant Service is employed, only the extension names within the same tenant are displayed.

## Programming Guide References

- 4.3 Extension Line  
– Name

## Features Guide References

None

## User Manual References

- 2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235
- 4.3.4 Extension Name Set (004)

# Special Display Features – Call Directory – Station Speed Dialling

## Description

A list of the names and telephone numbers stored in One-Touch Dialling is displayed. This allows the extension user to make a One-Touch call by knowing just the name.

## Conditions

- It is necessary to program One-Touch Dialling Numbers and Names into one of the 10 Function buttons (F1 through F10).
- **Initial Display Selection**  
Initial display of Station Speed Dialling display can be number or name. An extension user can choose either by Station or System Programming.

## Programming Guide References

- 2.8 System Option
  - Station Speed Dialling Initial display

## Features Guide References

- 1.7 Dialling Features
  - One-Touch Dialling

## User Manual References

- 2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235

# Special Display Features – Call Directory – System Speed Dialling

## Description

A list of the names stored in System Speed Dialling is displayed. This allows the extension user to dial by name without having to know the telephone number. All the user needs to do is to press the Function button associated with the desired name.

## Conditions

- System Speed Dialling numbers and names can be programmed either by User or System Programming.
- If a name is not stored for a number, it is not displayed and cannot be called with this feature.
- **Tenant Service**  
If Tenant Service is employed, System Speed Dialling numbers and names being displayed is limited within the same tenant.

## Programming Guide References

- 5.2 System Speed Dialling
  - Tenant No.
  - Name
  - Number

## Features Guide References

- 1.7 Dialling Features
  - System Speed Dialling

## User Manual References

- 2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235
- 4.3.2 System Speed Dialling Number Set (001)
- 4.3.3 System Speed Dialling Name Set (002)

## Special Display Features – Call Forwarding / Do Not Disturb

### Description

Allows the KX-T7436 and KX-T7235 users to set or cancel the Call Forwarding and Do Not Disturb (DND) features using the display messages after pressing the FWD / DND button.

### Conditions

None

### Programming Guide References

System programming is not required.

### Features Guide References

- 1.8 Ringing Features
  - Do Not Disturb (DND)
- 1.11 Transferring Features
  - Call Forwarding – All Calls
  - Call Forwarding – Busy
  - Call Forwarding – Busy / No Answer
  - Call Forwarding – Follow Me
  - Call Forwarding – No Answer
  - Call Forwarding – to CO / TIE

### User Manual References

- 2.5.1 Forwarding Your Calls (Call Forwarding)



# Special Display Features – Call Log, Outgoing

## Description

Provides a display of the last five outside telephone numbers (up to 16 digits for each) dialled at the extension. This allows the extension user to redial the number by pressing the Function button associated with the telephone number.

This is an extended version of "Last Number Redial."

## Conditions

- If the Call Log is full when a new outside call is made, the oldest telephone number is overwritten by a new one.

## Programming Guide References

System programming is not required.

## Features Guide References

None

## User Manual References

- 2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235

## Special Display Features – System Feature Access Menu

### Description

This feature provides a display of the system features available at any time and allows the extension user to have access to the desired features.

- The features available are:

Absent Message Capability	Electronic Station Lockout
Automatic Callback Busy (Camp-On) Cancel	Executive Busy Override Deny
Call Forwarding (set / cancel)	External Modem Control
Call Log, Incoming	Live Call Screening (LCS), Password Set
Call Log Incoming, Log Lock	Log-In / Log-Out
Call Park	Message Waiting
Call Pickup, access / deny	Paging, access / answer / deny
Call Waiting	Pickup Dialling (Hot Line)
Data Line Security	Station Programme Clear
Do Not Disturb (set / cancel)	Timed Reminder (Wake-Up Call)
Door Opener	Walking COS
Doorphone Call	

- In addition to the features above, the Manager extension can execute the following features.

Background Music (BGM) – External	Timed Reminder, Remote (Wake-Up Call)
Outgoing Message (OGM), Record / Playback	Trunk Busy-out Setting
Remote DND (Do Not Disturb)	Trunk Route Control
Remote FWD (Call Forwarding) Cancel-Once	UCD Monitor Mode

### Conditions

None

### Programming Guide References

System programming is not required.

## **Features Guide References**

None

## **User Manual References**

- 2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235



---

## *Section 2*

### *ISDN Features*

## 2.1 ISDN Features

### Integrated Services Digital Network (ISDN)

#### Description

Integrated Services Digital Network (ISDN) is a hierarchy of digital switching and transmission systems. ISDN transmits voice, data, and image in digital format. It is synchronised so all digital elements speak the same language at the same speed.

#### [ISDN Interface]

ISDN provides the following two interfaces:

##### •Basic Rate Interface (BRI)

BRI provides two 64,000 bps B channels for data transmission and one 16,000 bps D channel for signalling (2B + D).

##### •Primary Rate Interface (PRI)

PRI provides thirty 64,000 bps B channels for data transmission and one 64,000 bps D channel for signalling (30B + D).

#### [System Hardware Requirements]

To interface the KX-TD500 System with ISDN, one of the following two trunk cards is required depending on the ISDN interface type.

•KX-TD50288 (BRI Card) for Basic Rate Interface

•KX-TD50290 (PRI30 Card) for Primary Rate Interface


#### [Access Mode]

The KX-TD500 System can handle calls from ISDN with Point-to-Point (P-P) and / or Point-to-MultiPoint (P-MP) access mode. The PRI30 Card (KX-TD50290) is available for P-P access mode only.

##### Point-to-Point (P-P) access mode

A call from ISDN with DDI(Direct Dialling In) number is directed to a specific regular extension (with DN) or virtual extension (with FDN) directly after translation of the DDI number.

##### DDI (Direct Dialling In) Configuration




##### Point-to-MultiPoint (P-MP) access mode


If Multiple Subscriber Number (MSN) service is contracted with the Central Office, up to eight extensions and / or terminals can be connected to one ISDN BRI line. A different DN is assigned to each extension or terminal. A call from ISDN is directed to a specific regular

extension (with DN) or virtual extension (with FDN) directly after translation of the MSN number.

### MSN (Multiple Subscriber Number) Configuration



### Flow chart of required programmes for ISDN



### Conditions

None

### Programming Guide References

- 1.2 Slot Assignment
- 1.9 BRI Port Assignment
- 1.10 PRI Port Assignment
- 4.2 Trunk Line
  - Incoming Type
  - Digits to receive DDI / DID
  - [DDI / DID / TIE] Digits to delete
  - [DDI / DID / TIE] Number to be added
- 9.2 Number Transformation
  - DID / DDI / MSN No.

### Features Guide References

- 2.4 ISDN Attended Features
  - Direct Dialling In (DDI)
  - Multiple Subscriber Number (MSN) Ringing Service

### User Manual References

Not applicable.



## 2.2 ISDN Originating Features

### Calling Line Identification Presentation(CLIP)

#### Description

Calling Line Identification Presentation (CLIP) enables the calling party's number to be shown on the display of the called party's telephone when a call is received.

This is one of ISDN services. To use the CLIP service, number assignments are required as follows:

To use the CLIP service, number assignments are required as follows:

- CLIP / COLP number for each outside line
- CLIP / COLP number for each extension

#### Conditions

- The CLIP service for outgoing CO calls can be restricted by System Programming (CLIR: Calling Line Identification Restriction).
- The number actually sent to the calling or called party may be different from the system programming number. It depends on the contract with your ISDN supplier.

#### Programming Guide References

- 1.9 BRI Port Assignment
- 1.10 PRI Port Assignment
- 2.3 Numbering Plan
  - CLIP / COLP
- 4.2 Trunk Line
  - Subscriber
- 4.3 Extension Line
  - [CLIP / COLP Number] Public
  - [CLIP / COLP Number] Private

#### Features Guide References

- 2.2 ISDN Originating Features
  - Calling Line Identification Restriction (CLIR)

#### User Manual References

- 2.7.5 Displaying Your Number on the Called Party and Calling Party's Telephone (Calling / Connected Line Identification Presentation [CLIP / COLP])

# Calling Line Identification Restriction (CLIR)

## Description

Allows the extension user to restrict the presentation of the calling party's number to the called party when making a call. This is one of the ISDN services.

## Conditions

- If the presentation is enabled, the called party can check the calling party's number before the called party answers it (Calling Line Identification Presentation, CLIP).

## Programming Guide References

- 2.3 Numbering Plan
  - CLIR

## Features Guide References

None

## User Manual References

- 2.7.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])

# ISDN Network Service Access

## Description

ISDN provides a variety of supplementary services such as Calling Line Identification Presentation (CLIP) or Subaddressing or Call Forwarding, and some of them may require dialling of additional digits such as service access code. In this case, those additional digits can be stored in a flexible button for quick operation.

## Conditions

- For detailed information on ISDN services, please consult with the Central Office.

## Programming Guide References

- 4.3 Extension Line
  - CO Key

## Features Guide References

- 2.1 ISDN Features
  - Integrated Services Digital Network (ISDN)

## User Manual References

- 2.11.2 Accessing the ISDN Network Service (ISDN Network Service Access)
- 4.1.2 Customising the Buttons

## 2.3 ISDN Answering Features

### Connected Line Identification Presentation (COLP)

#### Description

Connected Line Identification Presentation (COLP) enables the called party's number to be shown on the display of the calling party's telephone when the called party answers a call. This is one of ISDN services. To use the COLP service, number assignments are required as follows:

To use the COLP service, number assignments are required as follows:

- CLIP / COLP number for each outside line
- CLIP / COLP number for each extension

#### Conditions

- The COLP service for outgoing CO calls can be restricted by System Programming (COLR: Connected Line Identification Restriction).
- The number actually sent to the calling or called party may be different from the system programming number. It depends on the contract with your ISDN supplier.

#### Programming Guide References

- 1.9 BRI Port Assignment
- 1.10 PRI Port Assignment
- 2.3 Numbering Plan
  - CLIP / COLP
- 4.2 Trunk Line
  - Subscriber
- 4.3 Extension Line
  - [CLIP / COLP Number] Public
  - [CLIP / COLP Number] Private

#### Features Guide References

- 2.3 ISDN Answering Features
  - Connected Line Identification Restriction (COLR)

#### User Manual References

- 2.7.5 Displaying Your Number on the Called Party and Calling Party's Telephone (Calling / Connected Line Identification Presentation [CLIP / COLP])

# Connected Line Identification Restriction (COLR)

## Description

Allows the extension user to restrict displaying the called party's number to the calling party when you receive the incoming call. This feature is one of the ISDN services.

## Conditions

If displaying is enabled, the calling party can check the called party's number before the called party answers it (Connected Line Identification Presentation).

## Programming Guide References

- 1.9 BRI Port Assignment
- 1.10 PRI Port Assignment
- 2.3 Numbering Plan
  - COLR
- 4.2 Trunk Line
  - Subscriber
- 4.3 Extension Line
  - [CLIP / COLP Number] Public
  - [CLIP / COLP Number] Private

## Features Guide References

- 2.2 ISDN Originating Features
  - Calling Line Identification Presentation (CLIP)
- 2.3 ISDN Answering Features
  - Connected Line Identification Presentation (COLP)

## User Manual References

- 2.7.7 Preventing Your Number Being Displayed on the Called Party's Telephone (Connected Line Identification Restriction [COLR])

## 2.4 ISDN Attended Features

### Direct Dialling In (DDI)


#### Description

Provides automatic direction of an incoming call from ISDN to a specific extension. To realise this service, the DDI number informed from ISDN is required. The DDI number is converted to a DN or FDN of the destination using a pre-programmed conversion table. This is an ISDN version of DID (Direct Inward Dialling) service.

#### Assignable destinations are:

1. Regular extension with DN
2. Virtual extension with FDN
  - External Pager (TAFAS)
  - Modem (Remote System Administration)
  - Extension Group
  - Phantom Extension

#### Call Flow



#### Digits Modification Procedures

The System modifies the DDI number according to the following three parameters.

1. **Digits to receive DDI / DID**  
The number of digits effective in the received DDI number.
2. **Digits to delete**  
The number of digits to be deleted from the beginning.
3. **Number to be added**  
The dials to be inserted at the beginning of the digits processed in Step 2.

**[Example]**

Digits to receive : 4 (digits)

Digits to delete : 1 (digit)

Number to be added : 2

The System modifies the received DDI number "4311" into "2311" as follows:

**Processed in Step 2:** 4311 → 311

The first digit "4" was deleted. This results in "311."

**Processed in Step 3:** 311 → 2311

The digit "2" was added to the beginning of "311." This results in "2311."

**DDI / DID Number Transformation**

The System converts the modified number into the destination DN or FDN according to this table.

**[Example]** The System searches for the number "2311" in the table. When matching is found, the call rings the corresponding extension or floating station.

Modified number (Max. 16 digits)	Destination (Day)	Destination (Night)	Destination Name (Max. 10 characters)
2311	200	300	PANASONIC

**Conditions**

- **What if the dialling digits received is not enough to decide the call destination?**

If the number of digits received is less than the number which is programmed in "Digits to receive DDI / DID", reorder tone is sent to the caller, or the call is redirected to the IRNA destination (IRNA feature). This is determined by System Programming.

- **What if the call destination is busy?**

If the destination of a DDI call is in busy status, the caller may hear a busy tone, or the call is redirected to the IRNA destination. This is determined by System Programming.

## **Programming Guide References**

- 1.9 BRI Port Assignment
- 1.10 PRI Port Assignment
- 2.8 System Option
  - Destination Busy - DDI / DID
  - Illegal Number - DDI / DID
- 3.2 Trunk Group
  - Intercept Destination – Day / Night
- 4.2 Trunk Line
  - Incoming Type
  - Digits to receive DDI / DID
  - [DDI / DID / TIE] Digits to delete
  - [DDI / DID / TIE] Number to be added
- 9.2 Number Transformation
  - DID / DDI / MSN No.

## **Features Guide References**

- 2.1 ISDN Features
  - Integrated Services Digital Network (ISDN)

## **User Manual References**

Not applicable.



---

# Multiple Subscriber Number (MSN) Ringing Service


## Description

Provides automatic direction of an incoming call from ISDN to a specific extension. To realise this service, the MSN number informed from ISDN is required. The MSN number is converted to a DN or FDN of the destination by using a pre-programmed conversion table.

### Assignable destinations are:

1. Regular extension with DN
2. Virtual extension with FDN
  - External Pager (TAFAS)
  - Modem (Remote System Administration)
  - Extension Group
  - Phantom Extension

### Call Flow



### Digits Modification Procedures

The System modifies the MSN number according to the following three parameters.

1. **Digit to receive DDI / DID**  
The number of digits effective in the received MSN number.
2. **Digits to delete**  
The number of digits to be deleted from the beginning of the digits processed in Step 1.

**3. Number to be added**

The dials to be inserted at the beginning of the digits processed in Step 2.

**[Example]**

Digits to receive DDI / DID: 4 (digits)

Digits to delete: 1 (digit)

Number to be added: 2

The System modifies the received MSN number "4311" into "2311" as follows:

**Processed in Step 1:** 4311 → 311

The first digit 4 was deleted. This results in 311.

**Processed in Step 2:** 311 → 2311

The digit 2 was added to the beginning of 311. This results in 2311.

**DDI / DID Number Transformation**

The System converts the modified number into the destination DN or FDN according to this table.

**[Example]**

The System searches for the number 2311 in the table. When matching is found, the call rings the corresponding extension or floating station.

<b>DID / DDI / MSN number (Max. 16 digits)</b>	<b>Destination (Day)</b>	<b>Destination (Night)</b>	<b>Name (Max. 10 characters)</b>
2311	200	300	PANASONIC

**Conditions**

- This service is available for ISDN BRI line only.
- **What if the dialling digits received is not enough to decide the call destination?**  
If the number of digits received is less than the number which is programmed in Digits to receive DDI / DID, reorder tone is sent to the caller, or the call is redirected to the IRNA destination (IRNA feature). This is determined by System Programming.
- **What if the call destination is busy?**  
If the destination of an MSN call is in busy status, the caller may hear a busy tone , or the call is redirected to the IRNA destination. This is determined by System Programming.

## Programming Guide References

- 1.9 BRI Port Assignment
- 2.8 System Option
  - Destination Busy - DDI / DID
  - Illegal Number - DDI / DID
- 3.2 Trunk Group
  - Intercept Destination – Day / Night
- 4.2 Trunk Line
  - Incoming Type
  - Digits to receive DDI / DID
  - [DDI / DID / TIE] Digits to delete
  - [DDI / DID / TIE] Number to be added
- 9.2 Number Transformation
  - DID / DDI / MSN No.

## Features Guide References

- 2.1 ISDN Features
  - Integrated Services Digital Network (ISDN)

## User Manual References

Not applicable.

## 2.5 ISDN Transferring Features

### Call Forwarding by ISDN Line

#### Description

This is the Call Forwarding feature provided by the ISDN Network.

This feature can be categorised as follows:

- **Call Forwarding Unconditional (CFU)**  
This allows you to have all your calls sent to another number via ISDN Network.
- **Call Forwarding Busy (CFB)**  
This allows you to have all your calls sent to another number via ISDN Network when your extension phone is busy.
- **Call Forwarding No Reply (CFNR)**  
Used to route incoming calls to another number via ISDN Network if your extension phone isn't answered after a pre-determined number of rings.

#### Conditions

- This feature can be used together with the regular Call Forwarding / Do Not Disturb feature provided by the KX-TD500 system.

#### Programming Guide References

- 2.3 Numbering Plan
  - Call FWD - Do Not Disturb Set / Cancel
- 9.2 Number Transformation
  - DID / DDI / MSN No.

#### Features Guide References

None

#### User Manual References

- 2.5.2 Forwarding Your Calls by ISDN (Call Forwarding by ISDN Provider)
- 4.1.2 Customising the Buttons
- 4.3.5 Flexible CO Button Assignment (005)

---

## *Section 3*

### *E&M Features*

## 3.1 E&M Features

### TIE LINES – A SUMMARY

#### Description


A TIE line is a privately leased communication line between two or more PBXs, which provides effective communications between company members at different locations.

TIE lines can be used to call through KX-TD500 to reach another switching system (PBX or CO). By utilising the TIE lines, the KX-TD500 can support not only communications with the public network but with other locations of the company in the private network of which your KX-TD500 can be a part.

To make a call to a person at a distant company location, an extension user must first obtain the appropriate TIE line to that person's PBX, and then dial the extension number only or a location number plus extension number.

#### A Network of TIE Lines


1. Interfaced by a TIE channel of E1 (Digital)



Hardware Requirements: E1 Digital Trunk card (KX-T96188)

T1 Digital Trunk card (KX-T96187)

2. Interfaced by an E&M card (Analogue)



Hardware Requirements: E&M card (KX-T96184)

#### Numbering Plan:

Extension users can make a call over the TIE Line Network to other extension users in a distant location by one of the following two ways: (See TIE LINES – Calling from TIE-to-TIE)

- a) Extension Number only

Extension Number

**b)** Location Number (PBX Code) + Extension Number

TIE Line Access Code

 + 

PBX Code

 + 

Extension Number

or

CO (TIE) button

### Routing Procedure 1: TIE Routing Table


Provides for the routing of calls over the TIE Line Network. Up to 36 routing patterns can be programmed in this table. This table is referenced by the system to identify the trunk route, when an extension user made a TIE call by dialling the feature number for "TIE Line Access" or other PBX extension number. A routing pattern appropriate for each call is decided by the first 3 digits (except TIE Line Access code) of the dialled number.

- **Routing Table Override**

If a TIE call is made by pressing a CO button, this table is not referenced by the system and the call is routed over the specified TIE line directly.

#### **(Programming Example)**

##### **A Network of TIE Lines**




**TIE Routing Table**

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	951	0		10				
02								
:								


When "(TIE Line Access Code) + 951 + 100" is dialled by an extension user, the routing pattern for this call is decided by "951." Then the call is routed over TG10.

**Routing Procedure 2: Routing Flow Chart (1)**

When a call is made by an extension user in your PBX





**Routing Procedure 3: Routing Flow Chart (2)**

## Conditions

- **Basic Programming**

The Programming items listed in the following "Programming Guide References" are always required to make use of TIE lines.

- **Application Programming**

Programming items required vary depending on a type of applications. Please refer to the following features for further information about each application programming.

- TIE LINES – Calling from TIE-to-TIE
- TIE LINES – Calling from TIE-to-CO
- TIE LINES – Calling from CO-to-TIE
- TIE LINES – Alternate Routing

## Programming Guide References

- 1.2 Slot Assignment
- 1.6 T1 Port Assignment
  - Channel Type
  - Group No.
- 1.7 E1 Port Assignment
  - Channel Type
  - Group No.
- 2.5 System Timer
  - TIE Inter-digit Time
- 4.2 Trunk Line
  - Group No.
  - [DDI / DID / TIE] Digits to delete
  - [DDI / DID / TIE] Number to be added

## Features Guide References

None

## User Manual References


Not applicable.

# TIE LINES – Alternate Routing

## Description

When more than two PBXs at different locations are interconnected with a network of TIE Lines, your KX-TD500 works as an intermediate switching office to other PBXs in the network by relaying TIE calls from one PBX to another. A problem of telephone switching is that blocking sometimes occurs on the network, and a call cannot be switched as required because all the lines on a given route are occupied or unavailable. By utilising this relay function, several alternative routes can be set up beforehand in addition to the primary-route. This permits TIE calls to be routed from "A to B" or "A through C to B" and so on. If the primary-route is poor because of equipment failure or congestion, KX-TD500 bypasses it and selects the secondary-route. On receipt of a TIE call, KX-TD500 analyzes it to determine the destination to which the call must be sent or the route by which the calls will be sent, and then transmit it. Alternate Routing makes a TIE Line network more flexible in adapting to peaks of traffic and it provides a variety of different routing plans.

### A Network of TIE Lines



## Call Flow

1. Ext.100 dials "77+952+200".
2. When "952" is found in the table, TG10 (Hunt Sequence 01 for "952") is selected automatically.
  - If TG10 is not available, TG11(Hunt Sequence 02) will be selected. In this case, the call is sent to PBX-2 via PBX-3 and -4. The treatment of the call is decided by Routing Table of PBX-3 and then PBX-4.
3. The call is sent to PBX-2.

### Programming example:

To realise the call flow mentioned above, the following System Programming is required at PBX-1, -3, and -4 respectively.

**PBX-1**

- 8.2 TIE Routing Table  
– PBX Code : 951

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	952	0		10	11			
02								
:								

- 2.7 Trunk to Trunk Restriction

**PBX-3**

- 8.2 TIE Routing Table  
– PBX Code : 953

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	952	0		12				
02								
:								

- 2.7 Trunk to Trunk Restriction

**PBX-4**

- 8.2 TIE Routing Table  
– PBX Code : 954

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	952	0		13				
02								
:								

- 2.7 Trunk to Trunk Restriction

**Note**

If you want to restrict "call relay from PBX-1 to PBX-2 via PBX-3," set TG11 to "Yes" at PBX-3 using Trunk to Trunk Restriction Programming.

## Conditions

None

## Programming Guide References

- 2.7 Trunk to Trunk Restriction
- 4.2 Trunk Line
  - [DDI / DID / TIE] Digits to delete
  - [DDI / DID / TIE] Number to be added
- 8.2 TIE Routing Table
  - PBX Code

## Features Guide References


None

## TIE LINES – Calling from CO-to-TIE

### Description

TIE lines are usually used to link two or more distant locations where high volume calling traffic exists. However, a person at a location outside of the TIE Line Network can also use it by first making a CO call via public network to the nearest point of TIE Line Network for the purpose of saving the toll call charge.

#### A Network of TIE Lines



### Call Flow

1. Employee-1 at a local branch makes a CO call to PBX-1 via DISA.
2. Employee-1 dials "77" (TIE Line Access Code).
3. After hearing dial tone, Employee-1 dials 951-100.
4. Employee-1 at a local branch will be connected to Ext.100 of PBX-2.

#### Programming example:

To make up the TIE Line Network above, the following System Programming is required at PBX-1 and -2 respectively.

#### PBX-1

- 2.7 Trunk to Trunk Restriction
- 8.2 TIE Routing Table
  - PBX Code : 950

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	951	0		10				
02								
:								

**PBX-2**

- 2.7 Trunk to Trunk Restriction
- 8.2 TIE Routing Table
  - PBX Code : 951

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	951	0		10				
02								
:								

**Conditions**

- **Trunk to Trunk Restriction**  
Used to allow or restrict trunk-to-trunk path connection. To permit the TIE caller to make a CO call via the TD500 System, the Trunk Group used for this purpose should be allowed to relay the call by System Programming.

**Programming Guide References**

- 2.7 Trunk to Trunk Restriction
- 4.2 Trunk Line
  - [DDI / DID / TIE] Digits to delete
  - [DDI / DID / TIE] Number to be added
- 8.2 TIE Routing Table
  - PBX Code

**Features Guide References**


- 1.11 Transferring Features
  - Call Forwarding – to CO / TIE
  - Call Transfer, Screened – to TIE
  - Call Transfer, Unscreened – to TIE

## TIE LINES – Calling from TIE-to-CO

### Description

TIE Lines can be used to minimise the cost of calls to a distant location outside of the TIE Line Network. A long distance call from one location may be a local call from another location. This fact should be considered before making a long distance call. If the destination of the long distance call is outside of the TIE Line Network, extension users first call to a distant PBX via TIE Line and then can make a local CO call to the final destination through that PBX.

#### A Network of TIE Lines



### Call Flow

1. Ext.100 dials 77-951-9 or 801 through 848 (TIE Line Access Code + PBX Code + CO Access Code).
2. Ext.100 may be required to enter a "DISA / TIE User Code" depending on the System Programming.\*<sup>1</sup>
3. Ext.100 hears dial tone from an idle CO line of PBX-2.
4. Ext.100 dials xxx-xxxx (phone number of the outside party).

#### Programming example:

To make up the TIE Line Network above, the following System Programming is required at PBX-1 and -2 respectively.

### PBX-1

- 8.2 TIE Routing Table  
– PBX Code

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	951	0		10				
02								

\*<sup>1</sup> Step 2 is required when "TIE-to-CO Security Mode" is set to "Yes" at PBX-2.



**PBX-2**

- 2.7 Trunk to Trunk Restriction
- 4.2 Trunk Line
  - TIE-to-CO Security Mode
- 8.2 TIE Routing Table
  - PBX Code

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	951	0		10				
02								
:								

**Conditions**

- **Trunk to Trunk Restriction**  
Used to allow or restrict trunk-to-trunk path connection. To permit the TIE caller to make a CO call via TD500 System, the Trunk Group used for this purpose should be allowed to relay the call by System Programming.
- **DISA / TIE User Code**  
Used to allow certain extension users "Calling from TIE to CO." If "TIE-to-CO Security Mode" of the Trunk Line is set to "Yes," an extension user must enter a valid DISA / TIE User Code before "Calling from TIE to CO."
- "Calling from TIE to CO" is available only when your system employs PBX Code (Location number) method for making / receiving TIE calls.

**Programming Guide References**

- 2.7 Trunk to Trunk Restriction
- 4.2 Trunk Line
  - [TIE Line] TIE-to-CO Security Mode
  - [DDI / DID / TIE] Digits to delete
  - [DDI / DID / TIE] Number to be added
- 5.10 DISA / TIE User Code
- 8.2 TIE Routing Table
  - PBX Code

**Features Guide References**

- 1.11 Transferring Features
  - Call Forwarding – to CO / TIE
  - Call Transfer, Screened – to TIE
  - Call Transfer, Unscreened – to TIE

## TIE LINES – Calling from TIE-to-TIE


### Description

TIE calls among several different company locations can be done by dialling a 3 or 4–digit extension number only, or by dialling a location number (PBX Code) and an extension number.

#### 1. Extension Number only

1. Extension users can make a call via TIE line to other extension users in other PBXs within a private network simply by dialling a 3 or 4–digit extension number.

#### A Network of TIE Lines



#### Call Flow

1. Ext.100 dials 200.
2. Ext.100 is connected to Ext.200 of PBX–2.

#### Programming example:

To make up the TIE Line Network above, the following System Programming is required at PBX–1 and –2 respectively.

#### PBX–1

- 2.3 Numbering Plan
  - (01) 1st Hundred Block Extension : 1
  - (77) Other PBX 01 : 2
- 8.2 TIE Routing Table

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	2XX	0		10				


**PBX-2**

- 2.3 Numbering Plan
  - (01) 1st Hundred Block Extension : 2
  - (77) Other PBX 01 : 1
- 8.2 TIE Routing Table

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	1XX	0		10				

**2. Location Number (PBX code) and Extension Number**

1. Extension users can make a call to other extension users in other PBXs within a TIE Line Network by dialling a location number (PBX Code) and an extension number. Each PBX in the same TIE Line Network can have its unique flexible extension numbering plan.

**A Network of TIE Lines****Call Flow**

1. Ext.100 of PBX-1 dials 77-951-100.
2. Ext.100 of PBX-1 is connected to Ext.100 of PBX-2.

**Programming example:**

To make up the TIE Line Network above, the following System Programming is required at PBX-1 and -2 respectively.

**PBX-1**

- 2.3 Numbering Plan
  - (76) TIE Line Access : 77
- 8.2 TIE Routing Table
  - PBX Code : 950

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	951	0		10				
02								
:								

**PBX-2**

- 2.3 Numbering Plan
  - (76) TIE Line Access : 77
- 8.2 TIE Routing Table
  - PBX Code : 951

No.	Leading Digit	Digits to delete	Number to be added	Trunk Group No.				
				01	02	03	04	05
01	950	0		10				
02								
:								

**Conditions**

None

**Programming Guide References**


- 2.3 Numbering Plan
  - TIE Line Access
- 2.7 Trunk to Trunk Restriction
- 4.2 Trunk Line
  - [DDI / DID / TIE] Digits to delete
  - [DDI / DID / TIE] Number to be added
- 8.2 TIE Routing Table
  - PBX Code
  - Leading Digit
  - Digits to delete
  - Number to be added
  - Trunk Group No.


---

## *Section 4*

### *Tones / Ring Tones*

<TONE>





This PBX fulfills the requirements of following European regulations:



73/23/EEC	"Low Voltage Directive"
89/336/EEC	"Electromagnetic compatibility" (Basic EMC Publication)
92/31/EEC	"Electromagnetic compatibility" (Supplement)
93/68/EEC	"CE mark"

For above mentioned standards the unit is signed with the CE-mark.

### Copyright:

This manual is copyrighted by Kyushu Matsushita Electric Co., Ltd. (KME). You may print out this manual solely for internal use with TD500. Except above, you may not reproduce this manual in any form, in whole or part, without the prior written consent of KME.

© Kyushu Matsushita Electric Co., Ltd. 2000

---

### Kyushu Matsushita Electric Co., Ltd.

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan