# **Panasonic**



# Digital Super Hybrid System User Manual

Model No. KX-TD500



Please read this manual before connecting the Digital Super Hybrid System.

# Thank you for purchasing the Panasonic Digital Super Hybrid System.




#### More Extensions •

This system can double the extension capacity by connecting a proprietary telephone and a single line telephone. The proprietary telephone can share the extension with another single line telephone. Furthermore, you can connect a Panasonic digital proprietary telephone and a single line telephone to one port and use them as individual extensions.



#### 1.2 Connection Example.



1.3 Adding Another Telephone in Parallel.

# Call Record (Station Message Detail Recording)

This system can record or print out call information: date, time, extension no., dialled no., duration, etc.

	Date	Time	Ext		
	06/24/97	10:03AM	123		1
1	06/24/97	11:07AM	223		
ᅪ				1	

Page 24.



Operation.

# You can forward your call to a voice processing system and let callers leave their messages in your mailbox when you are unable to receive calls.

VPS Integration in 2.8.3 If a Voice Processing System is Connected.

# **Note**

In this manual, the suffix of each model number is omitted.

# Warning

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. 73/23/EEC 89/336/EEC 92/31/EEC 93/68/EEC

# Important Information

# **WARNING**

THIS UNIT MAY ONLY BE INSTALLED AND SERVICED BY QUALIFIED SERVICE PERSONNEL. WHEN A FAILURE OCCURS WHICH RESULTS IN THE INTERNAL PARTS BECOMING ACCESSIBLE, DISCONNECT THE POWER SUPPLY CORD IMMEDIATELY AND RETURN THIS UNIT TO YOUR DEALER.

DISCONNECT THE TELECOM CONNECTION BEFORE DISCONNECTING THE POWER CONNECTION PRIOR TO RELOCATING THE EQUIPMENT, AND RECONNECT THE POWER FIRST.

THIS UNIT IS EQUIPPED WITH AN EARTHING CONTACT PLUG. FOR SAFETY REASONS THIS PLUG MUST ONLY BE CONNECTED TO AN EARTHING CONTACT SOCKET WHICH HAS BEEN INSTALLED ACCORDING TO REGULATIONS.

THE POWER SUPPLY CORD IS USED AS THE MAIN DISCONNECT DEVICE. ENSURE THAT THE SOCKET-OUTLET IS LOCATED / INSTALLED NEAR THE EQUIPMENT AND IS EASILY ACCESSIBLE.

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

#### Safety Instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- **1.** Do not use this product near water, for example, near a both tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- **2.** Avoid using a telephone (other than a cordless type) during an electric storm. There may be a remote risk of electric shock from lightning.
- **3.** Do not use the telephone to report a gas leak in the vicinity of the leak.
- **4.** Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

#### SAVE THESE INSTRUCTIONS

#### [Icon Descriptions]

The following icons are used frequently in this manual.



4 Important Information

# Attention

- Keep the unit away from heating appliances and electrical noise generating devices such as fluorescent lamps, motors and televisions. These noise sources can interfere with the performance of the unit.
- This unit should be kept free of dust, moisture, high temperature (more than 40°C) and vibration, and should not be exposed to direct sunlight.
- Never attempt to insert wires, pins, etc., into the vents or holes of this unit.
- If there is any trouble, disconnect the unit from the telephone line. Plug the telephone directly into
  the telephone line. If the telephone operates properly, do not reconnect the unit to the line until the
  problem has been repaired by an authorised Panasonic Factory Service Center. If the telephone
  does not operate properly, chances are that the problem is in the telephone system, and not in the
  unit
- Do not use benzine, thinner, or any abrasive powder to clean the cabinet. Wipe it with a soft cloth.

The serial number of this product may be found on the label affixed to the bottom of the unit. You should note the model number and the serial number of this unit in the space provided and retain this manual as a permanent record of your purchase, to aid in identification in the event of theft.		
MODEL NO.:		
SERIAL NO.:		
For future reference		
DATE OF PURCHASE		
NAME OF DEALER		
DEALER'S ADDRESS		

Attention 5

# Table of Contents

1	OVERVIEW	
1.1	Capacity	10
1.2	Connection Example	11
1.3	Adding Another Telephone in Parallel	
2	Operation	
2.1	Before Operating the Telephones	16
2.2	Making Calls	22
2.2.		
2.2.	2 Easy Dialling	25
2.2.		
2.2.		
2.2.		
2.2.		
2.2.	7 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])	46
2.3	Receiving Calls	48
2.3.	<b>o</b>	
2.3.	,	
2.3.		
2.3.	5 , , , , , , , , , , , , , , , , , , ,	
2.3.		
2.4	During a Conversation	56
2.4.	5	
2.4.	3 \ 1 \ 3/	
2.4.	<b>5</b>	
2.4.		
2.4.	1 ,	
2.4. 2.4.		
2.4.	and KX-T7436 only]	
2.4.	, .	
2.5	Before Leaving Your Desk	
2.5. 2.5.	5 \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	
2.5	· · · · · · · · · · · · · · · · · · ·	
2.5.		
2.5.		
2.6	Making / Answering an Announcement	
2.6.		
2.6. 2.6.		
۷.ن.	o Answering a rayeu Announcement	७∠

6

2.7	Setting the Telephone According to Your Needs	94
2.7.1	Setting the Alarm (Timed Reminder)	
2.7.2	Refusing Incoming Calls (Do Not Disturb [DND])	
2.7.3	Receiving a Call Waiting (Call Waiting / Off-Hook Call Announcement [OHCA Whisper OHCA)	-
2.7.4	Denying the Paged Announcement (Paging — Deny)	
2.7.5	Displaying Your Number on the Called Party and Calling Party's Telephone (Calling /	
	Connected Line Identification Presentation [CLIP / COLP])	102
2.7.6	Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])	103
2.7.7	Preventing Your Number Being Displayed on the Called Party's Telephone (Connected Li	
	Identification Restriction [COLR])	
2.7.8	Denying Other People the Possibility of Picking up Your Calls (Call Pickup Deny)	105
2.7.9	Denying Other People the Possibility of Joining Your Conversation (Executive	
	Busy Override Deny)	
2.7.10	3 3	
2.7.11	Protecting Your Line against Indication Tones (Data Line Security)	
2.7.12		
2.7.13 2.7.14		
2.8	Using User-supplied Equipment	114
2.8.1	If a Doorphone / Door Opener is Connected	
2.8.2	If a Host PBX is Connected	
2.8.3	If a Voice Processing System is Connected	
29	After Moving to a New Location in the Office	125
2.9.1	Using the Same Extension Number and the Setting of Your Previous Extensi	
2.5.1	(Walking Station)	
0.40	,	
2.10	Using the Display Proprietary Telephone	
2.10.	1 Calling Using the Call Log (Incoming Call Log) [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]	126
2.10.2	Recording a Call Log [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]	129
2.10.3	Denying Other People the Possibility of Seeing Your Call Log (Incoming Call Log Lock) [ T7433, KX-T7436, KX-T7230, KX-T7235 only]	
2 10 4	Using the KX-T7433, KX-T7436 or KX-T7235	
2.11		
	Controlling the External Modem (External Modem Control)	
2.11.2		
2.11.3	•	
2.11.4	Switching the Day / Night Service	154
	maratar / Managar Oparation	
, 0	perator / Manager Operation	
3.1	Extension Control	158
3.1.1	Setting the Alarm for Other Extensions (Remote Timed Reminder)	158
3.1.2	Setting or Cancelling the DND Feature to Other Extensions (Remote DND Control)	161
3.1.3	Calling the Extension that has set Call Forwarding (Remote FWD Cancel-Once)	
3.1.4	Changing the Settings (Station Programming)	164
3.2	System Control	165
3.2.1	Turning on the External Background Music (Background Music [BGM] - External)	
3.2.2	Recording Outgoing Messages	
	J	

Table of Contents 7

3.2.3 Trunk Busy-out Setting	169
3.2.4 Trunk Route Control	
3.2.5 Displaying a System Error Indication (Local Alarm Indication) [Manager only]	173
4 Customising Your Phone & System	
4.1 Customising Your Phone (Station Programming)	
4.1.1 Initial Settings	
4.1.2 Customising the Buttons	
4.2 Charge Fee Management (Station Programming)	186
4.3 Customising Your System (User Programming)	187
4.3.1 Date and Time Set (000)	196
4.3.2 System Speed Dialling Number Set (001)	
4.3.3 System Speed Dialling Name Set (002)	
4.3.5 Flexible CO Button Assignment (005)	
4.3.6 Caller ID Dial Set (006)	
4.3.7 Caller ID Name Set (007)	
4.3.8 Absent Messages Set (008)	
4.3.9 Quick Dial Number Set (009)	205
5 Appendix	
5.1 Troubleshooting	208
5.2 Feature Numbers List	212
5.3 Directory	216
5.4 What is This Tone?	230
5.5 Specifications	234
6 Index	
Index	235

Quick Reference Card for a Single Line Telephone


8 Table of Contents

# Section 1 OVERVIEW

This section briefly outlines your system.

# 1.1 Capacity

The KX-TD500 system can consist of one, two, or three shelves (Basic and Expansion1,2). Each shelf contains its own power supply. [Building Block System]



## Basic System

Basic System consists of one Shelf called Basic Shelf.

You can connect up to 192 lines (including Extensions and CO lines) to the Basic System.


#### 3-Shelf System


The KX-TD500 system's capacity can be expanded by installing up to two Expansion Shelves on the Basic Shelf. Fully expanded system (Basic Shelf + Expansion Shelf 1 + Expansion Shelf 2) is called "3-Shelf System."

You can connect up to 512 lines (including Extensions and CO lines) to the 3-Shelf System.

# 1.2 Connection Example

This diagram shows you a connection example including optional equipment.





· Parallel connections of extension is available. Please refer to "Paralleled Telephone" in 1.3 System Features of the Features Guide for further information.

# 1.3 Adding Another Telephone in Parallel

A Panasonic proprietary telephone and a single line telephone, including a facsimile, cordless telephone, etc., can be connected to one extension jack in parallel. There are two types of parallel connections.


#### Parallelled Telephone Connection

Any proprietary telephone and a single line telephone
These telephones share the same extension number. Follow Method 1 or 2.
To ring the single line telephone, set to ring (on) if necessary. (Please refer to "2.7.13 Setting the Parallel Connected Telephone Ringer (Parallelled Telephone Connection).")


#### Extra Device Port (XDP)

Digital proprietary telephone and a single line telephone Each telephone has a different extension number and can work individually. For more information, contact your dealer. Follow Method 2 or 3.


#### Method 1



## Method 2



## Method 3



# Section 2

# Operation

This chapter shows you how to operate each feature step by step. Read this chapter to become familiar with the many useful features of this system.

#### *2.1* Before Operating the Telephones

# What kind of telephone can be used?

You can use a single line telephone (SLT), such as a rotary pulse telephone or a Panasonic proprietary telephone (PT) such as the KX-T7436. Operate the feature depending on the telephone you are using. If you are using a Panasonic proprietary telephone with a special function button such

as and / or has a display (D-PT), you can follow the operation with the button or display messages for easy programming.

If you use a large display telephone (e.g. KX-T7436), you can follow the displayed messages to operate the features.

If your telephone does not have function buttons and / or a display, you may operate the unit by entering a feature number instead. Follow the available operation with your telephone. If you use a DSS Console, you can use the buttons on the DSS Console as the buttons on the connected proprietary telephone.







If you use a Panasonic proprietary telephone which does not have function buttons, you may change one of the unused flexible buttons to a function button. Please refer to "4.1.2 Customising the Buttons."

# Feature Numbers

To operate certain features, you need to enter specified feature numbers (and an additional parameter, if required).

There are two categories of feature numbers as follows:

- Flexible Feature Numbers (Please refer to "5.2 Feature Numbers List.")
- Fixed Feature Numbers (Please refer to "5.2 Feature Numbers List.")

Flexible feature numbers can be changed to other numbers for easier use by System Programming. There are two types of fixed feature numbers list in the System and either one of them can be selected by System Programming. If you want to change the feature numbers, consult your dealer. In this manual, the default numbers (factory installed) are used for operations.

A flexible number is shown as (half-shaded key). Use the new programmed number if you have changed the feature number. Write the new number in "5.2 Feature Numbers List."



If you use a single line telephone which does not have the "\*" or "#" keys; it is not possible to access features that have " $\star$ " or "#" in their feature numbers.

# Tones

You will hear various tones, during or after an operation, for confirmation. Please refer to "5.4 What is This Tone?"

# Display

In this manual, you will see "the display ...". This refers to the display of a Panasonic proprietary telephone. If your telephone is not a Panasonic proprietary telephone with a display, the message will not be displayed.

If you use a Panasonic display proprietary telephone, the display helps you confirm the settings. For example, when you set the Do Not Disturb feature, the display shows "Do Not Disturb". Some proprietary telephones also give you easy access to operations. A message is displayed depending on the operation. By pressing the corresponding button on the side or bottom of the display, or rotating a jog dial, you can access the desired feature. For example, if turning background music on becomes available, "BGM" will be shown on the display. Follow the instructions in each operation.



Furthermore, depending on the display proprietary telephone, you can operate features or make calls using the display message. Please refer to 2.10 Using the Display Proprietary Telephone.



# \*\* Restrictions

Some features may be restricted at your extension under system programming. Consult your System Manager or dealer.

# lcon Descriptions

The following icons show you the feature availability, notes and action to operate the features.

	This feature cannot be operated with a single line telephone.  Related Programming Title Please refer to "4 Customising Your Phone & System," if necessary.	(CO) (SO) (SO) (SO) (SO) (SO) (SO) (SO) (S	<ul> <li>Seize an external line (One of the following).</li> <li>Press the CO button.</li> <li>Dial automatic line access number 9.</li> <li>Dial trunk group access number 801 to 848.</li> </ul>
	Off-hook (One of the following).  Lift the handset.  Press the SP-PHONE button.  Press the MONITOR button. (To start talking, lift the handset.)		Press the Call button on the Doorphone.
	<ul><li>On-hook (One of the following).</li><li>Hang up.</li><li>Press the SP-PHONE button.</li><li>Press the MONITOR button.</li></ul>	<i>L</i> ∰√	Press the switchhook lightly.
	Press the corresponding function button on the proprietary telephone. (Refer to "When You Use a Panasonic Proprietary Telephone".)		Wait for an answer.
desired no.	Enter the required number. <examples>  account code  Enter the account code.  extension no.  Dial an extension number.  phone no.  Dial the telephone number.  group no.  Dial the group number.</examples>	<b>G</b> (1/2)	Talk.
			You will hear a confirmation, dial, ring or ringback tone.  C. Tone: confirmation tone D. Tone: dial tone R. Tone: ring tone R. B. Tone: ringback tone
			One short beep

# When You Use a Panasonic Proprietary Telephone

When you use a Panasonic proprietary telephone and the DSS Console, they may have some of the useful function buttons listed below. These buttons make operations simple. The illustrations may differ from the buttons on your telephone.


ANSWER	Used to answer an incoming call.	FWD / DND	Call Forwarding / Do Not Disturb: Used to perform Call Forwarding or Do Not Disturb.
AUTO ANSWER MUTE	Used to receive an incoming intercom call in the hands-free mode or mute the microphone during a conversation.	HOLD	Used to place a call on hold.
AUTO DIAL STORE	Used for System Speed Dialling or storing programme changes.	INTERCOM	Used to make or receive an intercom call.
(co)	CO: Used to make or receive an outside call. A Loop-CO button supports all lines. Pressing this button seizes an idle line automatically. (Button assignment is required.) (Only the CO "number" (e.g. 1, 2) may be shown on some telephones.)		Jog Dial: Used to adjust the volume and the display contrast or select desired items for each function.
CONF	Conference: Used to establish a three-party conversation.	MESSAGE	Used to leave a message waiting indication or call back the party who left the message waiting indication.
(DSS)	DSS: Used to access the extension. (Only the "S" may be shown on some telephones.)	MONITOR	Used for hands-free dialling. You can monitor the party's voice hands-free.
FLASH	Used to send a flash signal to the Central Office or another connected PBX. Or used to disconnect the current call and make another call without hanging up.	PAUSE	Used to insert a pause during dialling. Used to enter the programming mode instead of using the PROGRAM button.
	Function: Located beside the display. Used to perform the displayed function or operation.	(PDN)	PDN: Used to make or receive an intercom / outside call. This button can also be used to set / cancel various features available for the extension.

# \*\*

# Using a Jog Dial


subfunctions on the display.

The Jog Dial can be used for the display contrast and the volume control or you can search for desired items on the display. Rotate the Jog Dial in the either direction as desired. The contrast or the volume level and the items will change as follows:



# How to Follow the Steps

A sample operation is shown below.




# 2.2 Making Calls

# 2.2.1 Basic Calling

- Calling another extension
- Calling an external party


- Calling another extension
- ◆ To another extension (Intercom Call)




<Example>

When you call Mr. Thomas....

Mr. Thomas's extension number is 123.



# ◆ To another extension (PDN Call)



The DSS button light shows the current status as follows:

Off: The extension is idle.

Red on: You or another extension is using the line.



#### Do you have an extension directory?

Complete the directory on "Extension" in "5.3 Directory" and make a photo copy for your reference.

#### For quick operation

If you are an Operator or dial some extensions frequently, the DSS button is useful.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange a DSS button. Create or re-arrange a PDN button. Create or re-arrange a SDN button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)

# To an Operator (Operator Call)



# Calling an external party

You have to seize an outside line before dialling an outside phone number because external calls are made via your system.

Select one of the following methods:

- Press an idle (0) button.
- Dial automatic line access number 9. An idle line is selected automatically.
- Dial trunk group access number 8 0 1 to 8 4 8 A specific line is selected.



The CO button light shows the current status as follows:

Off: The line is idle.

Green on: You are using the line.

Red on: The line is in use.

**Emergency call** 

You can dial pre-programmed emergency numbers without any restrictions.



#### **Hands-free operation**

You can have a conversation in the hands-free mode using the SP-PHONE button. You can then perform other tasks at the same time.

#### Helpful hints for hands-free operation

Use your telephone in a quiet room for best performance.

If the other party has difficulty hearing you, decrease the volume.

If you and the other party talk at the same time, parts of your conversation will be lost. To avoid this, talk alternately.

- To select the less expensive line automatically, dial "9" or press the Loop-CO button to seize a line. (Automatic Route Selection)
- If you misdial, press the FLASH button or the switchhook lightly and then re-dial. The line will remain engaged.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.1 Initial Settings

#### Preferred Line Assignment — Outgoing

Select the seized line when going off-hook.

4.1.2 Customising the Buttons

You can re-arrange the CO button assignment and change the ringing tone for each CO button.

- 4.3 Customising Your System (User Programming)
  - 4.3.2 System Speed Dialling Number Set (001)
  - 4.3.3 System Speed Dialling Name Set (002)
  - 4.3.5 Flexible CO Button Assignment (005)


24

#### 2.2.2 Easy Dialling

This is convenient for frequently dialled phone numbers.

- With one button — To a pre-set party by going off-hook
- Using numbers stored at your extension Using a single digit number
- Using numbers stored in the system — To a Phantom extension

# With one button (One-Touch Dialling)








- 4.1 Customising Your Phone (Station Programming)
  - 4.1.1 Initial Settings— Full One-Touch Dialling Assignment Allow or cancel the one-touch operation while on-hook. (Default: Allow)
  - 4.1.2 Customising the Buttons Create or re-arrange the One-Touch Dialling button and store the desired number, phone number, feature number, etc.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)

# Using numbers stored at your extension (Station Speed Dialling)

You can store up to 10 numbers at your extension for your personal use. Telephone directory for "Station Speed Dialling" is provided in "5.3 Directory."


# ◆ To store a phone number






"X" and PAUSE can also be stored as digits.

#### To dial



# Using numbers stored in the system (System Speed Dialling)

You can make a call using up to 1000 speed dial numbers (000 - 999) which are previously stored by System / User Programming. Telephone directory for "System Speed Dialling" is provided in "5.3 Directory."





More than one speed dial number can be used for long telephone numbers, if the number is divided when stored.

# <Example>

If the number is divided and stored in system speed dial numbers 001 and 002:



• If "Tenant Service" is employed by System Programming, up to 2000 Speed Dialling codes can be shared among each tenant under the condition of up to 1000 codes per tenant.





- 4.3 Customising Your System (User Programming)
  - 4.3.2 System Speed Dialling Number Set (001)
  - 4.3.3 System Speed Dialling Name Set (002)


# To a pre-set party by going off-hook (Pickup Dialling)

You can make an extension or outside call simply by going off-hook if you pre-assigned.


# To store a phone number










# ◆ To set / cancel








## ◆ To dial





- To call another party, dial the desired party's phone number before the pre-set line is connected. (Default: 1 second)
- "\*" can also be stored as a digit.

# Using a single digit number (Quick Dialling)







- 4.3 Customising Your System (User Programming)
  - 4.3.9 Quick Dial Number Set (009)

# To a Phantom extension


You can call extensions associated with a Phantom extension. The call arrives at all extensions who have the same Phantom extension number.



# To call a phantom extension



#### To answer





The Phantom extension button light shows the current status as follows:

Red on: You are calling a phantom extension.

Flashing green: Incoming call

To set ringing or not, please refer to "4.1 Customising Your Phone (Station Programming)."



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange a Phantom extension button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)

# 2.2.3 Redial

This is convenient when calling the same external party again.

- Redialling the last outside phone number you dialled
- Saving the outside phone number for redialling




 Up to 24 digits can be programmed and redialled. The line access number is not counted as a digit.



 To redial automatically, go off-hook with the SP-PHONE button and then press the REDEAL button or press the REDIAL button directly. It will keep dialling the busy number until the called party answers within a specified time (Automatic Redial). You can perform other tasks during automatic redialling. To cancel, press the FLASH button.




- 4.1 Customising Your Phone (Station Programming)
  - 4.1.1 Initial Settings Full One-Touch Dialling Assignment
     Allow or cancel the one-touch operation while on-hook. (Default: Allow)
- Redialling the last outside phone number you dialled (Last Number Redial)




Saving the outside phone number for redialling (Saved Number Redial)

The saved number remains intact until another number is stored.

#### ◆ To save



# ♦ To dial





- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange a SAVE button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)

# 2.2.4 When the Dialled Line is Busy or There is No Answer

— Reserving a busy line


- Leaving a message waiting indication
- Sending a call waiting tone
- Joining an existing call

# Reserving a busy line (Automatic Callback Busy)


You can set the telephone to receive callback ringing when a dialled line becomes idle. When you answer the callback ringing:

For an outside call: The line is seized.

For an intercom call: The called extension starts ringing automatically.



#### To answer and call








• If you do not answer the recall ringing within 10 seconds (four callback rings), this feature will be cancelled.

34

# To cancel








# Sending a call waiting tone (Busy Station Signalling [BSS])

The other party will know your call is waiting.






- If "BSS" is not displayed or you hear a reorder tone, this feature is not set at the other party's phone. This feature is only available if the called extension has set the "Call Waiting" feature.
- Depending on the other party's telephone, the "Off-Hook Call Announcement (OHCA)" or the "Whisper OHCA" function can be applied. You can talk to the other party through the speaker and the microphone (OHCA) or you only send a call announcement through the handset (Whisper OHCA), while they are having another conversation using the handset.

## Leaving a message waiting indication (Message Waiting)


If the other extension is busy or does not answer your call, you can leave a message waiting indication (MESSAGE button light turns on and / or indication tone is emitted when going off-hook) on that extension. This prompts the other extension user to call you back.




#### ◆ To leave a message waiting indication




#### ◆ To leave / cancel a message waiting indication




#### ◆ To leave / cancel a message waiting indication (contd.)





#### To check and select the party


When you received more than one message waiting indications, you can select the desired party to call back.




38




- The extension number and name of the massage senders are shown in the received order.
- Single line telephone users may hear a special ring tone as notification while off-hook, if required.
- Indication tone



#### To call back



#### To clear all message waiting indications






- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange a MESSAGE button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)


## Joining an existing call (Executive Busy Override)

You can call the party who is talking with another on the telephone or add a third party to your existing conversation.


#### To join



#### To terminate one party and talk with another



#### ◆ To leave the conference






You can also deny others the possibility of joining your conversation (Executive Busy
Override Deny) (Default: Allow). Please refer to 2.7 Setting the Telephone According to
Your Needs.

## 2.2.5 Calling without Restrictions

- Using an account code
- Using your calling privilege at another extension
- To call an extension who is refusing to receive the call
- Changing the dialling mode

## Using an account code (Account Code Entry)

An Account Code gives information about outside calls for accounting and billing purposes. You may not be able to make an outside call without an account code entry depending on your account code entry mode. One of three modes is assigned to each extension by System Programming. Ask your System Manager about your mode.





- A Panasonic proprietary telephone user can enter an account code during a conversation and when hearing a reorder tone after the other party hangs up.
- If you enter the wrong code, press the "\*" key while entering the account code and then re-enter the code.
- To cancel the entry, press the Account button or the switchhook while entering the code.
- For your convenience, you can store the code with the phone number in memory (e.g. Speed Dialling).
- If you hear a reorder tone, the entered account code is wrong. Enter the correct code.
- The delimiter "99" is available for rotary type SLTs only.



The System Manager may give a specified account code to you and check your telephone
usage. The System Manager can specify an account code to each client and check the call
duration.





- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange an Account button.
- 4.3 Customising Your System (User Programming)
  - 4.3.5 Flexible CO Button Assignment (005)

### Using your calling privilege at another extension (Walking COS)


You can use your calling privileges (Class of Service) at another extension. You may override restrictions which may be set at the extension. To perform this feature, pre-programmed walking COS password is required.

Ask your System Manager about the walking COS password.





42






The available functions are as follows:

- The outgoing call restriction level (less restriced your restriction level)
- An outside call duration
- · Transferring a call to an outside party
- Using an account code entry mode (Account Code Entry)
- The number of digits you can dial during an outside call.
- · The outside lines you are permitted to use.

# To call an extension who is refusing to receive the call (Do Not Disturb (DND) Override)






• Only a pre-programmed extension can execute this feature.


## Changing the dialling mode (Pulse to Tone Conversion)

To access services such as computer telephone services, Voice Mail, etc., that require a tone dialling, you can temporarily change the dialling mode from Pulse to Tone, if you are using a dial pulse type CO line.




# 2.2.6 Alternating the Calling Method (Alternate Calling — Ring / Voice)


The calling method, either ring or voice, is set by the called extension when an intercom call is received. However, you can change the method temporarily. With Voice-Calling, you can talk to the party as soon as the line is connected. (Default: Ring-Calling)



#### ◆ For voice-calling



#### ◆ For ring-calling





If the called party uses a single line telephone, only Ring-Calling is available.




- 4.1 Customising Your Phone (Station Programming)
  - 4.1.1 Initial Settings Intercom Alert Assignment Which way do you prefer to receive an intercom call?


# 2.2.7 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])

External callers can call extensions in the KX-TD500 system. An outgoing message greets the caller and gives information about how to access an extension. You do not need the operator's assistance.


You may not be able to access the features without entering a DISA user code depending on the security mode. Ask your System Manager for the mode assigned to your system.




#### To call an extension



#### ◆ To call an external party



#### ◆ To re-try






- If a call between two external parties (you and the other party) is established, both parties will hear an alert tone 15 seconds before the time limit (Default: 10 min) expires. You can extend the call duration time by pressing any key except "\*" while hearing an alert tone.
- If you failed to enter a valid DISA user code three times consecutively, the call will be disconnected automatically.

# 2.3 Receiving Calls

## 2.3.1 Answering Calls





When going off-hook using the MONITOR button, you have to lift the handset to talk to the other party.



#### Hands-free operation

You can have a conversation in the hands-free mode with the SP-PHONE button. You can perform other tasks at the same time.

#### Helpful hints for the hands-free operation

Use your telephone in a quiet room for best performance.


If the other party has difficulty hearing you, decrease the volume.

If you and the other party talk at the same time, parts of your conversation will be lost. To avoid this, talk alternately.

• If the Caller ID feature is available, you may confirm the caller's phone number and name before answering an outside call.

Pressing the SHIFT button displays the outside line number and name.

#### <Example>



The caller's information from your telephone company will only be sent to the pre-assigned extension.




- 4.1 Customising Your Phone (Station Programming)
  - 4.1.1 Initial Settings— Preferred Line Assignment Incoming Select the seized line when going off hook. **Intercom Alert Assignment** 
    - Select the Calling method, either ring or the other party's voice.
  - 4.1.2 Customising the Buttons You can re-arrange the CO button assignment and change the ringing tone for each CO button.
  - 4.3 Customising Your System (User Programming)

# 2.3.2 Answering Hands-free (Hands-free Answerback)

You can answer an intercom call without going off-hook as soon as the line is connected. You will hear the caller talking without the phone ringing.



#### ◆ To set / cancel





The AUTO ANSWER / MUTE button light shows the current status as follows:

On:Set.

Off: Not set.

# 2.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)


You can answer an incoming call that is ringing at another extension from your phone without leaving your desk.


The following types are available:


Outside (CO) Call Pickup: Picks up an outside call.

Group Call Pickup: Picks up a call ringing at an extension within your extension group.

Directed Call Pickup: Picks up a specified extension's call.










If you receive a call waiting tone, you can ask a third party to pick up your second call with Directed Call Pickup.





You can also deny other people the possibility of picking up calls ringing at your extension (Call Pickup Deny). Please refer to "2.7 Setting the Telephone According to Your Needs."

# 2.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])

You can answer an incoming CO call ringing at an external speaker from any extension.










 You can also answer a paging announcement via an external speaker with this operation.

## 2.3.5 Using the ANSWER / RELEASE Button


The ANSWER and the RELEASE buttons are useful for operations with the headset or in the handsfree mode.

With the ANSWER button, you can answer all incoming calls to the paired / your own telephone. With the RELEASE button, you can disconnect the line during or after a conversation, or complete transferring a call.


#### To answer



#### To transfer a call



#### To transfer an outside call to an extension with One-Touch





ANSWER and RELEASE buttons are provided as a fixed button on the KX-T7441, DSS Console. For other PTs and DSS Consoles, these buttons can be assigned to a flexible button (CO, DSS, PF).

If you press the ANSWER button to answer a new call during the current call, the current call will be disconnected.

If a call which comes in on your extension is not ringing, you cannot answer it by pressing the ANSWER button.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange an ANSWER button and a RELEASE button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)

# 2.4 During a Conversation


## 2.4.1 Holding a Call

- Holding a Call
- Denying other people the possibility of retrieving calls held at your extension.
- Holding in a system call parking zone




- If a call is not retrieved within a pre-programmed time, you will hear an alarm as a reminder.
- If a call is not retrieved within 30 minutes, it is automatically disconnected.

## Holding a Call (regular)



56

#### To retrieve a call






- The CO, INTERCOM, PDN or SDN button light shows the current status as follows:
   Flashing green: The call is placed on hold at your extension.
   Flashing red: The call is placed on hold at another extension.
- A single line telephone user can hold either an intercom call or an outside call at one time.
- A proprietary telephone user can hold an intercom call and multiple outside calls at one time.
- To hold multiple intercom calls, use the "Call Park" feature.

# Denying other people the possibility of retrieving calls held at your extension (Exclusive Call Hold)


The call placed on Exclusive Hold can only be retrieved from the extension on which the call is held.



#### ◆ To place a call on Exclusive Hold



#### To retrieve a call







A PT user can hold an intercom call and multiple outside calls at one time.


## Holding a call in a system call parking zone (Call Park)

You can hold a call in the system common call parking zone and perform other operations. The parked call can be retrieved from any extension. Up to 100 calls can be parked.


#### ◆ To set









#### ◆ To retrieve











• If you hear a busy tone when entering the zone number, the zone is in use. Enter another number.


60

# 2.4.2 Talking to Two Parties Alternately (Call Splitting)

If a new call comes in on your extension when you are engaged in the call, you can answer the new call without loosing the current call. Then you can talk to either one of two parties alternately while putting the other on hold.









#### 2.4.3 Transferring a Call

- Transferring a call to an extension
- Transferring a call to a phantom extension
- Transferring a call to an extension (PDN Transferring a call to an extension Call)
  - (Ringing Tranfer)
- Transferring a call to the Remote Resource or a UCD Group
- Transferring a call to an external party


## Transferring a call to an extension



#### Transferring a call to a phantom extension




# Transferring a call to an extension (PDN Call)




## Transferring a call to an extension (Ringing Transfer)

You can transfer a call on an SDN button to another extension with a simple operation. The call will be transferred to the extension on which the PDN button (associated with the SDN button assigned to your extension) is assigned.




## Transferring a call to the Remote Resource or a UCD Group



## Transferring a call to an external party

Some extensions may be restricted from performing this function.





- If you misdial, press the FLASH button, and re-enter the number.
- If a call between two external parties is established, both parties will hear an alert tone 15 seconds before the time limit (Default: 10 min) runs out. The original extension will hear an alarm 50 seconds before the time runs out.
- To return to the held call, press the TRANSFER button, corresponding CO / INTERCOM / PDN / SDN button, or the switchhook, before the destination extension answers.
- To return to the conversation, press the corresponding CO button.
- If you hear an alert tone, the destination extension did not answer the call. Answer the call.



- You can transfer a call simply by pressing the DSS button associated with the transfer destination extension (One-Touch Transfer). You do not have to press the TRANSFER button.
- The call will be released from your extension automatically after dialling the destination extension number (Released Link Operation).
   If this feature is enabled by System Programming, you can perform another operation without going on-hook after transferring the call.


## 2.4.4 Answering a Call Waiting

- Answering a call waiting in the system
- Answering a call waiting from the central office

## Answering a call waiting in the system

During a conversation, a call waiting tone or voice announcement through the telephone speaker or the handset occurs when an outside call is received or another extension is letting you know another call is waiting. To activate this feature, set to "On." (Default: No tone) You can answer the second call by disconnecting the current call or placing it on hold.

#### To talk to the new party






- Depending on the type of the other party's telephone, the "Off-Hook Call Announcement (OHCA)" or the "Whisper OHCA" functions can be applied. You can talk to the other party through the speaker and the microphone (OHCA) or you only receive a call announcement through the handset (Whisper OHCA), while you are having another conversation using the handset.
- The calling extension's name or number is displayed for 5 seconds in 10 seconds intervals before answering a call.




- 4.1 Customising Your Phone (Station Programming)
  - 4.1.1 Initial Settings— Call Waiting Tone Type Selection Determine the tone depending on the second party, either an outside call or an extension.



## Answering a call waiting from the central office

This is an optional telephone company service. For more information, consult your telephone company.






To return to the original party, repeat the operation.


## 2.4.5 Three-party Conversation

- Adding a third party during a conversation
- Leaving a conference
- Letting a third party join your call

### Adding a third party during a conversation (Conference)




#### ◆ To talk to one party by terminating the other




### Leaving a conference


The other two parties can continue their conversation.




#### ◆ To return



#### ◆ To talk to the third party while holding the original party



#### ◆ To talk to the original party while holding the third party





#### Time Limit

Both parties will hear an alert tone 15 seconds before the time limit (Default: 10 min) runs out. The original extension will hear an alert tone 50 seconds before the time runs out. The call is disconnected when the time runs out unless the original extension returns to the conference.




- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange a Conference button.
- 4.3 Customising Your System (User Programming)
  - 4.3.5 Flexible CO Button Assignment (005)


## Letting a third party join your call (Privacy Release)

You can let a third party join your current outside call.






#### ◆ To leave



#### To talk to one party by terminating the other





• This feature overrides "Data Line Security" (122.7.11 Protecting Your Line against Indication Tones (Data Line Security)) and "Executive Busy Override Deny" (122.7.9 Denying Other People the Possibility of Joining Your Conversation (Executive Busy Override Deny)).

#### 2.4.6 Mute

You can disable the microphone or the handset to consult privately others in the room while listening to the other party on the phone through the telephone speaker or the handset. There are two types of mute as follows:



#### **Handset Mute:**


During a conversation using the handset.

This feature is available for the KX-T7400 series telephone users only.

#### **Microphone Mute:**

During a conversation using the microphone.

#### ◆ To set / cancel





 The AUTO ANSWER / MUTE or VOICE CALL / MUTE button light shows the current status as follows:

Flashing red: Mute

Off: Normal


• This feature is not available for KX-T7250.

70

## 2.4.7 Letting Other People Listen to the Conversation (Off-Hook Monitor) [KX-T7431, KX-T7433 and KX-T7436 only]

You can let other people in the room listen to the conversation through the telephone speaker while continuing the conversation using the handset.

#### ◆ To set / cancel





- This feature is only available during a conversation using the handset.
- The SP-PHONE button light shows the current status as follows:


On: The voice is heard through the telephone speaker.

Off: The voice is heard only through the handset.


# 2.4.8 End-to-End DTMF Signalling (Tone Through)

DTMF signalling is required for access to special network services offered by some telephone companies. This system allows you to signal the other end using DTMF tones during an established call.


#### End-to-End DTMF Signalling (1)



#### ◆ End-to-End DTMF Signalling (2) (When "Automatic Hold-All Calls" is enabled)



# To cancel End-to-End DTMF Signalling mode





- If the dial type of the line is assigned to DTMF, Tone Through mode is established automatically after the dialling sequence is finished and the call is established.
- Tone Through button is effective during a call between two extensions or extension to outside.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange a Tone Through button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)

# 2.5.1 Forwarding Your Calls (Call Forwarding)


You can have your incoming calls forwarded to a specific destination.

**ALL Calls:** All calls are forwarded to another extension regardless of the status of your extension.

**Busy:** All calls are forwarded to another extension when your extension is busy.

No Answer: All calls are forwarded to another extension when you do not answer the call. Busy / No Answer (BSY N/A): All calls are forwarded to another extension when you do not answer the call or when your extension is busy. To Outside Line (CO Line): All calls are forwarded to an external party regardless of the status of your extension. The call duration is limited. Some extensions may be restricted.

**Follow Me (From):** If you forget to set "All Calls" to be forwarded before leaving your desk, you can set the same function from the destination extension.







· You can set your mailbox or mobile telephone as the forwarding destination.


74


#### ◆ To set






# To cancel







A call can only be forwarded to one target telephone. For example, extension A's call is
forwarded to extension B. Extension B's call is forwarded to extension C. A call to extension
A is forwarded to extension B, but the call would not be forwarded directly to extension C
from A.



- The extension which is set as the destination can call the original extension.
- While setting, you can temporarily cancel this feature by pressing the FWD / DND button.
   Pressing the FWD / DND button alternates between setting or cancelling the mode.
- You can set the "Do Not Disturb (DND)" and "Call Forwarding (FWD)" features at the same time. However, only one feature will work at a time. Pressing the FWD / DND button while on-hook changes the feature as follows:



The FWD / DND button light shows the current status as follows:

Off: Both features are not set.

**Red on**: DND mode — This setting can be changed by System Programming.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange an FWD / DND button.
- 4.3 Customising Your System (User Programming)
  - 4.3.5 Flexible CO Button Assignment (005)

# Forwarding Your Calls by ISDN (Call Forwarding by 2.5.2 ISDN Provider)

You can have your incoming calls forwarded to an outside number via ISDN network.

This is the Call Forwarding feature provided by the ISDN network.

This feature can be categorized as follows:

#### **Call Forwarding Unconditional (CFU)**

Allows you to have all your incoming calls forwarded to an outside number via ISDN network regardless of the status of your extension.


#### **Call Forwarding Busy (CFB)**

Allows you to have your incoming calls forwarded to an outside number via ISDN network when your extension is busy.


#### Call Forwarding No Reply (CFNR)

Used to route your incoming calls to an outside number via ISDN network if your extension isn't answered after a pre-determined number of rings.

#### To set



# ◆ To cancel





• This feature can be used together with the regular Call Forwarding / Do Not Disturb feature provided by the KX-TD500 System.

## 2.5.3 Showing an Absent Message on the Caller's Telephone Display (Absent Message Capability)


You can show the reason for your absence, if the calling extension uses a Panasonic proprietary telephone with a display. This way the caller will know when you will be available. You can choose one of nine messages.

Message no.	Default Message
1	Will Return Soon
2	Gone Home
3	At Ext%%%% (Extension number)
4	Back at %%:%% (Hour:Minute)
5	Out Until %%/%% (Month/Day)
6	In a Meeting
7	( Blank )
8	( Blank )
9	( Blank )




- Enter the desired value in the "%" space. You must make your message in all of the "%"s using 0 to 9, #, or  $\times$ .
- The message can be changed. Consult your System Manager or dealer.


### To set




80


# ◆ To set (contd.)






#### ◆ To cancel









To confirm the message, go off-hook. It will be displayed.




- 4.3 Customising Your System (User Programming)
  - 4.3.8 Absent Messages Set (008)


# 2.5.4 Preventing Other People from Using Your Telephone (Electronic Station Lockout)

You can lock your extension so that other users cannot make CO calls from your extension.




#### ◆ To lock / unlock





# To lock / unlock (contd.)








If you forget the code or cannot unlock your phone, consult an Operator or the Manager. They can unlock your extension (Remote Station Lock Control).


# 2.5.5 Leaving an Extension Group (Log-In / Log-Out)

You can set your status in an extension group. Set Log-Out when you leave the office so that incoming calls will temporarily skip your extension in the receiving order. When you return, set Log-In so that calls will reach your extension. (Default: Log-In)











The Log-In / Log-Out button light shows the current status as follows:

Off: Log-In mode

Red on: Log-Out mode Flashing red: a call waiting

• There should be at least one extension in the extension group that is in the Log-In mode.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons

Create or re-arrange a Log-In / Log-Out button.

- 4.3 Customising Your System (User Programming)
  - 4.3.5 Flexible CO Button Assignment (005)

86

# 2.6 Making / Answering an Announcement


# 2.6.1 **Paging**

You can make a voice announcement to several people at the same time. Your announcement is sent over the proprietary telephone speakers and / or external speakers. The paged person can answer your paging from any telephone (including SLTs). There are three types as shown below:


**All:** Paging through both the telephone speakers and external speakers.

**External:** Paging through the external speakers.


**Group:** Paging to a particular paging group or all paging groups through the telephone speakers.




#### **♦** AII




## External




# ◆ External (contd.)







# Group



# ◆ Group (contd.)








- A ringing, busy extension, or a single line telephone cannot receive a paged announcement.
- The PT user can deny being paged. For more details, please refer to "To set / cancel" in "2.7.4 Denying the Paged Announcement (Paging — Deny)."


# 2.6.2 Paging a Person and Transferring a Call

You can transfer a call after making a paging announcement.


# ◆ Through an external speaker and telephone speakers



# ◆ Through an external speaker




# ◆ Through the telephone speakers of a particular paging group





# 2.6.3 Answering a Paged Announcement

You can answer an announced page at any extension within the system.


# ◆ Through an external speaker









# ◆ Through the telephone speakers









# 2.7 Setting the Telephone According to Your Needs

# 2.7.1 Setting the Alarm (Timed Reminder)


You can receive a ringback alarm at your telephone to remind you of a meeting, appointment or as a wake-up call. The setting can be for either one time or daily (every day until cancelled) at a pre-set time.

# ♦ To set







# ◆ To set (contd.)




## To cancel







# ◆ To cancel (contd.)



# ◆ To view the setting



## ◆ To stop or answer the ringback





- If you receive an incoming call during ringback, ringing starts after the ringback stops.
- If you are having a conversation during the pre-set time, the ringback will start after your conversation.
- If you go off-hook to answer, you can hear the alarm tone or the message recorded by an Operator or the Manager beforehand.




When the daily alarm is set, the display shows "\*" in the corner.


Alarm 10:10AM\*


# 2.7.2 Refusing Incoming Calls (Do Not Disturb [DND])

You may set this feature during a meeting or when you are busy.



#### ◆ To set / cancel







- A flashing CO button tells you an outside call is received. You can answer the call by pressing the flashing CO button.
- While setting, you can temporarily cancel this feature by pressing the FWD / DND button. Pressing the FWD / DND button alternates between setting or cancelling the mode.
- You can set the "Do Not Disturb" and "Call Forwarding" features at the same time. However, only one feature will work at a time. You can change the feature by pressing the FWD / DND button while on-hook. Pressing the FWD / DND button changes the feature as follows:



- Specified extensions can override this setting and call DND extensions (Do Not Disturb Override).
- The FWD / DND button light shows the current status as follows:

**Off**: Both features are not set. Red on : DND mode —— This setting can be changed Red flash: FWD mode by System Programming.

• This feature also works for an incoming call from a doorphone.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange an FWD / DND button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)

98

# 2.7.3 Receiving a Call Waiting (Call Waiting / Off-Hook Call Announcement [OHCA] / Whisper OHCA)

During a conversation, you can be informed of a call waiting with a tone or voice announcement through your speaker or handset. (Default: No tone)

#### Call waiting tone:

a waiting tone through the handset.

You can change the tone. Please refer to "4.1 Customising Your Phone (Station Programming)." **OHCA:** 

a voice announcement through the telephone speaker without pre-information.


(KX-T7436 and KX-T7235 telephone users only)


#### Whisper OHCA:

a voice announcement through the handset without pre-information.


(KX-T7400 series telephone users only)

# ◆ To set / cancel





# ◆ To set / cancel (contd.)






BSS, OHCA and Whisper OHCA do not function at a DN type PT.


100


# 2.7.4 Denying the Paged Announcement (Paging — Deny)

You can refuse any paged announcement sent through your telephone speaker.

## ◆ To set / cancel








# 2.7.5 Displaying Your Number on the Called Party and Calling Party's Telephone (Calling / Connected Line Identification Presentation [CLIP / COLP])

**CLIP:** When making a call, you can let the other party see your pre-assigned identification number. **COLP:** When receiving a call, you can let the party calling you see your pre-assigned identification number.

You can select to show an identification number assigned for an outside line or your extension. This is one of the ISDN supplementary services.


◆ To show an identification number assigned for an outside line or your extension




# 2.7.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])

When making a call, you can prevent the other party from seeing your identification number. You can change the setting at any time for a particular call. This is one of the ISDN supplementary services.

# ◆ To set / cancel




# ◆ To change the setting at any time for a particular call



# 2.7.7 Preventing Your Number Being Displayed on the Called Party's Telephone (Connected Line Identification Restriction [COLR])


When receiving a call, you can prevent the caller from seeing your identification number. This is one of the ISDN supplementary services.


# ◆ To set / cancel




# 2.7.8 Denying Other People the Possibility of Picking up Your Calls (Call Pickup Deny)

You can prevent other extension users from pickling up your calls with the "Call Pickup" feature.










# 2.7.9 Denying Other People the Possibility of Joining Your Conversation (Executive Busy Override Deny)

You can deny other extension users the possibility of intruding your established call.










Only a pre-programmed extension can execute this feature.

# 2.7.10 Turning on the Background Music (BGM)

You can listen to background music through your telephone speaker while onhook. To utilize this feature, an external music source, such as a radio, must be connected to the system beforehand.




# ◆ To set / cancel





# 2.7.11 Protecting Your Line against Indication Tones (Data Line Security)

You can protect the line against indication tones, such as call waiting tone or interruptions (Executive Busy Override). Set this feature if your extension is connected to a data communication device, such as a personal computer or facsimile, to secure data transmission.




# ◆ To set / cancel







### ◆ To set (contd.)



You can check the current system operation mode, day time (business hours) or night (after business hours).











• Any display PT user can check the status.


## 2.7.13 Setting the Parallel Connected Telephone Ringer (Parallelled Telephone Connection)

A proprietary telephone user can choose whether the single line telephone connected in parallel will ring or not, when an incoming call is received. (Default: No ring)













- Even if "No ring" is selected, the call can be answered with the single line telephone by lifting the handset.
- In the DPT + SLT combination, if one telephone goes off-hook while the other telephone is on a call, the call is switched to the former.


## 2.7.14 Clearing the Feature Settings at Your Extension (Station Programme Clear)

You can clear the following features which have been set on your phone. If you change desks, and notice settings which a previous owner left on the line, you can clear these features.

- Calling to a Pre-set Party by Going Off-Hook (Pickup Dialling): The stored number will be cleared.
- Reserving a Busy Line (Automatic Callback Busy)
- Leaving a Message Waiting Indication (Message Waiting): All messages will be removed.
- Forwarding Your Calls (Call Forwarding)
- Showing an Absent Message on the Caller's Telephone Display (Absent Message Capability)
- Leaving an Extension Group (Log-In / Log-Out)
- Calling Using the Call Log (Incoming Call Log)
- Setting the Alarm (Timed Reminder)
- Refusing Incoming Calls (Do Not Disturb [DND])
- Receiving a Call Waiting (Call Waiting / Off-Hook Call Announcement (OHCA) / Whisper OHCA)
- Denying the Paged Announcement (Paging Deny)
- Denying Other People the Possibility of Picking up Your Calls (Call Pickup Deny)
- Denying Other People the Possibility of Joining Your Conversation (Executive Busy Override Deny)
- Turning on the Background Music (BGM)
- Protecting Your Line against Indication Tones (Data Line Security)
- Setting the Parallel Connected Telephone Ringer (Parallelled Telephone Connection): The single line telephone will not ring.
- Using the same Extension Number and the Setting of Your Previous Extension (Walking Station)









## 2.8 Using User-supplied Equipment


### 2.8.1 If a Doorphone / Door Opener is Connected

- Doorphone call— Opening the door
- Doorphone call
- ◆ To call from the doorphone




### To call the doorphone





114

### ◆ To call the doorphone (contd.)





### Opening the door

You can unlock the door opener to let the visitor in.


Some extensions may be restricted from performing this function by System Programming.

### ◆ From a specified extension






### From a specified extension (contd.)



### From any extension while talking to the doorphone






- The door will be left open for five seconds (default). This setting can be changed by System Programming.
- To keep the door open for another five seconds, dial 5 again using a Panasonic proprietary telephone.
- If no one answers the doorphone call within 30 seconds, the call is cancelled.


116

### 2.8.2 If a Host PBX is Connected

### Accessing external services (External Feature Access)

You can access special features (e.g. Call Waiting) offered by a host PBX or Central Office. This feature is only effective with an outside call.





## 2.8.3 If a Voice Processing System is Connected

If your system is connected to a Panasonic Voice Processing System (e.g. KX-TVP100) which can be used with a digital proprietary telephone, the following functions are available:


- VPS (Voice Processing System) integration
- Screening calls
- Recording a conversation


### VPS integration

If you cannot answer calls, you can forward them to your mailbox. If your telephone has a MESSAGE button, the button light turns on and lets you know you have messages. Even if a MESSAGE button is not provided, you will hear an indication tone\* when going off-hook.


You can also transfer received outside calls to a certain mailbox so that callers can leave messages. If you create a Voice Mail Transfer button on your phone, the transfer is done easily without confirming the voice mail extension number (Voice Mail Transfer).

### ◆ To forward your calls to a mailbox







### ◆ To cancel



### ◆ To transfer calls



### ◆ To listen to a stored message





\*Indication tone





- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons
     Create or re-arrange a MESSAGE button and Voice Mail (VM) Transfer button.
- 4.3 Customising Your System (User Programming)
  - 4.3.5 Flexible CO Button Assignment (005)

### Screening calls (Live Call Screening [LCS])

While a caller is leaving a message in your mailbox, you can monitor the call. If desired, you can answer the call while monitoring. There are two methods available (Default: Hands-free mode). In both modes, if you are currently having a conversation, you will hear a call waiting tone.



#### Hands-free mode:

You can monitor the message automatically through the telephone speaker at the same time.


#### Private mode:


You will hear an alert tone while the caller is leaving a message.

#### Before operating


- Create a Live Call Screening (LCS) button (Station Programming).
- Select the mode, either Hands-free or Private (Station Programming).
- · Set the Password.
- Set the Live Call Screening feature.

### To set / cancel the password







### ◆ To set / cancel the password (contd.)



### ◆ To set Live Call Screening




### ◆ To cancel Live Call Screening



### **Operation Flowchart**

The operations in the shaded areas can be hands-free operations.





The Live Call Screening (LCS) button light shows the feature status as follows:

Red on: LCS is on. Off: LCS is off.

Flashing green rapidly: Alert ringing in the Private mode\* Flashing green slowly: Live Call Screening is in use.\*

- \* The DSS button light turns to red while Live Call Screening is in use.
- The Operators and the Manager can clear a password at any extension.




- 4.1 Customising Your Phone (Station Programming)
  - 4.1.1 Initial Settings Live Call Screening Mode Set Select the mode, either monitoring the message automatically or receiving alert ringing, when the caller leaves a message.
  - 4.1.2 Customising the Buttons Create or re-arrange a Live Call Screening button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)


### Recording a conversation (Two-Way Recording)

You can record a conversation into a mailbox while talking on the phone.

### To record into your mailbox



#### To record into another mailbox





The Two-Way Record button light shows the current status as follows:

On: Recording the conversation.

Off: Not recording.



When you record Two-Way telephone conversations, you should inform the other party that the conversation is being recorded.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange a Two-Way Record button and a Two-Way Transfer button.
- 4.3 Customising Your System (User Programming)
  - 4.3.5 Flexible CO Button Assignment (005)

124

### 2.9 After Moving to a New Location in the Office


## 2.9.1 Using the Same Extension Number and the Setting of Your Previous Extension (Walking Station)

Used to move an extension to a new location in the office without re-programming.


Extension data such as extension number, One-Touch dialling memory remain the same after the relocation of the extension.

This feature is convenient if you don't want to change the current extension setting (extension number, etc.) after moving to a new location in the office.

#### To start



### ◆ To end





- The telephone type (PT, SLT) must be the same at the previous location and a new location.
- Walking Station is not available for the extension connected to a DHLC card.


### 2.10 Using the Display Proprietary Telephone

# 2.10.1 Calling Using the Call Log (Incoming Call Log) [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]

If you do not answer an outside call, the caller's information is recorded automatically in the call log. When the SHIFT button light turns on, there is a call in the call log. You can also store the caller's information in the call log during a conversation. (Please refer to 2.10.2 Recording a Call Log [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only].) Up to 30 calls can be logged per extension. You can select how the 31st call is treated; either a new call can be disregarded or a new call overwrites the oldest call. (Default: Overwrite)


You can modify and call back the logged numbers.

#### To confirm






With the KX-T7433 and the KX-T7230, press the INFO button to scroll through information.






- To modify the phone no, press the "\*" key to erase and then enter the number. The number is modified from the first digit. The new number is programmed.
- After confirming, press the MENU button. You return to the intial display.


### ◆ To clear the log





### ◆ To call back



### ◆ How to treat the 31st call









### 2.10.2 Recording a Call Log [KX-T7433, KX-T7436, KX-T7230, **KX-T7235** only]

You can record the caller's information in the call log for the callback purpose. If you do not answer the call, the log is recorded automatically. You can see the call duration during the conversation.

### To record a call log




#### To view the call duration\*





A KX-T7433 and a KX-T7230 users may change the displayed message as follows by pressing the INFO button.



• To return to the initial display, press the MENU button.





- 4.1 Customising Your Phone (Station Programming)
  - 4.1.1 Initial Settings Initial Display Selection Select the initial display as either the Caller ID screen (default) or the outside line name.


# 2.10.3 Denying Other People the Possibility of Seeing Your Call Log (Incoming Call Log Lock) [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]

You can lock the display of your extension so that "Call Log" of your extension is not shown on the display.

### ◆ To lock / unlock









• If you forget the code, consult an Operator or the Manager. They can unlock the call log display of any extension (Call Log Incoming, Log Lock).

### 2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235

- Using the KX-T7433
- Using the KX-T7436
- Using the KX-T7235


- Storing the names and numbers for station speed dialling
- Display feature list

### Using the KX-T7433

A KX-T7433 Panasonic proprietary telephone with a 3-line display allows you to make calls and operate the features using the display message. You do not have to memorise the phone numbers or feature numbers.

### Operation

- 1. Press the SHIFT button repeatedly to show the third display.
- 2. Press the desired button, if required.
- Rotate the Jog Dial until the desired message is at the arrow.
   (Please refer to "Features" in "2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235" for the feature messages.)
- 4. Press the CALL button to call the party or the SEL button to select the desired feature.
- **5.** Enter parameters if required.





\*The names and phone numbers should be stored beforehand. See "Features" in "2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235."

### Using the KX-T7436


A KX-T7436 Panasonic proprietary telephone with a 6-line display allows you to make calls and operate the features using the display message. You do not have to memorise the phone numbers or feature numbers.

#### Operation using the function buttons

- **1.** Press the desired function button on the initial display.
- 2. Rotate the Jog Dial until the desired message is at the arrow. (Please refer to "Features" in "2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235" for the feature messages.)

- **3.** Press the CALL button or the function button to call the party.

  Or press the SEL button to select the desired feature at the arrow or press the function button next to the desired feature.
- **4.** Enter parameters if required.






\*The names and phone numbers should be stored beforehand. Please refer to "Features" in "2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235."

### Operation using the soft buttons

- 1. Press the SHIFT button repeatedly to show the third display.
- 2. Press the desired button, if required.
- Rotate the Jog Dial until the desired message is at the arrow.
   (Please refer to "Features" in "2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235" for the feature messages.)
- **4.** Press the CALL button to call the party or the SEL button to select the desired feature.
- **5.** Enter parameters if required.






\*The names and phone numbers should be stored beforehand. Please refer to "Features" in "2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235."

### Using the KX-T7235

A KX-T7235 Panasonic proprietary telephone with a 6-line display allows you to make calls and operate the features using the display message. You do not have to memorise the phone numbers or feature numbers.

#### Operation


- 1. Press the desired function button on the initial display.
- 2. Press the desired function button or NEXT button until the desired message is displayed. (Please refer to "Features" in "2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235" for the feature messages.)
- 3. Press the function button next to the desired party or the feature.
- **4.** Enter parameters if required.






\*The names and phone numbers should be stored beforehand. Please refer to "Features" in "2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235."

### Storing the names and numbers for station speed dialling







- \*1 "X", "#", FLASH, PAUSE, SECRET (INTERCOM) and (CONF) can also be stored.
- \*2 To enter characters, see "Entering characters" in "4.3 Customising Your System (User Programming)."

### **Features**

You can access the following features. These displays can be shown by pressing NEXT or PREV button after selecting "Features." For their operation, please refer to the respective operating instructions in the list below.

Display (KX-T7436 / KX-T7235)		Display (KX-T7433)		Feature Description
Absent MSG Off		ABST MSG Off		Cancel the absent message. Please refer to "To cancel" in "2.5.3 Showing an Absent Message on the Caller's Telephone Display (Absent Message Capability)."
Absent MSG On	(→1-9)	ABST MSG On	1-9	Set an absent message. Please refer to "To set" in "2.5.3 Showing an Absent Message on the Caller's Telephone Display (Absent Message Capability)."
BSY Out Cancel	( →PHY)	BSY Out Cancel		Cancel the Trunk Busy-out setting. *Please refer to "3.2.3 Trunk Busy-out Setting."
BSY Out Confirm	(→PHY)	BSY Out Confirm		Confirm the Trunk Busy-out setting. *Please refer to "3.2.3 Trunk Busy-out Setting."
BSY Out Set	(→PHY)	BSY Out Set		Busy out a specific trunk. *Please refer to "3.2.3 Trunk Busy-out Setting."
Busy Ovrd Deny	(→1/0)	BSY Ovr DNY	1/0	Deny or allow other people the possibility of joining your conversation. Please refer to "2.7.9 Denying Other People the Possibility of Joining Your Conversation (Executive Busy Override Deny)."
C.Pickup CO		C.Pickup CO		Pick up an outside call for another extension. Please refer to "2.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)."
C.Pickup Deny	(→1/0)	C.PickupDNY	1/0	Deny or allow other people the possibility of picking up your calls. Please refer to "2.7.8 Denying Other People the Possibility of Picking up Your Calls (Call Pickup Deny)."

Display (KX-T7436 / KX-T7	<b>'235</b> )	Display (KX-T7433)		Feature Description
C.Pickup Direct	(→ext)	C.PickupDRT	ext	Pick up a specific extension's call. Please refer to "2.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)."
C.Pickup Group		C.Pickup Grp		Pick up a call within your extension group. Please refer to "2.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)."
C.Waiting	(→0-3)	C.Waiting	0-3	Cancel or set the Call Waiting feature. Please refer to "To set / cancel" in "2.7.3 Receiving a Call Waiting (Call Waiting / Off-Hook Call Announcement [OHCA] / Whisper OHCA)."
Call Park	(→00-99)	Call Park	00-99	Place a call on hold in a system parking area. Please refer to "To set" and "To retrieve" in "2.4.1 Holding a Call."
Callback Busy Cancel		Callback Cancel		Cancel the setting which reserves a busy line. Please refer to "To cancel" in "2.2.4 When the Dialled Line is Busy or There is No Answer."
Data Line On/Off	(→1/0)	Data Line	1/0	Refuse (On) or accept (Off) an indication tone, e.g. call waiting tone. Please refer to "To set" in "2.7.11 Protecting Your Line against Indication Tones (Data Line Security)."
Door Open	(→1-8)	Door Open	1-8	Unlock the door. Please refer to "From specified extension" in "2.8.1 If a Doorphone / Door Opener is Connected."
Doorphone Call	(→1-8)	Doorphone	1-8	Call the doorphone. Please refer to "To call the doorphone" in "2.8.1 If a Doorphone / Door Opener is Connected."

Display (KX-T7436 / KX-T7235)	Display (KX-T7433)	Feature Description
Extrn BGM On/Off	Ext-BGM On/Off	Turn on / off the background music. *Please refer to "3.2.1 Turning on the External Background Music (Background Music [BGM] - External)."
Extrn MODEM CTL (→1-5)	Extrn MODEM 1-5	Control the external modem by sending a pre-assigned AT Command. Please refer to "2.11.1 Controlling the External Modem (External Modem Control)."
FWD Cancel Once (→ext)	FWD Cancel Once	Cancel the Call Forwarding feature set at other extensions. *Please refer to "3.1.3 Calling the Extension that has set Call Forwarding (Remote FWD Cancel-Once)."
LCS Password (→abcabc)	LCS # abcabc	Set or cancel the password for the Live Call Screening feature. Please refer to "To set / cancel the password" in "2.8.3 If a Voice Processing System is Connected."
Log Lock Call (→abcabc)	Log Lock abcabc	Deny or allow other people the possibility of seeing your call log. Please refer to "2.10.3 Denying Other People the Possibility of Seeing Your Call Log (Incoming Call Log Lock) [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]."
Log Ovrt On/Off (→1/0)	Log Ovrt 1/0	Select how the 31st call is treated, either it is disregarded (Off) or overwrites (On) the oldest call. Please refer to "How to treat the 31st call" in "2.10.1 Calling Using the Call Log (Incoming Call Log) [KX-T7433, KX-T7436, KX-T7230, KX-T7235 only]."
Login/Logout (→1/0)	Login/out 1/0	Join (Log-in) or leave (Log-out) the call receiving group. Please refer to "2.5.5 Leaving an Extension Group (Log-In / Log-Out)."

Display (KX-T7436 / KX-T7235)		Display (KX-T7433)		Feature Description
Message Off	(→ext)	MSG Off	ext	Cancel a notification. Please refer to "Leaving a message waiting indication (Massage Waiting)" in "2.2.4 When the Dialled Line is Busy or There is No Answer."
Message On	(→ext)	MSG On	ext	Leave a notification so that the called party may call you back. Please refer to "Leaving a message waiting indication (Massage Waiting)" in "2.2.4 When the Dialled Line is Busy or There is No Answer."
Night On/Off	(→1/0)	Night Mode	1/0	Change the day (Off) / night (On) mode. (Pre-assigned extension can also change the mode.) Please refer to "2.11.4 Switching the Day / Night Service."
OGM Playback	(→1-8)	OGM Play	1-8	Playback the outgoing message. *Please refer to "To play back" in "3.2.2 Recording Outgoing Messages."
OGM Recording	(→1-8)	OGM Record	1-8	Record an outgoing message. *Please refer to "To record" in "3.2.2 Recording Outgoing Messages."
Page Deny On/Off	(→1/0)	Page Deny	1/0	Deny (On) or allow (Off) being paged. Please refer to "To set / cancel in "2.7.4 Denying the Paged Announcement (Paging — Deny)."
Page-Ext Answer	(→1-2)	Page-E ANS	1-2	Answer the paged anouncement through a speaker. Please refer to "2.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])", "Through a speaker" in "2.6.3 Answering a Paged Announcement."

Display (KX-T7436 / KX-T7235)	Display (KX-T7433)	Feature Description
Page-GRP Answer	Page-GRP ANS	Answer the paged annoucement through a telephone in the same extension group. Please refer to "Through the telephones" in "2.6.3 Answering a Paged Announcement."
Paging External $(\rightarrow 0-2)$	Page Extrn 0-2	Page through the external speaker. Please refer to "External" in "2.6.1 Paging."
Paging Group (#,01-16)	Page GRP 01-16	Page to all or a particular paging group. Please refer to "Group" in "2.6.1 Paging."
Parallel On/Off (→1/0)	Parallel 1/0	Set whether a single line telephone connected in parallel will ring (On) or not (Off) when receiving a call. Please refer to "2.7.13 Setting the Parallel Connected Telephone Ringer (Parallelled Telephone Connection)."
Pickup Dialling (→1/0)	Pickup Dial 1/0	Set or cancel the feature, calling to a pre-set party by going off- hook. Please refer to "To set / cancel" in "2.2.2 Easy Dialling."
Pickup DL Prg (→+#)	Pickup DL PG#	Store the extension or phone number to call a party by going off-hook. Please refer to "To store a phone number" in "2.2.2 Easy Dialling."
Remote DND (→ext)	Remote DND	Set or cancel the DND feature set at other extensions. *Please refer to "3.1.2 Setting or Cancelling the DND Feature to Other Extensions (Remote DND Control)."
Remote Timed Reminder	R-Timed Remind	Set the alarm ringing time for any extension.*Please refer to "To set" and "To cancel" in "3.1.1 Setting the Alarm for Other Extensions (Remote Timed Reminder)."

Display (KX-T7436 / KX-T7235)	Display (KX-T7433)	Feature Description
Station Lock (→abcabc)	St.Lock abcabo	Deny other people the possibility of using your telephone. Please refer to "2.5.4 Preventing Other People from Using Your Telephone (Electronic Station Lockout)."
Station Programme Clear	STA Prog Clear	Clear the features set at your telephone. Please refer to "2.7.14 Clearing the Feature Settings at Your Extension (Station Programme Clear)."
Timed Reminder	Timed Reminder	Set the alarm ringing time. Please refer to "To set" and "To cancel in "2.7.1 Setting the Alarm (Timed Reminder)."
TRK Route CTL (→PHY)	TRK Route CTL	Verify the status of a specific trunk. *Please refer to "3.2.4 Trunk Route Control."
UCD Monitor End	UCD Monitor End	Cancel the monitoring of a UCD Group. Please refer to "To set" in "2.11.3 Monitoring the Number of UCD Calls Waiting to be Answered (UCD Monitor Mode)."
UCD Monitor STRT (→FDN)	UCD Monitor STR	Start the monitoring of a UCD Group. Please refer to "To cancel" in "2.11.3 Monitoring the Number of UCD Calls Waiting to be Answered (UCD Monitor Mode)."
Walking COS (→code+ext)	WK.COS code+ext	Call using your privileges at another extension. Please refer to "Using your password (Walking COS)" in "2.2.5 Calling without Restrictions."



\*Available for the Manager and the Operators only.

### **Call Forwarding / Do Not Disturb feature:**

You can also access the Call Forwarding and Do Not Disturb features. Go off-hook and press the FWD / DND button. You will see the following displays. For their operation, please refer to the respective operating instructions. The KX-T7436 and the KX-T7235 users only use this display operation.

FWD/DND Cancel		
Do Not Di	sturb	
FWD-All Calls		$(\rightarrow ext)$
FWD-Busy		$(\rightarrow ext)$
FWD-No Answer		$(\rightarrow ext)$
MENU	PREV	NEXT


FWD-BSY/	NA	$(\rightarrow ext)$
FWD-CO/T	IE Line	$(\rightarrow dial)$
FWD-From		$(\rightarrow ext)$
FWD-From	Cancel	$(\rightarrow ext)$
MENU	PREV	NEXT


### 2.11 Other Features

## 2.11.1 Controlling the External Modem (External Modem Control)


Allows you to control the external modem, connected to the KX-TD500 System, using an RS-232C cable, by sending a pre-assigned AT command (for enabling Automatic Answer, etc.).

### ◆ To activate an AT command





### ◆ To activate an AT command (contd.)






- An AT command can only be programmed by Serial Interface / Remote Programming software.
- For more information about AT Command, please refer to the modem instructions.


## 2.11.2 Accessing the ISDN Network Service (ISDN Network Service Access)

You can access services provided by the ISDN Network.

### ◆ To access an ISDN Service (1)



### ◆ To access an ISDN Service (2)





- For more information about ISDN Network Services or the specific numbers, please consult your ISDN Network provider.
- The ISDN Service button can be used, just after getting the outside line, during a call and after disconnecting the call. (This depends on the type of the service provided by the ISDN Network provider.)





- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange an ISDN Service button
- 4.3 Customising Your System (User Programming)
  - 4.3.5 Flexible CO Button Assignment (005)

## 2.11.3 Monitoring the Number of UCD Calls Waiting to be Answered (UCD Monitor Mode)


You can (if specified as the Supervisor Extension of a UCD Group by System Programming) monitor the number of calls waiting to be answered in the queue.

#### ◆ To set







### ◆ To set (contd.)




### To cancel





### ◆ To cancel (contd.)








• The Supervisor Extension of a UCD Group is specified by System Programming.

### 2.11.4 Switching the Day / Night Service

You can (if allowed by System Programming) turn on / off the Night service mode. The KX-TD500 System supports both the Night and Day modes of operation in a different arrangement. The system operation for originating and receiving calls can be programmed differently in Day and Night modes.









- To confirm the current mode, press the "#" key while on-hook.
- The Day / Night button light shows the current status as follows:

Off: Day mode Red: Night mode

The Manager and the Operators can also change the mode.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange a Day / Night button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)

### Section 3

## Operator / Manager Operation


This chapter shows the Operators and the Manager how to control the extensions and the system. Your system supports a group of operators and one manager.


Operator / Manager Operation 157

## 3.1.1 Setting the Alarm for Other Extensions (Remote Timed Reminder)


The Manager and the Operators can remotely set or cancel the Timed Reminder feature to any extension.

#### ◆ To set







### ◆ To set (contd.)




#### To cancel






### ◆ To cancel (contd.)



### To view the setting






• If the daily alarm is set, the display shows "\*" in the corner.


Alarm 10:10AM\*

## 3.1.2 Setting or Cancelling the DND Feature to Other Extensions (Remote DND Control)


The Manager and the Operators can set or cancel the Do Not Disturb (DND) feature to other extensions.

### ◆ To set / To cancel






### ◆ To set / To cancel (contd.)





## 3.1.3 Calling the Extension that has set Call Forwarding (Remote FWD Cancel-Once)

The Manager and the Operators can ring the extension that has set FWD (Call Forwarding) feature.

### ◆ To cancel Call Forwarding temporarily








### 3.1.4 Changing the Settings (Station Programming)





Item	Programming Input
Unlocking or locking any extension (Remote Station Lock Control)	O 1 extension no.* X  X= 1 : Unlock 2 : Lock outside calls 3 : Lock intercom calls except operator call
Unlocking the call log (Incoming Call Log Lock Control)	0 2 extension no.*
Clearing the Live Call Screening Password (Live Call Screening Password Control)	0 3 extension no.*





\*To assign all extensions, press the "\*" key.


### 3.2 System Control

## 3.2.1 Turning on the External Background Music (Background Music [BGM] - External)

The Manager and the Operators can turn on / off the background music (BGM) through external speakers.







### Recording Outgoing Messages

Up to 8 OGM (Outgoing Message) Groups are available in the System and OGM Type for each OGM group is determined by System Programming.


The following three types of Outgoing Messages can be recorded and played back:


DISA message: Used as the greeting message or guidance when an external party calls your company to access an extension or external party without any operator assistance.

Timed Reminder (Wake-up) message: Often used as a wake-up message which is played when answering the Timed Reminder alarm.


UCD (Uniform Call Distribution) message: This message is played when an outside caller to a UCD group cannot reach any UCD group member.

#### To record







### ◆ To record (contd.)




### To play back





### To play back (contd.)







- To stop recording or playing back, press the AUTO DIAL / STORE button.
- Message recording limit A maximum recording time for each OGM is 30 seconds.


### 3.2.3 Trunk Busy-out Setting

The Manager and the Operators can busy out a trunk.


### ◆ To set










### To cancel









### **♦** To confirm










### 3.2.4 Trunk Route Control

The Manager and the Operators can verify the status of the specified trunk.

#### ◆ To set








### 3.2.5 Displaying a System Error Indication (Local Alarm Indication) [Manager only]

If a system error is detected during on-line communication mode, the system alerts the Manager extension by turning on the Alarm button indicator on it. The Alarm button lights in red. The Manager can confirm the error indication by pressing the red lit Alarm button. If a major error occurs, minor errors will be neglected and only the first major error message will be displayed. The second error will be neglected, if the error priority is the same as the first one. Please refer to Section 7 "Troubleshooting" in the Installation Manual for the detailed information on error messages.

### To display an alarm indication



#### To clear the alarm indication





If multiple errors are generated at a time, only the error with the highest priority will be displayed by pressing the red lit Alarm button.



- 4.1 Customising Your Phone (Station Programming)
  - 4.1.2 Customising the Buttons Create or re-arrange an Alarm button.
  - 4.3 Customising Your System (User Programming)
    - 4.3.5 Flexible CO Button Assignment (005)

### Error Indications List (Priority order)

Indications	Description	Priority	Others
ERR CLCK IC	Calendar IC failure	1	А
ERR DC DOWN	DC power down	1	А
B/S FAN FLT!	Basic shelf fan alarm	1	В
E/S1 FAN FLT!	Expansion shelf 1 fan alarm	1	В
E/S2 FAN FLT!	Expansion shelf 2 fan alarm	1	В
B/S OVER HEAT!	Basic shelf heat alarm	1	В
E/S1 OVER HEAT!	Expansion shelf 1 heat alarm	1	В
E/S2 OVER HEAT!	Expansion shelf 2 heat alarm	1	В
ERR TSW DWN	TSW clock down	1	А
ERR BAT ALM	CPU RAM battery alarm	1	А
ERR AC DOWN	AC power down	2	А
ERR xyy CRD ERR	Option Card failure	2	А
ERR XYY DISCNCT	Card disconnect	2	А
ERR xyy DTR AIS	Digital trunk AIS reception	2	С
ERR xyy DTR FRM	Digital trunk frame failure	2	С
ERR xyy DTR RAI	Digital trunk RAI reception	2	С
ERR XYY DTR SYC	Digital trunk out of synchronization	2	С
ERR xyy LPR RAM	Option Card RAM failure	2	А
ERR xyy LPR ROM	Option Card ROM failure	2	А
ERR xyyz MODEM	Modem failure	2	А
ERR xyy OGM LOS	DISA OGM is lost	2	С
ERR xyy OPX POW	OPX power failure	2	С
ERR SMDR	Printer is not connected	2	А

### [Legend]

### **Indications**

x: Shelf Number (1-3)

yy: Slot Number (01-14) z : Error Number

#### **Priority**

1 : Major Error 2: Minor Error

### **Alarm LED**

(When a problem occurs)

LED on PT / Top Shelf.....OFF→ON

The corresponding error indication will be displayed on the LCD by pressing the red lit Alarm button.

B :

LED on PT / Top Shelf.....OFF→ON

The corresponding error indication will be displayed on the LCD automatically.

C :

LED on PT / Top Shelf.....OFF (no change)

The contents of the error will be printed out by SMDR.

(When the problem is solved)

Α

LED on PT.....ON (no change)

LED on Top Shelf.....ON→OFF

В:

LED on PT / Top Shelf.....ON→OFF

### Section 4

# Customising Your Phone & System

This chapter shows you how to customise your individual telephone or system according to your needs. Find the desired setting and program as necessary.

### Customising Your Phone (Station 4.1 **Programming)**

If you use a Panasonic proprietary telephone (e.g. KX-T7436), you can customise your telephone functions. For example, you can change the initial settings or button functions according to your needs.




After moving to a new location in the office, you can use the same extension number and the setting of your previous extension at a new location (Walking Station).

### 4.1.1 Initial Settings

The original settings are shown in bold letters in the shaded boxes. Find and mark your desired selections for programming.




- If nothing is entered within one minute in the programming mode, the mode returns to the normal call handling mode.
- To exit the programming mode at any time, lift the handset. The mode returns to the normal call handling mode.



Item	Selection	Programming Input
Which line do you prefer to seize when you go off-hook to receive calls?	☐ No line	2 1
	A ringing line	2 2
(Preferred Line Assignment – Incoming)	A pre-assigned line	2 3 INTERCOM  (PDN)  (SDN)  (SCO)  (SCO)  (GCO)  (GCO)  (ILCO)
Which way do you prefer to dial the One-Touch Dialling feature?	Going Off-hook and then pressing the One-Touch Dialling button	3 1
(Full One-Touch Dialling Assignment)	Pressing the One-Touch Dialling button directly.	3 2
Which way do you prefer to receive an intercom call?	Ringing	4 1
(Intercom Alert Assignment)	Directly – the party's voice is heard without ringing.	4 2
Do you prefer to distinguish the Call Waiting tone from an out-	No. Use the same tone.	5 1
side line and an intercom call? (Call Waiting Tone Type Selection)	Yes. Use a different tone.	5 2
Which display do you prefer when a CO call is received?	☐ Caller ID	8 1 1
(Initial Display Selection)	CO line name	8 1 2
Which language display do you prefer? (Bilingual Display Selection)	☐ English	8 2 1
	Optional Language	8 2 2
Which equipment will you use as a receiver? (Handset / Headset Selection)	☐ Handset	9 1
	Headset	9 2
Which voice mail service do you prefer when a caller is recording a message in your	You can monitor the message recording through the telephone speaker. (Hands-free mode)	7 1
mailbox? (Live Call Screening Mode Set)	Only an alert tone is heard. (Private mode)	7 2


#### To confirm the current setting




#### To clear all settings (Station Programming Data Default Set)

You can reset all of the following items assigned by Station Programming to their default settings at once.

- a) Full One-Touch Dialling Assignment (default: On)
- **b)** Bilingual Display Selection (default: English)
- c) Call Waiting Tone Type Assignment (default: Tone 2)
- d) Handset / Headset Selection (default: Handset)
- **e)** Initial Display Selection (default: Caller ID)
- f) Intercom Alert Assignment (default: Tone Call)
- g) Live Call Screen Mode Set (default: Hands-free)
- **h)** Preferred Line Preference Incoming (default: Ringing Line)
- i) Preferred Line Preference Outgoing (default: INTERCOM Line)




## To confirm your own extension number (Self-Extension Number Confirmation)




#### 4.1.2 Customising the Buttons

You can change the flexible CO buttons, DSS buttons and programmable function (PF) buttons to the following function buttons. For example, if your telephone has more CO buttons than available CO lines, you may change an unused CO button to a One-Touch dialling button.




Button	Programmable Button			Programming Input	
Button	СО	DSS	PF	Frogramming input	
Loop-CO	<b>'</b>			*	
Group-CO	<b>✓</b>	<b>✓</b> *1		# Trunk group no. (01–48)	
Single-CO	<b>✓</b>	<b>✓</b> *1		Trunk port physical no. (5 digits)	
Direct Station Selection (DSS)	<b>✓</b>	<b>'</b>		1 Extension no.	
One-Touch Dialling	~	~	~	<b>Desired no.</b> *2 (max. 24 digits)	
MESSAGE	~	~		3	
FWD / DND (Forward / Do Not Disturb)	~	~	~	4	
SAVE	~	~	~	5	
Account	~	~	~	6	
CONF (Conference)	~	~	~	7 0	
Log-In / Log-Out	~			7 1	
Phantom Extension	<b>✓</b>			7 Phantom extension no.	
Day / Night	~			7 3	
Primary Directory Number (PDN)	<b>/</b>			7 4	
Secondary Directory Number (SDN)	<b>/</b>			7	
Alarm	<b>V</b>			7 7	



Button	Progra	ımmable	Button	Drogramming Innut	
Button	СО	DSS	PF	Programming Input	
Tone Through	~	<b>'</b>		7 8	
Voice Mail Transfer*3	<b>'</b>	<b>'</b>		8 Voice mail extension no.	
Two-Way Record*3	<b>'</b>	<b>'</b>		9 Voice mail extension no.	
Two-Way Transfer*3	<b>'</b>	<b>'</b>		9 1 Voice mail extension no.	
Live Call Screening*3	<b>'</b>	<b>'</b>		9 2	
Live Call Screening Cancel*3	<b>'</b>	<b>'</b>		9 3	
Answer	<b>'</b>	<b>'</b>	<b>'</b>	9 4	
Release	<b>'</b>	<b>'</b>	<b>'</b>	9 5	
ISDN Service (SS)	<b>'</b>	<b>'</b>	<b>'</b>	9 6 Service no.	




- Available for monitoring the call activity only.
- "2" \* ", "#", FLASH, PAUSE, SECRET (INTERCOM) and (CONF) can also be stored. KX-T7220 and KX-T7250 telephone users can use the PROGRAM button instead of the PAUSE button.
- If you do not want to display the stored number, press the SECRET (INTERCOM) button before and after the numbers you wish to conceal.
- If you store an external party's number, you should first store a line access number (9, 801 848).
- If you need to enter an account code, you can enter the specified account code before the line access number.
  - <Example>




- '3 These buttons are used for the VPS integration feature.
- To exit the mode at any time, lift the handset.


## To distinguish the ringing tones for each CO button (Digital proprietary telephone only)




## To change the ringing tone for intercom calls (Digital proprietary telephone only)




## To set a phantom extension ringing or not (Digital proprietary telephone only)




#### To delay the ringing start timing of PDN / SDN buttons (DN type PT only)



#### To clear the button data



# 4.2 Charge Fee Management (Station Programming)



Item	Programming Input
Checking each extension charge.	1 Extension no. SEL
Clearing each extension charge.	1 Extension no. CLR AUTO DIAL STORE
Checking each outside line charge.	Trunk port physical no. (5 digits)
Checking the total charge.	3 SEL
Checking each account code charge.	4 Location no. (0001–1000) SEL
Clearing each account code charge.	4 Location no. (0001–1000) CLR AUTO DIAL STORE
Setting a New Rate	New rate. (1-8 digits) STORE
Clearing all outside line and account code charge.	6 CLR Displays the last clearing date and time.
Clearing all extension charges.	6 NEXT CLR Displays the last clearing date and time. AUTO DIAL STORE
Printing the total telephone charge (each outside line and account code),	7 1 total telephone charge
all extension charges or each	7 2 all extension charges
extension charge by SMDR.	7 (3 Extension no. each extension charge
Assigning an account code.	R Location no. (0001-1000) CLR New account code (10 digits)

## 4.3 Customising Your System (User Programming)

You can customise your system according to your application.

Your system already has default settings (factory installed). Most of the programming is done by your dealer. Consult your dealer about system applications and re-programming according to your needs. If you would like to assign / change the following features, extensions which meet certain conditions can re-programme them at any time.

#### The available programming items are shown below. (Programme number)

- 4.3.1 Date and Time Set (000)
- 4.3.2 System Speed Dialling Number Set (001)
- 4.3.3 System Speed Dialling Name Set (002)
- 4.3.4 Extension Name Set (004)
- 4.3.5 Flexible CO Button Assignment (005)
- 4.3.6 Caller ID Dial Set (006)
- 4.3.7 Caller ID Name Set (007)
- 4.3.8 Absent Messages Set (008)
- 4.3.9 Quick Dial Number Set (009)

#### Required Telephone

A Panasonic Proprietary Telephone with display (e.g. KX-T7433, KX-T7436)

#### User Password

To enter the programming mode, a user password (4-7digits) is required. It should be programmed by System Programming beforehand. Check pre-programmed password (Default:1234).

#### **Conditions**

Only one extension, which is on-hook and holding no calls, is available for performing user programming at one time. If another extension is programming, "Another Use" is displayed.

#### List


Before programming, decide your selections and write them down in the list for each programming item. These are useful for easy programming and future reference. Your dealer also has programming tables which contain all of the assignments. You may ask for photo copies of these tables to be aware of the features / conditions available.

#### Overlay / Button Function

A programming overlay sheet is packed with the telephone at the factory. This overlay sheet should be used at all times in the programming mode since the functions of the telephone keys change in the programming mode as follows: (The original functions are in parentheses.)

<b>During Normal Operation</b>	<b>During Programming</b>
(PAUSE / PROGRAM)	PAUSE / PROGRAM
(SP-PHONE)	NEXT
(REDIAL)	PREV(PREVIOUS)
(AUTO ANSWER / MUTE)	SELECT
(FLASH)	FLASH
(TRANSFER)	CLEAR
(FWD / DND)	•
(CONF)	-/ <b>◆</b> ■
(INTERCOM)	SECRET
(AUTO DIAL / STORE)	STORE
(HOLD)	END
(Up / Down / JOG)	Skip+ / Skip-


If your display PT shows the necessary functions, the overlay may be not required.



KX-T7436 with the overlay

#### Display


The display gives you useful messages about programming. The multiple-line display also shows the available functions. Follow the message at each step. This is a display sample in the initial programming mode.



The message line guides you through programming and lets you confirm your selection. The display shows up to 16(KX-T7230,KX-T7433) or 24(KX-T7235,KX-T7436) characters at a time. To scroll the display, press  $\rightarrow$  or  $\leftarrow$ . The function line shows you the function of the Soft button located below it. When the SHIFT button light beside the display is on, subtitles are available. Press the SHIFT button to confirm the available functions.

#### **Extension Number**

If you do not know the extension no., confirm it as shown below.



#### **Confirmation**

To confirm your entry after storing data;

- The STORE button light: Lights red.
- Confirmation Tone:
  - One beep: Your entry is accepted.
  - Three beeps: Your entry is rejected.

#### Icon Descriptions

Icons are given to guide you through programming. The following is an example of how the icons may be used:



Enter the programme number. (xxx= the specified number)



Press the corresponding button on the telephone or the Soft button which corresponds to the display.

#### <Example>

NEXT : "NEXT" is displayed.

In this case, both of the following methods are available:

- Press the NEXT (☐ ) button.
- Press the Soft button which corresponds to "NEXT" shown on the display.



The display messages "SEL+, SEL- and SEL" mean "SELECT." "CLR" means "CLEAR."



Press the button until the desired entry appears.



Enter your selection.

#### <Example>


extension no. : "Extension no." is displayed.

Enter the extension number.


#### **Procedure**

The basic steps are shown below.

#### 1. Entering the programming mode



#### 2. Programming



To go to the next/previous programme or entry.

To enter the desired programme or entry.




- To delete or change an entry, press CLEAR (TRANSFER).
- To confirm your entry after storing data:
  - The STORE button light: Lights red.
  - Confirmation Tone:

One beep: Your entry is accepted. Three beeps: Your entry is rejected.

• To exit the programming mode at any time, lift the handset.

#### 3. Exiting the mode






#### Character Entry

When storing a name or message, enter the characters as follows. The tables on the next page show you the characters available for each key. You can enter letters by pressing the alphanumeric keys on your telephone.

Example: Key 2 can be used to enter A, a, B, b, C or c.



#### Entering characters

- · Press the desired character key.
- Press the matching Soft button, press the SELECT (AUTO ANSWER) button or rotate the Jog Dial
- Repeat the appropriate steps for the remaining characters.



- To erase the last letter, press the  $\leftarrow$  (CONF) button.
- To erase all letters, press the CLEAR (TRANSFER) button.
- To alternate between capital and lower case letters, press the SHIFT button. Once this button is pressed, the mode remains until the SHIFT button is pressed again.


#### Combination Table 1

Rotating Jog Dial (Pulses) keys	0	1	2	3	4	5	6	7	8
1	1	Q	q	R	r	S	s	Т	t
2	2	А	а	В	b	С	С	D	d
3	3	D	d	Е	е	F	f	G	g
4	4	G	g	Н	h	I	i	J	j
5	5	J	j	K	k	L	I	М	m
6	6	М	m	N	n	0	0	Р	р
7	7	Р	р	Q	q	R	r	S	S
8	8	Т	t	U	u	V	V	W	w
9	9	W	W	Х	х	Y	у	Z	Z
0	0	(Space)	!	?		,	,	:	;
*	*	/	+	-	=	<	>	#	\$
#	#	\$	%	&	@	(	)	Α	а

#### Combination Table 2

SHIFT & Soft Combination		S1	SHIFT+S1	S2	SHIFT+S2	S3	SHIFT+S3	SHIFT+ SHIFT+ S1	SHIFT+ SHIFT+ S2
Pressing SELECT (Times) keys	0	1	2	3	4	5	6	7	8
1	1	Q	q	Z	Z	!	?		
2	2	Α	а	В	р	С	С		
3	3	D	d	Е	е	F	f		
4	4	G	g	Н	h	I	i		
5	5	J	j	K	k	L	I		
6	6	М	m	N	n	0	0		
7	7	Р	р	Q	q	R	r	S	S
8	8	Т	t	U	u	V	V		
9	9	W	W	Х	х	Y	у	Z	Z
0	0	(Space)		,	,	:	;		
<del>*</del>	*	/	+	-	=	<	>		
#	#	\$	%	&	@	(	)		


<Example> To enter "Ann,"



#### 4.3.1 Date and Time Set (000)

You can set / adjust the system date and time which affects system-wide operation. After setting the current date and time, the proprietary telephone displays the current date and time while on-hook.

Default: '99 JAN 1 FRI 12:00AM 12-hour clock time






- After changing the desired entries, you can press the STORE button. You do not have to perform the rest of the steps.
- The clock starts immediately after the STORE button is pressed.
- You cannot leave an entry empty.

#### 4.3.2 System Speed Dialling Number Set (001)

You can store up to 1000 frequently dialled phone numbers which can be used by any extension user in the system.

Default: No entry





- The telephone directory for "System Speed Dialling" is provided in "5.3 Directory."
- If the desired number is more than 24 digits, divide the number and store it into two or more speed dial numbers.
- "\times", "\pi", FLASH, PAUSE, SECRET (INTERCOM) and (CONF) can also be stored.
  - If you do not want to display the stored number when it is dialled, press the SECRET (INTERCOM) button before and after the numbers you wish to conceal.
  - If you store an external party's number, you should first store a line access number (9, 801 to 848).
  - If you need to enter an account code, you can enter the specified account code before the line access number.

<Example>




### 4.3.3 System Speed Dialling Name Set (002)

You can store the corresponding name for each speed dialling number. These names are displayed when making call with the display operation. (Please refer to "2.10.4" Using the KX-T7433, KX-T7436 or KX-T7235.")

Please refer to "Entering characters" in "4.3 Customising Your System (User Programming)."

Default: No entry






The telephone directory for "System Speed Dialling" is provided in "5.3 Directory."

#### 4.3.4 Extension Name Set (004)

You can assign the name for each extension individually. This is useful if you want to know who is calling, or who you are calling when making an intercom call using the directory.

Please refer to "Entering characters" in 4.3 Customising Your System (User Programming).

Default: No entry






• The directory is on "Extension" in 5.3 Directory.

#### 4.3.5 Flexible CO Button Assignment (005)

You can change the flexible CO buttons of all PTs in the system to the function buttons listed on the next page. For example, if someone's telephone has more CO buttons than available CO lines, you may change an unused CO button to a One-Touch Dialling button.

**Default:** For all PTs – CO button 1 = Loop-CO; Ring tone type 2 Other CO buttons = Not Stored.





- The number of CO buttons available for each PT varies depending on the telephone type. (Please refer to Section 1.16 Button Features "Buttons on Proprietary Telephones" in the Features Guide).
  - To programme 24 CO buttons, please use the PT with 24 CO buttons, such as KX-T7436.
- If you press the same CO button twice consecutively during <Programming>, you can select
  a desired ringer frequency for the CO button from eight types of ring tones. When you enter
  the tone type number (1 through 8), you will hear the selected tone type until STORE is
  pressed. This selection is possible only for the CO buttons that have been assigned to
  Single-CO, Group-CO, Loop-CO, PDN or SDN.


Button Code	Parameter
0 (Single-CO)	10101 through 31408 (trunk port physical number)
1 (DSS)	3 through 4 digits (Extension number)
2 (One-Touch)	24 digits max. (Telephone number)
3 (Message Waiting)	None
4 (FWD / DND)	None
5 (Save)	None
6 (Account)	None
70 (Conference)	None
71 (Log-In / Log-Out)	None
72 (Phantom)	3 through 4 digits (Phantom extension number)
73 (DAY / NIGHT)	None
<b>74</b> (PDN)	None
<b>75</b> (SDN)	3 through 4 digits (Owner extension number)
<b>76</b> (PDN / SDN Delayed Ringing)	0 through 4 (delayed ringing type)
<b>77</b> (Alarm)	None
78 (Tone Through)	None
8 (Voice Mail Transfer)	3 through 4 digits (VM Extension number)
90 (Two-Way Record)*	3 through 4 digits (VM Extension number)
91 (Two-Way Transfer)*	3 through 4 digits (VM Extension number)
92 (Live Call Screening)*	None
93 (Live Call Screening Cancel)*	None
94 (Answer)	None
95 (Release)	None
96 (ISDN service)	24 digits max. (Service number)
*(Loop-CO)	None
# (Group-CO)	01 through 48 (trunk group number)
CO / INTERCOM (ringer frequency)	1 through 8 (ring tone type number)
Phantom (ringing on / off)	1 (off) / 2 (on)

<sup>\*:</sup> Available when the Digital Super Hybrid System is connected to a Digital Proprietary Telephone capable Panasonic Voice Processing System.(one that supports digital proprietary telephone integration; e.g. KX-TVP100.

#### 4.3.6 Caller ID Dial Set (006)

You can set the identification code of the calling party (Caller ID Code) to utilize Caller ID Service provided by a specific Central Office (CO). If an ID Code transmitted from CO is found in the Caller ID Code Table, the Caller's ID Code or a name given to the code in "4.3.7 Caller ID Name Set (007)" is displayed on the display PT, allowing the called party to recognize the caller.

Default: All locations: Not Stored.






- Up to 1000 Caller ID Codes (a maximum of 24 digits for each consisting of 0-9, \* or #) per tenant, 2000 per system can be assigned.
- Programme "4.3.7 Caller ID Name Set (007)" is used to give names to Caller ID Codes.
   If an ID Code is given a name, the called party's display PT shows the name with the Caller ID Code.

#### 4.3.7 Caller ID Name Set (007)

With the Caller ID Service, the calling party is displayed either by its ID Code or by its name. If the name display is required, use this programme to give a name to a Caller ID Code stored in programme "4.3.6 Caller ID Dial Set (006)."

Default: All locations: Not Stored.





- Up to 1000 Caller ID Names per tenant, 2000 per system, can be assigned.
   Each name corresponds to a Caller ID Code programmed by "4.3.6 Caller ID Dial Set (006)."
- A Caller ID Name cannot be assigned if the corresponding Caller ID Dial is not assigned.
- For entering characters, please refer to "Character Entry" in "4.3 Customising Your System (User Programming)."

#### 4.3.8 Absent Messages Set (008)

You can programme the absent messages. An absent message, if set by the extension user, is displayed on the display of calling extension's PT to show the reason for the user's absence.

Default: 1: Will Return Soon

2: Gone Home


3: At Ext %%%%

4: Back at %%: %%

5: Out Until %% / %%

6: In a Meeting

7: through 9: Blank (not stored)






- Up to nine Absent Messages can be assigned. Messages 1 through 6 are programmed at the factory but can be changed. Each message has a maximum of 16 characters.
- For entering characters, please refer to "Character Entry" in "4.3 Customising Your System (User Programming)."
- You can enter a maximum of seven "%" characters per message which can be programmed
  at each user's extension. The extension user can enter 0-9, \* or # for the % characters. If
  the extension user enters digits less than the number of "%" characters, it is recommended
  to fill the remaining "%" characters with "#" or "\*."
- To display parts of the message which have scrolled off the display, press  $\rightarrow$  or  $\leftarrow$ .

#### 4.3.9 Quick Dial Number Set (009)

You can store up to eight Quick Dial numbers (Quick Dial 1-8) which are commonly used by any extension user in the system.

**Default:** All location numbers: Not Stored





- A maximum of 16 digits, consisting of 0-9, \* or # keys, and the FLASH, PAUSE, SECRET
  and "-" (hyphen) button can be assigned to a quick dial number:
- Before programming this programme, a feature number for each location should be programmed by System Programming.

### Section 5

## Appendix

This chapter provides the Troubleshooting, Feature Number List, Directory, Tone List and Specifications. Check the Troubleshooting before consulting your dealer.

## 5.1 Troubleshooting

Problem	Remedy
The telephone does not work properly.	The wiring is wrong.     ⇒ Check the wiring.
I cannot use the telephone.	The telephone is locked.  Unlock your telephone. (□ "To lock" in  "2.5.4 Preventing Other People from Using Your Telephone (Electronic Station Lockout),"  "3.1.4 Changing the Settings (Station Programming)")  Your telephone is connected to an eXtra Device Port.  System programming is required. Consult your dealer.
Some features do not work.	<ul> <li>System management may restrict certain features.</li> <li>⇒ Consult your System Manager.</li> <li>The feature numbers have changed.</li> <li>⇒ Confirm the revised number and try again.</li> </ul>
Even though following the manual instructions, none of the operations work when using a proprietary telephone.	The Intercom line was not seized. The seized line, when going off-hook, was changed by personal setting. (□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
The parallelled single line telephones do not ring.	This is the default setting.     ⇒ Change the setting to ring. (□ "2.7.13 Setting the Parallel Connected Telephone Ringer (Parallelled Telephone Connection)")
The telephone does not work using the personal settings or with other settings. (One-Touch dialling, forwarding destination, etc.)	The extension line has been changed. The previous telephone's settings have not been cleared.     Clear the settings and then programme your desired settings again. (□ "2.7.14 Clearing the Feature Settings at Your Extension (Station Programme Clear)," To clear all settings" in "4.1.1 Initial Settings," "To clear the button data" in "4.1.2 Customising the Buttons")
My proprietary telephone does not have a function button.	Some models do not have the function button.     ⇒ Change a flexible button to the desired button.     (□ "4.1.2 Customising the Buttons")     ⇒ Enter the specified feature number instead of the function button. (□ "Feature Numbers" in "2.1 Before Operating the Telephones")

Problem	Remedy
I cannot make an outside call.	The telephone is locked.
	→ Unlock your telephone. ( □ "2.5.4 Preventing Other People from Using Your Telephone (Electronic Station Lockout)," "3.1.4 Changing the Settings (Station Programming)")
	Toll restriction is activated.
	→ Consult your manager or dealer.
	An account code is required. (1887 "2.2.5 Calling without Restrictions")
	Another PBX is connected to your system.
	⇒ A host PBX access code is required. (□ "2.8.2 If a Host PBX is Connected")
	<ul> <li>Nothing was dialled within 10 seconds after going off- hook.</li> </ul>
	→ Hang up, off-hook and re-dial again.
A reorder tone is audible or	The telephone is locked.
"Restricted" is displayed.	→ Unlock your telephone. (♣ "2.5.4 Preventing Other People from Using Your Telephone (Electronic Station Lockout)," "3.1.4 Changing the Settings (Station Programming)")
	Toll restriction is activated.
	→ Consult your System Manager or dealer.
	An account code is required. (1887 "2.2.5 Calling without Restrictions")
I cannot make an outside call using the	A line access number was not stored.
One-Touch Dialling button or speed dialling.	→ A line access number is required for outside calls. (  "2.2.2 Easy Dialling," "Storing the names and numbers for station speed dialling" in "2.10.4 Using the KX-  T7433, KX-T7436 or KX-T7235," "4.1.2 Customising the Buttons")
I cannot remember the feature numbers.	→ Ask your dealer to change the feature numbers for easier use.
	⇒ Store the feature numbers into the One-Touch Dialling buttons. (☞ "4.1.2 Customising the Buttons")
While talking to an outside party, the line is disconnected.	The time limit has expired. (□ "Transferring a call to an external party" in "2.4.3 Transferring a Call," "Leaving a conference " in "2.4.5 Three-party Conversation")     Consult your dealer to extend the time, if necessary.
Redialling does not function.	The stored number is more than 24 digits or an extension number. ( 2.2.3 Redial")
I cannot mute the conversation.	You are using the handset. ( "2.4.6 Mute")
I cannot access computer services, banking-by-phone, etc.	A tone signal is required. ( "Changing the dialling mode (Pulse to Tone Conversion)" in "2.2.5 Calling without Restrictions")

Problem	Remedy
The personal computer and facsimile communication failed.	An indication tone may have interrupted communication.     ( 2.7.11 Protecting Your Line against Indication Tones (Data Line Security)")
I cannot send a call waiting tone to the dialled extension.	<ul> <li>The other party has not set the Call Waiting feature.         (INT "Sending a call waiting tone (Busy Station Signalling [BSS]) in "2.2.4 When the Dialled Line is Busy or There is No Answer," "2.7.3 Receiving a Call Waiting (Call Waiting / Off-Hook Call Announcement [OHCA] / Whisper OHCA)")</li> <li>The other party has set Data Line Security.</li> </ul>
	(12) "2.7.11 Protecting Your Line against Indication Tones (Data Line Security)")
I forgot the lock code / Live Call Screening Password.	→ Ask the Manager or an Operator to assist you.  (IST "3.1.4 Changing the Settings (Station Programming)")
The background music started suddenly.	→ Turn off the music.  (INT "2.7.10 Turning on the Background Music (BGM),"  "3.2.1 Turning on the External Background Music  (Background Music [BGM] - External)")
I do not want to display a number which is stored in memory.	→ Conceal the number. (☞ "Storing the names and numbers for station speed dialling" in "2.10.4 Using the KX-T7433, KX-T7436 or KX-T7235")
The display does not show the message described in the manual.	The telephone is not a Panasonic proprietary telephone.     ⇒ This manual shows messages which appear only on Panasonic proprietary telephones (e.g. KX-T7436).     (□ "Display" in "2.1 Before Operating the Telephones")
I want to confirm my extension number and extension port physical number.	(🖙 "To confirm your own extension number" in "4.1 Customising Your Phone (Station Programming)")
The date and time are not correct.	Set the date and time by user programming.     (
The display is abnormal.	The lithium battery for memory back-up needs to be replaced.      → Consult your dealer.
I want to distinguish the tones.	(EST "To confirm the current setting" and "To clear all setting" in "4.1.1 Initial Settings," "To distinguish the ringing tones for each CO button (Digital proprietary telephone only) in "4.1.2 Customising the Buttons")
I hear a warning tone from the telephone.	The handset was off-hook in an idle status for an extended period of time.      Replace the handset.
The MESSAGE button light lit.	Another extension left you a message waiting indication during you were on the phone or not at your desk.

Problem	Remedy
A Power Failure occurred.	When a power failure occurs
	The system and Panasonic proprietary telephones stop all functions. Specific extensions are automatically connected straight to specific CO lines. This provides CO line conversations between the pre-assigned extensions and CO lines:
	→ Consult your dealer for detailed information.
	All intercom calls and features do not function.
	When turning the power back on
	Your system restarts with the stored data automatically.  Memory is protected by a pre-installed lithium battery.  There is no memory loss except for Automatic Callback Busy (Reserving a busy line) and Held calls.

#### 5.2 Feature Numbers List

There are flexible feature numbers and fixed feature numbers.

#### Flexible Feature Numbers

Numbers listed below are the default settings. If the flexible feature numbers are changed by System Programming, fill in the newly assigned numbers in the list for future reference.

Feature	Default	Assigned no.	Additional digits
Calling the operator	0		
Automatic line access number / ARS	9		
Outside line group number	8		01-48
TIE line access number	77		
Calling a pre-set party by going off-hook / cancelling / storing	74		1 / 0 / 2+phone no.+#
Calling using the number stored at your extension Storing the numbers	3* 30		0-9 [0-9]+phone no.+#
Calling using the number stored in the system	*		000-999
Redialling the last phone number you dialled	#		
Cancel the reserving of a busy line	46		
Leaving a message waiting indication / cancelling / calling back / clearing a received indication	70		1+ext. no. / 0+ext. no. / 2 / 0+your ext.no.
31st incoming call log is stored / disregarded	56		1/0
Picking up a call for someone else - outside call - group - direct	4* 40 41		ext. no.
Holding or retrieving a call	50		
Retrieving from another extension - outside call - intercom / outside call	53 51		trunk port physical no. ext. no.
Holding in a system parking zone or retrieving	52		00-99
Paging or transferring and paging - all devices / all paging groups / individual paging group - all external speakers / individual external speaker	32 / 33		*/#/01-16 0/1/2
Answering a paged announcement or an incoming call through the external speaker	42		1/2
Answering the paged annoucement through telephones	43		

Feature	Default	Assigned no.	Additional digits
Receiving or refusing a call waiting tone or voice no tone / tone / OHCA / whisper OHCA	731		0/1/2/3
External feature access	6		
Forwarding your call - All calls / Busy / No answer / Busy, No answer - to an external party - cancel - Follow Me / cancel	710		[2 / 3 / 4 / 5]+ ext. no. 6+phone no.+# 0 [7 / 8]+your ext. no.
Preventing others from disturbing you (DND) / cancelling	<b>\</b>		1/0
Showing a message to the caller / cancelling	750		[1-9]+(parameter) / 0
Joining the call receiving group / leaving	45		1/0
Calling with account codes	49		code+[# or 99]
Calling using your privileges	47		password+your ext. no.
Setting the alarm / cancelling / viewing	761		1+time+ [0 (AM) / 1 (PM)] + [0 (once) / 1 (daily)] / 0 / 2
Refusing / receiving the indication tones	730		1/0
Denying other people the possibility of - seeing your call logs / Allowing - using your telephone / Allowing	57 762		3-digit code twice / stored code 3-digit code twice /
- picking up your calls / Allowing - paging through the speaker / Allowing - joining your conversation / Allowing	720 721 733		stored code 1 / 0 1 / 0 1 / 0
Parallelled telephones ring / do not ring	39		1/0
Cancelling the feature settings	790		
Displaying the number on the called and calling party's phone [CLIP / COLP], outside line / extension	711		1/2
Preventing the number being displayed on the called party's phone [CLIR], restrict / present / one-time setting	59		2/0/1
Preventing the number being displayed on the calling party's phone [COLR], restrict / present	58		1/0
Calling the doorphone	31		1-8
Opening the door from a specified phone	55		1-8

Feature	Default	Assigned no.	Additional digits
Setting the Live Call Screening password / cancelling	799		3-digit code twice / stored code
Setting the Walking Station, Start / End	727		1 / 0+source extension no.
Controlling the External Modem	791		[1-5]
Monitoring the number of UCD calls waiting to be answered / cancelling	725		ext. no. of UCD group /
* Setting the alarm / cancelling / viewing	7*		1+ext. no.+time+ [0 (AM) / 1 (PM)]+ [0 (once) / 1 (daily)] / 0+ext. no. / 2+ext. no.
* Controlling the DND feature on other extensions, set / cancel	722		destination ext. no.
* Calling the extension that has set Call Forwarding	723		destination ext. no.
* Turning on / off the background music external	35		
Switching the Day / Night service - to night / to day	78		1/0
* Recording an outgoing message / playing back	36		1 / 2+1-8
* Trunk Busy-out, set / cancel / confirm	726		1 / 0 / 2 +trunk port physical no.
* Trunk Route Control	724		trunk port physical no.

<sup>\*</sup> Operator / Manager only

#### Fixed Feature Numbers

Features	Type-1 (Default)	Type-2
While busy tone is heard:		
Automatic Callback Busy	6	6
Busy Station Signalling (BSS) / Off-Hook Call	1	2
Announcement (OHCA) / Whisper OHCA		
Executive Busy Override	2	3
While Do Not Disturb tone is heard:		
Do Not Disturb Override	1	2
While calling or talking:		
Account Code Delimiter	# / 99	# / 99
Alternate Calling - Ring / Voice	*	×
Conference	3	3
Door Open	5	5
Pulse to Tone Conversion	<del>×</del> #	<del>×</del> #
When the extension is on-hook:		
Background music (BGM) on / off	1	HOLD / TRANSFER
Day / Night mode display	#	#
Time display / Self-Extension Number display	*	×
switching		
When a CO call is arriving (Receiving the Caller ID information):		
Switching CO Line Name / Caller ID Number / Caller ID Name	*	*



Fixed Feature Numbers Type-1 or Type-2 can be selected by System Programming (Default: Type-1 ).

### 5.3 Directory

#### **Extension**

Extension no.	Name	Extension no.	Name
l			
ļ			
l			
l			

Extension no.	Name	Extension no.	Name
l		L	
l			
}			
}			

Note: Please make photo copies of this sheet if necessary.

## System Speed Dialling

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
000			046		
001			047		
002			048		
003			049		
004			050		
005			051		
006			052		
007			053		
800			054		
009			055		
010			056		
011			057		
012			058		
013			059		
014			060		
015			061		
016			062		
017			063		
018			064		
019			065		
020			066		
021			067		
022			068		
023			069		
024			070		
025			071		
026			072		
027			073		
028			074		
029			075		
030			076		
031			077		
032			078		
033			079		
034			080		
035			081		
036			082		
037			083		
038			084		
039			085		
040			086		
041			087		
042			088		
043			089		
044			090		
045			091		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
092			138		
093			139		
094			140		
095			141		
096			142		
097			143		
098			144		
099			145		
100			146		
101			147		
102			148		
103			149		
104			150		
105			151		
106			152		
107			153		
108			154		
109			155		
110			156		
111			157		
112			158		
113			159		
114			160		
115			161		
116			162		
117			163		
118			164		
119			165		
120			166		
121			167		
122			168		
123			169		
124			170		
125			171		
126			172		
127			173		
128			174		
129			175		
130			176		
131			177		
132			178		
133			179		
134			180		
135			181		
136			182		
137			183		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
184			230		
185			231		
186			232		
187			233		
188			234		
189			235		
190			236		
191			237		
192			238		
193			239		
194			240		
195			241		
196			242		
197			243		
198			244		
199			245		
200			246		
201			247		
202			248		
203			249		
204			250		
205			251		
206			252		
207			253		
208			254		
209			255		
210			256		
211			257		
212			258		
213			259		
214			260		
215			261		
216			262		
217			263		
218			264		
219			265		
220			266		
221			267		
222			268		
223			269		
224			270		
225			271		
226			272		
227			273		
228			274		
229			275		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
276			322		
277			323		
278			324		
279			325		
280			326		
281			327		
282			328		
283			329		
284			330		
285			331		
286			332		
287			333		
288			334		
289			335		
290			336		
291			337		
292			338		
293			339		
294			340		
295			341		
296			342		
297			343		
298			344		
299			345		
300			346		
301			347		
302			348		
303			349		
304			350		
305			351		
306			352		
307			353		
308			354		
309			355		
310			356		
311			357		
312			358		
313			359		
314			360		
315			361		
316			362		
317			363		
318			364		
319			365		
320			366		
321			367		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
368			414		
369			415		
370			416		
371			417		
372			418		
373			419		
374			420		
375			421		
376			422		
377			423		
378			424		
379			425		
380			426		
381			427		
382			428		
383			429		
384			430		
385			431		
386			432		
387			433		
388			434		
389			435		
390			436		
391			437		
392			438		
393			439		
394			440		
395			441		
396			442		
397			443		
398			444		
399			445		
400			446		
401			447		
402			448		
403			449		
404			450		
405			451		
406			452		
407			453		
408			454		
409			455		
410			456		
411			457		
412			458		
413			459		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
460			506		
461			507		
462			508		
463			509		
464			510		
465			511		
466			512		
467			513		
468			514		
469			515		
470			516		
471			517		
472			518		
473			519		
474			520		
475			521		
476			522		
477			523		
478			524		
479			525		
480			526		
481			527		
482			528		
483			529		
484			530		
485			531		
486			532		
487			533		
488			534		
489			535		
490			536		
491			537		
492			538		
493			539		
494			540		
495			541		
496			542		
497			543		
498			544		
499			545		
500			546		
501			547		
502			548		
503			549		
504			550		
505			551		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
552			598		
553			599		
554			600		
555			601		
556			602		
557			603		
558			604		
559			605		
560			606		
561			607		
562			608		
563			609		
564			610		
565			611		
566			612		
567			613		
568			614		
569			615		
570			616		
571			617		
572			618		
573			619		
574			620		
575			621		
576			622		
577			623		
578			624		
579			625		
580			626		
581			627		
582			628		
583			629		
584			630		
585			631		
586			632		
587			633		
588			634		
589			635		
590			636		
591			637		
592			638		
593			639		
594			640		
595			641		
596			642		
597			643		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
644			690		
645			691		
646			692		
647			693		
648			694		
649			695		
650			696		
651			697		
652			698		
653			699		
654			700		
655			701		
656			702		
657			703		
658			704		
659			705		
660			706		
661			707		
662			708		
663			709		
664			710		
665			711		
666			712		
667			713		
668			714		
669			715		
670			716		
671			717		
672			718		
673			719		
674			720		
675			721		
676			722		
677			723		
678			724		
679			725		
680			726		
681			727		
682			728		
683			729		
684			730		
385			731		
686			732		
687			733		
688			734		
689			735		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
736			782		
737			783		
738			784		
739			785		
740			786		
741			787		
742			788		
743			789		
744			790		
745			791		
746			792		
747			793		
748			794		
749			795		
750			796		
751			797		
752			798		
753			799		
754			800		
755			801		
756			802		
757			803		
758			804		
759			805		
760			806		
761			807		
762			808		
763			809		
764			810		
765			811		
766			812		
767			813		
768			814		
769			815		
770			816		
771			817		
772			818		
773			819		
774			820		
775			821		
776			822		
777			823		
778			824		
779			825		
780			826		
781			827		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
828			874		
829			875		
830			876		
831			877		
832			878		
833			879		
834			880		
835			881		
836			882		
837			883		
838			884		
839			885		
840			886		
841			887		
842			888		
843			889		
844			890		
845			891		
846			892		
847			893		
848			894		
849			895		
850			896		
851			897		
852			898		
853			899		
854			900		
855			901		
856			902		
857			903		
858			904		
859			905		
860			906		
861			907		
862			908		
863			909		
864			910		
865			911		
866			912		
867			913		
868			914		
869			915		
870			916		
871			917		
872			918		
873			919		

Speed dial no.	Name	Phone no.	Speed dial no.	Name	Phone no.
920			966		
921			967		
922			968		
923			969		
924			970		
925			971		
926			972		
927			973		
928			974		
929			975		
930			976		
931			977		
932			978		
933			979		
934			980		
935			981		
936			982		
937			983		
938			984		
939			985		
940			986		
941			987		
942			988		
943			989		
944			990		
945			991		
946			992		
947			993		
948			994		
949			995		
950			996		
951			997		
952			998		
953			999		
954					
955					
956					
957					
958					
959					
960					
961					
962					
963 964					
965					

## Quick Dialling

Name	Quick dial no.		

### Station Speed Dialling

No.	Name	Phone no.	No.	Name	Phone no.
0			5		
1			6		
2			7		
3			8		
4			9		

Note: Please make photo copies of this sheet if necessary.

### 5.4 What is This Tone?

# While on-hook Ring Tones

#### Tone 1

- Incoming call from an extension
- An intercom call is held for more than a specified time (default: 60 seconds).



- Incoming call from an external party
- An outside call is held for more than a specified time (default: 60 seconds).


### Tone 3


- Incoming call from a doorphone
- The pre-set alarm time has arrived.

### Tone 4

- A reserved outside line or extension became idle.
- A caller is leaving a message in your mailbox (Live Call Screening-Private mode).









# When going off-hook Dial Tones

### Tone 1

Normal (The features stated in Tone 2 through 4 are not set.)



### Tone 2

The following features are set.

- Alarm
- · Forwarding Calls
- · Call Waiting
- Calling a pre-set party by going off-hook
- Turning on the background music
- Showing a message to the caller
- Denying
  - an indication tone
  - an incoming call
- Denying other people the possibility of
  - picking up your calls
  - using your telephone
  - joining your call
  - making a paging announcement through your PT

#### Tone 3

- The alarm is being answered.
- Enter an account code to turn off the tone.

### Tone 4

A call waiting indication was received.






### $\Leftrightarrow$

### When you make calls


### **Busy Tone**



### Reorder Tone

- The outside line you tried to seize is not assigned or denied.
- The wrong account code was entered.

### Ringback Tone



### Do Not Disturb Tone

The dialled extension is denying incoming calls.




## While off-hooking

### **Indication Tones**


### Tone 1

Call waiting tone (default)




### Tone 2

Call waiting tone from another intercom




### Tone 3

Call waiting tone from CO



### Tone 4

A call is held for more than a specified time (default: 60 seconds).




### 40

### When taking to an external party

### Warning Tone

This tone is sent 15, 10 and 5 seconds before the time limit.




### When setting the features or programming

### **Confirmation Tones**


#### Tone 1

- Set / cancel to deny other people the possibility of using your phone.
- The new setting differs from the previous setting by station / user programming.
- · Changing the setting by station / user programming was completed successfully.



### Tone 2


- The feature setting was completed successfully.
- Before paging through an external speaker
- The new setting is same as the previous setting by station / user programming.



#### Tone 3


Before performing the following features:

- · Retrieving a held call
- Picking up another call
- · Paging / Answering a paged annoucement
- Answering the call through a speaker



### Tone 4

Establishing or leaving a threeparty conversation



# 5.5 Specifications

### General Description

Item	Description		
System Capacity	CO lines Stations	192 max. 448 max.	
Power Supplies	Primary Secondary Power Failure	<ul> <li>220-240 VAC, 50 / 60 Hz</li> <li>Station Supply Volt: 30V</li> <li>Circuit Volt: ±5V, ±15V</li> <li>Memory backup duration: seven years with a factory-provided lithium battery</li> <li>Power Failure Transfer function is provided.</li> <li>System operation for about four hours using recommended batteries (consisting of two 12 VDC 40 Ah Automobile type batteries)</li> </ul>	
Dialling	Outward / Internal  Mode Conversion	Dial Pulse (DP) 10 pps, 20 pps, Tone (DTMF) Dialling DP-DTMF, DTMF-DP	
Connector	LCO lines ISDN lines Stations Paging Output External Music Input	Amphenol Connector Modular Jack (RJ45) Amphenol Connector Pin Jack (RCA JACK) Two-conductors Jack (MINIJACK 3.5 mm 9 / 64 inch diameter)	
SMDR (Station Message Detail Recording)	Interface Output Equipment Detail Recording	Serial Interface (RS-232C)(D-SUB, 25-pin) Printer / Personal Computer Date, Time, Extension Number, Outside Line Number, Dialled Number, Ring Duration, Call Duration, Account Code, Caller ID, Timed Reminder	

### **Characteristics**

Item	Description	
Maximum Number of Station Instruments per Line	1 or 2 by Parallel or eXtra Device Port Connection of a Proprietary Telephone and a Single Line telephone	
Ring Voltage	75 Vrms at 25 Hz depending on the ringing load	
Environmental Requirements	0 - 40 ° C, 10 - 90% relative humidity	

# Section 6 Index

A	Connected Line Identification Restriction
Absent Message Capability 80, 112	[COLR] 104
Absent Messages Set (008) 204	Customising the Buttons 182, 208, 209, 210
Account Code Entry 41	Customising Your System (User
Alternate Calling — Ring / Voice 45	Programming 187
Automatic Callback Busy 34, 112, 211	ů ů
Automatic Hold-All Calls 72 Automatic Redial 32	D
Automatic Redial 32 Automatic Route Selection 2, 24	Data Line Security 108, 112, 210
Automatio Rodic Gelection 2, 24	Date and Time Set (000) 196, 210
В	Dial Tones 230
	Direct Inward System Access [DISA] 46
Background Music (BGM) 107, 112 Background Music [BGM] - External 165,	Directory 216
210	DISA message 166
Bilingual Display Selection 180, 181	Display 17, 189
Busy Station Signalling [BSS] 36, 210	Display Proprietary Telephone 126
Busy Tone 231	Do Not Disturb (DND) 161 Do Not Disturb (DND) Override 44, 98
Button Code 201	Do Not Disturb (DND) Override 44, 98 Do Not Disturb [DND] 97, 112
_	Do Not Disturb Tone 232
C	Door Opener 114
Call Forwarding 74, 112, 163	Doorphone 114
Call Forwarding Busy (CFB) 78	
Call Forwarding by ISDN Provider 78	E
Call Forwarding No Reply (CFNR) 78	Easy Dialling 25, 209
Call Forwarding Unconditional (CFU) 78	Electronic Station Lockout 83, 208, 209
Call Forwarding – ALL Calls 74	Emergency call 24
Call Forwarding – Busy 74 Call Forwarding – Busy / No Answer (BSY N/	End-to-End DTMF Signalling 72
A) 74	Error Indications List 174
Call Forwarding – Follow Me (From) 74	Exclusive Call Hold 58
Call Forwarding – No Answer 74	Executive Busy Override 10, 108
Call Forwarding – To Outside Line (CO	Executive Busy Override Deny 40, 106, 112
Line) 74	Extension 216
Call Log 129	Extension Dialling 133, 134, 136, 138
Call Log Incoming, Log Lock 131	Extension Group 85
Call Park 57, 59 Call Pickup 51	Extension Name Set (004) 199
Call Pickup Deny 52, 105, 112	Extension Number 190
Call Splitting 61	External Feature Access 117
Call Waiting 36, 65, 99, 112, 210	External Modem Control 148 Extra Device Port (XDP) 13
Call Waiting Tone Type Assignment 181	Extra Device Port (XDP) 13
Call Waiting Tone Type Selection 180	F
Caller ID Dial Set (006) 202	-
Caller ID feature 48	Feature Numbers 16, 208
Caller ID Name Set (007) 203 Calling / Connected Line Identification Presen-	Feature Numbers List 212 Features 141
tation [CLIP / COLP] 102	Fixed Feature Numbers 16, 215
Calling an external party 23	Flexible CO Button Assignment (005) 200
Calling another extension 22	Flexible Feature Numbers 16, 212
Calling Line Identification Restriction	Full One-Touch Dialling Assignment 180,
[CLIR] 103	181
Calling without Restrictions 41, 209	Function Line 189
Character Entry 194	••
Charge Fee Management 186 Conference 67	Н
Confirmation Tones 233	Handset / Headset Selection 180, 181

Handset Mute 70 Hands-free Answerback 50 Hands-free operation 24, 48 Holding a Call (regular) 56 Host PBX 117, 209  I Icon Descriptions 18, 191 Incoming Call Log 112, 126 Incoming Call Log Lock 130 Incoming Call Log Lock Control 164 Indication Tones 232 Initial Display Selection 180, 181 Initial Settings 179, 208 Intercom Alert Assignment 180, 181 Intercom Call 22 ISDN Network Service Access 150	Paging 87 Paging – All 87 Paging – External 87 Paging – Group 87 Paging — Deny 101, 112 Parallelled Telephone Connection 13, 111, 112, 208 PDN Call 22, 63 Phantom extension 31 Pickup Dialling 28, 112 Power Supplies 234 Preferred Line Assignment – Incoming 180 Preferred Line Assignment – Outgoing 179 Preferred Line Preference – Incoming 181 Preferred Line Preference – Outgoing 181 Privacy Release 69
J	Programmable Button 182, 183 Pulse to Tone Conversion 44, 209
Jog Dial 20	Q
L Last Number Redial 32 Live Call Screen Mode Set 181 Live Call Screening [LCS] 120 Live Call Screening Mode Set 180 Live Call Screening Password Control 164 Local Alarm Indication 173 Log-In / Log-Out 85, 112  M Message Line 189 Message Waiting 37, 112 Microphone Mute 70 Multiple-Line Display 189 Mute 70, 209	Quick Dial Number Set (009) 205 Quick Dialling 30, 229  Redial 32, 209 Released Link Operation 64 Remote DND Control 161 Remote FWD Cancel-Once 163 Remote Resource 64 Remote Station Lock Control 84, 164 Remote Timed Reminder 158 Reorder Tone 231 Restrictions 17 Ring Tones 230 Ringback Tone 232 Ringing Transfer 63
N Night Service 110, 154	Saved Number Redial 32
Off-Hook Call Announcement (OHCA) 36, 65, 112 Off-Hook Call Announcement [OHCA] 99, 210 Off-Hook Monitor 71 One-Touch Dialling 25 One-Touch Transfer 64 Operator / Manager Operation 157 Operator Call 23 Outgoing Call Log 134, 138 Outgoing Messages 166 Overlay / Button Function 188	Self-Extension Number Confirmation Specifications 234 Station Message Detail Recording 2, 234 Station Programme Clear 112, 208 Station Programming 164, 178, 186, 208, 209, 210 Station Programming Data Default Set 181 Station Speed Dialling 25, 133, 134, 136, 138, 229 System Capacity 234 System Feature Access 133, 134, 136, 138 System Speed Dialling 26, 133, 134, 136, 138, 218 System Speed Dialling Name Set (002) 198

System Speed Dialling Number Set (001)197 Т Three-party Conversation 67, 209 Time Limit 68 Timed Reminder 94, 112 Timed Reminder (Wake-up) message 166 Tone Through 72 Tones 16 Transferring a Call Trunk Answer From Any Station [TAFAS] 53 Trunk Busy-out Setting 169 Trunk Route Control 172 Two-Way Recording 124 U UCD (Uniform Call Distribution) message 166 UCD Group 64 **UCD Monitor Mode Unattended Conference** 67 User Password 187 Using the KX-T7235 137 Using the KX-T7433 132 Using the KX-T7436 133 V Voice Mail Transfer 118 Voice Processing System 118 **VPS Integration** 3 VPS integration 118

### W

Walking COS 42
Walking Station 112, 125, 178
Warning Tone 232
Whisper OHCA 36, 65, 99, 112, 210

### Please cut out these cards and distribute to the single line telephone users.

#### **Quick Reference Card**

#### To Make Calls

- Intercom: Ext. no.
- Operator: 0
- External Party: ( 9 or 801-848 ) + Phone no.
- Station Speed Dialling: 3 + No. 0-9
- System Speed Dialling: X + No. 000-999
- Doorphone: 3 1 + No. 1-8

### When a Line is Busy

- Reserving a busy line: 6
- Sending a call waiting tone: 1
- Redialling the last dialled number: #

### To Pick Up Someone's Call

- Outside Call: 4 ×
- Specified Extension: 4 1 + Ext. no.
- Extension Group: 4 0

### **During a Conversation**

- Holding: + 50 +
- Retrieving: + 50
- Transferring: + Dial no.
- Answering Call Waiting: + 50 + + +

#### **Quick Reference Card**

#### To Make Calls

- Intercom: Ext. no.
- Operator: 0
- External Party: ( 9 or 801-848 ) + Phone no.
- Station Speed Dialling: 3 + No. 0-9
- System Speed Dialling: X + No. 000-999
- Doorphone: 3 1 + No. 1-8

### When a Line is Busy

- Reserving a busy line: 6
- Sending a call waiting tone: 1
- Redialling the last dialled number: #

### To Pick Up Someone's Call

- Specified Extension: 4 1 + Ext. no.
- Extension Group: 4 0

### **During a Conversation**

**Quick Reference Card** 

• External Party: ( 9 or 801-848 ) + Phone no. • Station Speed Dialling: 3 + No. 0-9

• System Speed Dialling: 🔀 + No. 000-999

To Make Calls

- Holding: + 50 +
- Retrieving: + 50
- Transferring: 4 Dial no.
- Answering Call Waiting: 🕌 + 50 + 📦 + 🥌

• Intercom: Ext. no.

• Operator: 0

### **Quick Reference Card**

### To Make Calls

- Intercom: Ext. no.
- Operator: 0
- External Party: ( 9 or 801-848 ) + Phone no.
- Station Speed Dialling: 3 🔀 + No. 0-9
- System Speed Dialling: X + No. 000-999
- Doorphone: 3 1 + No. 1-8

### When a Line is Busy

- Reserving a busy line: 6
- Sending a call waiting tone: 1
- Redialling the last dialled number: #

### When a Line is Busy

- Reserving a busy line: 6
  - Sending a call waiting tone: 1

• Doorphone: 3 1 + No. 1-8

Redialling the last dialled number: #

### To Pick Up Someone's Call

- Outside Call: 4 ×
- Specified Extension: 4 1 + Ext. no.
- Extension Group: 4 0

### **During a Conversation**

- Holding: 4 5 0 + 5
- Retrieving: + 50
- Transferring: + Dial no.



### To Pick Up Someone's Call

- Outside Call: 4 ★
- Specified Extension: 4 1 + Ext. no.
- Extension Group: 4 0

### **During a Conversation**

- Holding: 4 5 0 +
- Retrieving: + 50
- Transferring: + Dial no.
- Answering Call Waiting: + 50 + +





## Please cut out these cards and distribute to the single line telephone users.

### **Locking / Unlocking Your Phone**

- Lock: 7 6 2 + 3-digit desired code + same code
- Unlock: 7 6 2 + Stored code

### **Settings**

- Storing the number for Station Speed Dialling:
  - 3 0 + No. 0-9 + Line no. 9 or 801-848 + Phone no. + #
- Call Waiting:
  - Set: 7 3 1 1
  - Cancel: 7 3 1 0

### Frequently Used Features at Your Extension

### **Locking / Unlocking Your Phone**

- Lock: 7 6 2 + 3-digit desired code + same code
- Unlock: 7 6 2 + Stored code

#### **Settings**

- Storing the number for Station Speed Dialling:
- 3 0 + No. 0-9 + Line no. 9 or 801-848 + Phone no. + #
- Call Waiting:
  - Set: 7 3 1 1
  - Cancel: 7 3 1 0

### **Frequently Used Features at Your Extension**

### **Locking / Unlocking Your Phone**

- Lock: 7 6 2 + 3-digit desired code + same code
- Unlock: 7 6 2 + Stored code

#### Settings

- Storing the number for Station Speed Dialling:
- 3 0 + No. 0-9 + Line no. 9 or 801-848 + Phone no. + #
- Call Waiting:
  - Set: 7 3 1 1
  - Cancel: 7 3 1 0

### Frequently Used Features at Your Extension

### Locking / Unlocking Your Phone

- Lock: 7 6 2 + 3-digit desired code + same code
- Unlock: 7 6 2 + Stored code

#### Settings

- Storing the number for Station Speed Dialling:
- 3 0 + No. 0-9 + Line no. 9 or 801-848 + Phone no. + #
- Call Waiting:
  - Set: 7 3 1 1
  - Cancel: 7 3 1 0

### Frequently Used Features at Your Extension

This PBX fulfills the requirements of following European regulations:



73/23/EEC "Low Voltage Directive"

89/336/EEC "Electromagnetic compatibility" (Basic EMC Publication)
92/31/EEC "Electromagnetic compatibility" (Supplement)

93/68/EEC "CE mark"

For above mentioned standards the unit is signed with the CE-mark.

### Copyright:

This manual is copyrighted by Kyushu Matsushita Electric Co., Ltd. (KME). You may print out this manual solely for internal use with TD500. Except above, you may not reproduce this manual in any form, in whole or part, without the prior written consent of KME.

© Kyushu Matsushita Electric Co., Ltd. 2000

### Kyushu Matsushita Electric Co., Ltd.

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan