2600-0057POGAA Ver. 5.1

SCM Express

Installation Manual





COPYRIGHT

This manual is proprietary to SAMSUNG Electronics Co., Ltd. and is protected by copyright. No information contained herein may be copied, translated, transcribed or duplicated for any commercial purposes or disclosed to the third party in any form without the prior written consent of SAMSUNG Electronics Co., Ltd.

TRADEMARKS

Product names mentioned in this manual may be trademarks and/or registered trademarks of their respective companies.

This manual should be read and used as a guideline for properly installing and operating the product.

All reasonable care has been made to ensure that this document is accurate. If you have any comments on this manual, please contact our documentation centre at the following address:

Address: Document & Training Center 3rd Floor Jeong-bo-tong-sin-dong. 129, Samsung-ro, Yeongtong-gu, Suwonsi, Gyeonggi-do, Korea 443-742

Homepage: http://www.samsungdocs.com

©2010~2013 SAMSUNG Electronics Co., Ltd. All rights reserved.

INTRODUCTION

Purpose

This manual describes how to install and configure the Samsung Communication Manager (SCM).

Document Content and Organization

This document consists of 7 Chapters and an Abbreviation as follows.

CHAPTER 1. Pre-Installation

Describes how to prepare the environment.

CHAPTER 2. Network Design Guide

Describes how to design the IP network.

CHAPTER 3. License Guide Describes how to configure license.

CHAPTER 4. Installing SCM Server Describes how to install the SCM server.

CHAPTER 5. Installing Ubigate iBG Series Gateway

Describes how to install Ubigate iBG Series gateways.

CHAPTER 6. Installing OfficeServ 7000 Series Gateways

Describes how to install OfficeServ 7000 Series gateways.

CHAPTER 7. Installing SIP Phones

Describes how to install the SIP telephones.

ABBREVIATION

Provides the definitions of the abbreviations used in this manual.

Conventions

The following types of paragraphs contain special information that must be carefully read and thoroughly understood. Such information may or may not be enclosed in a rectangular box, separating it from the main text, but is always preceded by an icon and/or a bold title.



WARNING

Provides information or instructions that the reader should follow in order to avoid personal injury or fatality.



CAUTION

Provides information or instructions that the reader should follow in order to avoid a service failure or damage to the system.



NOTE

Indicates additional information as a reference.

Console Screen Output

- The lined box with 'Courier New' font will be used to distinguish between the main content and console output screen text.
- **'Bold Courier New'** font will indicate the value entered by the operator on the console screen.

Revision History

VERSION	DATE OF ISSUE	REMARKS
5.1	09. 2013.	Updated for modification of the SCM version 4.1
5.0	06. 2013.	Updated for modification of the SCM version 4.0
4.0	01. 2013.	Updated for modification of the SCM version 3.3.
3.0	11. 2011.	 Updated for modification of the SCM version 3.2.2.x. * Manual Edition allocation method is changed. (Ed.02 → Ver.3.0)
01	07. 2010.	 Add installing Server hardware, Gateway and Phones. Modified hardware requirements, basic accounts information, database setting subjects.
00	04. 2010.	First Version

SAFETY CONCERNS

The purpose of the Safety Concerns section is to ensure the safety of users and prevent property damage. Please read this document carefully for proper use.

Symbols



Indication of a general caution



Restriction Indication for prohibiting an action for a product



Instruction

Caution

Indication for commanding a specifically required action



HIGH LEAKAGE CURRENT!

Earth connection is essential before connecting power supply.



Unplug the power cord from the AC outlet before attempting to connect the ground. Hazardous voltage may cause death or injury. Observe with extreme caution when working with AC power. Remove lines from trunk cards.





All the data stored in the HDD will be deleted when installing the SCM software.



All the existing data will be deleted when initializing the database.



When assigning IP addresses to configure the system, their subnet addresses should be set carefully.

- For the data link IP addresses (eth0, eth1), their subnet addresses must be identical.
- For the data link IP addresses of the active and standby systems, their subnet addresses must be also identical.
- For the system IP addresses of the active and standby systems, their subnet addresses must be identical.
- For the heartbeat IP addresses of the active and standby systems, their subnet addresses must be identical.
- For the data link IP address, system IP address, and heartbeat IP address, their subnet addresses must be different from each other.



When updating the SCM software, all the services of the SCM stop.

When the upgrade is complete, the SCM restarts automatically.

TABLE OF CONTENTS

INTRO	DUCTI	ON	3
	Purpo)SE	3
	Docur	ment Content and Organization	3
	Conve	entions	4
	Conso	ole Screen Output	4
	Revisi	ion History	5
SAFET	Y CON	ICERNS	6
	Symb	ols	6
	WAR	NING	7
	CAUT	TION	7
СНАРТ	'ER 1.	Pre-Installation	14
1.1	Site F	Requirements	14
	1.1.1	Safety Conditions	14
	1.1.2	Environmental Conditions	15
1.2	Grou	nding Conditions	
1.3	Powe	r Conditions	20
	1.3.1	SCM Server	20
	1.3.2	Gateway	21
1.4	UPS	Considerations	22
1.5	Netwo	ork Requirements	23
	1.5.1	Single Site Example	23
	1.5.2	Headquarters and Branch Example	26
	1.5.3	Network Considerations	29
СНАРТ	ER 2.	Network Design Guide	31
2.1	Overv	view	31
2.2	IP Net	twork Considerations	34
	2.2.1	Local Access Network (LAN)	34
	2.2.2	Virtual Local Access Network (VLAN)	34

	2.2.3	Speed and Duplex Setup	35
	2.2.4	Spanning Tree-Related Setup	35
2.3	QoS (Quality of Service)	36
	2.3.1	What Is QoS?	36
	2.3.2	Basic Elements of QoS	36
	2.3.3	Applying the QoS Settings	37
2.4	IP Ap	plications	39
	2.4.1	Domain Name System (DNS)	39
	2.4.2	Trivial File Transfer Protocol (TFTP)	39
	2.4.3	Network Time Protocol (NTP)	39
	2.4.4	Dynamic Host Configuration Protocol (DHCP)	40
2.5	Secur	rity (& Firewall)	42
2.6	IPT S	ervice Deployment Guide	47
	2.6.1	Workgroup Switch	47
	2.6.2	Core Switch	54
	2.6.3	DHCP Server	61
	2.6.4	Security device	67
	2.6.5	WAN Router	72
2.7			- 4
	IPT R	equirements and Measurement	
2.8	IPT R	equirements and Measurement	74
2.8	IPT R IPT S 2.8.1	equirements and Measurement ervice Deployment Example German Samsung Corporation	74 76 76

CHAPTER 3. License Guide

77

3.1	Licens	se Key Туре	.77
	3.1.1	Users	.77
	3.1.2	Embedded Application	.77
	3.1.3	External Application	.77
	3.1.4	Wireless Enterprise	.77
3.2	Licens	se Policy	.78
	3.2.1	Evaluation Period	.78
	3.2.2	Active-Active Validation	.78
	3.2.3	License Status Notification	.78

CHAPTER 4. Installing SCM Server

79

4.1	SCM	Server Hardware	79
	4.1.1	Preparing the SCM Hardware	79
	4.1.2	Unpacking and Inspection	79
	4.1.3	Preparing Peripherals	79

	4.1.4	Cabinet Mounting	80
	4.1.5	Connecting to Network	96
4.2	SCM	Server Software	
	4.2.1	Preparing the SCM Software	98
	4.2.2	SCM Software Installation Procedure	
4.3	Config	guring Stand Alone Server	
	4.3.1	Server Basic Configuration	101
	4.3.2	SCM Software Configuration	105
4.4	Config	guring High Availability Service	
	4.4.1	Server Basic Configuration	112
	4.4.2	SCM Software Configuration	116
	4.4.3	Configuring HA-Active Server	118
	4.4.4	Configuring HA-Standby Server	123
4.5	Updat	ting SCM Server Software	
	4.5.1	Updating Stand Alone System	128
	4.5.2	Updating High Availability System	132
CHAPT	ER 5.	Installing Ubigate iBG Series Gateways	136
5.1	Prepa	ring SCM Server	136
5.1 5.2	Prepa Ubiga	ring SCM Server	136 139
5.1 5.2 5.3	Prepa Ubiga Ubiga	ring SCM Server te iBG series Hardware te iBG series Software	136 139 140
5.1 5.2 5.3	Prepa Ubiga Ubiga 5.3.1	ring SCM Server Ite iBG series Hardware Ite iBG series Software Configuring Gateway System	
5.1 5.2 5.3	Prepa Ubiga Ubiga 5.3.1 5.3.2	ring SCM Server Ite iBG series Hardware Ite iBG series Software Configuring Gateway System Connecting to Network	
5.1 5.2 5.3	Prepa Ubiga 5.3.1 5.3.2 5.3.3	te iBG series Hardware te iBG series Software Configuring Gateway System Connecting to Network Connecting to PSTN	136 139 140 140 142 142
5.1 5.2 5.3	Prepa Ubiga Ubiga 5.3.1 5.3.2 5.3.3 5.3.4	Iring SCM Server Ite iBG series Hardware Ite iBG series Software Configuring Gateway System Connecting to Network Connecting to PSTN Connecting to SCM Server	136 139 140 140 142 145 156
5.1 5.2 5.3	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5	Iring SCM Server Ite iBG series Hardware Ite iBG series Software Configuring Gateway System Connecting to Network Connecting to PSTN Connecting to PSTN Updating Gateway Software	136 139 140 140 142 145 156 158
5.1 5.2 5.3	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5	Iring SCM Server	136 139 140 140 142 145 156 158
5.1 5.2 5.3 CHAPT	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5 ER 6.	Installing OfficeServ 7000 Series Gateway	136 139 140 140 142 145 156 158 159
5.1 5.2 5.3 CHAPT 6.1	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5 ER 6. Prepa	Intering SCM Server Intering Series Hardware Intering Series Software Configuring Gateway System Connecting to Network Connecting to PSTN Connecting to SCM Server Updating Gateway Software Installing OfficeServ 7000 Series Gateway aring SCM Server	136 139 140 140 142 145 156 158 158 159
5.1 5.2 5.3 CHAPT 6.1 6.2	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5 ER 6. Prepa Office	Installing OfficeServ 7000 Series Gateway	136 139 140 140 142 145 145 156 158 159 159
5.1 5.2 5.3 CHAPT 6.1 6.2 6.3	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5 ER 6. Prepa Office	Installing OfficeServ 7000 Series Gateway Installing SCM Server	136
5.1 5.2 5.3 CHAPT 6.1 6.2 6.3	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5 ER 6. Prepa Office 6.3.1	Inite iBG series Hardware Ite iBG series Software Configuring Gateway System Connecting to Network Connecting to PSTN Connecting to SCM Server Updating Gateway Software Installing OfficeServ 7000 Series Gateway eserv 7000 series Hardware Serv 7000 series Software Configuring Gateway System	136 139 140 140 142 145 156 158 159 159 159 159 160 160
5.1 5.2 5.3 CHAPT 6.1 6.2 6.3	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5 ER 6. Prepa Office 6.3.1 6.3.2	Inite iBG series Hardware Ite iBG series Software Configuring Gateway System Connecting to Network Connecting to PSTN Connecting to SCM Server Updating Gateway Software Installing OfficeServ 7000 Series Gateway aring SCM Server eServ 7000 series Hardware Configuring Gateway System Configuring Gateway System Configuring Gateway System	136 139 140 140 142 142 145 156 158 159 159 159 160 160
5.1 5.2 5.3 CHAPT 6.1 6.2 6.3	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5 ER 6. Prepa Office 6.3.1 6.3.2 6.3.3	aring SCM Server	136 139 140 140 142 142 145 156 158 159 159 159 160 160 160 161
5.1 5.2 5.3 CHAPT 6.1 6.2 6.3	Prepa Ubiga 5.3.1 5.3.2 5.3.3 5.3.4 5.3.5 ER 6. Prepa Office 6.3.1 6.3.2 6.3.3 6.3.4	arring SCM Server arte iBG series Hardware configuring Gateway System Connecting to Network Connecting to PSTN Connecting to SCM Server Updating Gateway Software Installing OfficeServ 7000 Series Gateway arring SCM Server eServ 7000 series Hardware Configuring Gateway System Connecting to Network configuring Gateway System configuring Gateway System Connecting to Network connecting to Network connecting to Network connecting to Network connecting to PSTN Connecting to Network Connecting to PSTN Connecting to SCM Server	136 139 140 140 142 145 156 158 159 159 159 160 160 160 161 163

CHAPTER 7.		. Installing SIP Phones	
7.1	Conne	ecting SIP Phones	166
	7.1.1	Safety Precautions	
	7.1.2	Wall-Mounting SMT-i5200 Keysets	
	7.1.3	Wall-Mounting SMT-i3100/3105 Keysets	
	7.1.4	SMT-i5264 Add On Module	171
	7.1.5	Connecting the SMT-A52GE Gigabit Adaptor	172
7.2	Conne	ecting to Network	173
	7.2.1	How to connect to a phone	173
7.3	Conne	ecting to SCM Server	176
	7.3.1	Configuration Type	
	7.3.2	Easy Installation of SMT-i3100/3105/5210/5210S/5220/5230	
	7.3.3	Easy Installation of SMT-5243	
	7.3.4	Easy Installation of SMT-5343	
7.4	Upgra	ading SIP Phone Software	189

ABBREVIATION

LIST OF FIGURES

Figure 1. Configuration for a Stand Alone of SCM Express	23
Figure 2. Configuration for Active-Standby of SCM Express	25
Figure 3. Configuration for Active-Active of SCM Express	25
Figure 4. Configuration for Headquarter and branch	
Figure 5. Configuration for Headquarter and multiple branches	27
Figure 6. Configuration for Headquarter and multiple branches (Active-Active)	
Figure 7. IPT Network Infrastructure	
Figure 8. DHCP Request for an IP Address from a DHCP Server	
Figure 9. HQ-BO Network Diagram	
Figure 10. HQ-BO VPN Tunnel Configuration Example	43
Figure 11. HQ-BO VPN Configuration Type	
Figure 12. ALG Configuration Example	
Figure 13. DHCP Deployment Configured with Voice and Data VLANs	61
Figure 14. Test Network Architecture	74
Figure 15. Ping Plotter Test Results	75
Figure 16. Identifying the Static Rail Kit Contents	80
Figure 17. Configuring Flush-Mount Static Rails (Two- or Four-Post)	81
Figure 18. Installing Flush-Mount or Center-Mount Static Rails (Two-Post)	82
Figure 19. Configuring Four-Post Threaded Static Rails	83
Figure 20. Installing and Removing Four-Post Threaded Static Rails	84
Figure 21. Installing and Removing Chassis Rail Members	85
Figure 22. Installing, Removing, Cabling, and Securing the System in the Rack	
Figure 23. Identifying the Rail Kit Contents	87
Figure 24. Installing and Removing the Rails (round-hole racks)	
Figure 25. Installing the System in the Rack	91
Figure 26. Removing the System from the Rack	92
Figure 27. Installing the CMA Attachment Brackets	94
Figure 28. Routing the Cables	95

LIST OF TABLES

Table 1. Environmental conditions for SCM server (Dell R210)	15
Table 2. Environmental conditions for SCM server (Dell R210-II)	16
Table 3. Environmental conditions for SCM server (Dell R410I)	16
Table 4. Environmental conditions for Gateways	17
Table 5. Power conditions for Gateways	21
Table 6. Port List for Management and Provisioning	29

Table 7. Port List for Telephony services	30
Table 8. Traffic Types, Packet Labels, and Queues	50
Table 9. Auto-QoS Configuration for the Ingress Queues	50
Table 10. Auto-QoS Configuration for the Egress Queues	50
Table 11. Generated Auto-QoS Configuration	51
Table 12. Firewall Configurations for the Headquarters	67
Table 13. Firewall Configurations for Branch Offices	68
Table 14. Minimum hardware requirements for SCM server	79
Table 15. Minimum peripherals for SCM server	80
Table 16. Creating Gateway Link	137
Table 17. Supplementary Service on Survival mode	138
Table 18. Voice Port Capacity of iBG series	139
Table 19. Voice Port Capacity of OfficeServ 7000 series	159

CHAPTER 1. Pre-Installation

1.1 Site Requirements

Select a location that satisfies the following conditions for safety, temperature, humidity, power and grounding.

1.1.1 Safety Conditions

- The SCM Express Servers and Gateways should not be installed near materials that can cause a fire, such as explosive gas and inflammables. The SCM Express Servers and Gateways should not be near equipment that generates electromagnetic waves, such as monitors or copying machines.
- The installation location should be convenient for distributing trunk lines and extension lines, for connecting power and grounding wires, and for maintenance and repair.
- The SCM Express Servers and Gateways should not be installed in aisles or passageways that are populated or used for moving equipment.
- Always maintain cleanliness to prevent dust from damaging the board connectors of the cabinet.
- Before installing the SCM Express Servers and Gateways, check items such as the electrical wiring status, grounding status, voltage and frequency.
- Do not expose equipment to direct sunlight, corrosive fumes, and constant vibrations.
- Do not install in close proximity to a fire sprinkler or other sources of water.
- A dedicated commercial AC power outlet is required. Do not use extension cords.
- Ensure that all wires and cables to and from the SCM Express Servers and Gateways do not cross fluorescent lights or run in parallel with AC wires.
- This equipment is to be installed only in restricted access areas (dedicated, equipment closets, etc.) in accordance with articles 110-16, 110-17, 110-18 of the National Electric Code, ANSI/NFPA 70.

1.1.2 Environmental Conditions

The section describes conditions for temperature, humidity and others environmental conditions as follows:

1.1.2.1 SCM Server



This section referenced on the Dell's R210 environmental datasheets by Dell. For additional information about environmental measurements for specific system configurations, see www.dell.com.

Environment	Condition
Temperature	 Operating: 10 to 35°C (50 to 95°F) with a maximum temperature graduation of 10°C per hour Storage: -40 to 65°C (-40 to 149°F) with a maximum temperature gradation of 20°C per hour
Humidity	 Operating: 20 to 80 % (non condensing) with a maximum humidity gradation of 10 % per hour Storage: 5 to 95 % (non condensing)
Maximum vibration	- Operating: 0.26 Grms at 5-350 Hz for 15 min - Storage: 1.54 Grms at 10-250 Hz for 15 min
Maximum shock	 Operating: One shock pulse in the positive z axis (one pulse on each side of the system) of 31 G for 2.6ms in the operational orientation. Storage: Six consecutively executed shock pulse in the positive and negative x, y, and z axes (one pulse on each side of the system) of 71 G for up to 2 ms. Six consecutively executed shock pulses in the positive and negative x, y, and z axes (one pulse on each side of the system) of 32 G faired square wave pulse with velocity change at 270 inches/second (686 centimeters/second)
Altitude	- Operating: -16 to 3,048 m (-50 to 10,000 ft) - Storage: -16 to 10,600 m (-50 to 35,000 ft)
Airborne Contaminant Level	Class: G2 or lower as defined by ISA-S71.04-1985

Table 1. Environmental conditions for SCM server (Dell R210)

Environment	Condition
Temperature	 Operating: 10 to 35°C (50 to 95°F) with a maximum temperature graduation of 10°C per hour Storage: -40 to 65°C (-40 to 149°F) with a maximum temperature gradation of 20°C per hour
Humidity	 Operating: 20 to 80 % (non condensing) with a maximum humidity gradation of 10 % per hour Storage: 5 to 95 % (non condensing)
Maximum vibration	- Operating: 0.26 Grms at 5-350 Hz for 15min - Storage: 1.87 Grms at 10-250 Hz for 15min
Maximum shock	 Operating: One shock pulse in the positive z axis (one pulse on each side of the system) of 31 G for 2.6 ms in the operational orientation. Storage: Six consecutively executed shock pulses in the positive and negative x, y, and z axes (one pulse on each side of the system) of 71 G for up to 2 ms. Six consecutively executed shock pulses in the positive and negative x, y, and z axes (one pulse on each side of the system) of 32
Altitude	- Operating: -16 to 3,048 m (-50 to 10,000 ft) - Storage: -16 to 10,600 m (-50 to 35,000 ft)

Table 2. Environmental conditions for SCM server (D	Dell R210-II)
---	---------------

Table 3. Environmental conditions for SCM server (Dell R410I)

Environment	Condition
Temperature	 Operating: 10 to 35°C (50 to 95°F) with a maximum temperature gradation of 10°C per hour Note: For altitudes above 2950 feet, the maximum operating temperature is debated 1°F/550 ft. Storage: -40 to 65°C (-40 to 149°F) with a maximum temperature gradation of 20°C per hour
Humidity	 Operating: 20 to 80 % (noncondensing) with a maximum humidity gradation of 10 % per hour Storage: 5 to 95 % (noncondensing) with a maximum humidity gradation of 10 % per hour
Maximum vibration	- Operating: 0.26 Grms at 5-350 Hz in operational orientations - Storage: 1.54 Grms at 10-250 Hz in all orientations
Maximum shock	 Operating: Half sine shock in all operational orientations of 31 G +/- 5 % with a pulse duration of 2.6 ms +/-10 %. Storage: Half sine shock on all six sides of 71 G +/- 5 % with a pulse duration of 2 ms +/-10 % Square wave shock on all six sides of 27 G with velocity change @ 235 in/sec or greater
Altitude	- Operating: -16 to 3,048 m (-50 to 10,000 ft) - Storage: -16 to 10,600 m (-50 to 35,000 ft)

1.1.2.2 Gateways

Table 4. Environmental conditions for Gateways

Environment	OfficeServ 7400/7200/7100/7070	Ubigate iBG 3026/2016/2006/1003/1004
Operating temperature	32 to 113°F (0 to 45°C)	32 to 104°F (0 to 40°C)
Storage temperature	14 to 122°F (-10 to 50°C)	-13 to 158°F (-25 to 70°C)
Humidity	10 to 90 %	5 to 95 %, non-condensing

1.2 Grounding Conditions

An equipment grounding conductor that is not smaller in size than the ungrounded branchcircuit supply conductors is to be installed as part of the circuit that supplies the product or system. Bare, covered, or insulated grounding conductors are acceptable. Individually covered or insulated equipment grounding conductors shall have a continuous outer finish that is either green or green with one or more yellow stripes. The equipment grounding conductor is to be connected to ground at the service equipment.

The attachment-plug receptacles in the vicinity of the product or system are all to be of a grounding type, and the equipment grounding conductors serving these receptacles are to be connected to earth ground at the service equipment.



HIGH LEAKAGE CURRENT!

Earth connection is essential before connecting power supply.

The SCM Express Servers and Gateways require that a supplementary earth ground be connected to the system. This is the preferred method of grounding the SCM Express Servers and Gateways. It should be noted that when the third wire ground becomes inferior, it many prevent the digital data bus from canceling out noise. This may result in erratic operation of the SCM Express Servers and Gateways. Another problem that has occurred is that some UPS battery systems do not pass the ground through to the power cord resulting in no ground to the system. The ground lug in the back of the cabinet must be connected to one of the following: bonded building steel, cold water pipe, or a ground rod using at least #16 AWG copper wire. Additionally, the ground between cabinets in a multiple cabinet system must also be at least #16 AWG copper wire. The third wire AC ground or field ground is connected to the system frame via the ground strap from the ground connector on the AC socket.

A supplementary equipment grounding conductor shall be installed between the system and ground that is in addition to the equipment grounding conductor in the power supply cord. The supplementary equipment grounding conductor shall not be smaller in size than the ungrounded branch-circuit supply conductors. The supplementary equipment grounding conductor shall be connected to the product at the terminal provided, and shall be connected to ground in a manner that will retain the ground of the supplementary equipment grounding conductor shall be in compliance with the rules for terminating bonding jumpers in Part K of Article 250 of the National Electrical Code ANSI/NFPA 70. Termination of the supplementary equipment grounding conductor is permitted to be made to building steel, to a metal electrical raceway system, or to any grounded item that is permanently and reliably connected to the electrical service equipment ground.

Bare, covered, or insulated grounding conductors are acceptable. A covered or insulated grounding conductor shall have a continuous outer finish that is either green or green with one or more yellow stripes.

Failure to provide an adequate ground may cause a safety hazard, confusing trouble symptoms, or even circuit card failure.



Unplug the power cord from the AC outlet before attempting to connect the ground. Hazardous voltage may cause death or injury. Observe with extreme caution when working with AC power. Remove lines from trunk cards.

What the above paragraphs mean is that when conventional analog telephone circuits are connected to the SCM Express Servers and Gateways, under fault conditions (i.e. the tip and/or ring conductor is crossed with a power line, or the circuit is affected by lightning during a storm), it is possible for hazardous potentials to appear across the tip and ring wiring coming into the SCM Express Servers and Gateways from the outside plant (i.e. overhead cables, buried cables, cable head pedestal). These circuits are provided with both primary and secondary protection circuitry which will attempt to drain off these high voltages and currents to earth ground. Obviously, it is important to have a good source of ground connected to the SCM Express Servers and Gateways to drain this energy off. Again, a good earth ground source is required by the SCM Express Servers and Gateways. The SCM Express Servers and Gateways have two ground reference points. One point is via the green wire in the power cord connected to the AC power outlet. This ground connection is provided to meet local electrical codes when the AC ground is required to be common with the earth ground. However, this can be disconnected either intentionally or unintentionally. Consequently, a more permanent ground connection is required by connecting a high current/voltage capacity ground wire which is bonded to ground at the electric service power entrance or via some other method approved by the National Electrical Code to the SCM Express Servers and Gateways ground lug. This is a more secure ground connection, which can only be disconnected intentionally. These precautions are taken for safety reasons to protect personnel working on the SCM Express Servers and Gateways and also for operational reasons to accommodate ground return and/or groundreferenced analog telephone circuits, which require this solid earth ground connection for normal functioning.

1.3 Power Conditions

1.3.1 SCM Server

The rating is as follows:

Dell R210 model

- AC Cord Rating: 15Amps @ 120 V, 10 Amps @ 240 V
- Input Voltage: AC 90-26 4V
- Line Frequency: 40-63H z
- Output Power: 250 W
- BTU: 1039 Btu/hr maximum

Dell R210-II model

- AC Cord Rating: 15 Amps @ 120 VAC, 10 Amps @ 240 VAC
- Input Voltage: 90-264 VAC
- Line Frequency: 47-63 Hertz
- Output Power: 250 W
- BTU: 1039 Btu/hr maximum

Dell R410 model

- Maximum Input Amps Non-Redundant power supply: 7.5-3.8 A at 100-240 VAC, 50/60 Hz Redundant power supply: 7-3.5 A at 100-240 VAC, 50/60 Hz
- Output Power Non-Redundant power supply: 480 W Redundant power supply: 500 W
- BTU: 1039 Btu/hr maximum
 1706 BTU/hr maximum (redundant power supply)
 1637 BTU/hr maximum (non-redundant power supply)

1.3.2 Gateway

Table 5. Power conditions for Gateways

Gateway	Rating	Power Consumption (each PSU)
OfficeServ 7400	AC 100-240 V, 50/60 Hz or DC 48 V	580 W
OfficeServ 7200	AC 100~120 V, 50/60 Hz or DC 48 V (USA) AC 220~240 V, 50/60 Hz or DC 48 V (non USA)	210 W
OfficeServ 7100	AC 100-240 V, 50/60 Hz or DC 48 V	120 W
OfficeServ 7070	AC 220~240 V, 50/60 Hz or DC 48 V (non USA)	135 W
iBG3026	AC 100-240 V, 50/60 Hz or DC 48 V	275 W (w/o POE)
iBG2016	AC 100-240 V, 50/60 Hz or DC 48 V	180 W
iBG2006	AC 100-240 V, 50/60 Hz or DC 48 V	100 W
iBG1003	AC 100-240 V, 50/60 Hz or DC 48 V	72 W

1.4 UPS Considerations

We strictly recommend using uninterruptible power supply (UPS) to help protect your SCM Server (and Gateways) from sudden (transient) increases and decreases in electrical power.

Even a brief power outage could result in loss of unsaved data on a server/servers that was/were running. A UPS is an electronic device that continues to supply electricity for a certain period of time during a utility failure or when the line voltage varies outside the normal limits. UPS can be used for a server backup power and, large models can be used to feed entire machines in a room/building.

After the power gone, we recommend that a UPS keeps a server/servers alive for minimum 15 minutes. If it is important for a server/servers to survive hours without power, it should probably be a more robust power backup solution that includes a generator and other components.

If you get a UPS that's too big, then you've overpaid, but your equipment can survive a longer outage. If you get a UPS that's too small, your equipment might not be protected. Therefore, we recommend that you get advice from UPS vendors.

1.5 Network Requirements

We describe network requirements to provide general SCM services in network infrastructure examples shown in following figures.

Our examples may not cover all conditions and requirements which are requested by clients. However we provide representative cases to deploy a network environment which is appropriate for SCM VoIP services.

For more detail information, you can see 'CHAPTER 2. Network Design Guide.'

1.5.1 Single Site Example

Following figure shows an example of network configuration for a single site. There is a SCM Express server which is an active-alone mode. O7400 Gateway is directly connected to PSTN. If needs, it can be connected to PSTN via a Legacy PBX. We recommend the voice network to be separated from the data network. For security, NAT and Firewall is also recommended.



Figure 1. Configuration for a Stand Alone of SCM Express

Following figure shows an example of network configuration for an High Availability Service (Active-Standby) SCM Express. There two SCM servers where each SCM server is connected to both two switches. It is good to improve availability when one switch (network link) fails. OfficeServ 7400 Gateways can be duplicated too.



Figure 2. Configuration for Active-Standby of SCM Express

Following figure shows an example of network configuration for an High Availability Service (Active-Active) SCM Express.Two SCM servers set up a master node and a slave node. The master node using DB and Administrator can modify the information of the slave node. If one node of the two nodes is down or network is disconnected, Entire phones and gateways would be registered to other node and can continue to communicate.



Figure 3. Configuration for Active-Active of SCM Express

1.5.2 Headquarters and Branch Example

Following figure shows networks between a headquarters and a branch. The headquarters and the branch may have a dedicated link such as an E1 VPN or a MSPP tunnel.

The integrated Business Gateway (iBG) 2016 gateway in the branch may have a backup line which is connected to PSTN.

The backup line is optional and it is used when the iBG2016 gateway loses a connection with SCM Express at the headquarters.



Figure 4. Configuration for Headquarter and branch

Following figure, there are multiple branches. Each branch is recommended to use NAT and Firewall to improve security. If there is no network node which supports the function of NAT and Firewall, you can configure iBG Gateways to provide the function of NAT and Firewall as well as the function of routing. The gateways in branches may have a connection to Local PSTN alternatively.



Figure 5. Configuration for Headquarter and multiple branches

Following figure, there are multiple branches. The SCM server of Active/Standby structure is configured as the master node and slave node. To work as one single network, NAT and firewall installation between nodes is not recommended



Figure 6. Configuration for Headquarter and multiple branches (Active-Active)

1.5.3 Network Considerations

Network Condition

- Packet loss rate < 0.1 %
- Packet delay < 100 ms (average) Packet delay < 200 ms (maximum)
- Jitter < 40 ms (maximum)

VLAN

- Address space conservation and voice device protection from external networks: Private addressing of phones on the voice or auxiliary VLAN ensures address conservation and ensures that phones are not accessible directly via public networks. PCs and servers are typically addressed with publicly routed subnet addresses; however, voice endpoints should be addressed using RFC 1918 private subnet addresses.
- 2) Protection from malicious network attacks VLAN access control, 802.1Q, and 802.1p tagging can provide protection for voice devices from malicious internal and external network attacks such as worms, denial of service (DoS) attacks, and attempts by data devices to gain access to priority queues via packet tagging.
- Ease of management and configuration
 Separate VLANs for voice and data devices at the access layer provide ease of management and simplified QoS configuration

NAT/Firewall

A NAT and firewall are recommended to prevent unauthorized Internet users from accessing SCM Express in private networks.

SCM Express has an embedded solution to provide Media Proxy. However SCM Enterprise does NOT provide it. If you want, you can deploy an additional network infrastructure such as Session Border Controller (SBC).

To access SCM from the public Internet, you need to configure NAT traversal and open several port numbers at NAT/Firewall. The port number list is in following tables.

1			
Service	TCP Port	UDP Port	Description
General	20, 21	-	FTP Server
	22	-	Secure Shell
	23	-	Telnet
	80, 443	-	HTTP Web Server
	123	123	NTP
Provisioning	69	-	TFTP Server

Table 6. Port List for Management and Provisioning

Service	TCP Port	UDP Port	Description
	8088	-	Gateway Provisioning
	-	6000	Phone upgrade from Proprietary to SIP
NMS	-	161	SNMP Agent
Personal	8080, 9500	-	Personal Assistant for Call Service
Management	4002, 4003, 4004	-	Single Sign-On, PWP for UMS/Conference
System Management	20001, 20002, 20003, 20005, 20006	-	SCM Administrator
	5432	-	PostGRE DBMS connection

Table 7. Port List for Telephony services

Service	TCP Port	UDP Port	Description
Call	5060, 5061	5060	SIP signaling
UMS	5080, 8624	5080	Call signaling for UMS
	-	14002~14130	RTP path for UMS
	25, 143, 993	-	Signaling for E-mail Server
	3681, 3683, 2001, 22001	-	Signaling for Outlook client
	2200	-	UMS File Server
Conference	3333	5090, 5098	Call signaling for Conference
	-	44000~49998	RTP path for Conference
МОН	-	35000~35999	RTP path for MOH/Announcement
MPS	-	40000~40799	RTP path for MPS (Media Proxy Service)
Others	6000~6127	-	CSTA link for each user group
	9050, 9052	-	PMS link
	9090, 9092	-	Proprietary Application server link
	9000, 9002	-	Voice Monitoring server link
	9011	-	MVS client link
	18122	-	mySingle link
	10306, 10307, 2300	-	CDR (Call Data Record)

CHAPTER 2. Network Design Guide

2.1 Overview

This document describes the design considerations and requirements for network infrastructure required when deploying the IPT service in a typical IPT network infrastructure as shown in following figure.



Figure 7. IPT Network Infrastructure

The IPT service is extremely sensitive to **IP packet loss, packet delay, and jitter**. Therefore, to deploy the IPT service, a network topology to which all available QoS and redundancy technologies are applied and in which convergence can be provided quickly when a network failure occurs, must be used.

That is, the network technology that will be described in the next chapter must be applied to the network infrastructure.

2.2 IP Network Considerations

2.2.1 Local Access Network (LAN)

For the IPT service in the LAN environment, the following should be considered: Setting up equipment so that basic communications can be performed properly, separating physically or logically the IPT network from the normal data network, and giving priorities by applying QoS-related concepts to the service.

The most common way to configure a logical domain in the LAN environment is to use the VLAN. For the IPT service, it is recommended in principle that the IPT network be configured with a separate VLAN and the QoS applied to it. The IPT network must also be configured so that quick connectivity to IP phones can be provided and the status of the link to be connected, including speed and duplex status, can be checked.

2.2.2 Virtual Local Access Network (VLAN)

The VLAN is a way to separate the physical switching ports into a logical broadcast domain. That is, the switching ports on the LAN are configured into one domain. Within this single domain, multicast & broadcast traffic can be transmitted without limitations. On the IP data network, there exist many applications that generate multicast & broadcast traffic. Typical examples are ARP, RARP, VRRP, RIP, and OSPF. The VLAN is a technology that divides this multicast & broadcast domain to reduce unnecessary traffic. Basically, to apply the VLAN to the IPT service properly, the VLAN for voice should be separated and the QoS should be configured to give a high priority to the VLAN for voice. In the case of CISCO Ethernet switches, it is recommended to separate the voice VLAN due to the following reasons:

Address space conservation and voice device protection from external networks

Private addressing of phones on the voice or auxiliary VLAN ensures address conservation and ensures that phones are not accessible directly via public networks. PCs and servers are typically addressed with publicly routed subnet addresses; however, voice endpoints should be addressed using RFC 1918 private subnet addresses.

• QoS trust boundary extension to voice devices

QoS trust boundaries can be extended to voice devices without extending these trust boundaries and, in turn, QoS features to PCs and other data devices.

• Protection from malicious network attacks.

VLAN access control, 802.1Q, and 802.1p tagging can provide protection for voice devices from malicious internal and external network attacks such as worms, denial of service (DoS) attacks, and attempts by data devices to gain access to priority queues via packet tagging.

• Ease of management and configuration

Separate VLANs for voice and data devices at the access layer provide ease of management and simplified QoS configuration.

2.2.3 Speed and Duplex Setup

Most recent devices providing an Ethernet interface have an auto-negotiation function. Auto-negotiation should first be enabled for the ports of the IP phones and PCs that will be connected to an Ethernet Switch. For old Ethernet switches or PCs or some IP phones, an auto-negotiation function is not provided. In this case, it may be that one party is set to half-duplex and the other party is set to full-duplex. Under these conditions, a packet loss occurs intermittently and has a major effect on the voice traffic's sound quality in the IPT environment. Therefore, it is absolutely essential to check that the speed and duplex options of the equipment to be connected are set to the same values. If the equipment at one end does not have auto-negotiation, the two pieces of equipment to be connected should be manually set to the same speed, and full-duplex if possible.

2.2.4 Spanning Tree-Related Setup

In the LAN environment, if the network is composed of Ethernet switches connected to each other, the spanning tree protocol should be enabled to prevent loops and provide a redundant path. When a new port is enabled or the root bridge changes, the spanning tree protocol raises a topology change event and requires a specific period of converged time to provide a stable network path. In the case of the IP phone, it is connected to an access port of an Ethernet switch and it is recommended to enable the following functions to make connections to IP phones smoothly:

2.2.4.1 PortFast

For the ports that do not generate BPDU and do not affect the network topology, such as ports of IP phones and PCs, the PortFast function should be enabled. If this function is enabled, when a port is connected to a switch, the port status is immediately changed so that data can be sent and received via the port, making the IP phones or PCs able to communicate immediately.

2.2.4.2 Root guard/BPDU guard

For the ports for which PortFast is enabled, it is also recommended to set a root guard and BPDU guard for them. This prevents those ports from becoming the root port (the port connected to the root bridge). Whenever the root port is changed, traffic is stopped for a certain period of time since the entire topology has to be re-calculated. This may cause a serious problem to user traffic. Moreover, when a BPDU guard is stably set, if a BPDU packet is received the BPDU guard makes the port change to blocking status to prevent potential dangers. When a BPUD packet is received, the port is changed to err-disable status. The port can be configured so that an administrator can re-enable it or it is enabled automatically after a specified period of time.

2.3 QoS (Quality of Service)

2.3.1 What Is QoS?

QoS refers to the quality of an application or service the end users of a network experience. For the IPT in particular, it frequently means call quality. To guarantee QoS, low latency and loss rates must be guaranteed for all voice packets in all paths through which they pass starting from an IP phone. To guarantee low delay and loss rates in a data network, such as LAN or WAN, where various types of packets are mixed, special measures must be taken for voice packets.

2.3.2 Basic Elements of QoS

To guarantee QoS for voice packets, the following basic technologies must be applied:

QoS setting (IP phone) or Marking:

When generating a voice packet in an IP phone or a soft phone running as a PC application, a marking or setting is made to indicate that it is a voice packet. Usually, a special value is set in the 802.1p field of the packet's Ethernet header or in the TOS byte field or DSCP field of the packet's IP header. According to Cisco's recommendations, the 802.1p or TOS byte field should be set to 5. The DSCP field should be set to 46 to configure the packet's class as Expedited Forwarding (EF) class.

For not only voice packets but also voice signaling packets, video packets or the packets needed to run a voice application, QoS can ensure that their bandwidth is guaranteed. For these packets, it is also recommended that the packet generation application set an appropriate value in the 802.1p, TOS byte, and DSCP fields. Any value can be set for each traffic type. However they must be consistent within the same network environment (that is, connected Ethernet switches and routers) and be able to be recognized by all nodes. For example, if the DSCP field is set to 46 for voice packets in an IP phone, the connected Ethernet switches or routers should be able to recognize the voice packets for which the DSCP field is set to 46 and assign an appropriate bandwidth or priority to them.

Classification:

To guarantee QoS for each application's traffic (for example, voice packets, video packets, and voice signaling packets), the packets that belong to each application must be able to be recognized. The process that processes this operation is classification. For example, when an IP phone sends a voice packet for which the DSCP field is set to 46 and it reaches a LAN switch or WAN router, each node along the path the packet passes through checks the DSCP field value and, if it is 46, recognizes the packet as a voice packet. This process is called classification. Besides the 802.1p, TOS byte, and DSCP field values, network equipment provides another way to classify each application by using various data.
For example, if a special subnet address is assigned to voice equipment, the source or destination IP addresses are used for classification or the VLAN ID, protocol field, or application port can be used as the key for classification.

Classification refers to the process that classifies various mixed traffic into each application traffic type. A group of each of this classified traffic is called a class.

Action (Per-hop behavior):

The mechanism that provides QoS by applying a special rule to each of traffic groups classified by classification is called a policy or action. The following polices are required to guarantee the delay and loss rates for voice packets.

- Bandwidth Setup
- Priority Setup

For example, to compare the voice class with other classes and process it preferentially, the priority settings give a higher priority to the voice class and make it possible that when there are data traffic and voice traffic simultaneously, the voice traffic can be sent first. Alternatively, the following method can be used: When voice traffic and data traffic arrive at the same time, a specific bandwidth is assigned to voice traffic-regardless of the arrival order or the number of arrived packets-to guarantee the voice packets are sent at a specific transfer rate regardless of the amount of total traffic (bandwidth setup).

2.3.3 Applying the QoS Settings

IP Phone

IP Phone setting: Set the 802.1p, TOS byte, and IP DSCP values for the traffic generated by IP phones. All or some of these values can be set for each phone. The important point is that a field to which a value can be set should later be a standard for classification. IP Phone's Switch: An IP phone embeds a 3port Ethernet switch. The first port is connected to an upper PoE switch. The second is connected to the IP phone itself. The third is connected to a PC. The third is connected only if a PC is connected to an upper PoE switch via the IP phone. In the case of Samsung phones, this Ethernet switch is configured using their Configurations screen. Usually, for PC traffic and IP phone traffic, the 802.1p, DSCP, or TOS byte field can be set.

Soft Phone

Because a soft phone is a PC application, the 802.1p, DSCP and TOS byte settings cannot be configured in the PC's Ethernet adapter and must be configured in the application itself.

Ethernet Switch or PoE Switch

For Ethernet switches, set a classification rule and action (policy), rather than a marking rule, for voice traffic. That is, classify voice traffic using the 802.1p, DSCP, and TOS byte fields and give priority and bandwidth to voice traffic to guarantee the delay or loss rate.

For L3 switches with good specifications, besides those fields, provide an option in which voice, video, and voice signaling traffic can be classified using the source/destination IP address, application port, and protocol fields, etc. to guarantee QoS.

Wan Router

In case of the WAN Router, in general, the QoS settings are very important because the WAN link's bandwidth is small. The QoS settings, classification and action should be configured for all WAN links though which voice traffic pass. Usually, for the WAN intervals, the 802.1p field is not used. Instead, set a classification rule so that voice packets are classified using the DSCP, TOS byte, source/destination IP address, application port, protocol fields, etc. Set an action so that priority and bandwidth are guaranteed for voice packets.

2.4 IP Applications

2.4.1 Domain Name System (DNS)

The DNS refers to the system that translates an Internet domain name into an IP address on a network. The DNS gives the advantage that a host can connect to another host on a network with only its domain name. A DNS server maintains a database in which domain names and their corresponding IP addresses are stored, and provides information when a host requests a translation. For example, if a host sends the domain name, www.sec.co.kr, to a DNS server, it sends an IP address like 201.57.66.216 to the host.

When using a DNS server to use domain names, each host requests a name to address translation from the DNS server to and performs the actual operation after receiving an IP address from it. However, if the connection to the DNS server is disconnected for any reason, the host cannot find out the IP address of other hosts it wants to connect to and thus cannot connect to them.

For this reason, it is better not to configure the DNS settings for the network elements on an IP telephony network. If the DNS settings, such as host name, domain name, DNS server address, etc. are not configured, the hosts on the network do not use the DNS and hence the disconnections due to a connection problem to the DNS server can be avoided.

2.4.2 Trivial File Transfer Protocol (TFTP)

TFTP is, like FTP, a protocol for transferring files, but which is designed to transfer files in a more simplified way than FTP. Since TFTP uses UDP as its transmission protocol, it has the disadvantage that it is unstable and, for example, data can be lost during data transmission. However, since it does not use such a complex protocol as FTP, it can be implemented simply. Because of this, it is frequently used when updating the firmware or configuration in an embedded system such as IP phones.

2.4.3 Network Time Protocol (NTP)

NTP is a protocol used to synchronize the clock times of the hosts connected to a network. NTP uses UTC to synchronize the system clock times up to 1/1000 seconds or less. It is important to maintain an exact time all over the network, for several reasons. In the telephony service, a small difference in time can cause a problem. For example, the time stamps of the error logs, trace logs, and system reports for the errors that occur during network management must be synchronized.

NTP consists of NTP clients and a NTP server. An NTP client requests the server to exchange the exact current time. Through this, the client can calculate the link delay time using the difference with the server's time and adjust its clock to match it to the server's. NTP supports clock synchronization by broadcasting as well as synchronizing by a client's request.

The routers and switches on an IP telephony network play the role of servers, set the exact time through time synchronization with an upper NTP server, and provide the clients with this time information.

IP phones or personal hosts play the role of clients, request time information from an NTP server, and synchronize their time with the received broadcast time information.

2.4.4 Dynamic Host Configuration Protocol (DHCP)

DHCP is a protocol that allows a network administrator to manage and assign the IP addresses of his organization's network from a central location. A DHCP server provides a way to dynamically assign the detailed configuration information, such as an IP address, default gateway information, and TFTP sever information, to the DHCP clients on the network. DHCP uses the concept of 'lease' in which an IP address assigned to a host is valid only for a specific period of time. The lease time can be varied depending on how long the Internet connection is needed at a specific location.

In an IP telephony network, there are many hosts to which an IP address has to be assigned since not only the user PCs but also IP phones exist on the network and it is inconvenient to manually assign IP addresses from an IP phone console. Therefore, it is better to use the dynamic assignment using DHCP.

The operation principle of DHCP is that, as shown in the figure below, a user (DHCP client) sends the DHCP DISCOVER message to obtain a DHCP lease. As the response to this message, the DHCP server sends the IP configuration information including an IP address and default gateway address. If the client accepts the information sent, it sends the REQUEST message to the server. The server then assigns the address and sends the ACK message to the client to complete the DHCP address assignment procedure.



Figure 8. DHCP Request for an IP Address from a DHCP Server

Described below are the contents of the messages that are sent during the 4 step DHCP procedure above.

DHCP DISCOVER

The client sends the DISCOVER message to the server.

- Source port number: 68 (DHCP client port)
- Destination port number: 67 (DHCP server port)
- Source IP address: 0.0.0.0
- Destination IP address: 255.255.255.255 (broadcast address)

At this step, when receiving the DISCOVER message, the server searches the address pool for an available address and runs a ping test on the address found prior to assigning it to the client to avoid IP address duplication. If a ping response is received, it is recognized as an address being used and the server tries to assign another available address.

DHCP OFFER

The server sends the OFFER message to the client.

- Source port number: 67
- Destination port number: 68
- Source IP address: DHCP server's IP address
- Destination IP address: 255.255.255.255 or the IP address assigned by the DHCP server

DHCP REQUEST

The client sends the REQUEST message to the server.

- Source port number: 67
- Destination port number: 68
- Source IP address: The IP address assigned by the DHCP server
- Destination IP address: 255.255.255.255 (broadcast address)

DHCP ACK

The server sends the ACK message to the client.

- Source port number: 67
- Destination port number: 68
- Source IP address: DHCP server's IP address
- Destination IP address: The IP address assigned to the client by the DHCP server

2.5 Security (& Firewall)

A firewall serves to protect internal networks from external networks. To protect internal networks, a firewall blocks traffic that is not set in the firewall policy and allows only traffic that matches a service and IP address set in the policy. In the IPT operation environment, to communicate with an IP phone on an external network via a WAN interface, a firewall policy for IPT service must be set in each of the headquarters' and remote site's firewalls.



Figure 9. HQ-BO Network Diagram

In the previous firewall configurations, all outbound traffic is normally allowed and a policy is set to allow inbound traffic for the ports and IP addresses to be served. Recently, however, to protect against internal worm and virus propagations and block outflows of internal information, a policy is set to allow both of inbound and outbound traffic for specific services only.

When designing an IPT service network, the following items must be checked to add and modify the firewall policy.

- The firewall policy of the existing data communication network
- The service ports, protocols, and directions to be used in the IPT service
- The list of the IP addresses of the servers and IP phones to be operated for the IPT service

If the IPT service is operated at a single site or all VoIP nodes of the headquarters and branch offices are connected to a dedicated voice WAN network and use routable private IP addresses, no separate NAT configuration is needed. However, in a multiple site environment, if each of the headquarters and branch offices uses its own private IP addresses and the IPT is served via a public network, such as the Internet, the NAT function is required. The NAT function deployed in a router or firewall, through public to private IP address translations, not only supports a large number of private IP addresses with a small number of public IP addresses but also plays the role of hiding internal IP information from external networks.

However, the NAT traversal problem can occur in the VoIP protocols, such as the SIP and H.323, for the following reasons:

- The IP address and port information is contained in the signaling packet's L7 payload.
- Different connections are being used for signaling and media (RTP).

The best method to solve the NAT traversal problem is to configure the network with only public IP addresses or to configure the network so that private IP addresses are used but they are made to be routable by using a dedicated network between the headquarters and branch offices.

However, if an existing data network is used and NAT must be used, the following technologies are available to solve the NAT traversal problem in present day network environments:

- Tunneling
- IPsec VPN, GRE over IPsec
- VoIP Aware Firewall NAT
- ALG (Application Level Gateway)
- SBC (Session Border Controller)
- STUN, TURN, ICE

This section describes the tunnel and SIP ALG.

IPSec VPN not only provides a secure encrypted communication channel between the headquarters and each branch office by connecting a virtual channel between them, but also provides a function allowing the users to use them as a same single site. If IPSec VPN is used in the Samsung IPT service environment, the same IPT service environment can be provided to a single site.



Figure 10. HQ-BO VPN Tunnel Configuration Example



The methods for configuring a tunnel between the headquarters and each branch office are divided into the following two types:

Figure 11. HQ-BO VPN Configuration Type

Hub and Spoke

- Each branch is tunneled to the headquarters only.
- Since the traffic between branches is transmitted via the headquarters, the delay and jitter are larger than in the Full Mesh type when supporting a VoIP service.

Full Mesh

- All branches and the headquarters are tunneled between themselves.
- The delay and jitter are smaller than in the Hub and Spoke type.
- As the number of branches increases, the configuration becomes more complex. When a new branch is added, the corresponding tunnel configurations must be added to other branches.

The VPN connection type should be determined by considering the IPI service's traffic characteristics and the number of branches.

If the network is already connected between the headquarters and branch offices with an IPSec VPN, the QoS of the IPSec VPN must be considered to support the VoIP service via a tunnel.

Most of the firewalls and NAT equipment on the market not only change the L3 and L4 protocol header information during NAT but also recognize VoIP protocols, such as SIP and H.323, and change the IP address and port information for L7 VoIP packets. This is called the VoIP Aware Firewall/NAT or Application Level Gateway (ALG).



Figure 12. ALG Configuration Example

The ALG carries out the following functions.

- Translates the internal IP address and port information for SIP and H.323 packets.
- Generates pin holes for RTP packets.

When operating the IPT, the firewall policy should be set after checking whether the firewall installed supports SIP ALG.

If the ALG function, which changes the content of SIP packets in the NAT equipment or firewall which is an intermediate node through which they pass, is implemented incorrectly or is not tested fully in interoperation with other VoIP systems, this may affect existing VoIP processing. Therefore, it is better to disable ALG supporting in the firewall or NAT equipment when using other NAT traversal functions, such as an SBC or tunnel.

2.6 IPT Service Deployment Guide

This chapter describes step by step the check points and configurations for each node on an IP network when deploying the IPT service. Therefore, the site engineers taking charge of the IPT service should check the check points for each node according to the procedure below and add a configuration to a node if a recommendation in this chapter is not set for it.

2.6.1 Workgroup Switch

2.6.1.1 Cisco Catalyst 3750 LAN Setup Guide

1) Voice VLAN Setup

For most Catalyst switches providing, such as Catalyst 2950/3750, the VLAN for voice is separated and the QoS function is operated for that VLAN automatically in order to provide the voice VLAN function and thus acquire a quality for voice packets. Therefore, by using the voice VLAN function, the protection function can be provided for the voice packets for IPT service.

For example, if an IP phone and a PC are connected to Fast Ethernet 0/1, the VLAN for voice set to 112, and the VLAN for data set to 12, configure the voice VLAN as follows:

```
CAT2950 (config)# interface interface-id
CAT2950 (config-if)# switchport mode access
CAT2950 (config-if)# switchport voice vlan 112
CAT2950 (config-if)# switchport access vlan 12
CAT2950 (config-if)# exit
```

2) Speed and Duplex Setup

It is recommended to set the speed and duplex values to auto. You only have to set them as shown below. If you have to set the speed and duplex values manually, you can set them easily using the help on the speed command.

interface FastEthernet0/1
speed auto

3) Spanning Tree-Related Setup

If a host device, such as a PC or IP phone, is connected to the corresponding port, it is recommended that the convergence time required in the spanning tree protocol be minimized to make communication possible immediately. By using the Portfast command, you can change the port to the state that it is ready to communicate as soon as the link is set up. For a port that uses Portfast, it is assumed that a host device is used. Therefore, a problem may occur if a hub or switch is connected to the bottom end. To prevent this, it is recommended that a stabilization mechanism be provided by applying bpduguard and rootguard. Below is a spanning tree-related setup example.

```
interface FastEthernet0/1
spanning-tree portfast
spanning-tree portfast bpduguard
spanning-tree portfast rootguard
```

2.6.1.2 Cisco Catalyst 3750 QoS Setup Guide

In the Catalyst 3750, you can automatically generate the QoS configuration for protecting voice traffic using auto-QoS. Below is an example in which auto-QoS is enabled in the gigabitethernet2/0/1.

```
Switch (config)# interface gigabitethernet2/0/1
Switch (config-if)# auto qos voip trust
```

You can view the Auto-QoS configuration using the 'show auto qos interface gigabitethernet2/0/1' command.

When auto-QoS is enabled, the content described in the highlighted descriptions below is applied, which you should be aware of.

- It is assumed that, for voice packets, the DSCP field is marked as 46 and the CoS field is marked as 5. The related configuration should be set in the IP phone. Voice packets are assigned to the strict priority queue, that is, queue 2.
- It is assumed that, for VoIP control packets, the DSCP field is marked as 24 or 26 and the CoS field is marked as 3. The related configuration should be set in the IP phone and soft phone. If there is no configuration made, packets are considered as All other traffic in Table 1 below and the corresponding QoS configuration is applied. VoIP control packets are assigned to the strict priority queue, that is, queue 2.
- It is assumed that, for real-time video traffic, the DSCP field is marked as 34 and the CoS field is marked as 4. The source generating real-time video traffic must set the values above. Real-time video traffic is assigned to the strict priority queue, that is, queue 2.

When auto-QoS is enabled, it uses the ingress packet label to categorize traffic, to assign packet labels, and to configure the ingress and egress queues as shown in following three tables.

	VoIP Data Traffic	VoIP Control Traffic	Routing Protocol Traffic	STP BPDU Traffic	Real-Time Video Traffic	All Othe	er Traffic
DSCP	46	24, 26	48	56	34	-	
CoS	5	3	6	7	4	-	
CoS-to- Ingress Queue Map	2, 3, 4, 5, 6, 7 (queue 2) 0, 1 (qu				0, 1 (queue 1)		
CoS-to- Egress Queue Map	5 (queue 1)	3, 6, 7 (queue 2)		4 (queue 3)		2 (queue 3)	0, 1 (queue 4)

Table 8. Traffic Types, Packet Labels, and Queues

Table 9. Auto-QoS Configuration for the Ingress Queues

Ingress Queue	Queue Number	CoS-to-Queue Map	Queue Weight (Bandwidth)	Queue (Buffer) Size
SRR shared	1	0, 1	81 percent	67 percent
Priority	2	2, 3, 4, 5, 6, 7	19 percent	33 percent

Table 10. Auto-QoS Configuration for the Egress Queues

Egress Queue	Queue Number	CoS-to- Queue Map	Queue Weight (Bandwidth)	Queue (Buffer) Size for Gigabit- Capable Ports	Queue (Buffer) Size for 10/100 Ethernet Ports
Priority (shaped)	1	5	10 percent	16 percent	10 percent
SRR shared	2	3, 6, 7	10 percent	6 percent	10 percent
SRR shared	3	2, 4	60 percent	17 percent	26 percent
SRR shared	4	0, 1	20 percent	61 percent	54 percent

When you enable the auto-QoS feature on the first port, these automatic actions occur:

- QoS is globally enabled (**mls qos global** configuration command), and other global configuration commands are added.
- When you enter the **auto qos voip trust interface** configuration command on a port connected to the interior of the network, the switch trusts the CoS value for nonrouted ports or the DSCP value for routed ports in ingress packets (the assumption is that traffic has already been classified by other edge devices). The switch configures the ingress and egress queues on the port according to the settings in the above tables.

Besides the configurations above, the auto qos voip Cisco-phone command and the auto qos voip Cisco-softphone command can be used. However, these are applicable only if a Cisco phone or Cisco softphone is used. It is advisable to enable auto-QoS using the **auto qos voip trust interface** command.

When auto-QoS is enabled using the **auto qos voip trust interface** command, the QoS configuration shown in the following table is automatically generated in the switch.

Description	Automatically Generated Command
The switch automatically enables standard QoS and configures the CoS-to-DSCP map (maps CoS values	Switch (config)# mls qos Switch (config)# mls qos map cos-dscp 0 8 16 26 32 46 48 56
in incoming packets to a DSCP value).	
The switch automatically maps CoS values to an ingress queue and to a threshold ID.	Switch (config)# no mls qos srr-queue input cos-map Switch (config)# mls qos srr-queue input cos-map queue 1 threshold 3 0 Switch (config)# mls qos srr-queue input cos-map queue 1 threshold 2 1 Switch (config)# mls qos srr-queue input cos-map queue 2 threshold 1 2 Switch (config)# mls qos srr-queue input cos-map queue 2 threshold 2 4 6 7 Switch (config)# mls qos srr-queue input cos-map queue 2 threshold 2 4 6 7
The switch automatically maps CoS values to an egress queue and to a threshold ID.	Switch (config)# no mls qos srr-queue output cos-map Switch (config)# mls qos srr-queue output cos-map queue 1 threshold 3 5 Switch (config)# mls qos srr-queue output cos-map queue 2 threshold 3 3 6 7 Switch (config)# mls qos srr-queue output cos-map queue 3 threshold 3 2 4 Switch (config)# mls qos srr-queue output cos-map queue 4 threshold 2 1 Switch (config)# mls qos srr-queue output cos-map queue 4 threshold 2 1
The switch automatically maps DSCP values to an ingress queue and to a threshold ID.	Switch (config)# no mls qos srr-queue input dscp-map Switch (config)# mls qos srr-queue input dscp-map queue 1 threshold 2 9 10 11 12 13 14 15 Switch (config)# mls qos srr-queue input dscp-map queue 1 threshold 3 0 1 2 3 4 5 6 7 Switch (config)# mls qos srr-queue input dscp-map queue 1 threshold 3 32 Switch (config)# mls qos srr-queue input dscp-map queue 2 threshold 1 16 17 18 19 20 21 22 23
The switch automatically maps DSCP	Switch (config)# mls qos srr-queue input dscp-map

Description	Automatically Generated Command
values to an ingress queue and to a threshold ID.	queue 2 threshold 2 33 34 35 36 37 38 39 48 Switch (config)# mls qos srr-queue input dscp-map queue 2 threshold 2 49 50 51 52 53 54 55 56 Switch (config)# mls qos srr-queue input dscp-map queue 2 threshold 2 57 58 59 60 61 62 63 Switch (config)# mls qos srr-queue input dscp-map queue 2 threshold 3 24 25 26 27 28 29 30 31 Switch (config)# mls qos srr-queue input dscp-map queue 2 threshold 3 40 41 42 43 44 45 46 47
The switch automatically maps DSCP values to an egress queue and to a threshold ID.	Switch (config)# no mls qos srr-queue output dscp-map Switch (config)# mls qos srr-queue output dscp-map queue 1 threshold 3 40 41 42 43 44 45 46 47 Switch (config)# mls qos srr-queue output dscp-map queue 2 threshold 3 24 25 26 27 28 29 30 31 Switch (config)# mls qos srr-queue output dscp-map queue 2 threshold 3 48 49 50 51 52 53 54 55 Switch (config)# mls qos srr-queue output dscp-map queue 2 threshold 3 56 57 58 59 60 61 62 63 Switch (config)# mls qos srr-queue output dscp-map queue 3 threshold 3 16 17 18 19 20 21 22 23 Switch (config)# mls qos srr-queue output dscp-map queue 3 threshold 3 32 33 34 35 36 37 38 39 Switch (config)# mls qos srr-queue output dscp-map queue 4 threshold 1 8 Switch (config)# mls qos srr-queue output dscp-map queue 4 threshold 1 8 Switch (config)# mls qos srr-queue output dscp-map queue 4 threshold 2 9 10 11 12 13 14 15 Switch (config)# mls qos srr-queue output dscp-map queue 4 threshold 3 0 1 2 3 4 5 6 7
The switch automatically sets up the ingress queues, with queue 2 as the priority queue and queue 1 in shared mode. The switch also configures the bandwidth and buffer size for the ingress queues.	Switch (config)# no mls qos srr-queue input priority-queue 1 Switch (config)# no mls qos srr-queue input priority-queue 2 Switch (config)# mls qos srr-queue input bandwidth 90 10 Switch (config)# mls qos srr-queue input threshold 1 8 16 Switch (config)# mls qos srr-queue input threshold 2 34 66 Switch (config)# mls qos srr-queue input buffers 67 33
The switch automatically configures the egress queue buffer sizes. It configures the bandwidth and the SRR mode (shaped or shared) on the egress queues mapped to the port.	Switch (config)# mls qos queue-set output 1 threshold 1 138 138 92 138 Switch (config)# mls qos queue-set output 1 threshold 2 138 138 92 400 Switch (config)# mls qos queue-set output 1 threshold

Description	Automatically Generated Command
	3 36 77 100 318 Switch (config)# mls qos queue-set output 1 threshold 4 20 50 67 400 Switch (config)# mls qos queue-set output 2 threshold 1 149 149 100 149 Switch (config)# mls qos queue-set output 2 threshold 2 118 118 100 235 Switch (config)# mls qos queue-set output 2 threshold 3 41 68 100 272 Switch (config)# mls qos queue-set output 2 threshold 4 42 72 100 242 Switch (config)# mls qos queue-set output 1 buffers 10 10 26 54 Switch (config)# mls qos queue-set output 2 buffers 16 6 17 61 Switch (config-if)# srr-queue bandwidth shape 10 0 0 0 Switch (config-if)# srr-queue bandwidth share 10 10 60 20
If you entered the auto qos voip trust command, the switch automatically sets the ingress classification to trust the CoS value received in the packet on a nonrouted port by using the mls qos trust cos command or to trust the DSCP value received in the packet on a routed port by using the mls qos trust dscp command.	Switch (config-if)# mls qos trust cos Switch (config-if)# mls qos trust dscp
After creating the class maps and policy maps, the switch automatically applies the policy map called <i>AutoQoS-Police-SoftPhone</i> to an ingress interface on which auto-QoS with the Cisco SoftPhone feature is enabled.	Switch (config-if)# service-policy input AutoQoS-Police-SoftPhone

Effects of Auto-QoS on the Configuration

When auto-QoS is enabled, the auto qos voip interface configuration command and the generated configuration are added to the running configuration.

The switch applies the auto-QoS-generated commands as if the commands were entered from the CLI. An existing user configuration can cause the application of the generated commands to fail or to be overridden by the generated commands. These actions occur without warning. If all the generated commands are successfully applied, any user-entered configuration that was not overridden remains in the running configuration. Any user-entered configuration that was overridden can be retrieved by reloading the switch without saving the current configuration to memory. If the generated commands fail to be applied, the previous running configuration is restored.

2.6.2 Core Switch

2.6.2.1 Cisco Catalyst 6500/4500 LAN-related Setup Guide

1) auxiliary VLAN

For most Catalyst switches providing CatOS, such as Catalyst 6500/4500, the VLAN for voice is separated and the QoS function is operated automatically for that VLAN in order to provide the auxiliary VLAN function and thus acquire a quality for voice packets. Therefore, by using the auxiliary VLAN function, the protection function can be provided for the voice packets for IPT service.

For example, if an IP phone and a PC are connected to Fast Ethernet 0/1, the VLAN for voice set to 112, and the VLAN for data set to 12, configure the voice VLAN as follows:

```
cat6k-access> (enable) set vlan 12 name 10.1.10.0_data
cat6k-access> (enable) set vlan 112 name 10.1.110.0_voice
cat6k-access> (enable) set vlan 12 5/1-48
cat6k-access> (enable) set port auxiliaryvlan 5/1-48 112
```

2) Speed and Duplex Setup

It is recommended to set the speed and duplex values to auto. You have only to set them as shown below. If you have to set the speed and duplex values manually, you can set them easily using the help on the speed command.

```
cat6k-access> (enable) set port inlinepower 5/1-48 auto
cat6k-access> (enable) set port speed 5/1-48 auto
```

3) Spanning Tree-Related Setup

In the CatOS, you can optimize the properties of the port that is connected to a host device, such as a PC or IP phone, by using the 'set port host' command. This command enables the portfast function, turns off trunk mode, and automatically turns off the link aggregation function, such as channel mode.

To prevent loops due to an abnormal hub or switch connection from a port to which Portfast is applied, it is recommended that a stabilization mechanism be provided by applying bpduguard to all ports to which Portfast is applied.

```
cat6k-access> (enable) set port host 5/1-48
cat6k-access> (enable) spanning-tree portfast bpduguard default
```

2.6.2.2 Cisco Catalyst 6000/6500 Port Scheduling

The Cisco Catalyst 6000/6500 supports two operating systems, IOS and CatOS. This sections describes port scheduling for IOS.

Output Queueing Capability of Different Line Cards on the Catalyst 6500/6000 To enable QoS in the Catalyst 6000/6500, you should configure the following:

```
cosmos#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
cosmos (config)#mls qos
```

The Catalyst 6500/6000 provides a different queuing mechanism depending on the type of line card, that is, interface card. To check this, you should run the 'show interface capabilities' command. Below is an example.

```
cosmos #show interface gigabitethernet 6/2 capabilities
GigabitEthernet6/2
                     : WS-SUP720-BASE
 Model
 Type
Speed : 1000
Duplex : full
Trunk encap. Type : 802.1Q,ISL
: on,off,desirable,nonegotiate
 Broadcast suppression : percentage(0-100)
 Flowcontrol : rx-(off, on, desired), tx-(off, on, desired)
 Membership
                     : static
 Fast Start
                      : yes
 QOS scheduling
CoS rewrite
                     : rx-(1p1q4t), tx-(1p2q2t)
                      : yes
 ToS rewrite
 Inline power
SPAN
                      : yes
                      : no
 SPAN
                      : source/destination
 UDTD
                      : yes
 Link Debounce : yes
 Link Debounce Time : yes
 Ports on ASIC : 1-2
```

In the example above, the output queuing type of this port is 1p2q2t. The input queuing type is 1p1q4t.

The queuing type of each module can be found in this document. <u>http://www.cisco.com/en/US/products/hw/switches/ps700/products_tech_note09186a00801</u> 5bf98.shtml

Receive Interface

To prevent voice packets from being dropped at the receive interface due to a congestion, they should be protected using queuing. It is assumed that the CoS, that is, 802.1p value of voice packets is set to 5 by the IP phone.

The following queuings are provided by default for each interface card type.

- rx-(1p1q4t)-one strict-priority queue and one wrr (Weighted Round Robin) queue with four thresholds
- rx-(1q4t)-one wrr queue with four thresholds
- rx-(1p1q0t)-one strict-priority queue and one wrr queue with no configurable thresholds.

The strict-priority queue is served first before other wrr queues. That is, when the strictpriority queue has a packet, it is served first before all of other queues. 1q4t port has the following drop-threshold configuration:

- Receive-queue drop threshold 1: When the buffer is filled 50 % or more, the switch drops the packets of CoS 0 or 1.
- Receive-queue drop threshold 2: When the buffer is filled 60 % or more, the switch drops the packets of CoS 2 or 3.
- Receive-queue drop threshold 3: When the buffer is filled 80 % or more, the switch drops the packets of CoS 4 or 5.
- Receive-queue drop threshold 4: When the buffer is filled 100 %, the switch drops the packets of CoS 6 or 7.

1P1Q4T is composed of one priority queue and one wrr queue. It has the following characteristics:

Queue #	% of Buffer Capacity	Drop CoS Value
1	50 %	0-1
1	60 %	2-3
1	80 %	4
1	100 %	6-7
2	100 %	5

That is, Queue 2 is the priority queue and receives packets for which CoS (Class of Service), that is, 802.1P is set to 5. It is processed preferentially before Queue 1.

Moreover, it does not drop packets until its buffer is filled 100 %. Queue 1 is a common queue. It receives other traffic. In the table above, the packets for which CoS is 4 are processed by a common queue. When the buffer is filled 80 %, packets start to be dropped. 1p1q0t port has the following drop-threshold configuration by default:

- The packets of CoS 0, 1, 2, 3, 4, 6 or 7 are filled in the wrr receive-queue. When the receive-queue buffer is filled 100 %, packets are dropped.
- The packets of CoS 5 are filled in the strict receive-queue. When the strict receivequeue buffer is filled 100 %, packets are dropped.

To use the queuing engine of the receive interface using the packets' CoS set already in the IP phone, the trust state of the port should be set to trust CoS using the following commands:

```
cosmos#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
cosmos (config)#interface gigabitethernet 1/1
cosmos (config-if)# mls qos trust cos
```

Transmit Queues

To prevent voice packets from being dropped at the transmit interface due to congestion, they should be protected using queuing. It is assumed that the CoS, that is, 802.1p value of voice packets is set to 5 by the IP phone.

You can check the queue structure of the port using the 'show interface capabilities' command. Check whether one of the following transmit queue sets is displayed:

- tx-(2q2t)-Two wrr queues and two drop thresholds for each wrr queue.
- tx-(1p2q2t)-One strict priority queue, two wrr queues and two drop thresholds or each wrr queue.
- tx-(1p3q1t)-One strict priority queue, three wrr queues and two drop thresholds for each wrr queue.

2q2t Ports

For the 2q2t port, each of the two wrr queues supports two drop thresholds as follows:

- The packets of CoS 0, 1, 2 or 3 are served by being filled in Queue 1.
- transmit queue 1, drop-threshold 1: When the queue buffer is filled 80 % or more, the packets of CoS 0 or 1 are dropped.
- transmit queue 1, drop-threshold 2: When the queue buffer is filled 100 % or more, the packets of CoS 2 or 3 are dropped.
- The packets of CoS 4, 5, 6 or 7 are served by being filled in Queue 2.
- transmit queue 2, drop-threshold 1: When the queue buffer is filled 80 % or more, the packets of CoS 4 or 5 are dropped.
- transmit queue 2, drop-threshold 2: When the queue buffer is filled 100 % or more, the packets of CoS 6 or 7 are dropped.

1p2q2t Ports

For the 1p2q2t port, one strict priority queue and two wrr queues are provided Each of wrr queues supports two drop thresholds as follows.

- The packets of CoS 0, 1, 2 or 3 are served by being filled in Queue 1.
- transmit queue 1, drop-threshold 1: When the queue buffer is filled 80 % or more, the packets of CoS 0 or 1 are dropped.
- transmit queue 1, drop-threshold 2: When the queue buffer is filled 100 % or more, the packets of CoS 2 or 3 are dropped.
- The packets of CoS 4, 6 or 7 are served being filled in Queue 2.
- transmit queue 2, drop-threshold 1: When the queue buffer is filled 80 % or more, the packets of CoS 4 are dropped.
- transmit queue 2, drop-threshold 2: When the queue buffer is filled 100 % or more, the packets of CoS 6 or 7 are dropped.
- The packets of CoS 5 are served by being filled in Queue 3, that is, a strict-priority queue. They are dropped when the queue buffer is filled 100 %.

To use QoS in the Catalyst 6500/6000, QoS should be configured with the following steps:

- Enable QoS.
- (This step is optional) Map CoS values to the queues and drop thresholds.
- 1) Enable QoS. Follow this example:

```
cosmos#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
cosmos (config)#mls qos
QoS is enabled globally
Microflow policing is enabled globally
QoS global counters:
Total packets: 552638
IP shortcut packets: 0
Packets dropped by policing: 0
IP packets with TOS changed by policing: 0
IP packets with COS changed by policing: 0
Non-IP packets with CoS changed by policing: 0
```

2) Map CoS values to the queues and drop thresholds.

For example, for the 1p2q2t ports, Queue 1 is a wrr queue with the lowest priority. Queue 2 is a wrr queue with high-priority. Queue 3 is a strict-priority queue. If the CoS value of voice packets is not 5, you should map the value to the priority queue by applying the example below:

```
cosmos#configure terminal
cosmos (config)#interface gigabitethernet 1/1
cosmos (config-if)#priority-queue cos-map 1 5 !--- Assign a CoS of 5
to priority queue. cos-map configured on: Gi1/1 Gi1/2
cosmos (config-if)#wrr-queue cos-map 1 1 0 1 !--- Assign CoS 0 and 1
to the first threshold of low-priority WRR queue.
 cos-map configured on:
Gi1/1 Gi1/2
cosmos (config-if)#wrr-queue cos-map 1 2 2 3 !--- Assign CoS 2 and 3
to the second threshold of low-priority WRR queue.
cos-map configured on: Gi1/1 Gi1/2
cosmos (config-if)#wrr-queue cos-map 2 1 4 6 !--- Assign CoS 4 and 6
to the first threshold of high-priority WRR queue.
 cos-map configured on: Gi1/1 Gi1/2
cosmos (config-if)#wrr-queue cos-map 2 2 7 !--- Assign CoS 7 to the
first threshold of high-priority WRR queue.
 cos-map configured on:
Gi1/1 Gi1/2Check the configuration:
cosmos#show queueing interface gigabitethernet 1/1
!--- Output suppressed.
Queue thresh cos-map
                  _____
      _____
       1 0 1
   1
            23
      2
   1
       1 46
   2
   2 2
            7
   3
       1
             5
!--- Output suppressed.
```

You can check QoS information using the following commands: You can check that CoS 5 is assigned to the priority queue.

```
cosmos#show queueing interface gigabitethernet 1/1
Interface GigabitEthernet1/1 queueing strategy: Weighted Round-Robin
 Port QoS is enabled
 Port is untrusted
 Default COS is 0
 Transmit queues [type = 1p2q2t]:
   Queue Id Scheduling Num of thresholds
   _____
     1 WRR low 2
    2 WRR high 2
3 Priority 1
   WRR bandwidth ratios: 20[queue 1] 80[queue 2]
queue-limit ratios: 70[queue 1] 15[queue 2]
   queue random-detect-max-thresholds
         _____
    1 50[1] 80[2]
       40[1] 60[2]
    2
```

```
queue thresh cos-map
 -----
 Receive queues [type = 1p1q4t]:
 Queue Id Scheduling Num of thresholds
 _____
   1 Standard 4
  2
          Priority
                          1
 queue tail-drop-thresholds
 ------
     100[1] 100[2] 100[3] 100[4]
 1
 queue thresh cos-map
 _____
                   _____
 Packets dropped on Transmit:
 BPDU packets: 0
 queue thresh dropped [cos-map]
                                ------
 _____

      1
      1
      0
      [0 1]

      1
      2
      0
      [2 3]

      2
      1
      0
      [4 6]

      2
      2
      0
      [7]

      3
      1
      0
      [5]

Packets dropped on Receive:
 BPDU packets: 0
 queue thresh dropped [cos-map]
 _____
 1 1
1 2
1 3
1 4
2 1
          0 [0 1 ]
                   0 [2 3 ]
                  0 [4]
0 [67]
0 [5]
```

For more information on QoS configuration for the Catalyst 6500/6000, visit the link below. http://www.cisco.com/en/US/prod/collateral/switches/ps5718/ps708/prod_white_paper090 0aecd80233956.html

2.6.3 DHCP Server

In an IP telephony network, since user PCs and IP phones are mixed on it and it is very inconvenient to assign IP addresses to IP phones manually, from the standpoint of network management, it is better to use DHCP to manage IP addresses smoothly. Moreover, if the network is managed with the data and voice networks divided logically, IP address management becomes more convenient and the management of IP address and IP phone configurations through DHCP also becomes simpler.

The figure below shows an example in which a network is divided into voice and data networks. This section describes the procedure to configure the DHCP service using the DHCP server contained in the CISCO router based on the network architecture below.



Figure 13. DHCP Deployment Configured with Voice and Data VLANs

1) Enabling the DHCP Service

Router (config) # service dhcp

Enable the DHCP service. (default enable)

2) Configuring the DHCP Database Agent and DHCP Conflict Logging

Set the database agent that will periodically store the DHCP binding information in a permanent storage device. In DHCP, the binding information in which lease information is contained should be maintained between the server and client. To do this, the binding database is stored in an external storage device so that binding information can be preserved even when an unexpected reboot or shutdown occurs. Generally, binding information can be stored in a file at a remote location via a

protocol, such as FTP or TFTP.

Even if the system has been rebooted, the lease information for the client can be recovered by loading binding information from the database. Below is an example in which the database agent is configured to store binding information at the 172.16.4.253 host via FTP. In this example, the server records the changes of the database with an interval of 120 seconds.

```
Router (config)# ip dhcp database
ftp://user:password@172.16.4.253/router-dhcp write-delay 120
```

When an address conflict is detected through the ICMP echo or DHCPDECLINE message, the DHCP conflict logging function transmits the conflict information using a syslog message and thus ensures the address remains unused. It is disabled by default. By doing so, even if a conflict occurs temporarily, when it is cleared afterward, the address can be reused.

Router (config) # no ip dhcp conflict logging

3) Selecting Addresses to Exclude from Dynamic Assignment

By default, the DHCP server is configured to assign sequentially all addresses in the subnet that the address pool has. If a network administrator does not want to assign some addresses dynamically, an exclusion setting should be made for them. To do so, set the address band not to be assigned to DHCP clients using the excluded-address command, which operates in the global configuration mode, as follows:

Router (config) # ip dhcp excluded-address low-address [high-address]

4) Configuring a DHCP Address Pool

In the DHCP server, an address to be assigned to a client can be selected from an address pool. Each address pool has a name of string type. You can configure an address pool by setting the pool name and pool parameters as shown in the procedure below:

- Configuring the DHCP Address Pool Name and Entering DHCP Pool Configuration Mode
- Set the DHCP address pool name. You then enter the DHCP pool configuration mode.

```
Router (config)# ip dhcp pool name
Router (config-dhcp)#
```

- Configuring the DHCP Address Pool Subnet and Mask
- Configure the subnet address and netmask for the newly created DHCP address pool. By default, all addresses within the subnet address band configured at this step can be assigned to clients.

Router (config-dhcp)# network network-number [mask | /prefix-length]

- · Configuring the Address Lease Time
- By default, each address has a lease period of one day. The lease period can be changed using the following lease command:

Router (config-dhcp) # lease {days [hours][minutes] | infinite}

- The lease time can be varied depending on how long the Internet connection is needed at a specific location. If more hosts than the number of available IP addresses exist, the network should be made to be reconfigured dynamically and continually by shortening the lease period of IP addresses. However, in the IP telephony network environment, it is better that once an address is assigned to an IP phone, it is not changed frequently. If the address of an IP phone changes because the information configured for the IP telephony service using the previous address is also changed, a service synchronization operation is required. It is therefore better that the DHCP lease period is set to one week or longer for an IP telephony network in which the network architecture or configuration does not change frequently once it is deployed.
- Configuring the Pool Parameters
- Configure the network settings, such as the domain name, DNS server IP address, NetBIOS server address, and default router to be used by the clients.
- In the example below, a DHCP address pool is configured for each address band when VLAN 100 and 101 exist as shown in the figure above. The pool data and pool voice are the address pool for each VLAN, respectively. Each of them is an address pool for the network 172.16.1.0/24 and 172.16.2.0/24. The domain name and DNS server information are set for each pool. The addresses, except those set as excluded-address, are assigned to the clients and the lease period is set to 30 days.

```
ip dhcp excluded-address 172.16.1.100 172.16.1.103
ip dhcp excluded-address 172.16.2.100 172.16.2.103
1
ip dhcp pool data
      network 172.16.1.0 /24
      domain-name sec.com
      dns-server 172.16.1.102 172.16.2.102
      default-router 172.16.1.100 172.16.1.101
      lease 30
1
ip dhcp pool voice
      network 172.16.2.0 /24
      domain-name sec.com
      dns-server 172.16.1.102 172.16.2.102
      default-router 172.16.2.100 172.16.2.101
      lease 30
```

5) Viewing the DHCP Server Information

Router# show ip dhcp binding [address]

• Check a list of binding information with clients created in the DHCP server.

```
Router# show ip dhcp conflict [address]
```

- Check a list of conflict addresses recorded in the DHCP server.
- Check the statistics information related to the DHCP server and the message transmission reception statistics information.

Router# show ip dhcp server statistics

2.6.4 Security device

Table 7 shows a list of the service, protocol and port pairs used in the OfficeServ IPT service environment. Referring to this, you should set a firewall for a service which is transmitted between the headquarters and a branch via a WAN network. The tables and configurations below show an example of configuring a Cisco firewall for the headquarters and branch offices in the SIP-based IPT operation environment.

Priority	Dir	Service	Port	Source	Destination
1	In	SIP	UDP 5060 TCP 5060	IP address area for branches	SCM
2	In	SIP TLS	TCP 5061	Branch IP address area	SCM
3	Out	SIP	UDP 5060 TCP 5060	SCM	Branch IP address area
4	Out	SIP TLS	TCP 5061	SCM	Branch IP address area
5 ¹⁾	In	RTP	Any	External branch IP address area	Internal IP phone IP address area
6	Out	RTP	Any	Internal IP phone IP address area	External branch IP address area
7	Out	NTP	TCP 123 UDP 123	SCM Server	External NTP server
8	Out	SNMP	UDP 161	NMS server	Branch IP phone area
9	In	SNMPTrap	UDP 162	Branch IP phone area	NMS server
10	In	HTTP	TCP 80	External branch IP address area	SCM Server
11	In	NTTPS	TCP 443	External branch IP address area	SCM Server
12	In	TFTP	UDP 69	External branch IP address area	SCM Server

Table 12. Firewall Configurations f	for the Headquarters
-------------------------------------	----------------------

 For the firewalls and NAT equipment that support the ALG function, a policy for RTP does not need to be set since the firewall policy is generated by dynamic pin-hole connection.

Priority	Dir	Service	Port	Source	Destination
1	In	SIP	UDP 5060 TCP 5060	Headquarters/other branch IP addresses	Internal IP phone IP addresses
2	In	SIP TLS	TCP 5061	Headquarters/other branch IP addresses	Internal IP phone IP addresses
3	Out	SIP	UDP 5060 TCP 5060	Internal IP phone IP addresses	Headquarters/other branch IP addresses
4	Out	SIP TLS	TCP 5061	Internal IP phone IP addresses	Headquarters/other branch IP addresses
5	In	RTP	UDP ANY	External branch IP address area	Internal IP phone IP addresses
6	Out	RTP	UDP A NY	Internal IP phone IP addresses	External branch IP address area
7	Out	TFTP	UDP 69	IP phone address	TFTP Server
8	Out	NTP	TCP 123 UDP 123	IP phone address	External NTP server
9	In	SNMP	UDP 161	NSM server	IP phone address
10	Out	SNMPTrap	UDP 162	IP phone address	NSM server
11	Out	HTTP	TCP 80	Internal IP phone IP addresses	SCM

Table 13. Firewall Configurations for Branch Offices

You should configure the IPT policy for the firewalls operating in the data network in accordance with the tables above. Below is an example of how to configure the IPT service in a Cisco firewall:

Set the Access-list.

Set the ACL with the ports and IP addresses for which the IPT service is to be allowed. Below is an example of how to configure a firewall for the headquarters based on Firewall Configurations for the Headquarters.

```
ip access-list extended HQ_out_access_list
permit udp any host <<ntp_server_ip>> eq ntp
permit udp any <<brackdrs_server_ip >> eq dns
permit udp any <<brackdrs_server_ip >> eq sip
permit tcp any <<brackdrs_range>> eq sip
permit tcp any <<brackdrs_range>> eq 5061
deny ip any any
!
ip access-list extended HQ_in_access_list
permit udp any host <<tft_server_ip>> eq tftp
permit tcp any host <<htp_server_ip> eq http
```

```
permit udp any <<branch_ip_range>> eq sip
permit tcp any <<branch_ip_range>> eq sip
deny ip any any
```

The firewalls for branch offices should also be configured referring to table. Firewall Configurations for Branch Offices.

Create the Cisco Inspect Rule.

The inspect command sets the Stateful Packet (SPI) function for a Cisco ACL. When the inspect command with timeout 180 is executed for the SIP protocol, the firewall creates and manages the SIP response messages and pin-hole connections to RTP.

```
ip inspect name IPT_INSPECT_1 sip timeout 180
ip inspect name IPT_INSPECT_1 tftp timeout 30
ip inspect name IPT_INSPECT_1 http timeout 60
ip inspect name IPT_INSPECT_1 and timeout 10
ip inspect name IPT_INSPECT_1 snmp timeout 60
ip inspect name IPT_INSPECT_1 icmp timeout 60
ip inspect name IPT_INSPECT_1 tcp timeout 3600
ip inspect name IPT_INSPECT_1 udp timeout 60
```

Cisco inspect is an ALG function. If a firewall from another vendor besides Cisco's is used, you should check whether it supports the ALG function and then determine whether to enable the ALG function.

If the ALG function is not used, the firewall policy for RTP traffic should be set separately. Generally, because the RTP traffic used by VoIP peers uses a wide area of UDP ports, if the inbound and outbound firewall permission policy is set explicitly for RTP traffic, internal security may become weak.

Set the ACL and Inspect Rule for Network Interface

```
interface FastEthernet0/0
  ip access-group HQ_in_access_list in
  ip inspect IPT_INSPECT_1 in
  !
  interface FastEthernet0/1
   ip access-group HQ_out_access_list out
  ip inspect IPT_INSPECT_1 out
```

IPSec VPN not only provides a secure encrypted communication channel between the headquarters and each branch office by connecting a virtual channel between them, but also provides a function allowing the users to use them as a same single site.

If IPSec VPN is used in the Samsung IPT service environment, the same IPT service environment can be provided to a single site.

Cisco VPN equipment also support QoS for encrypted ESP and AH packets. For more information on Cisco IPSec VPN and QoS supporting, visit the URL below.

- Configuring Per Site QoS with IPsec VPN
- PIX/ASA 7.x: QoS for VoIP Traffic on VPN Tunnels Configuration Example

In the network environment for which the IPT needs to be supported using NAT without connecting tunnels between single sites or multiple sites, a plan for solving the NAT traversal problem is required. If a dedicated system for solving the NAT traversal problem, such as SBC, cannot be used in that network environment, the firewall and NAT equipment should support NAT traversal. The SIP ALG function of the firewall and NAT equipment analyzes SIP packets and then performs public/private IP address and port translation for SIP packet payloads and creates pin hole connections for RTP packets. In the NAT environment, with Cisco products, the inspection function described previously performs the ALG function.

Below is an example of how to configure the NAT in the Cisco IOS. Define the IP area to apply NAT to using the ACL. Define the IP area of LAN environment to which NAT will be applied using ACL.

```
access-list 7 permit 192.168.1.0 0.0.0.24
access-list 7 permit 192.168.2.0 0.0.0.24
```

Create a NAT pool and configure the ACL for NAT.

```
ip nat pool ovrld 172.16.10.1 172.16.10.1 prefix 24
!
ip nat inside source list 7 pool ovrld overload
!
```

Configure NAT for network interfaces.

```
interface ethernet 1
  ip address 10.10.20.1 255.255.255.0
  ip nat inside
interface serial 0
  ip address 172.16.10.64 255.255.255.0
  ip nat outside
```

2.6.5 WAN Router

2.6.5.1 An example for configuring a Cisco WAN router (2800, 3800, 7200)

You should configure QoS for each link at the Cisco WAN router. To provide the best voice quality, it is better to configure QoS for outbound traffic from the interface.

Defining the voice traffic

First, define the voice traffic as follows:

```
access-list 100 permit ip any any precedence 5
access-list 100 permit ip any any dscp ef
```

Define the voice control traffic as follows:

```
! MGCP Control Traffic
access-list 101 permit udp any host 10.1.10.20 2427
access-list 101 permit tcp any host 10.1.10.20 2428
!
! H.323 Control Traffic
access-list 101 permit tcp any host 10.1.10.20 1720
access-list 101 permit tcp any host 10.1.10.20 range 11000 11999
```

For SIP or OSPP, the access-list should be defined using the proper port range information.

```
class-map VoIP-RTP
match access-group 100
class-map VoIP-Control
match access-group 101
```

Defining the class-map for voice traffic/voice control traffic

```
policy-map QoS-Policy
class VoIP-RTP
priority 100  # 100 means 100 kbps for a single call. If there are
# multiple voice calls, you should increase this value
class VoIP-Control
bandwidth 8  # 8 means 8 kbps for a single call. If there are
multiple
# voice calls, you should increase this value
class class-default
fair-queue  # Other traffic is processed in the round robin
method.
# for each flow.
```
Setting the policy for each class-map

```
interface FastEthernet1/0
service-policy output QoS-Policy
```

Applying the policy to all interfaces

show service-policy interface FastEthernet1/0

Checking the applied policy

2.7 IPT Requirements and Measurement

Below are the requirements for a smooth IPT service.

- Packet loss rate: 0.1 % or less
- Packet delay: Average 100 ms or less, maximum 200 ms or less
- Jitter: Maximum 40 ms or less

If the IPT service has been deployed in accordance with the directions in Chapter 3, using the following criteria and tool measure whether the IP network where the IPT service is deployed meets the requirements above. If it does not meet the requirements above, it is recommended that the IPT service be deployed after it is made to meet the requirements above by optimizing it in accordance with the directions in the 'IP Network Infrastructure' section.

- 1) Measurement Criteria
 - When measuring data, make sure to include the time when the most IP network traffic occurs.
 - Measure 8 times or more a day for at least one week.
 - Measure data including the longest path through which the IPT service is provided.



Figure 14. Test Network Architecture

- 2) Measurement Tool
 - Ping Plotter: Loss rate, delay time and jitter time between network nodes can be measured using ping tests unlimitedly and simultaneously. Measurement results are displayed and categorized into green, yellow, and red according to delay time. The delay time and jitter time are displayed graphically.

Below are the measurement results obtained when a ping plotter was installed into the test_PC and the network status from phone B to phone C was measured in the IPT network topology as shown in the figure above.

Ľ
$1 \times$
0 9
239
nutes
1072
80
Packet Los
W.2
10.0

Figure 15. Ping Plotter Test Results

2.8 IPT Service Deployment Example

In this section, we have listed the problems that occurred when deploying the Samsung IPT service in a real life example so that they can be used as a reference for future IPT service deployments.

2.8.1 German Samsung Corporation

- The IPT service was stopped because a broadcast storm occurred in the IPT service network.
- It was cleared by dividing the network into the IPT service network and IP data network logically.
- In more detail, because the versions of the workgroup switch (Sermit1, Extreme) and core switch (Black Diamond 6808, Extreme) images being used by the Unified German Corporation were early, we divided the network into the IPT service network and IP data network using VLAN. However, because the network was configured so that all STPs operated as a subnet, a broadcast storm on the IP data network flowed into the IPT service network. Therefore, we first separated logically the broadcast domain from the IP data network by removing the VLAN for IPT service from all STPs.
- The low S/W versions have now been completely upgraded to versions that can enable RSTP for each VLAN of all switches, and the RSTP is being enabled for each Per VLAN.

A time mismatch occurred due to a packet sending/receiving error between the SCM and NTP server.

This problem occurred because a private address for the SCM was blocked by the ACL (packet filter type) in the gateway switch. It was cleared by modifying the ACL. The Internet access speed of a PC connected to the IP phone of a subscriber of SCG slowed down. A large quantity of CRC errors occurred due to a fault in the cable between the workgroup switch and IP phone. The cable was replaced.

Measures were put in place so that the same action could be taken if a similar problem occurs in the future (when a Tx CRC error occurs in a workgroup switch).

This problem is related to a slowing down of the Internet connection speed; the speed and duplex options for the workgroup switch port connected to the IP phone should always be operated in auto negotiation mode.

The IP address received by a specific IP phone via DHCP conflicted.

This problem occurred because a user used an IP address in the DHCP pool as a static IP address. Measures were taken so that he could not use the static IP address.

To prevent similar problems from occurring during future operation, we strongly recommended that a notice should be sent to all employees and that this kind of problem be managed continually.

CHAPTER 3. License Guide

3.1 License Key Type

3.1.1 Users

This describes the phone types.

License items are:

Samsung SIP Phones, Samsung Soft Phones, Samsung Mobile Phones, Samsung PC Attendants, 3rd Party SIP Phones, Analog Phones (Gateway)

3.1.2 Embedded Application

This describes the types of embedded application channels.

License items are: Meet-Me Conference Channels, UMS Channels

3.1.3 External Application

This describes the types of external application channels

License items are: Total CSTA Applications, Samsung Operators, Embedded ACD Agent Links, Communicators (Desktop), Other CSTA Applications, SIP Application Channels

3.1.4 Wireless Enterprise

This describes the types of wireless service channels

License items are: FMS Phones, MVS Phones

3.2 License Policy

3.2.1 Evaluation Period

If you didn't install the license, the evaluation license will work for 30 days.

3.2.2 Active-Active Validation

If license is for active-active system and link down occur for 30 days continuously, the license will not work.

3.2.3 License Status Notification

If evaluation work or active-active system is link-down, the elapsed time will be notified at 9:00.

If the states of active-active system changed to normal, elapsed time will reset and be notified on time.

If evaluation license is expired, this information will be notified. But, If you already install the license, system will work normally.

CHAPTER 4. Installing SCM Server

4.1 SCM Server Hardware

4.1.1 Preparing the SCM Hardware

The table below lists the minimum hardware requirements for installing the SCM.

Category	SCM Express	SCM Enterprise
CPU	2.4 GHz or higher (Quad Core, at least 1 CPU)	2.4 GHz or higher (Quad Core, at least 1 CPU)
RAM	4 GB or more (DDR3, 1333 MHz or higher)	8 GB or more (DDR3, 1333 MHz or higher)
HDD	160 GB or more	160 GB or more
ODD	1 DVD-ROM	1 DVD-ROM
Network Interface	3 Gigabit Ethernet	3 Gigabit Ethernet

Table 14. Minimum hardware requirements for SCM server

4.1.2 Unpacking and Inspection

For SCM Express software install to server, the server must meet right above the minimum requirements. SAMSUNG supply the Dell's R210 model for SCM server that brand name is IPX-S500 system.

For additional hardware installation of the IPX-S500, please refer to the 'IPX-S500 Hardware Owner's Manual'.

4.1.3 **Preparing Peripherals**

Following peripherals should be preparing for operating of SCM server. Preparing peripherals are different between stand alone system and twin system (high availability service system).

Category	Stand Alone	Twin System
KVM (keyboard, video, mouse) switch (USB Type)	Not Need	1
Keyboard (USB type)	1	1
Mouse (USB type)	1	1
Monitor	1	1
L2 Switch	1 (Recommend 2)	2
UPS (Uninterruptible power supply)	Recommend	Recommend

Table 15. Minimum peripherals for SCM server

4.1.4 Cabinet Mounting



This section referenced on the Dell's R210 installation guide by Dell.

For additional information about installing to cabinet, see www.dell.com.

4.1.4.1 Installing with Static Rail

Identifying the Static Rail Kit Contents

Locate the components for installing the rail kit assembly:

- Two DellTM ReadyRailsTM static rails (1)
- Two chassis rail members (2)
- Two Velcro straps (3)



Figure 16. Identifying the Static Rail Kit Contents

Configuring Flush-Mount Static Rails (Two- or Four-Post)

Lay both rails flat with both end pieces facing up. Remove the Remove the two screws on the front end pieces and rotate each piece 180 degrees (1). Reattach both end pieces with the two pairs of screws (2).



The rails as they are shipped must be converted to tooled rails to install in a flushmounted rack.



Figure 17. Configuring Flush-Mount Static Rails (Two- or Four-Post)

Installing Flush-Mount or Center-Mount Static Rails (Two-Post)

Attach right and left mounting rails to the front mounting flanges with two pairs of screws (1). Slide each flush-mount adjustable bracket forward against the two-post rack. Secure each side to the mounting flange with two pairs of screws (2). For a center-mount installation, push the adjustable rear mounting brackets toward the back of the right and left mounting rails. Attach the fixed center mount brackets to the front mounting flanges with two pairs of screws. Slide both the adjustable rear-mounting brackets forward against the two-post rack. Secure each side to the mounting flange with two screws (3).



To configure your rails for a tooled flush-mount installation, refer to PANEL 3.



Figure 18. Installing Flush-Mount or Center-Mount Static Rails (Two-Post)

Configuring Four-Post Threaded Static Rails

Press the rail release button on each rail to disengage the rear segments (1). Rotate the rear segments 180 degrees so that the tooled end piece is in the rear position (2). With the end pieces positioned outward, align and rejoin the midsections and slide the rear segments into place until the release button engages (3).



To configure the front end pieces of your rails for a tooled installation, refer to PANEL 3. To configure the rear end pieces of your rails for a tooled installation, perform the following steps.



Figure 19. Configuring Four-Post Threaded Static Rails

Installing and Removing Four-Post Threaded Static Rails

Attach the right and left mounting rails to the front mounting flanges with two pairs of screws (1). Repeat the preceding step for the rear mounting flanges (2).



To your rails for a tooled installation, refer to PANEL 3 and PANEL 5.



Figure 20. Installing and Removing Four-Post Threaded Static Rails

Installing and Removing Chassis Rail Members

Place the system on a level surface and align the keyhole slots on the chassis rail members with the pins on the system (1). Slide the chassis rail members toward the back of the system until they lock into place. To remove the chassis rail members, lift the lock spring until it clears the head of the pin (2). Slide the chassis rail member towards the front of the system until the pins slip through the keyhole slots.



Figure 21. Installing and Removing Chassis Rail Members

Installing, Removing, Cabling, and Securing the System in the Rack

Insert the ends of the chassis rail members into the front of the static rails and push the system into the rack (1). For tool-less four-post racks and center-mount two-post configurations, the slam latches engage automatically as the system is pushed into the rack (2). To secure the system for shipment in the rack or for other unstable environments, locate and tighten the hard-mount screw under each latch (3). Bundle the system cables, pulling them clear of the system connectors to the left and right sides. Secure the bundles by threading the Velcro straps through the tooled rail slots (4). To remove the system from the rack, pull the system out of the rack until the rails lock into place. The lock position is intended to provide the opportunity to reposition the grip for removal, it is not intended for service. Locate the blue tabs on the sides of the chassis rail members. Push the tabs inward and continue pulling the system until the chassis rail members are completely clear of the rails (5).



Figure 22. Installing, Removing, Cabling, and Securing the System in the Rack

4.1.4.2 Installing with Sliding Rail

Identifying the Rail Kit Contents

Locate the components for installing the rail kit assembly:

- Two A3 DellTM ReadyRailsTM sliding rails (1)
- Two chassis rail members (2)
- Two Velcro straps (3)
- Two cable management arm (CMA) attachment brackets (4)



Figure 23. Identifying the Rail Kit Contents

Installing and Removing the Rails (square-hole racks)

Position the left and right rail end pieces of the sliding rail labeled FRONT facing inward and orient each end piece to seat in the square holes on the front side of the vertical rack flanges (1). Align each end piece to seat the pegs in the bottom hole of the first U and the top hole of the first U (2). Engage the back end of the rail until it fully seats on the vertical rack flange and the second 'tooth' on the latch locks in place. Repeat these steps to position and seat the front end piece on the vertical flange (3). To remove the rails, pull on the latch release button on the end piece midpoint and unseat each rail (4).



Installing and Removing the Rails (square-hole racks)

Installing and Removing the Rails (round-hole racks)

Position the left and right rail end pieces of the sliding rail labeled FRONT facing inward and orient each end piece to seat in the round holes on the front side of the vertical rack flanges (1). Align each end piece to seat the pegs in the bottom hole of the first U and the top hole of the first U (2). Engage the back end of the rail until it fully seats on the vertical rack flange and the first 'tooth' on the latch locks in place. Repeat these steps to position and seat the front end piece on the vertical flange (3). To remove the rails, pull on the latch release button on the end piece midpoint and unseat each rail (4).



Figure 24. Installing and Removing the Rails (round-hole racks)

Installing and Removing the Chassis Rail Members

Place the system on a level surface and align the four keyhole slots on the chassis rail members with the corresponding pins on the system (1). Slide the chassis rail members towards the back of the system until each one locks into place. To remove the chassis rail members, lift the lock spring until it clears the head of the pin (2). Slide the chassis rail member toward the front of the system until the pins slip through the keyhole slots.



Installing and Removing the Chassis Rail Members

Installing the System in the Rack

Pull the sliding rails out of the rack until they lock into place (1). Align and insert the ends of the chassis rail members into the ends of the rails (2). Push the system inward until the chassis rail members lock into place. Push or pull the blue tab located near the front of the system and slide the system into the rack (3).



Ensure that the system is properly supported until the chassis rail members are locked into the slide rails on both sides.



Figure 25. Installing the System in the Rack

Removing the System from the Rack

Pull the system out of the rack until the sliding rails lock into place (1). Locate the white tabs on the sides of the chassis rail members (2). Pull the tabs towards the front of the system to release the chassis rail members from the rails. Continue pulling the system until the chassis rail members are completely clear of the rails and place the system on a level surface (3).



To remove the chassis rail members from the system, refer to PANEL 4.



Figure 26. Removing the System from the Rack

Engaging and Releasing the Slam Latch

Facing the front, locate the slam latch on either side of the system (1). The latches engage automatically as the system is pushed into the rack and are released by pulling up on the latches (2). To secure the system for shipment in the rack or for other unstable environments, locate the hard-mount screw under each latch and tighten each screw with a #2 Phillips screwdriver (3).



For systems not equipped with slam latches, you can secure the system using screws, as described in Step 3.



Figure 27. Engaging and Releasing the Slam Latch

Installing the CMA Attachment Brackets

Locate the CMA attachment bracket marked A and install it at the back of the slide rail marked with a corresponding A (1). Align the holes on the bracket with the pins on the slide rail and push the bracket forward until it locks into place. Repeat the same process for the CMA attachment bracket marked B.



Figure 28. Installing the CMA Attachment Brackets

4.1.4.3 Routing the Cables

Bundle the cables gently, pulling them clear of the system connectors to the left and the right sides (1). Thread the Velcro straps through the tooled slots on the outer or inner CMA brackets on each side of the system to secure the cable bundles (2).



If you did not order the optional CMA, use the two Velcro straps provided in the rail kit to help route the cables at the back of your system. To allow proper fit in racks that do not accommodate the CMA, the outer CMA brackets can be removed using a #2 Phillips screwdriver.



Figure 29. Routing the Cables

4.1.5 Connecting to Network

Stand Alone SCM

Following figure is connecting to IP network diagram for Stand Alone SCM without network redundancy.



Following figure is connecting to IP network diagram for Stand Alone SCM with network redundancy.

When using network redundancy, the SCM network cables should be connecting to different switches.



High Availability Service SCM

Following figure is connecting to IP network diagram for High Availability service SCM with network redundancy.



When SCM using High Availability service, should be used network redundancy. The SCM network cables should be connecting to different switches.

The network cable of connecting between active and standby SCM, should be used Category E5 or more.

4.2 SCM Server Software

4.2.1 Preparing the SCM Software

To install the SCM, the installation DVD provided by Samsung Electronics is required. The installation DVD contains the SCM software and Linux operating system. It requires no separate installation of the Linux operating system.

You need to install the SCM software on the device with a valid software license.

4.2.2 SCM Software Installation Procedure

The installation DVD provided contains the SCM software and the Linux operating system optimized for the software.

To install the SCM:

Insert the installation DVD into your DVD-ROM drive and run the setup program.

Samsung Communication Manager	
Welcome to the Samsung Communication Manager Setup Wizard	
This wizard will guide you through the steps required to install Samsung Communication Manager on your system.	
If you press "Next" button, the installation will proceed. During the installation process, ALL DATA will be removed.	
Click "Next" to continue.	

Click the **Next** button to start the installation.

Samsung Communication Manger is a comprehensive communication solution		
The one of following package will be installed depending on your business sizes in the installation process.		
SCM Express edition is an all-in-one Solution for small and midsize business with smaller IT staffs, delivering Enterprise-level performance. Call control and rich applications are integrated on a single appliance		
with simple management,		
solution for large enterprise with high availability and scalability.		
talling glibc-common-2.5-42.el5_4.3.i386 (63 MB) mmon binaries and locale data for glibc		
talling glibc-common-2.5-42.el5_4.3.i386 (63 MB) mmon binaries and locale data for glibc <u>Release Notes</u>	↓ <u>B</u> ack	⇒ N

 When the installation is complete, eject the DVD and click the **Reboot** button to restart your computer.

Samsung Communication Manager	
Congratulations, the Installation is complete. Remove any media used during the installation process and	
press the "Reboot" button to reboot your system.	
<u>] R</u> elease Notes	💠 Back 🛃 Re

The following directories are created under the /DI directory after installing the SCM.

- BASE: Base components
- CM: The components related to the SIP and the supplementary services
- etc: The shell scripts and other utilities for supporting installation
- HA: The components for redundancy processing
- MP: The components for announcement and mixing processing
- WEBCLI: The components for operation management

After rebooting, should be configured following 3.3 or 3.4 section.

4.3 Configuring Stand Alone Server

After the installation, if you log in with the default administrator account (ID: admin, Password: samsung*#), the setup wizard runs automatically.

The configuration procedure consists of the following steps in sequential order:

- Server Basic Configuration
 - Language setting
 - Keyboard setting
 - Time zone setting
 - Date and time setting
- SCM Software Configuration
 - Database setting
 - IP address setting

4.3.1 Server Basic Configuration

Configure language, keyboard, time zone, and date & time.

4.3.1.1 Language Setting

Select the language to use.

Setup Wizard Language	-
🦻 Please select the default language for the system.	
English (USA) Korean (Republic of Korea) - 한국어	
Belease Note	« Back) » Next

4.3.1.2 Keyboard Setting

Select the keyboard to use.

Setup Wizard Keyboard	
Select the appropriate keyboard for the system.	
Slovakian Slovenian Spanish Swedish Swiss French Swiss French (latin1) Swiss German Swiss German (latin1) Tamil (Inscript) Tamil (Inscript) Tamil (Typewriter) Turkish Ukrainian United Kingdom U.S. English U.S. International	
Belease Note	« <u>B</u> ack » <u>N</u> ext

4.3.1.3 Time Zone Setting

Select the time zone where you are located.



4.3.1.4 Date and Time Setting

Set the date and time.

p Wiza	ard D	ate	& Ti	me				
ase s ate	set th	e dat	e and	l time	for th	ne syst	Time	
Febr	Mon	Tuo	Wed	Thu	Esi	2010 ·	Guireile IIIIe : 05.20.44	
31	1	2	3	4	5	5at	Hour : 5	
7	8	9	10	11	12	13		
14	15	16	17	18	19	20	<u>M</u> inute : 20	•
21	22	23	24	25	26	27		
28	1	2		4	5	6	Second : 34	Ŧ
			10	11	12	13		
ease	Note						**	<u>B</u> ack » 1

4.3.2 SCM Software Configuration

Configure the database and IP addresses for the SCM Software.

4.3.2.1 Database Setting

Edition	Package	The Lot N	Remarks
SCM Express	Standard	0	Requires SCM-S500 server with 4GB DRAM.
	Extended	0	Requires SCM-S500 server with 8GB DRAM. Available in Korea only.
SCM Enterprise	Standard	0	Requires SCM-S500 server with 8GB DRAM.
	Extended	0	Requires SCM-S700 server with 16GB DRAM.
Press the "Yes" but This Operation will	ton to initialize I destroy all DB o	DB. 1ata.	
Press the "Yes" but This Operation will The system may no which has lower sp Are you sure you w	ton to initialize I destroy all DB o of work properly ecification than vant to do this?	DB. Jata. y when the reco	installed on a server commended server.
Press the "Yes" but This Operation will The system may no which has lower sp Are you sure you w Yes	ton to initialize I destroy all DB o t work properly ecification than i vant to do this?	DB. data. y when the reco	installed on a server commended server.
Press the "Yes" but This Operation will The system may no which has lower sp Are you sure you w Yes	ton to initialize I destroy all DB c t work properly ecification than vant to do this?	DB. data. y when the reco	installed on a server commended server.

• Select either SCM Express or SCM Enterprise according to your purchased license.



- Select the country to use. (The system capacity changes depending on the selected country.)
- Click the Yes button to initialize the database.



All the existing data will be deleted when initializing the database.

4.3.2.2 IP Address Setting

To set the IP addresses, you must have the ones assigned by the network administrator.



Before the installation of the SCM, the correct network address must be assigned by the network administrator, and each port (eth0, eth1, and eth2) must be ready to connect to the LAN.

The table below lists the number of IP addresses that need to be assigned on the standalone system configuration.

Category	Need IP Address
Data Link IP	2
System IP	1
Heartbeat IP	None
Component IP	None



When assigning IP addresses to configure the system, their subnet addresses should be set carefully.

- For the data link IP addresses (eth0, eth1), their subnet addresses must be identical.
- For the data link IP addresses of the active and standby systems, their subnet addresses must be also identical.
- For the system IP addresses of the active and standby systems, their subnet addresses must be identical.
- For the heartbeat IP addresses of the active and standby systems, their subnet addresses must be identical.
- For the data link IP address, system IP address, and heartbeat IP address, their subnet addresses must be different from each other.

4.3.2.3 Selecting the Installation Mode

Select the SCM installation mode appropriate for your system configuration. You can select either a standalone or high availability (HA-Active, HA-Standby) configuration.

Setup Wizard IP Addresses		
Standalone System Standalone Standalone	Active System U HA - Active	Active System U HA - Standby
Belease Note	tion not appropriate to your lice	<u>« Back</u> » Next nse, the system does not

NOTE

4.3.2.4 Checking the LAN Ports

Remove all LAN cables from the system. Then connect one at a time and click the **Check** button. Through this process, you can identify port connections for the LAN cards.

Setup Wizard IP Addresses	
Standalone System Data Link IP () Same network address area	Step1 : Please remove all LAN cables from the system. Step2 : Please check network links. eth0 Check eth0 Link : yes eth1 Check eth1 Link : yes
eth0:1 or eth1:1 System IP 🔮 Physical IP 📓 Ethernet Virtual IP	
Belease Note	« <u>B</u> ack » <u>N</u> ext
4.3.2.5 Entering IP Addresses

Enter the network information for your system configuration.

Setup Wizard IP Addresses	
Please set the IP addresses for the system.	
Standalone System Data Link IP () Same network address area	[Data Link IP] Prefix(Netmask) eth0 . . eth1 . . [System IP] Prefix(Netmask) IP Address Prefix(Netmask) . . . IP Address Prefix(Netmask) . . . IP Address Prefix(Netmask)
eth0:1 or eth1:1 System IP	[Host Name]
 Physical IP III Ethernet Virtual IP 	
Belease Note	« <u>B</u> ack » <u>N</u> ext

ltem	Description
Data Link IP	- eth0: Enter the IP address of eth0.
	- eth1: Enter the IP address of eth1.
	- Netmask: Enter '255.255.255.0'.
	The subnet addresses of eth0 and eth1 must be identical.
System IP	- IP Address: Enter the IP address that the SCM will use.
	- Netmask: Enter the netmask that the SCM will use.
Default Gateway	Enter the gateway address.
Host Name	Enter the host name of the SCM.

	Warning
	If all network links are not active, the system does not operate properly. Do you want to proceed?
	• No • Yes
the next step.	s as shown below. Concertate port error and their p
	Warning



4.3.2.6 Finishing the Configuration

When the configuration is completed, click the **Reboot** button to restart your computer. If a configuration value is incorrect, you can click the **Back** button to correct it.



4.4 Configuring High Availability Service

After the installation, if you log in with the initial administrator account (ID: admin, Password: samsung*#), the setup wizard runs automatically.

The configuration procedure consists of the following steps in sequential order:

- Server Basic Configuration
 - Language setting
 - Keyboard setting
 - Time zone setting
 - Date and time setting
- SCM Software Configuration
 - Database setting
 - IP address setting

In case of High Availability Service System, each Active system and Standby system will be configured following above courses.

4.4.1 Server Basic Configuration

Configure language, keyboard, time zone, and date & time.

4.4.1.1 Language Setting

Select the language to use.

Setup Wizard Language	
😚 Please select the default language for the system.	
English (USA) Korean (Republic of Korea) - 한국어	
Belease Note	« <u>B</u> ack) » <u>N</u> ext

4.4.1.2 Keyboard Setting

Select the keyboard to use.

Setup Wizard Keyboard	
Select the appropriate keyboard for the system.	
Slovakian Slovenian Spanish Swedish Swiss French Swiss French (latin1) Swiss German Swiss German (latin1) Tamil (Inscript) Tamil (Inscript) Tamil (Typewriter) Turkish Ukrainian United Kingdom U.S. English U.S. International	
Belease Note	« Back » Next

4.4.1.3 Time Zone Setting

Select the time zone where you are located.



4.4.1.4 Date and Time Setting

Set the date and time.

p Wiz	ard D	ate	& Ti	me			-	
ease <u>D</u> ate • Feb	set th ruary	e dat	e and	l time	for th	ne sys	Time Current Time	05:20:44
Sun 31	Mon 1	Tue 2	Wed 3	Thu 4	Fri 5	Sat 6	Hour	5
7 14	8 15	9 16	10 17	11 18	12 19	13 20	Minute	20
21 28 7	22 1	23 2 9	24 3	25 4 11	26 5 12	27 6 13	<u>S</u> econd	34
elease	Note							« <u>B</u> ack » <u>N</u>

4.4.2 SCM Software Configuration

Configure the database and IP addresses for the SCM Software.

4.4.2.1 Database Setting

Edition	Package		Remarks
SCM Express	Standard	0	Requires SCM-S500 server with 4GB DRAM.
	Extended	0	Requires SCM-S500 server with 8GB DRAM. Available in Korea only.
SCM Enterprise	Standard	0	Requires SCM-S500 server with 8GB DRAM.
	Extended	0	Requires SCM-S700 server with 16GB DRAM.
which has lower sp	ecification than t vant to do this?	he rec	ommended server.
Are you sure you w			
 Yes 			
 Yes 			
 Yes 			

1) Select either SCM Express or SCM Enterprise according to your purchased license.



If you select the edition not appropriate to your license, the system does not operate.

- 2) Select the country to use. (The system capacity changes depending on the selected country.)
- 3) Click the Yes button to initialize the database.



All the existing data will be deleted when initializing the database.

4.4.2.2 IP Address Setting

To set the IP addresses, you must have the ones assigned by the network administrator.



Before the installation of the SCM, the correct network address must be assigned by the network administrator, and each port (eth0, eth1, and eth2) must be ready to connect to the LAN.

The table below lists the number of IP addresses that need to be assigned on the high availability system configuration.

Catagory	High Availability (HA)			
Category	Active	Standby		
Data Link IP	2	2		
System IP	1	1		
Heartbeat IP	1	1		
Component IP		1		



When assigning IP addresses to configure the system, their subnet addresses should be set carefully.

- For the data link IP addresses (eth0, eth1), their subnet addresses must be identical.

For the data link IP addresses of the active and standby systems, their subnet addresses must be also identical.

- For the system IP addresses of the active and standby systems, their subnet addresses must be identical.
- For the heartbeat IP addresses of the active and standby systems, their subnet addresses must be identical.
- For the data link IP address, system IP address, and heartbeat IP address, their subnet addresses must be different from each other.

4.4.3 Configuring HA-Active Server

4.4.3.1 Selecting the Installation Mode

Select the SCM installation mode appropriate for your system configuration. You can select either a standalone or high availability (HA-Active, HA-Standby) configuration.

Setup Wizard IP Addresses		
Standalone System	Active System U U U U HA - Active	Active System U HA - Standby
📓 Ethernet Ethernet 💼 Server		« <u>B</u> ack » <u>N</u> ext



NOTE

4.4.3.2 Checking the LAN Ports

Remove all LAN cables from the system. Then connect one at a time and click the **Check** button. Through this process, you can identify port connections for the LAN cards.

	Step1 : Please remove all LAN cables from the system.
Heartbeat IP (Cross cable) Active System	Step2 : Please check network links.
Data Link IP P Same network	eth0 Check eth0 Link : yes
address area	eth1 Check eth1 Link : yes
eth0:1 or eth1:1 eth0:1 or eth1:1 System IP 😵 Same network address area	eth2 Check eth2 Link : yes
eth0:2 or eth1:2 Component IP 😲	

4.4.3.3 Entering IP Addresses

Enter the network information for your system configuration.

Setup Wizard IP Addresses		
Please set the IP addresses for the system.	[Data Link IP] IP Address eth0 eth1 IP Address ACT STB STB [System IP] IP Address ACT STB [Component IP] Component IP] Default Gateway Host Name	Prefix(Netmask)
Virtual IP	Host Name	(« <u>B</u> ack) » Next

ltem	Description
Data Link IP	- eth0: Enter the IP address of eth0.
	- eth1: Enter the IP address of eth1.
	I he subhet addresses of ethu and eth1 must be identical.
Heartbeat IP	- ACT: Enter the heartbeat IP address of the active system.
	- STB: Enter the heartbeat IP address of the standby system.
	- Netmask: Enter '255.255.255.0'.
	The subnet addresses of the active and standby systems must be
	identical.
System IP	- ACT: Enter the system IP address of the active system.
	- STB: Enter the system IP address of the standby system.
	- Netmask: Enter '255.255.255.0'.
	The subnet addresses of the active and standby systems must be
	identical.
Component IP	- IP Address: Enter the IP address that the SCM will use.
	- Netmask: Enter '255.255.255.0'.
Active System	- Default Gateway: Enter the gateway address.
	- Host Name: Enter the host name of the active system.
Standby System	Enter the host name of the standby system.

Ш

	Warning
	If all network links are not active, the system does not operate properly. Do you want to proceed?
- If you install the message appea	No Yes SCM when there is an error in the LAN port, the warning rs as shown below. Correct the port error and then proce
- If you install the message appea the next step.	No Yes SCM when there is an error in the LAN port, the warning rs as shown below. Correct the port error and then proce Warning
- If you install the message appea the next step.	No Yes SCM when there is an error in the LAN port, the warning rs as shown below. Correct the port error and then proce Warning Network connection is incorrect.



4.4.3.4 Finishing the Configuration

When the configuration is completed, click the **Reboot** button to restart your computer. If a configuration value is incorrect, you can click the **Back** button to correct it.

Setup Wizard Finish	
Congratulations, the setup	is complete.
press the "Reboot" button to rel	boot your system.
Belease Note	« <u>B</u> ack » <u>R</u> eboot

4.4.4 Configuring HA-Standby Server

4.4.4.1 Selecting the Installation Mode

Select the SCM installation mode appropriate for your system configuration. You can select either a standalone or high availability (HA-Active, HA-Standby) configuration.

Setup Wizard IP Addresses		
Standalone System Standalone Standalone	Active System System Unit of the standby System Unit of the standby System Unit of the standby System HA - Active	Active System System HA - Standby
<u>Release Note</u>		« <u>B</u> ack » <u>N</u> ext
f you select the edi	tion not appropriate to your lice	nse, the system does not

If you select the edition not appropriate to your license, the system does no operate.

NOTE

4.4.4.2 Checking the LAN Ports

Remove all LAN cables from the system. Then connect one at a time and click the **Check** button. Through this process, you can identify port connections for the LAN cards.

	Step1 : Please remove all LAN cables
Heartbeat IP (Cross cable) Active System	Step2 : Please check network links.
Data Link IP e Same network	eth0 Check eth0 Link : yes
address area	eth1 Check eth1 Link : yes
eth0:1 or eth1:1 eth0:1 or eth1:1 Same network address area	eth2 Check eth2 Link : yes
eth0:2 or eth1:2 Component IP 😻	

4.4.4.3 Entering IP Addresses

Enter the network information for your system configuration.

Please set the IP addresses for the system.		
Heartbeat IP (Cross cable) Active Standby System Data Link IP (P) Same network address area eth0:1 or eth1:1 eth0:1 or eth1:1 Ethernet	[Data Link IP] IP Address eth0 eth1 [Heartbeat IP] IP Address ACT STB [System IP] IP Address ACT STB [Component IP] Host Name [Standby System] Default Gateway Hust Name	Prefix(Netmask) · · Prefix(Netmask) · · Prefix(Netmask) · · · · · · · · · · · · · · · · · · · · · · · · · · · ·

Item	Description
Data Link IP	- eth0 IP Address: Enter the IP address of eth0.
	- eth1 IP Address: Enter the IP address of eth1.
	- Netmask: Enter '255.255.255.0'.
	The subnet addresses of eth0 and eth1 must be identical.
Heartbeat IP	- ACT IP Address: Enter the heartbeat IP address of the active system.
	- STB IP Address: Enter the heartbeat IP address of the standby system.
	- Netmask: Enter '255.255.255.0'.
	The subnet addresses of the active and standby systems must be identical.
System IP	- ACT IP Address: Enter the system IP address of the active system.
	- STB IP Address: Enter the system IP address of the standby system.
	- Netmask: Enter '255.255.255.0'.
	The subnet addresses of the active and standby systems must be identical.
Component IP	- IP Address: Enter the IP address that the SCM will use.
	- Netmask: Enter '255.255.255.0'.
Active System	Enter the host name of the active system.
Standby System	- Default Gateway: Enter the gateway address.
	- Host Name: Enter the host name of the standby system.





If the network information is not provided, the warning message appears as shown in the figure below. If the network information is configured incorrectly, the system may not operate properly.



4.4.4.4 Finishing the Configuration

When the configuration is completed, click the **Reboot** button to restart your computer. If a configuration value is incorrect, you can click the **Back** button to correct it.



4.5 Updating SCM Server Software

This chapter describes the procedure for updating SCM software.



When updating the SCM software, all the services of the SCM stop. When the upgrade is complete, the SCM restarts automatically.



To upgrade SCM Express software, you should upload upgrade files to SCM server by using USB memory stick. Next you can execute upgrade program on SCM server. The reason upgrade program should be executed on SCM server is that the Linux system do not allow you to execute programs on USB memory stick because of security.

4.5.1 Updating Stand Alone System

For standalone configuration, you can perform a updating as follows:

1) Store the package directory in your USB memory stick.



2) Login as root user by using the keyboard and mouse that is connected to the SCM server.

- 3) Insert the USB memory stick into the SCM server
- 4) Double-click a USB memory icon on the Linux desktop.



5) Click a directory stored in the USB memory and click right button of mouse. And select 'Copy' menu.

1				dis	ik			
<u>F</u> ile	<u>E</u> dit	<u>V</u> iew	<u>P</u> laces	<u>H</u> elp				
20	010120	01_SCM 0.0	IE_3.					
📁 di	sk 🔻	"20101	201_SCN	E_3.1.0.0" sel	ected (con	taining 24 item	s)	

6) Double-click a 'scm_packages' directory icon on the Linux desktop.



 Click right button of mouse in 'scm_packages' directory window. And select 'Paste' menu. So the package directory stored in the USB memory will be copied into the 'scm_packages' directory.



8) After copy, double-click the package directory. And double-click 'start_upgrade.sh' executable file.



9) Click 'Run in terminal' button.



10) Enter 'yes' if you want to update SCM software. Updating is progressed as follow. And system will reboot if all procedure is done.

Terminal	
<u>F</u> ile <u>E</u> dit <u>V</u> iew <u>T</u> erminal Ta <u>b</u> s <u>H</u> elp	
This program will upgrade scm express software.	
Will you execute ? (yes/no) yes	
Upgrade Started	
Backup current package	
Upgrading SCM Express Software	
warning: compat-openldap-2.3.43_2.2.29-3.el5.i386.rpm: Header V3 DSA signature: NC	KEY,
key ID e8562897	
package compat-openidap-2.3.43_2.2.29-3.el5.1386 is already installed	2007
warning: unixobbl-2.2.11-7.1.1360.1pm: neduer v5 DSA signature: NORET, key 1D e650	2897
warning: unixODBC-devel-2 2 11-7 1 i386 rpm: Header V3 DSA signature: NOKEY key 1	(D e85
62897	
package unixODBC-devel-2.2.11-7.1.i386 is already installed	
warning: java-1.6.0-openjdk-1.6.0.0-1.7.b09.el5.i386.rpm: Header V3 DSA signature:	NOKE
Y, key ID e8562897	
package java-1.6.0-openjdk-1.6.0.0-1.7.b09.el5.i386 is already installed	
warning: qt-3.3.6-23.el5.i386.rpm: Header V3 DSA signature: NOKEY, key ID e8562897	/
package qt-3.3.6-23.el5.i386 is already installed	
warning: openssl097a-0.9.7a-9.el5_2.1.i386.rpm: Header V3 DSA signature: NOKEY, ke	y ID
e8562897	
package openssl097a-0.9.7a-9.el5_2.1.1386 is already installed	
package expect-5.42.1-1.1386 is already installed	=
package postgresql-libs-8.1.18-2.el5_4.1.1386 is already installed	
package postgresgl-devel_8 1 18-2 el5 4 1 1386 is already installed	
package postgresgl-dever-0.1.10-2.205_4.1.1500 is already installed	
package postgresqt server 0.1.10-2.ets_4.1.1500 is atleady instatted	
•	-

4.5.2 Updating High Availability System

For high availability configuration, you can perform a updating as follows:

1) Store the package directory in your USB memory stick.



- 2) Login as root user by using the keyboard and mouse that is connected to the standby SCM server.
- 3) Double-click a 'Stop SCM' icon on the Linux desktop. And you have standby SCM stopped.



- 4) Login as root user by using the keyboard and mouse that is connected to the active SCM server.
- 5) Double-click a 'Stop SCM' icon on the Linux desktop. And you have active SCM stopped.



6) Insert the USB memory stick into the active SCM server

7) Double-click a USB memory icon on the Linux desktop.



8) Click a directory stored in the USB memory and click right button of mouse. And select 'Copy' menu.

1				disk	
<u>F</u> ile	<u>E</u> dit	<u>V</u> iew	<u>P</u> laces	Help	
20	10120	21_SCM	IE_3.	Πch	
📁 di	sk 🔻	"20101	201_SCN	E_3.1.0.0" selected (containing 24 items)	

9) Double-click a 'scm_packages' directory icon on the Linux desktop.



10) Click right button of mouse in 'scm_packages' directory window. And select 'Paste' menu. So the package directory stored in the USB memory will be copied into the 'scm_packages' directory.



- P 20101201_SCME_3.1.0.0 X <u>File Edit View Places H</u>elp backup_package.sh compat-openIdap-2. expect-5.42.1-1. db_upgrade 3.43_2.2.29-3.el5. i386.rpm i386.rpm 5. install_previous_ inst_scm_debug_ java-1.6.0-openjdkinstall.sh 1.6.0.0-1.7.b09.el5. package.sh info_bin.sh i386.rpm list_upgrade_sql.sh minicli-1.0-1.0.i386. minicli-ipv6-1.0-1.0 openssl097a-0.9.7arpm i386.rpm 9.el5_2.1.i386.rpm postgresql-libs-8.1. postgresql-devel-8.1. postgresql-8.1.18-2. postgresql-server-8. el5_4.1.i386.rpm 18-2.el5 4.1.i386. 18-2.el5 4.1.i386. 1.18-2.el5 4.1.i386. rpm rpm rpm qt-3.3.6-23.el5.i386 scm_debug_info_ samsung rpm callmanager-3.1-0.0 bin.tar.gz i386.rpm --------20101201_SCME_3.1.0.0
 start_upgrade.sh" selected (163 bytes)
- 12) Click 'Run in terminal' button.



11) After copy, double-click the package directory. And double-click 'start_upgrade.sh' executable file.

13) Enter 'yes' if you want to update SCM software. Updating is progressed as follow. And system will reboot if all procedure is done.

Terminal .	
<u>F</u> ile <u>E</u> dit <u>V</u> iew <u>T</u> erminal Ta <u>b</u> s <u>H</u> elp	
This program will upgrade scm express software.	
Will you execute ? (yes/no) yes	
upgrade started Backup current package	
Upgrading SCM Express Software	
warning: compat-openidap-2.3.43_2.2.29-3.el5.i386.rpm: Header V3 DSA signature: NOK key ID e8562897	ΞEY,
package compat-openldap-2.3.43_2.2.29-3.el5.i386 is already installed warning: unixODBC-2.2.11-7.1.i386.rpm: Header V3 DSA signature: NOKEY, key ID e8562 package unixODBC-2.2.11-7.1.i386 is already installed	897
warning: unixODBC-devel-2.2.11-7.1.i386.rpm: Header V3 DSA signature: NOKEY, key ID 62897	e85
package unixODBC-devel-2.2.11-7.1.i386 is already installed warning: java-1.6.0-openjdk-1.6.0.0-1.7.b09.el5.i386.rpm: Header V3 DSA signature:	NOKE
Y, key ID e8562897	
warning: qt-3.3.6-23.el5.i386.rpm: Header V3 DSA signature: NOKEY, key ID e8562897	
warning: openssl097a-0.9.7a-9.el5_2.1.i386.rpm: Header V3 DSA signature: NOKEY, key e8562897	ID
package openssl097a-0.9.7a-9.el5_2.1.i386 is already installed	
package expect-5.42.1-1.i386 is already installed	=
package postgresql-libs-8.1.18-2.el5_4.1.i386 is already installed	
package postgresql-8.1.18-2.el5_4.1.i386 is already installed	
package postgresql-devel-8.1.18-2.el5_4.1.1386 is already installed	
package posigresql-server-8.1.18-2.et5_4.1.1386 is already installed	v

Insert the USB memory stick into the standby SCM server. And proceed to update as you do active server

CHAPTER 5. Installing Ubigate iBG Series Gateways

5.1 Preparing SCM Server

To have Gateways interoperate with SCM, the following items must be configured for SCM server.

Creating Gateway Link

You must register the Gateway to interoperate with SCM using the [CONFIGURATION > Gateway] menu.

File Tool Tab Dialog	ng Help	🖀 Server165,213,80,187 💄 Useradmin 🛛 EvelENGINEERING
AT		
SCM Administra	rator 🔳 🛍 🖳 🖼 🎦	
CONFIGURATION	Gateway Link Setting Process System Options Call Management Call	Frace Registration Status Service Activation
	User Group	Name
Location	Gateway Type	
User Gloop	IDIALOG]Gateway Link Setting - Change	
Trunk Bouting	User Group UG1 Vame	gw2006
Time Schedule	Gateway Type IB G2006	
Service	IP Address(for SIP register) IP Address(for Pi	rovision)
🗄 Wireless Enterprise	NAT Enable Public IP Add	ress
Application	URL Gateway Reco	nnect
Phone Setting	[Selected]	
Announcement	2000 2002	
Miscellaneous	2001 2003 2004	
🖯 Gateway	2005	
Gateway Link Setting	9 2006	
Ubigate Slot Setting	2007 2008	
Ubigate Port Setting	2009	
Active/Active Redundance	2010 2011	
	2012	
System Viewer	* *	Search
System: scme-ymc-51	Survivability Users - FXS	
Status: Active Alone	[All]	
Alarm: CRI (0) MAJ (1)	3000 3004 3004 3005	
CPU Memory F	F 3002 3006	
	3003 3007	
	₩ 3009	
	Characterized Characterized	
	Change Apply Close	

ltem	Description		
User Group	Specify a user group which will be assigned to Gateway.		
Name	Enter a name for Gateway.		
Gateway Type	Enter a model type for Gateway.		
IP Address (for SIP register)	Enter the IP address of Gateway for SIP registration.		
IP Address (for Provision)	Enter the IP address of Gateway for provision. Generally this should be same address for SIP register.		
NAT	If the gateway is running under NAT, Enables this option.		
Public IP Address	When the gateway is running under NAT, enter the public IP address of Gateway.		
Survivability Users-SIP	This is the list of SIP phones for survivability to allocate to the voice gateway. When SCM creates the profile for a SIP phone, it includes the IP address and the port of the interoperating gateway in survival mode. When the SIP phone is disconnected from SCM, it sends a register message to the gateway included in the profile.		
Survivability Users-FXS	This is the list of FXS phones of the voice gateway. If the gateway type is Ubigate iBG, this item is not selective list.		

Table 16. Creating	Gateway Link
--------------------	--------------

SCM provides the survivable telephony support service, whereby, when an IP phone is disconnected from SCM, the phone is connected to the gateway for minimum PBX features. The survival feature really works by the gateway and the IP phone and not by SCM. Generally, it is usually used not when there is a problem with SCM but when the IP network between the IP phone and SCM experiences a trouble, especially when the phone and SCM are in different locations.

Ubigate iBG and OfficeServ 7000 series used as gateways for SCM support both the survival mode and the SCM interoperation mode.

Survivable Telephony Mode

When SCM's gateway is interoperating with SCM, if the gateway determines that the IP network with SCM is disconnected, it uses the service profiles downloaded from SCM for the FXS subscribers and SIP phone subscribers to continue to provide gateway's native call processing services.

In particular, Ubigate iBG and OfficeServ 7000 series use the SIP phone subscriber service profile downloaded from SCM to automatically configure dial-peer for processing incoming calls for SIP phones and authenticates SIP phones in order to make calls and provide supplementary services.

Ubigate iBG and OfficeServ 7000 series periodically (30 seconds by default) send Register messages to SCM. If it receives a 200 OK response, it enters the SCM interoperation mode again.

Supplementary Service on Survival mode

Ubigate iBG and OfficeServ 7000 series service following features only on survival mode.

Service	Description
Call Forward	Call Forward All, Busy and No Answer
Hold/Resume	-
Transfer	Consultation and Blind Transfer
DND	Do Not Disturb
Conference	Conference On Answer Only
Call Waiting	-
Call Pickup	Direct and Group Call Pickup
МОН	Music On Hold

Table 17. Supplementary Service on Survival mode

5.2 Ubigate iBG series Hardware

The Ubigate iBG series are available for the voice gateway of SCM Express, and can be used following models.

Model	FXS	FXO	T1/E1	SIP Phone (Survivability)
iBG3026	60	28	4	256
iBG2016	40	24	4	128
iBG2006	16	16	2	64
iBG1003	16	2	2	50

Table 18. Voice Port Capacity of iBG series

For further information on installation, please refer to the installation manuals dedicated to the each IBG systems provided separately

5.3 Ubigate iBG series Software

5.3.1 Configuring Gateway System

Following example shows the commands used verify the gateway version.

Router# show version				
Kernel	: WIND version 2.6.			
Boot	: 1.0.7 (NORMAL Boot)			
System	: R2 2.0.1			
Created	: Apr 3 2007, 05:40:10			
Bld Path	: "/home1/build	/release	e/u2rel_2.0.1/srd	2"
Ву	: build			
SNOS class	: Advanced SNOS			
Including fea	tures : Secur	ity Voic	e	
NorBoot	: 1.0.7			
GolBoot	: 1.0.4			
Slot/SubSlot	Card-Type	Status	FPGA-Rev	CPLD-Rev
				0.00
0/-	MPU-A	NORMAL	0x08	0x02
0/0	WTE-2SM	NORMAL	N/A	0x00
0/1	FXS-4M	NORMAL	N/A	0x15
0/2	T1E1-1M	NORMAL	N/A	0x17
1/-	VCU-A	NORMAL	N/A	0x07
1/0	FXS-4M	NORMAL	N/A	0x14
1/1	BRI-2U	NORMAL	N/A	0x0e
2/-	T1E1-4	NORMAL	N/A	0x0c
3/-	ESG-8	NORMAL	N/A	0x06
	LDU-A	NORMAL	N/A	N/A
	VOP-128	NORMAL	N/A	0x35

How to Configure IP address

Configuration Steps

- configure terminal
- interface
- ip address
- exit

Step	Command	Purpose
1	configure terminal	Enters global configuration mode.
	Example)	
	# configure terminal	
2	Interface type number	Enters interface configuration mode to
		configure specific interface.
	Example)	
	/configure# interface Ethernet 0/0	
3	ip address ip_address subnet_mask	Configure a IP Address for an
		interface.
	Example)	
	/configure/interface/ethernet (0/0)# ip address	
	90.90.90.90 255.255.255.0	
4	exit	Exits the current mode
	Example)	
	/configure/interface/ethernet (0/0)# exit	

Configuring Static Routes

Static routes are specified by adding and deleting route entries to and from the route table. This section shows how to add a route entry.

Following steps show the way to add a route entry.

Step	Command	Purpose
1	Router# configure terminal	Enters the terminal configuration mode.
2	Router/configure# ip route [network] [mask] {address interface}	Adds a routing entry
	Or	
	Router/configure# ip route [network]/[number of bit mask] {address interface}	

To delete a route entry, just add the key word 'no' in front of the command that have added it. Following figure illustrates a simple network configuration.



Following example shows the way to add a routing entry in the figure. Router# configure terminal Router/configure# ip route 165.213.100.0 255.255.255.0 165.213.89.238 or Router# configure terminal Router/configure# ip route 165.213.100.0/24 165.213.89.238 To delete the entry, simply add 'no' just as follows. Router# configure terminal Router/configure# no ip route 165.213.100.0 255.255.255.0 165.213.89.238 or Router# configure terminal Router# configure terminal Router# configure terminal Router# configure# no ip route 165.213.100.0/24 165.213.89.238

5.3.2 Connecting to Network

This section describes how to configure source IP address for VoIP gateway. With this feature, you can specify the source address of SIP and H323 signaling, and media stream-RTP/RTCP. You can assign an existing IP address on a specific interface by the 'bind' command or create a new IP address by the 'host ip-address' command. The interfaces which you can bind with as the source address of VoIP signaling and media stream are Ethernet, bundle, VLAN, and virtual-access interface. The 'host ip-address' command will create a new IP address.

VoIP gateway must be shut down before setting the VoIP source address. Interface bound with VoIP-gateway cannot be removed before VoIP-gateway unbinds the interface.

shutdown voip-gateway

VoIP gateway must be shutdown before set the IP address of VoIP gateway, follows next procedures.

Configuration Steps

- configure terminal
- voip-gateway
- shutdown
- exit

Step	Command	Purpose
1	configure terminal	Enters global configuration mode.
	Example) # configure terminal	
2	voip-gateway	Enters voip-gateway configuration mode.
	Example)	
	/configure# voip-gateway	
3	shutdown	Shuts down voip call services
	Example)	
	/configure/voip-gateway# shutdown	
4	exit	Exits the current mode
	Example)	
	/configure/interface/ethernet (0/0)# exit	

bind interface

To bind the interface for source address of VoIP signaling and media, follow next procedures.

Configuration Steps

- configure terminal
- voip-gateway
- bind control
- bind media
- exit

Step	Command	Purpose
1	configure terminal	Enters global configuration mode.
	Example)	
	# configure terminal	
2	voip-gateway	Enters voip-gateway configuration mode.
	Example)	
	/configure# voip-gateway	
3	bind control interface type num	Sets source interface for SIP and H.323.
	Example)	
	/configure/voip-gateway# bind control interface ethernet 0/0	
4	bind media interface type num	Sets source interface for media -
	Example)	RTP/RTCP.
	/configure/voin-gateway# bind control interface	
	ethernet 0/0	
5	exit	Exits the current mode
	Example)	
	/configure/voip-gateway# exit	
host domain-name

VoIP gateway must have a domain name. 'samsung.com' or IP address form should be used. Configuration Steps

- configure terminal
- voip-gateway
- host domain-name
- exit

Step	Command	Purpose
1	configure terminal	Enters global configuration mode.
	Example) # configure terminal	
2	voip-gateway	Enters voip-gateway configuration mode.
	Example)	
	/configure# voip-gateway	
3	host domain-name DOMAIN.COM	Sets domain name for Ubigate iBG
	Example)	
	/configure/voip-gateway# host domain-name	
	samsung.com	
4	exit	Exits the current mode
	Example)	
	/configure/voip-gateway# exit	

5.3.3 Connecting to PSTN

To allow interoperation between Ubigate iBG series and SCM, the following information must be configured. You can use the SCM Administrator and modify the information for Ubigate iBG series.

5.3.3.1 Configuring Slot Setting

This section describes the configuration of Slot Setting.

Selects a Gateway which you want to configure in the following window, and press change button and select change.

Selects a Slot Configuration item and choose a card type properly.

Slot State indicates actual card equipment state. This state can be updated by receiving information from the gateway.

If necessary, change following configurations for the gateway.

ISCM Administrator]				1.0						_ D X
File Tool Tab Dial	og Help						🔚 Server16	521380,187 💄	Useradmin 目 Lev	elengineering
SCM Administ	trator 🗉	Å.	P 🔁	*	-	-	-	-		
CONFIGURATION		FXO (Analog	Trunk) FXS	(Analog Phone)	iBG2006/2016	/3026 Gate	way Link Setting	Route	Main Monitor	
		Us	er Group			-	Gateway Name	, _		▼
Wireless Enterprise	_				Search	Clear	Reset			
Application		User Group	Gateway Nan	ne Gateway Type	Country	S1(0/0)	S1(0/0) State	e S2(0/1)	S2(0/1) State	S3(0/2)
Phone Setting		UG1	UG1-GW1	18G2006	Korea	FXS-4M	0	FXO-4M	0	T1E1-2M
Announcement			-							
Miscellaneous	E [DIALOG]IB	G2006/2016/3026	- Change							
🗆 Gateway	L L	Jser Group	UG1			•	Sateway Name	UG1-GW	1	_
Gateway Link Sett	Ga	ateway Type	IBG2006			Lo	ocated Country	Korea		<u> </u>
🗆 Ubigate Slot Settir	Slot S1((0/0) Configuration	FXS-4M			SI SI	ot S1(0/0) State			
iBG2006/2016/3	Slot S2	(U/1) Configuration	FXO-4M				ot S2(U/1) State			<u> </u>
iBG1003/1004	Slot SA	(0/2) Configuration	None])] (1	ot S3(0/2) State			
🗆 Ubigate Port Setti	Slot NM	(1) Configuration	None				of NM1(1) State			
PRI Trunk	Slot NM	2(2) Configuration	None			l si	ot NM2(2) State			
FX0 (Analog T		FAX Relay	None			1	DTMF Relay	Inband		
FXS (Analog P		wedia Type	RTP		•	Ĩ	T1/E1 Select	E1		-
MCN (Survival I	Use Di	version User Info	Disable]				
					Change A	pply Cl	ose			

FAX Relay

To selects type of FAX relay for the gateway, use the 'FAX relay' menu in Slot Setting configuration window.

- T38 redundancy 0: Using T38 fax relay with redundancy number 0.
- T38 redundancy 1: Using T38 fax relay with redundancy number 1.
- T38 redundancy 2: Using T38 fax relay with redundancy number 2.
- T38 redundancy 3: Using T38 fax relay with redundancy number 3.
- Path-through g.711 U-law: Using Path-through g.711 U-law fax relay.
- Path-through g.711 A-law: Using Path-through g.711 A-law fax relay.

DTMF Relay

To selects type of DTMF relay for the gateway, use the 'DTMF relay' menu in Slot Setting configuration window.

- Inband: inband.
- SIP Notify: SIP NOTIFY method.
- SIP Info: SIP INFO method using named events.
- SIP Info-digits: SIP INFO method using decimal number.
- RFC2833: Out-of-band 2833 (RTP-NTE)

Media Type

To selects type of RTP media type for the gateway, use the 'Media Type' menu in Slot Setting configuration window.

- RTP: RTP
- SRTP-AES: SRTP using AES Counter Mode.
- SRTP-ARIA: SRTP using ARIA counter Mode.
- SRTP-ARIA-AES: SRTP using ARIA and AES.

T1/E1 Select

To selects carrier-type of T1/E1 for the gateway, use the 'T1/E1 Select' menu in Slot Setting configuration window. If this value is different with the gateway configuration, the gateway will reboot to change carrier-type of T1/E1.

- E1
- T1

Diversion Userinfo Select

Select to whether to use the userinfo (sip:userinfo@domain) of Diversion header as Caller ID.

- disable
- enable

5.3.3.2 Configuring FXS ports

This section describes the configuration of analog FXS voice ports.

Selects an FXS port which you want to configure in the following window, and press change button and select change.

Change configurations of the FXS port, in the following window you can change items except User Group, Slot/Port and Gateway Name.

8 [SCM Administrator]	•							1.1	·	– – X
File Tool Tab Dialo	g Help						🔚 Server16	5213,80,187	💄 Useradmin 📒	LevelENGINEERING
scм Administ	rator 🗖	- ⁴ 1 - 1	o D	2	_		-		-	
CONFIGURATION		FXO (Analog	Trunk) FXS (#	Analog Phone)	iBG2006/2016/3026	Gatewa	y Link Setting	Route	Main Monitor	·]
		Use	er Group		[-	Gateway Name			•
🕀 Wireless Enterprise	-				Search (lear	Reset			
Application		User Group	Gateway Name	Slot/Port	Extension Nu., Mes	sage Wai	CID Send	CID Sign	al Ty., Polarity	Reve Loop Open
Phone Setting		UG1	UG1-GW1	0/0/0	Dise	ble	Disable	FSK	Disable	Disable
Announcement		001		0/0/1	Dise	LUIE	Disable	FOR	Disable	Disable
Miscellaneous	😹 [DIALOG]F	XS (Analog Phone) - Change	-		_		-	in the second second	
🗆 Gateway		User Group	UG1		-	Ga	teway Name	UG1	I-GW1	
Gateway Link Settin		Slot/Port	0/0/0		-	Exte	nsion Number			
Ubigate Slot Setting	Messag	e Waiting Indicati	on Disable				CID Send	Dise	able	
iBG2006/2016/302	C	D Signal Type	FSK		-	Polarity	y Reverse Signal	Dise	able	
iBG1003/1004	Loo	p Open Release	Disable		<u> </u>	Call I	Progress Tone	Sys	tem Default	
🖯 Ubigate Port Setting	м	edia Dial Tone	None							
PRI Trunk					Change Apply	/ Clos	se			
FXO (Analog Tru	nk)									
FXS (Analog Pho	one)									
MCN (Survival Mo	ode)									
Active/Active Redundar	ncy									

Message Waiting Indication (MWI)

To enables/disables MWI for a specified FXS voice port, use the 'Message Waiting Indication' menu in FXS port configuration window.

- Disable: Disables MWI
- Audible: Enables audible MWI
- Visible: Enables visible MWI

CID Signal Type

To selects type of caller ID for a specified FXS voice port, use the 'CID Signal Type' menu in FXS port configuration window.

- FSK: Using FSK type for sending and receiving the caller ID. This is the most common setting. (default)
- DTMF: Using DTMF type for sending and receiving the caller ID.

Loop Open Release

To enables/disables a supervisory disconnect signal on an FXS port, use the 'Loop Open Release' menu in FXS port configuration window.

Extension Number

To sets extension number of an FXS port, use the 'Extension Number' menu in FXS port configuration window.

CID Send

To enables/disables allowance of sending of caller ID information for a specified FXS port, use the 'CID Send' menu in the FXS port configuration window.

Polarity Reverse Signal

To enables/disables battery polarity reversal function, use the 'Polarity Reverse Signal' menu in the FXS port configuration window.

Call Progress Tone

To specify a regional analog voice-interface-related call progress tone, use the 'Call Progress Tone' menu in the FXS port configuration window.

- Korea
- USA/Canada
- Britain
- Italy
- Germany
- Russia
- Australia

5.3.3.3 Configuring FXO ports

This section describes the configuration of analog FXO voice ports. Selects an FXO port which you want to configure in the following window, and press change button and select change.

Change configurations of the FXO port, in this window you can change items except User Group, Slot/Port, Link State and Gateway Name.

File Tool Tab Dialo	g Help						E Server165	213,80,187 👗	Useradmin 🗏 Leve	IENGINEERING
scм Administ	rator 📕	<u></u>	? 🛯	*	-	-	-	-		
CONFIGURATION		FXO (Analog	Trunk) FXS (/	Analog Phone)	iBG2006/2016/	3026 Gateway	/ Link Setting	Route	Main Monitor	
		Use	er Group			-	Gateway Name			-
🗄 Wireless Enterprise	<u> </u>				Search	Clear	Reset			
Application		User Group	Gateway Name	Slot/Port	Route Name	Destination N.,	CID Receive	CID Signal	Ty., Polarity Reve,	Loop Open
Phone Setting		UG1	UG1-GW1	0/1/0			Disable	FSK	Disconnect	Disable
Announcement		UG1	UG1-GW1	0/1/1			Disable	FSK	Disconnect	Disable
Miscellapeous		UG1	UG1-GW1	0/1/2			Disable	FSK	Disconnect	Disable
		(Analog Trunk) - C	hange	0/1/3			Diseble	FCK	Disconnect	
Gateway Link St		(Analog Hullk) C	luor			0.1		Liot out		
Ubigata Slat Sal	08	er Group	001			Gatewa	iy name	UG1=GW1		
Dolgate Slot Sel	Sector	loveon	U/1/0			CID D	: Name	Disable		<u> </u>
IBG2006/2016	CID S	anon womber	FOR			CID R	eceive Vesse Sienel	Disable		E
iBG1003/1004	CID 3	ngnar rype	Disable			Coll Drog	verse Signal	Sustem De	-1	
Ubigate Port Sei	LUOP O	pell helease	Disable			Call Flog		System De	ndon	Ľ
PRI Trunk					hange App	ly Close				
FXO (Analog Tru	ink)									
FXS (Analog Pho	one)									
MCN (Survival Mo	ode)									
Active/Active Redundar	ncy	•								•
							6	20	24	

Destination Number

To selects destination number of plar, use 'Destination Number' menu in FXO port configuration window. PLARs (switched) connections enable the user to make a call without dialing any digits.

CID Signal Type

To selects type of caller ID for a specified FXO voice port, use the 'CID Signal Type' menu in FXO port configuration window.

- FSK: Using FSK type for sending and receiving the caller ID. This is the most common setting. (default)
- DTMF: Using DTMF type for sending and receiving the caller ID.

Loop Open Release

To enables/disables a supervisory disconnect signal on an FXO port, use the 'Loop Open Release' menu in FXO port configuration window.

Route Name

To selects name of an FXO trunk, use 'Route Name' menu in the FXO port configuration window.

CID Receive

To enables/disables allowance of receiving of caller ID information for a specified FXO port, use the 'CID Receive' menu in the FXO port configuration window.

Polarity Reverse Signal

To enables/disables battery polarity reversal function, use the 'Polarity Reverse Signal' menu in the FXO port configuration window.

- Disconnect: Enables Polarity Reverse Signal to detect disconnect
- Disconnect-Answer: Enables Polarity Reverse Signal to detect disconnect and answer.
- Disable: Disables Polarity Reverse Signal detection.

Call Progress Tone

To specify a regional analog voice-interface-related call progress tone, use the 'Call Progress Tone' menu in the FXO port configuration window.

- Korea
- USA/Canada
- Britain
- Italy
- Germany
- Russia
- Australia

5.3.3.4 Configuring PRI trunk

This section describes the configuration of ISDN-PRI trunks. Selects an ISDN-PRI trunk which you want to configure in the following window, and press change button and select change.

Change configurations of the ISDN-PRI trunk, in this window you can change items except User Group, Slot/Port and Gateway Name.

File Tool Tab Dialog Help							E Server165	213,80,187 👗 U:	seradmin	Level EN	IGINEERING
SCM Administrator		ŝ.	P 🔁	**	-	-	-	-			
CONFIGURATION	PRI T	Frunk 📘	XO (Analog Tru	nk) 🛛 FXS (Ana	alog Phone)	iBG2006/2016/302	6 Gateway L	ink Setting.	Route	Main Mo	nitor
	N	Usi	er Group				Gateway Name				-
Wireless Enterprise					Search	Clear	Reset				
Application	User	r Group	Gateway Name	Slot/Port	Route Name	Sending Com,	PRI Trunk Type	Switch Typ	e Use Ch	annels	
Phone Setting	UGI		UG1-GW1	0/2/0		Disable	TE	NI2	30		
Announcement						0100010					
Miscellaneous											
Gateway	RI Trunk - C	Change									
Gateway Link Se L	User Group)	UG1			Gatewa	ay Name	UG1-GW1			
Ubigate Slot Set	Slot/Port		0/2/0		<u> </u>	Route	Name				
IBG2006/2016, Sen	Switch Type	a	FURO			PRI HU	nk rype	30			Ľ
18G1003/1004	sinten rypi	-	Lono					00			
					nange Ap	ply Close					
EXO (Applag Trupk)		_									_
EXS (Analog Phone)											
MCN (Survival Mode)											
Active/Active Bedundancy											
							Detail C	hange Ex	cel D	etach	Close

Sending Complete

To enables/disables sending complete options parameter, use 'Sending Complete' item in the PRI Trunk-Change window.

Switch Type

To selects switch type, use 'Switch Type' menu in the PRI Trunk-Change window.

- N12
- DMS100
- NTT
- QSIG
- DMS250
- EURO
- CCITT
- 4ESS
- 5ESS
- AUS

Route Name

To selects name of an ISDN-PRI trunk, use 'Route Name' menu in the PRI Trunk-Change window.

PRI Trunk Type

To selects type of PRI trunk, use 'PRI Trunk Type' menu in the PRI Trunk-Change window

- TE
- NT

Use Channels

To sets number of channels, use 'Use Channels' menu in the PRI Trunk-Change window.

5.3.3.5 Configuring MCN

This section describes the configuration of MCN (Survival Mode).

Press Create button to make a MCN rule for survival mode of the gateway. MCN translates an original number into modified number when a call is incoming or outgoing on the specific port. This works only for survival mode of the gateway.

[SCM Administrator]	
File Tool Help	🔡 8 orvor 165.213.66.103 💄 Uborroot 📑 LovolENGMEERING
SCM Administrator	i 🐐 🖳 🖼 🍟
CONFIGURATION	MCN (Survival Mode) iBG2006/2016/3026 Gateway Link Setting PRI Trunk Main Monitor User Group Gateway Name
Time Schedule	Search Clear
E Service	User Group Gateway Name Slot/Port Number Type Original Num, Modified Num,
Application	
Phone Setting	
Announcement S [DIALOG]MCN (S)	rvival Mode) - Create
Miscellaneous User C	roup UG1 🔽 Gateway Name gw1003 🔽
⊟ Gateway Slot/	ort 0/0/0 V Number Type Inbound/DID V
Gateway Lir Original	umber 9010 Modified Number 010
Ubigate Slo	Create Apply Close
iBG2006/2014 0020	
IBG1003/1004	
Digate Port Setting	
EYO (Appleg Trupk)	
EXS (Analog Phone)	
MCN (Survival Mode)	
	Detail Create Change Delete Excel Detach Close
System Viewer	Europh Viewar
3 fstelli viewei	Level Date/Time System Name ID Type Category
System : scm_iot	
Alarm : CBI (0) MAJ (0) MIN (0)	
CPU Memory File	Clear Detach Close
Message	1972-01-04 02:23:00

5.3.4 Connecting to SCM Server

Before setting iBG, you must configure SCM in advance. Here is the essential information to start configuration:

- IP address, port number, and transport type of SCM
- Domain name
- gw-uri name
- FXS subscriber's number and password
- Trunk URI name if it needs to register the trunk

gw-uri is a representative name of Ubigate iBG and SCM maintains iBG as an Endpoint. Domain name of iBG must be same with SCM's configuration.

Check if TCP 8088 port is being used for the management channel.

Timer values such as registration refresh timer and failure retry timer.

Other parameters such as type of DTMF relay, use of Session Timer, list of IP phones that are maintained by iBG when in survivable telephony mode.

You should shutdown voip-gateway before configuring call-server, and the VoIP gateway source address must be set in advance.

You can set the call server in the following ways:

Step	Command	Purpose
1	configure terminal	Enters global configuration mode.
	Example)	
Z	voip-galeway	mode.
	Example)	
	/configure# voip-gateway	
3	shutdown	Shuts down voip call services
4	bind control interface type num	Sets source interface for SIP
	Example)	
	configure/volp-gateway# bind control interface	
5	bind media interface type num	Sets source interface for media
Ū		
	Example)	
	/configure/voip-gateway# bind media interface	
	ethernet 0/0	
6	host domain-name DOMAIN.COM	Sets domain name
	Evample)	

Step	Command	Purpose
	/configure/voip-gateway# host domain-name	
	scme.com	
7	call-server ip-address ip-addr [udp tcp tls] [sip	Sets a SCM IP Address.
	sips] [expires expires] [retry retry]	Expires and retry timer for FXS
		subscribers and trunks may be set.
	Example)	
	/configure/voip-gatway# call-server ip-address	Use voice service SIP global
	ipv4:90.90.90.100	configuration for transport type and uri.
8	call-server ip-address <i>ip-addr</i> [udp tcp tls] [sip	Sets secondary SCM server IP
	sips] [expires expires] [retry retry] secondary	Address.
		Expires and retry timer for FXS
	Example)	subscribers and trunks may be set.
	/configure/voip-gatway# call-server ip-address	
	ipv4:90.90.90.101 secondary	Use voice service SIP global
		configuration for transport type and uri.
9	call-server gw-uri uri [expires expires] [retry retry]	Set gw-uri and Ubigate iBG will
		register to SCM as an Endpoint.
	Example)	Expires and retry timer of GW-URI
	/configure/voip-gateway# call-server gw-uri	may be set.
	iBG2016	
10	no shutdown	Enables voip call services
11	exit	Exits the current mode.
	Example)	
	/configure/voip-gateway# exit	

5.3.5 Updating Gateway Software

The system contains Ubigate SNOS images. Your system already has an image on it when you receive the system. Nevertheless, you may want to load a different image onto the Ubigate system at some point. For example, you may want to upgrade your software to the latest release, or you may want to use the same SNOS release for all the Ubigate systems in a network. Different system images contain different sets of SNOS features.

SNOS Update Procedure

Following steps presume that the storage media to save the new SNOS image is compact flash.

- 1) Verify the amount of free space on the flash memory card.
- 2) Verify that the FTP/TFTP Server has IP Connectivity to the Router.
- 3) Copy the New Image onto the Flash Memory Card Through the FTP/TFTP Server.
- 4) Verify SNOS image's validation.
- 5) Set Boot Parameter to Load the New Image On Startup.
- 6) Reboot the Router to Load the New Image.
- 7) Verify the Upgraded Image Version.

Step	Command	Purpose
1	Router #file	Enters the file mode.
2	Router /file# ls /cf0	Checks free space in compact flash.
3	Router /file#ping 90.90.90.240	Verify Connectivity to ftp/tftp server
4	Router /file# download 90.90.90.240 ftpboot/mpu81/iBG2016_Advanced_2.0.1.Z /cf0/iBG2016_Advanced_2.0.1.Z type ftp	Download from ftp server to compact flash
5	Router /file# ls /cf0	Check downloaded images in compact flash
6	Router /file # version /cf0/iBG2016_Advanced_2.0.1.Z	Verify image's validation
7	Router /file # boot_params	Change boot file name
8	Router# show version	Verify version number

CHAPTER 6. Installing OfficeServ 7000 Series Gateway

6.1 **Preparing SCM Server**

6.2 OfficeServ 7000 series Hardware

The OfficeServ 7000 series are available for the voice gateway of SCM Express, and can be used following models.

Model	FXS	FXO	T1/E1	SIP Phones (Survivability)
OfficeServ 7400 (MP40)	480	256	10	480
OfficeServ 7200 (MP20)	128	64	2	128
OfficeServ 7100 (MP10a)	32	60	2	56
OfficeServ 7070 (MP07)	48	42	1	32

Table 19. Voice Port Capacity of OfficeServ 7000 series

OfficeServ 7400

Detailed installation for the OfficeServ 7400, please refer to the 'OfficeServ 7400 Installation Manual'.

OfficeServ 7200

Detailed installation for the OfficeServ 7200, please refer to the 'OfficeServ 7200 Installation Manual'.

OfficeServ 7100

Detailed installation for the OfficeServ 7100, please refer to the 'OfficeServ 7100 Installation Manual'.

OfficeServ 7070

Detailed installation for the OfficeServ 7070, please refer to the 'OfficeServ 7070 Installation Manual'.

6.3 OfficeServ 7000 series Software

6.3.1 Configuring Gateway System

SCM provides the survivable telephony support service, whereby, when an IP phone is disconnected from SCM, the phone is connected to the gateway for minimum PBX features. The survival feature really works by the gateway and the IP phone and not by SCM. Generally, it is usually used not when there is a problem with SCM but when the IP network between the IP phone and SCM experiences a trouble, especially when the phone and SCM are in different locations.

OfficeServ 7000 series used as gateways for SCM support both the survival mode and the SCM interoperation mode.

6.3.2 Connecting to Network

On the SIO screen connected to OfficeServ 7000 series, enter the ip_help command to view a list of available commands.

-> ip_help	
ip_help	Display this help message
ip_set "IP","NM","GW"	Set IP Address, NetMask, Gateway
ip_config	Show Info. about Network Interfaces
sys_reset	System restart

Set the IP address with the ip_set command, check the IP address with the ip_config command, and restart OfficeServ 7000 series with the sys_reset command. Example)

N 1	2.1					
-> ip	_cont ig					
		onfiguration >>>>				
	No¦ Items	Value Value				
	0 MAC Address	00-00-F0-E8-3E-77				
	1 IP Address 2 Subnet Mask 3 Default Gateway	165.213.176.207 255.255.255.0 165.213.176.1				
value ->	= 1 = 0×1					
-> ip	-> ip_set "165.213.176.207", "255.255.255.0","165.213.176.1"					
>>> >>> >>>	IP Address = 165.213.176.207 Subnet Mask = 255.255.255.0 Gateway = 165.213.176.1					
value	= 1 = 0×1					

6.3.3 Connecting to PSTN

To allow interoperation between OfficeServ 7000 series and SCM, the following information must be configured. You can use the DM to connect and modify the information for OfficeServ 7000 series.

This document only contains information on OfficeServ 7000 series gateway settings.

6.3.3.1 FXS Phone Settings

To register an FXS phone connected to OfficeServ 7000 series with SCM and use it as a SIP phone, the following items must be configured for SCM and OfficeServ 7000 series.

SCM Settings

A device must be created in the [CONFIGURATION > User > Single Phone User] menu in the SCM Administrator.

OfficeServ 7000 series Settings

The following must be configured in the [5.2.13 SIP Carrier Options] menu.

Name	Description	
SIP server Enable	Set to Enable.	
Outbound Proxy	Specify the IP address or the domain name of SCM.	
Regist. Per User	Set to Enable.	
Send CLI Table	Specify a table containing the subscriber's caller number. Select one from Tables 1 through 4 in the [2.4.3 Send CLI Number] menu.	

In the **[5.2.14 SIP Users]** menu, **[User Name]**, **[Auth Username]**, **[Auth Password]**, and **[Tel number]** must all be set to the extension number of the FXS phone.

Name	Description	
User Name	Specify the number for the extension to be registered as an subscriber.	
Auth Username		
Auth Password		
Tel number	Specify the extension number of [2.8.0 Numbering Plan]	

If you want to call the called party without EOD (End Of Digit), the following two items must be configured.

Tables 1 through 4 must be configured in the [2.4.3 Send CLI Number] menu. Enter the FXS phone's extension number in the table selected for [Send CLI Table] in the [5.2.13 SIP Carrier Options] menu.

The following must be configured in the [3.3.6 SCM Dial Plan] menu.

Name	Description
SCM Digit	Enter various numbers entered by the subscriber. They can be up to 10 digits long.
Tel Length	Enter the number of digits specified as the SCM digit. Example) For an 8-digit phone number starting with 1, enter 1 for SCM Digit and 8 for Length.

To service the FXS phones with SRTP, **[SRTP Option]** must be set to Enable in the **[5.2.16 MGI Options]** menu.

6.3.3.2 Trunk Interoperation Settings

To register a trunk connected to OfficeServ 7000 series with SCM and use it as a SIP trunk, the following items must be configured for SCM and OfficeServ 7000 series.

SCM Settings

Following items must be created in the SCM Administrator.

- A route must be created in the [CONFIGURATION > Trunk Routing > Route] menu.
- A LCR route must be created in the [CONFIGURATION > Trunk Routing > Route Sequence] and the [CONFIGURATION > Trunk Routing > Route Partition] menu.
- An access code must be created in the [CONFIGURATION > Trunk Routing > Access Code] menu.

OfficeServ 7000 series Settings

The following must be configured in the [5.2.13 SIP Carrier Options] menu.

Name	Description	
SIP server Enable	Set to Enable.	
Outbound Proxy	Specify the IP address or the domain name of SCM.	
Regist. Per User	Set to Enable.	
Trunk CLI Table	Specify a table containing the called phone number to be used for incoming analog trunk calls. Select one from Tables 1 through 4 in the [2.4.3 Send CLI Number] menu.	
SCM Trunk Group	Specify the phone number for the SIP trunk group to interoperate with SCM.	

The following must be configured in the [5.2.14 SIP Users] menu.

Name	Description	
User Name	Specify the number for the trunk group to be registered as an endpoint.	
Auth Username		
Auth Password		
Tel number	Enter the called group number for the trunk. The called group number is	
	the number specified for [Group Number] in the [4.1.2 Trunk Groups]	
	menu.	

Tables 1 through 4 must be configured in the **[2.4.3 Send CLI Number]** menu. Enter the called phone number to use for incoming analog trunk calls in the table selected for **[Trunk CLI Table]** in the **[5.2.13 SIP Carrier Options]** menu.

6.3.4 Connecting to SCM Server

6.3.4.1 Normal Connection Mode

To have OfficeServ 7000 series interoperate with SCM, the following items must be configured for SCM and OfficeServ 7000 series.

SCM Settings

You must register the OfficeServ 7000 series to interoperate with SCM using the **[CONFIGURATION > Gateway]** menu.

OfficeServ 7000 series Settings

You must register the SCM to interoperate using the [5.6.1 Ethernet Parameter] menu.

Name	Description	
SCM Server IP	Enter the IP address of SCM to interoperate.	
SCM Server Port	Specify the port of SCM to interoperate. The default value is 8088.	

The following must be configured in the [5.2.13 SIP Carrier Options] menu.

Name	Description	
SIP server Enable	Set to Enable.	
Outbound Proxy	Specify the IP address or the domain name of SCM.	
Regist. Per User	Set to Enable.	
User Name Auth Username Auth Password	Specify the number for the gateway to be registered as an endpoint.	

The following must be configured in the [5.2.14 SIP Users] menu.

Name	Description
User Name	Specify the number for the gateway to be registered as an endpoint.
Auth Username	
Auth Password	
Tel number	Enter the any trunk group number for the trunk. The trunk group number
	is the number specified for [Group Number] in the [4.1.2 Trunk
	Groups] menu.

6.3.4.2 Survivable Telephony Mode

When SCM's gateway is interoperating with SCM, if the gateway determines that the IP network with SCM is disconnected, it uses the service profiles downloaded from SCM for the FXS subscribers and SIP phone subscribers to continue to provide gateway's native call processing services.

In particular, OfficeServ 7000 series use the SIP phone subscriber service profile downloaded from SCM to automatically configure dial-peer for processing incoming calls for SIP phones and authenticates SIP phones in order to make calls and provide supplementary services.

OfficeServ 7000 series periodically (30 seconds by default) send Register messages to SCM. If it receives a 200 OK response, it enters the SCM interoperation mode again. To provide services in the survivable telephony mode, the following must be configured for SCM and OfficeServ 7000 series.

SCM Settings

A list of SIP phones to be accommodated by each gateway when in survival mode must be configured in the **[CONFIGURATION > Gateway]** menu.

When SCM creates the profile for a SIP phone, it includes the IP address and the port of the interoperating gateway in survival mode. When the SIP phone is disconnected from SCM, it sends a register message to the gateway included in the profile.

Database Settings for OfficeServ 7000 series

When interoperating with SCM, OfficeServ 7000 series download the subscriber profile from SCM and configures a database to be used by OfficeServ 7000 series in survival mode. For OfficeServ 7000 series to be able to download subscriber profiles from SCM, SIP extension slots must be created for saving the subscriber information. The number of SIP extension slots created must match the number of SIP subscribers to allocate in [6.3.2 Virtual Card Change].

Provisioning Settings for OfficeServ 7000 series

The OfficeServ 7000 series provisioning feature automatically download the database from SCM, modifies it into the OfficeServ 7000 series database format and applies it to OfficeServ 7000 series. To use the OfficeServ 7000 series provisioning feature, TCP links for provisioning must be created for both SCM and OfficeServ 7000 series. The settings are the same as the normal gateway interoperation settings.

6.3.5 Updating Gateway Software

Store appropriate package file provided by provider in the media card of MP Card using media card reader. (7100/7070 package needs to unzip) And then reboot OfficeServ 7000 series by pressing RST of MP Card.

System	MP Card	Package Name
OfficeServ 7400	MP40	MPE_GXXX.pgm
OfficeServ 7200	MP20	MPS_GXXX.pgm
OfficeServ 7100	MP10a	mp10a_gXXX.zip
OfficeServ 7070	MP07	mp07_gXXX.zip

CHAPTER 7. Installing SIP Phones

7.1 Connecting SIP Phones

7.1.1 Safety Precautions

To reduce the risk of personal injury, follow these precautions before connecting telephone circuits:

Never install telephone wiring during a lightning storm.

Never install telephone jacks in a wet location unless the jack is specifically designed for wet locations.

Do not connect stations in a humid area.

Never touch non-insulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.

Connect stations using #24 AWG or #26 AWG cables.

7.1.2 Wall-Mounting SMT-i5200 Keysets

Assemble the wall-mount bracket where you want to use the phone. The wall-mount bracket is an optional item.

7.1.2.1 To install the wall-mounting bracket follow the steps below:

- 1) First, choose the location where you want to install the phone, and then determine the positions of the screws by placing the phone at the target location on the wall.
- 2) Remove the desk cradle of the phone.
 - a) Fix one latch of the cradle to the top or bottom groove of the phone.
 - b) Push the remaining latch into the remaining groove on the opposite side.



3) Insert the wall-mount bracket as shown in the figure.



4) Pull out the handset rack, and then insert it in the opposite direction, as shown in the figure.

Only the up-down direction changes. The front-back remains unchanged.



5) Install the phone on the wall.

7.1.2.2 To detach the wall-mounting bracket follow the steps below:

1) You can detach the phone from the bracket by pressing the **[Push]** section at the bottom of the bracket.

Detach the phone more easily by pulling the entire bottom of the bracket instead of only the **[Push]** section.



2) Pull out the handset rack, change the direction and then insert it again.



7.1.3 Wall-Mounting SMT-i3100/3105 Keysets

The SMT-i3105 keysets do not require an optional wall-mounting bracket.

7.1.3.1 To wall-mount the SMT-i3100/3105 follow the steps below:

- 1) First, choose the location where you want to install the phone, and then determine the positions of the screws by placing the phone at the target location on the wall.
- 2) Remove the cradle of the phone by pressing the **[Push]** mark on the top of the cradle to push it out



3) Use screw holes 1 and 2 to attach the base wedge to a standard electrical outlet box.



7.1.4 SMT-i5264 Add On Module

The SMT-i5264 Add On Module only attaches to SMT-i5200 series.

If PoE is used, PoE connection should be connected to the LAN port of the SMT-i5264 first then transfer over to the phone. As shown in following figure the SMT-i5264 can transfer the power from the LAN port to the phone port, but the phone can't transfer power to the AOM.



7.1.4.1 Setting-Up SMT-i5264 AOM

SMT-i5264 AOM will register to an SIP phone device. The SMT-i5264 will receive an SIP phone extension. It can be paired to any SIP phone as the add-on module.



Connecting the SMT-A52GE Gigabit Adaptor 7.1.5

The Gigabit Adaptor processes the Gigabit data for a Gigabit LAN connection on the PC connected to the SMT-i5200 series IP phone.

7.1.5.1 **COMPONENTS**

The SMT-A52GE comes with the following components:





2 Fixing Screws



LAN Cable

7.1.5.2 **CONFIGURATION AND FUNCTIONS**



Port	Function	
qQPower (DC 5 V)	DC power adaptor connection port	
wQIP Phone PSE	 A port connected to the IP phone's LAN port via the LAN cable. This is shipped together with the Gigabit Adaptor (10/100 BASE-TX) If PoE (Power over Ethernet) is provided via the G-LAN PD port, it supplies PoE to the IP phone. 	
eQG-PC	LAN cable port connected to the PC (10/100/1000BASE-T)	
rQG-LAN PD	 LAN cable port connected to the network (10/100/1000 BASE-T) If PoE is supplied via the LAN, a power supply is not required for the IP phone or adaptor. 	



DC power adaptor is not included.

7.2 Connecting to Network

7.2.1 How to connect to a phone

1) Separate the cradle at the back of the phone.



2) Mount the Gigabit Adaptor onto the back of the body.



The back of the Gigabit Adaptor is sharp, so take care to avoid injury. When you connect the Gigabit Adaptor to the IP phone which is currently in use, disconnect the PC cable connected to the IP phone, and connect it to the G-PC port of the Gigabit Adaptor. This will leave the PC connection port, usually used for the IP phone, vacant.



3) Connect the cable.

When PoE is supplied via the LAN:



4) Connect the cable.When PoE is supplied via the LAN:



When PoE is not supplied via the LAN:



5) Atach the cradle to the back of the phone.



7.3 Connecting to SCM Server

The User can configure the register information and the network information easily, when the phone is not registered with the system.



If you enter the wrong information in the easy install menu, the phone may not be registered with a system or cannot connect to the network. You should enter the information correctly provided from the system administrator.

7.3.1 Configuration Type

The SMT-i5300, SMT-i5200 and SMT-i3100 series SIP phones support 3 types of configuration methods.

Config Type	Description
Standard	User can configure all the information to register with system manually.
	This mode is including following steps.
	- SIP server setting
	- SIP authentication setting
	- NTP server setting
Server	All the information to register with system is downloaded from a Configuration
	server.
	- If the system using MAC Address authentication type, ID/Password is not
	mandatory.
	- Please contact the system administrator detail information about the phone
	authentication type.
PnP	This feature allows a phone to be registered with the system when powered on
(Plug & Play)	so that it becomes available for service.
	- To use the [PnP] mode, the PnP environment must be configured by the
	system administrator.
	- If you choose the [PnP] mode, the network mode of the phone is changed to
	DHCP and the network setting step is skipped.
	- Please contact the system administrator about detail information about the
	[PnP] mode.

7.3.2 Easy Installation of SMT-i3100/3105/5210/5210S/5220/5230

1) To get to the SETUP MODE unplug the power cord from the phone. Press and hold the * button while you plug power back into the phone. Release the * button when you see Samsung in the display.

When the phone reboot is complete, the Language Menu will display. Select the language to use and press the Next soft button to advance to the Configuration Menu.

• The system administrator can change the language of the phone after registered with the system.

∠ English	
한국어	-
Italiano	
Deutsch	₹
Next	Back

2) Select the **[1 Easy Install]** Menu.



- 3) Select the Keypad Type.
 - In case of use Korean language, select Korea, in other case select Normal.

Press the [Next] Button.

[Keypad ∠Norma]	Туре]
Korea	
Cancel	Next

4) Select the configuration mode. The steps of the easy install menu might be changed depending on type of the configuration mode.

Press the [Next] Button.

[1.Provisioning Info]	[1.Provisioning Info]	[1.Provisioning Info]
Configure <mark>≼ Standard ♪</mark>	Configure∢ Standard ▶	Configure <mark>≼ PnP ♪</mark>
Back Next	Back Next	Back Next

- 5) If the **[Standard]** configuration mode is selected, The following steps are added.
 - SIP Server: Enter the SIP server information.
 - SIP Register Information: Enter the sip register information.
 - Time Server: Enter the time server (NTP) URL and update interval.

Press the [Next] Button.



- 6) In case the **[Server]** configuration mode is selected, You can enter ID/Password.
 - If the system using MAC Address authentication type, ID/Password is not mandatory.
 - Please contact the system administrator detail information about the configuration server address and authentication type.

Press the [Next] Button.



- 7) In case the **[PnP]** configuration mode is selected, There is nothing to do in this step.
 - Please contact the system administrator about detail information about the PnP mode.

Press the [Next] Button.

[1.Provis Configure	ioning Info] ∢ PnP ♪
Back	Next

- 8) Select the network mode and enter detail network information.
 - If you choose the PnP configuration mode, the Network mode of the phone is changed to DHCP and the Network Setting step is skipped in the easy Install feature.
 - If you enter the wrong information, the phone may not be registered with a system or cannot connect to the network.



- 9) Enter VLAN information.
 - If you enter the wrong information, the phone may not be registered with a system or cannot connect to the network.



10) Enter 802.1x information

11) LLDP setting

• If you enter the wrong information, the phone may not be registered with a system or cannot connect to the network.

[7. 802.1	802.1× L× :	Setting] lot Use	C
Bac	k į	Save	
Mode	[8. LL ∢ ∎N	.DP] ot Use	C

Back Next

- 11) All steps of the easy install is ended, press the **[Yes]** button to finish the easy install. Then the phone will be restart.
 - You can change the information already entered. Press the **[Back]** button till the step you want, and edit the information


7.3.3 Easy Installation of SMT-5243

 In case the phone is not registered with the system, [Easy Install] button will be displayed. Press [Easy Install] button, then the easy install menu will be shown. Check a network cable and press [Next] button.



- 2) Select the language to use.
 - The system administrator can change the language of the phone after registered with the system.

🔅 Easy Install			🕒 12:05 em
-	Language	< En	glish >
	KeyPad Type	< No	rmal >
	✓ 1 2 ABC		
Setting	7 8 PORS TUV		
Language		#	* 0** #
Cancel Prev	/ious	Next	

 Select the configuration mode. The steps of the easy install menu might be changed depending on type of the configuration mode. Press the [Next] Button.



- 4) If the [Standard] configuration mode is selected, The following steps are added.
 - SIP Server: Enter the SIP server information.
 - SIP Register Information: Enter the sip register information.
 - Time Server: Enter the time server (NTP) URL and update interval.

Press the **[Next]** Button.

🗘 Easy Install			e * a	🔅 Easy Install		(9 * 123
	Domain				Phone Number		
	Address				Phone Name		
	Signal	< UDP	>		Auth. ID		
Setting	Port	5060		Setting SIP Register	Auth. Passwd		
SIP Server	Data	< RTP	>	Information			line and the second
Cancel Prev	vious .	Next	Cancel	Cancel Prev	vious	Next	Cancel
		🔅 Easy Install	1st URL		0 * a		
			2nd URL	,			
			Refresh (min)	0			
		Setting Time Server					
		Cancel Pre	evious .	Next	Cancel		

- 5) In case the [Server] configuration mode is selected, You can enter ID/Password.
 - If the system using MAC Address authentication type, ID/Password is not mandatory.
 - Please contact the system administrator detail information about the configuration server address and authentication type.

Press the **[Next]** Button.

🔅 Easy Install		e 12:05	Easy Install	8 * a
	Configure	Server	×	Config Server
	If not use a l	MAC profile		Directory
	Login ID			
Setting Provisioning	Password		Setting	
Infomation			Server	
Cancel Prev	vious	Next	Cancel Prev	vious . Next Cancel

- 6) In case the **[PnP]** configuration mode is selected, There is nothing to do in this step. Press the **[Next]** Button.
 - Please contact the system administrator about detail information about the PnP mode.



- 7) Select the network mode and enter detail network information.
 - If you choose the PnP configuration mode, the Network mode of the phone is changed to DHCP and the Network Setting step is skipped in the easy Install feature.
 - If you enter the wrong information, the phone may not be registered with a system or cannot connect to the network.

🗘 Easy Install			12:06 eff	🗘 Easy Ins	stall	_	_	3826 🕑	9:38 AT
	Mode	Kat Stat	ic >		M	ode	<	DHCP	>
	IP Address								
	Gateway								
Setting	Subnet Mask			Settin	g rk				
Information	DNS 1			Informat					
Cancel Prev	vious	Next		Cancel	Previous			Next	
	¢	Easy Install			3826 🕑	9:38 AH			
			Mode	<	PPPoE	>			
	· .		ID						
			Password						
		Setting Network	ServiceNam	e					
		Cancel Pre	vious	Ne	ext				

- 8) Enter VLAN information.
 - If you enter the wrong information, the phone may not be registered with a system or cannot connect to the network.

🔅 Easy Install		3826 🖰	:39 en
	Phone VLAN	On Off	
	Phone VLAN ID	3	
	Phone Priority	6	
Setting	PC VLAN	ON OFF	
VLAN	PC VLAN ID	102	
Cancel Pre	vious	Next	

- 9) Enter 802.1x information
 - If you enter the wrong information, the phone may not be registered with a system or cannot connect to the network.



10) LLDP setting

🔅 Fasy Insta			A an 2.22
age Euroy intota			0 11 2.22
	Mode		Off
Setting LLDP			
Cancel	Previous	Done	

- 11) All steps of the easy install is ended, press the **[Finish]** button to finish the easy install. Then the phone will be restart.
 - You can change the information already entered. Press the **[Previous]** button till the step you want, and edit the information.



7.3.4 Easy Installation of SMT-5343

 In case the phone is not registered with the system, [Easy Install] button will be displayed. Press [Easy Install] button, then the easy install menu will be shown. Check a network cable and press [Next] button.

Easy Install		🗟 17:09
1 Start Easy Install	Connect Network Cable And Press [Next] button	
Cancel		Next >

- 2) Select the language to use.
 - The system administrator can change the language of the phone after registered with the system.

Easy Install							n	17:09
	Languag	e					Engl	ish 🔊
•	Keypad	Туре	,				Norr	nal 🕥
Z Setting Language	Normal	1 4 GHI 7 PORS	2 ABC 5 JKL 8 TUV	3 DEF MNO 9 WXYZ	Korea	1 I .oz 473 GHI 788	2 • ABC 5 • = JKL 8 • * TUV	3 - DEF MNO 9 **
		*	0	#		*	0°"	#
Cancel	< Prev						N	ext >

 Select the configuration mode. The steps of the easy install menu might be changed depending on type of the configuration mode. Press the [Next] Button.

Easy Install			n	17:09
	Configure		Serv	er 🔊
2		Unregistered Mac		
Setting	ID	UG11124		
Provisioning Information	Password	****		
Cancel	< Prev		Ne	ext >

- 4) If the [Standard] configuration mode is selected, The following steps are added.
 - SIP Server: Enter the SIP server information.
 - SIP Register Information: Enter the sip register information.
 - Time Server: Enter the time server (NTP) URL and update interval.

Press the [Next] Button.

Easy Install		2] 🛜 (★) a	
	Domain	ug1.scm.com		
,	Server Address	23.30.152.189		
4 Setting	Signal		UDP 🕥	
SIP Server	Port	5060		
	Data		RTP 🕥	
Cancel	< Prev .	Erase	Next >	

- 5) In case the [Server] configuration mode is selected, You can enter ID/Password.
 - If the system using MAC Address authentication type, ID/Password is not mandatory.
 - Please contact the system administrator detail information about the configuration server address and authentication type.

Press the [Next] Button.

Easy Install		1	? ★ 12
	Config Server	23.30.152.189	
4	Directory	1	
Setting Config Server			
Cancel	< Prev	. Erase	Next >

- 6) In case the **[PnP]** configuration mode is selected, There is nothing to do in this step. Press the **[Next]** Button.
 - Please contact the system administrator about detail information about the PnP mode.
- 7) Enter network information.
 - If the [Wired] network is selected, you can choose DHCP/Static/ or PPPoE mode.
 - If you enter the wrong information, the phone may not be registered with a system or cannot connect to the network.

Easy Install		I 🔶 17:09
	Wired/Wireless	Wired 📎
5	Mode	DHCP ()
Setting Network Information		
Cancel	< Prev	Next >

- 8) In case the [Wireless] network is selected,
 - The phone will start to search AP automatically.
 - Wi-Fi is only running under AC Adaptor connection.
 - After select AP in the searched list, connect to Static or DHCP mode.

Easy Install		🖪 🛜 17:09	Easy Install	D 🔶 17:09
	Wired/Wireless	Wireless 🕥	Wi-Fi	
_	Wi-Fi	9	yumi	Connected 🗟
5 Setting Network Information	Wi-Fi is only running under AC Adaptor connection		iptime5G_mine2	WPA/WPA2 🛸
			iptime_scomm	WPA 🛸
			SAMSUNG	802.1x 🛸
Cancel	< Prev	Complete	Add < Prev	Scan Edit Complete

- 9) Enter VLAN information.
 - If you enter the wrong information, the phone may not be registered with a system or cannot connect to the network.

Easy Install			n 🗟	17 10
	Phone VLAN			
e	Phone VLAN ID	1		
Setting	Phone Priority	7		
VLAN	PC VLAN			
	PC VLAN ID	1		
Cancel	< Prev		N	ext >

- 10) Enter 802.1x information
 - If you enter the wrong information, the phone may not be registered with a system or cannot connect to the network.

Easy Install		n	17:10
	802.1x		
7	ID		
Setting 802.1x	Password		
Cancel	< Prev	N	ext >

- 11) After Setting LLDP service, press the **[Finish]** button to finish the easy install. Then the phone will be restart.
 - You can change the information already entered. Press the **[Previous]** button till the step you want, and edit the information.

Easy Install		🖪 🤶 1710
	LLDP-MED	
8 Setting LLDP		
Cancel	< Prev	Complete

7.4 Upgrading SIP Phone Software

When you need upgrading SIP phone software, follow by these steps.

1) Preparing Software

First of all, you should copy phone software image file to your local PC.

2) Uploading Package

You can upload the phone software image file using [CONFIGURATION > Phone Setting > File Upload] menu.

😻 [SCM Administrator]	* * * * * * * *	E States	
File Tool Help		Berver165.213.89.181	LevelENGINEERING
scм Administrator 🔳	n 🐴 🖭 🗠 🏪	-	
CONFIGURATION	File Upload Main Monitor		
	Phone Image File 18135703_SMT-i5243,tar.gz Search		
User Group	Phone Info SMT-15243		
H User	Send		
Trunk Houting			
H Time Schedule			
Application Deces Setting			
Phone Setting			
Liborade Software			
Eile Uploed			
Change Display			
Dial Plan			
Software Versions			
NTP Options			
SIP Options			
Service Options			
Tone Setting 🤍			Detach Close
System Viewer	Event Viewer		,
Sustan : concurrente	Level Date/Time System Name	ID	Type Category
Status : Active Alone			
Alarm : CRI(0) MAJ(0) MIN(0)			
CPU Memory File	4	Cle	ear Detach Close
Message			2011-01-06 17:26:56

You can upload the phone software image file to SCM following steps:

- ① Click Search button.
- ② Select Upgrade phone software image
- ③ Check Phone name in Phone Info category.
- ④ Click Send button.

The Phone software image sends to SCM and copy to pre-defined directory in system automatically.

3) Check Software Version

You can check the phone software information using [CONFIGURATION > Phone Setting > Software Versions] menu.

SCM Administrator]			
File Tool Help		🔠 8 erv er 165.218.99.181 💄 User root 📑 Lev elen Gineenin G	
scм Administrator 🔳	i 🏝 🖭 🖼 🎽		
CONFIGURATION	Upgrade Software Software Versions Phone Pro	offile Information File Upload Main Monitor	
Trunk Routing	Name	Value	
∃ Time Schedule	Phone Version (SMT-i2205)	SCME-V00,10	
E Service	Phone Version (SMT-i3100/3105)	SCME-V00,80	
	Phone Version (SMT-i5210)	i5210-SCME-V01,00	
	Phone Version (SMT-i5220)	15220-SCME-V01,00	
Bhope Brofile Information	Phone Version (SMT-i5230)	15230-SCME-V01,00	
Phone Phone information	Phone Version (SMT-i5243)	i5243-SCME-V1,01	
Upgrade Software	Phone Version (SMT-i5264)	V1.14	
File Upload	Phone Update Protocol	http	
Change Display	Phone Update Public Zone Protocol	πττρ	
Dial Plan			
Software Versions			
NTP Options			
SIP Options			
Service Options			
Tone Setting			
Announcement			
+ Miscellaneous		Detail Change Excel Detach Close	
System Viewer	Event Viewer		
System : scme-vmc-16	Level Date/Time System Name	ID Type Category	
Status : Active Alone			
Alarm : CRI(0) MAJ(0) MIN(0)			
CPU Memory File		Clear Detach Close	
Message		2011-01-06 17:44:27	

4) Upgrading Software

You can upgrade the phone software using [CONFIGURATION > Phone Setting > Upgrade Software] menu.

First of all, press Create button then pop-up following window.

In Dialog box, select Type to Model Update, User Group, Phone Name, Model Name and Extension Number.

After click Apply button, phone will reboot automatically and start upgrade process.

😸 [DIALOG]Upgrade Software - Create					
Туре	Model Update	User Group	UG1	-	
Class of Service		Extension Number		-	
Phone Name	2004	Model Name	SMT-i2205	-	
Update Time		Start Time			
Start Phone Name		Update Count/Round			
Interval (min)					
Create Apply Close					

You can use scheduled upgrade for multiple phones in this menu.

Nw

ABBREVIATION

Α		
	ACL AH	Access Control List Authentication Header
	ALG	Application Layer Gateway
	AOM	Add On Module
С		
	CLI	Command Line Interface
	CPU	Central Processing Unit
D		
	DDR	Double Data Rate
	DHCP	Dynamic Host Configuration Protocol
	DVD	Digital Video Disc
F		
	FTP	File Transfer Protocol
н		
	НА	High Availability
	HDD	Hard Disk Drive
	HTTP	Hyper Text Transport Protocol
	iBG	integrated Business Gateway
	IP	Internet Protocol
	IPsec	Internet Protocol security
	IPT	Internet Protocol Telephony
L		
	LAN	Local Area Network

Ν		
	NAT NMS	Network Address Translation Network Management System
0		Ontical Disc Drive
Q		
_	QoS	Quality Of Service
R		
	RAM	Random Access Memory
	ROM	Read Only Memory
	RIF	Real-lime transport Protocol
S		
	SBC	Session Border Controller
	SCM	Samsung Communication Manager
	SIP	Session Initiation Protocol
	SNMP	Simple Network Management Protocol
Т		
	TCP	Transmission Control Protocol
	TFTP	Trivial File Transfer Protocol
	TLS	Transport Layer Security
U		
	UDP	User Datagram Protocol
	URL	Uniform Resource Locator
V		
	VoIP	Voice over Internet Protocol
	VPN	Virtual Private Network

SCM Express Installation Manual

©2010~2013 Samsung Electronics Co., Ltd.

All rights reserved.

Information in this manual is proprietary to SAMSUNG Electronics Co., Ltd.

No information contained here may be copied, translated, transcribed or duplicated by any form without the prior written consent of SAMSUNG.

Information in this manual is subject to change without notice.

