

# BYE BLOCK

## Description

The BYE Block is very simple. Its purpose is to say good-bye to the caller, disconnect the call, and free the port. The only parameter is the prompt to be spoken before disconnecting. There is only one bye block available in the SVMi-20E but additional Bye blocks can be added.

SVMi-20E	BYE - GoodBye	Page 1 of 1
Bye Block Controls		
Prompt played to caller prior to disconnect: 0051		
Activity	Calls: 1	From: 8/06/04 To: 7/12/05
Block Name. To Rename, Type new name then Press Enter		

**Bye Block**

Page 1 of 1

**BYE** The name of this block. A block name can be any alphanumeric string up to 16 characters long (including spaces). A Block name may not be the same as another Block name. MBX, EXT or LIST Numbers may not be duplicated within the same group.

**PROMPT** The number of the prompt that the SVMi-20E speaks before disconnecting the caller. Allowable inputs are 0001-9999 with blank indicating "say nothing". Press 'Ctrl+O' at this field to review or edit the prompt text.