

**Input allowed IP lists for Admin PC and IP Phones in [MANAGEMENT > Access Control List(ACL) > Miscellaneous ACL].**  
The index of allowed list should be ahead of deny ACL.

SCM Administrator

File Tool Tab Dialog Help

Server10.251.192.27 Userroot Level1,Engineer

scm Administrator PERFORMANCE

MANAGEMENT

- Access Permission
- CDR Storage Options
- Database
- Call Admission Control
- Authentication
- Access Control List(ACL)
  - ACL Options
  - ICMP ACL
  - Unauthorized SIP ACL
  - Management Port ACL
  - Miscellaneous ACL
  - SNMP Trap ACL
- TOS Control
- LDAP Data Import
- Photo File Management
- External Server Digest Authentication

System Viewer

System: scme-vmc-08 Status: Active Alone Alarm: CRI ( 0 ) MAJ ( 0 ) MIN ( 0 )

CPU Memory File

Message [Search] Completion (Total : 100 / 200)

[DIALOG]Miscellaneous ACL - Change

Index: 190

Protocol: TCP

Source IP address: 10.251.191.174

Source Subnet Mask Length: 32

Source Port: 0

Destination IP address: 0.0.0.0

Destination Subnet Mask Length: 0

Destination Port: 80

Policy: Allow

Direction: Inbound

Node Name: NODE 0

Change Apply Close

\* You can input "10.251.191.1" and Subnet Mask Length '24' for c-class range.

[DIALOG]Miscellaneous ACL - Change

Index: 191

Protocol: TCP

Source IP address: 10.251.191.174

Source Subnet Mask Length: 32

Source Port: 0

Destination IP address: 0.0.0.0

Destination Subnet Mask Length: 0

Destination Port: 443

Policy: Allow

Direction: Inbound

Node Name: NODE 0

Change Apply Close

\* You can input "10.251.191.1" and Subnet Mask Length '24' for c-class range.

Input deny ACL for 80, 443 ports in [MANAGEMENT > Access Control List(ACL) > Miscellaneous ACL].  
Input the list in the latest index (199, 200).

